

Notes:

√ Functions is fully supported and already existed in former software version.

Functions left with blank is not supported.

Year	Mode	Capacity	EngineType	Module	Read Codes	Erase Codes	Live Data	Active Test
2005	(All05)	2.3L	DURATEC-HE / I4	4X4	√	√	√	√
2005	(All05)	2.3L	DURATEC-HE / I4	ABS	√	√	√	√
2005	(All05)	2.3L	DURATEC-HE / I4	GEM	√	√	√	√
2005	(All05)	2.3L	DURATEC-HE / I4	IC	√	√	√	√
2005	(All05)	2.3L	DURATEC-HE / I4	PAM	√	√	√	√
2005	(All05)	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2005	(All05)	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2005	(All05)	2.3L	DURATEC-HE / I4	RCM	√	√	√	√
2005	(All05)	3.0L	4V	4X4	√	√	√	√
2005	(All05)	3.0L	4V	ABS	√	√	√	√
2005	(All05)Escape/Tribute/Maverick/Mariner	3.0L	4V	GEM	√	√	√	√
2005	(All05)Escape/Tribute/Maverick/Mariner	3.0L	4V	GEM	√	√	√	√
2005	(All05) Escape/Tribute/Maverick/Mariner	3.0L	4V	IC	√	√	√	√
2005	(All05)	3.0L	4V	PAM	√	√	√	√
2005	(All05)	3.0L	4V	PCM	√	√	√	√
2005	(All05)	3.0L	4V	RCM	√	√	√	√
1997	626 / 626 WAGON / TELSTAR	1.8L	FP	PCM	√	√	√	√
1997	626 / 626 WAGON / TELSTAR	2.0L	FS	ABS	√	√	√	√
1997	626 / 626 WAGON / TELSTAR	2.0L	FS	PCM	√	√	√	√
1997	626 / 626 WAGON / TELSTAR	2.0L	FS	PCM	√	√	√	√
1997	626 / 626 WAGON / TELSTAR	2.0L	RF-T	PCM	√	√	√	√
1997	626 / 626 WAGON / TELSTAR	2.5L	KL	PCM	√	√	√	√
1998	626 / 626 WAGON / TELSTAR	2.0L	FS	ABS/TCS	√	√	√	√
1998	626 / 626 WAGON / TELSTAR	2.0L	FS	PCM	√	√	√	√
1998	626 / 626 WAGON / TELSTAR	2.5L	KL	ABS/TCS	√	√	√	√
1998	626 / 626 WAGON / TELSTAR	2.5L	KL	PCM	√	√	√	√
1999	626 / 626 WAGON / TELSTAR	1.8L	FP	ABS	√	√	√	√
1999	626 / 626 WAGON / TELSTAR	1.8L	FP	PCM	√	√	√	√
1999	626 / 626 WAGON / TELSTAR	2.0L	FS	ABS	√	√	√	√
1999	626 / 626 WAGON / TELSTAR	2.0L	FS	ABS/TCS	√	√	√	√
1999	626 / 626 WAGON / TELSTAR	2.0L	FS	PCM	√	√	√	√
1999	626 / 626 WAGON / TELSTAR	2.0L	FS	PCM	√	√	√	√
1999	626 / 626 WAGON / TELSTAR	2.0L	RF-T	ABS	√	√	√	√
1999	626 / 626 WAGON / TELSTAR	2.0L	RF-T	PCM	√	√	√	√
2000	626 / 626 WAGON / TELSTAR	1.8L	FP	ABS/TCS	√	√	√	√
2000	626 / 626 WAGON / TELSTAR	1.8L	FP	PCM	√	√	√	√

2000	626 / 626 WAGON / TELSTAR	2.0L	FS	ABS/TCS	✓	✓	✓	✓
2000	626 / 626 WAGON / TELSTAR	2.0L	FS	PCM	✓	✓	✓	✓
2000	626 / 626 WAGON / TELSTAR	2.0L	FS	PCM	✓	✓	✓	✓
2000	626 / 626 WAGON / TELSTAR	2.0L	RF-T	ABS	✓	✓	✓	✓
2000	626 / 626 WAGON / TELSTAR	2.0L	RF-T	PCM	✓	✓	✓	✓
2000	626 / 626 WAGON / TELSTAR	2.5L	KL	ABS/TCS	✓	✓	✓	✓
2000	626 / 626 WAGON / TELSTAR	2.5L	KL	PCM	✓	✓	✓	✓
2001	626 / 626 WAGON / TELSTAR	2.0L	FS	ABS/TCS	✓	✓	✓	✓
2001	626 / 626 WAGON / TELSTAR	2.0L	FS	PCM	✓	✓	✓	✓
2001	626 / 626 WAGON / TELSTAR	2.5L	KL	ABS/TCS	✓	✓	✓	✓
2001	626 / 626 WAGON / TELSTAR	2.5L	KL	PCM	✓	✓	✓	✓
1996	AEROSTAR	3.0L	Other	PCM	✓	✓	✓	✓
1996	AEROSTAR	4.0L	Other	PCM	✓	✓	✓	✓
1997	AEROSTAR	3.0L	Other	PCM	✓	✓	✓	✓
1997	AEROSTAR	4.0L	Other	PCM	✓	✓	✓	✓
1996	Aspire	1.3L	Other	PCM	✓	✓	✓	
1997	Aspire	1.3L	Other	PCM	✓	✓	✓	
1997	Aspire	1.5L	Other	PCM	✓	✓	✓	✓
2003	Aviator	4.6L	4V	4X4	✓	✓	✓	✓
2003	Aviator	4.6L	4V	ABS/TCS	✓	✓	✓	✓
2003	Aviator	4.6L	4V	DCSM	✓	✓	✓	✓
2003	Aviator	4.6L	4V	DSM	✓	✓	✓	✓
2003	Aviator	4.6L	4V	EATC	✓	✓	✓	✓
2003	Aviator	4.6L	4V	IC	✓	✓	✓	✓
2003	Aviator	4.6L	4V	NAV	✓	✓	✓	✓
2003	Aviator	4.6L	4V	PAM	✓	✓	✓	✓
2003	Aviator	4.6L	4V	PCM	✓	✓	✓	✓
2003	Aviator	4.6L	4V	PCSM	✓	✓	✓	✓
2003	Aviator	4.6L	4V	RCM	✓	✓	✓	✓
2003	Aviator	4.6L	4V	TPM	✓	✓	✓	✓
2003	Aviator	4.6L	4V	VAPS	✓	✓	✓	✓
2003	Aviator	4.6L	4V	VEMS	✓	✓	✓	✓
2003	Aviator	4.6L	4V	VSM	✓	✓	✓	✓
2004	Aviator	4.6L	4V	4X4	✓	✓	✓	
2004	Aviator	4.6L	4V	ABS/TCS	✓	✓	✓	✓
2004	Aviator	4.6L	4V	DCSM	✓	✓	✓	✓
2004	Aviator	4.6L	4V	DSM	✓	✓	✓	✓
2004	Aviator	4.6L	4V	IC	✓	✓	✓	✓
2004	Aviator	4.6L	4V	NAV	✓	✓	✓	✓
2004	Aviator	4.6L	4V	PAM	✓	✓	✓	✓
2004	Aviator	4.6L	4V	PCM	✓	✓	✓	✓
2004	Aviator	4.6L	4V	PCSM	✓	✓	✓	✓
2004	Aviator	4.6L	4V	RCM	✓	✓	✓	✓
2004	Aviator	4.6L	4V	TPM	✓	✓	✓	✓
2004	Aviator	4.6L	4V	VAPS	✓	✓	✓	✓

2004	Aviator	4.6L	4V	VSM	✓	✓	✓	✓
2005	Aviator	4.6L	4V	4X4	✓	✓	✓	
2005	Aviator	4.6L	4V	ABS/TCS	✓	✓	✓	✓
2005	Aviator	4.6L	4V	DCSM	✓	✓	✓	✓
2005	Aviator	4.6L	4V	DSM	✓	✓	✓	✓
2005	Aviator	4.6L	4V	EATC	✓	✓	✓	✓
2005	Aviator	4.6L	4V	IC	✓	✓	✓	✓
2005	Aviator	4.6L	4V	NAV	✓	✓	✓	✓
2005	Aviator	4.6L	4V	PAM	✓	✓	✓	✓
2005	Aviator	4.6L	4V	PCM	✓	✓	✓	✓
2005	Aviator	4.6L	4V	PCSM	✓	✓	✓	✓
2005	Aviator	4.6L	4V	RCM	✓	✓	✓	✓
2005	Aviator	4.6L	4V	TPM	✓	✓	✓	✓
2005	Aviator	4.6L	4V	VAPS	✓	✓	✓	✓
2005	Aviator	4.6L	4V	VSM	✓	✓	✓	✓
2008.75	B-Max	1.25L	DURATEC 16V	ABS	✓	✓	✓	✓
2008.75	B-Max	1.25L	DURATEC 16V	ACM	✓	✓	✓	✓
2008.75	B-Max	1.25L	DURATEC 16V	BCMii	✓	✓	✓	
2008.75	B-Max	1.25L	DURATEC 16V	FCDIM	✓	✓	✓	
2008.75	B-Max	1.25L	DURATEC 16V	HVAC	✓	✓	✓	
2008.75	B-Max	1.25L	DURATEC 16V	IPC	✓	✓	✓	
2008.75	B-Max	1.25L	DURATEC 16V	PCM	✓	✓	✓	
2008.75	B-Max	1.25L	DURATEC 16V	PSCM	✓	✓	✓	
2008.75	B-Max	1.25L	DURATEC 16V	RCM	✓	✓	✓	
2008.75	B-Max	1.25L	DURATEC 16V	RFA	✓	✓	✓	
2008.75	B-Max	1.25L	DURATEC 16V	SRM	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	ABS	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	ACM	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	BCMii	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	FCDIM	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	HVAC	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	IPC	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	PCM	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	PSCM	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	RCM	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	RFA	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	SRM	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	TCM	✓	✓	✓	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail	ABS	✓	✓	✓	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail	ACM	✓	✓	✓	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail	BCMii	✓	✓	✓	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail	FCDIM	✓	✓	✓	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail	HVAC	✓	✓	✓	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail	IPC	✓	✓	✓	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail	PCM	✓	✓	✓	

2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail	PSCM	√	√	√	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail	RFA	√	√	√	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	
2008.75	B-Max	1.6L	DURATEC VCT	ABS	√	√	√	
2008.75	B-Max	1.6L	DURATEC VCT	ACM	√	√	√	
2008.75	B-Max	1.6L	DURATEC VCT	BCMii	√	√	√	
2008.75	B-Max	1.6L	DURATEC VCT	FCDIM	√	√	√	
2008.75	B-Max	1.6L	DURATEC VCT	HVAC	√	√	√	
2008.75	B-Max	1.6L	DURATEC VCT	IPC	√	√	√	
2008.75	B-Max	1.6L	DURATEC VCT	PCM	√	√	√	
2008.75	B-Max	1.6L	DURATEC VCT	PSCM	√	√	√	
2008.75	B-Max	1.6L	DURATEC VCT	RCM	√	√	√	
2008.75	B-Max	1.6L	DURATEC VCT	RFA	√	√	√	
2008.75	B-Max	1.6L	DURATEC VCT	SRM	√	√	√	
2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	
2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	
2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail	BCMii	√	√	√	
2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail	FCDIM	√	√	√	
2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail	IPC	√	√	√	
2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	
2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail	PSCM	√	√	√	
2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	
2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail	RFA	√	√	√	
2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	√	√	√	√
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct	BCMii	√	√	√	√
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	√
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct	FCDIM	√	√	√	√
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct	FDSM	√	√	√	√
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	√
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct	GWM	√	√	√	√
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	√
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct	PDM	√	√	√	√
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	√
2012.75	B-Max	1.4L	DURATEC 16V	ABS	√	√	√	√

2012.75	B-Max	1.4L	DURATEC 16V	ACM	√	√	√	√
2012.75	B-Max	1.4L	DURATEC 16V	APIM	√	√	√	√
2012.75	B-Max	1.4L	DURATEC 16V	BCMii	√	√	√	√
2012.75	B-Max	1.4L	DURATEC 16V	DDM	√	√	√	√
2012.75	B-Max	1.4L	DURATEC 16V	FCDIM	√	√	√	√
2012.75	B-Max	1.4L	DURATEC 16V	FDSM	√	√	√	√
2012.75	B-Max	1.4L	DURATEC 16V	GPSM	√	√	√	√
2012.75	B-Max	1.4L	DURATEC 16V	GWM	√	√	√	√
2012.75	B-Max	1.4L	DURATEC 16V	HVAC	√	√	√	√
2012.75	B-Max	1.4L	DURATEC 16V	IPC	√	√	√	√
2012.75	B-Max	1.4L	DURATEC 16V	PCM	√	√	√	√
2012.75	B-Max	1.4L	DURATEC 16V	PDM	√	√	√	√
2012.75	B-Max	1.4L	DURATEC 16V	PSCM	√	√	√	√
2012.75	B-Max	1.4L	DURATEC 16V	RCM	√	√	√	√
2012.75	B-Max	1.4L	DURATEC 16V	RFA	√	√	√	√
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail	APIM	√	√	√	√
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail	BCMii	√	√	√	√
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail	DDM	√	√	√	√
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail	FCDIM	√	√	√	√
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail	FDSM	√	√	√	√
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail	GPSM	√	√	√	√
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail	GWM	√	√	√	√
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail	HVAC	√	√	√	√
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail	IPC	√	√	√	√
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail	PDM	√	√	√	√
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail	PSCM	√	√	√	√
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail	PSCM	√	√	√	√
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail	RFA	√	√	√	√
2012.75	B-Max	1.6L	DURATEC VCT	ABS	√	√	√	√
2012.75	B-Max	1.6L	DURATEC VCT	ACM	√	√	√	√
2012.75	B-Max	1.6L	DURATEC VCT	APIM	√	√	√	√
2012.75	B-Max	1.6L	DURATEC VCT	BCMii	√	√	√	√
2012.75	B-Max	1.6L	DURATEC VCT	DDM	√	√	√	√
2012.75	B-Max	1.6L	DURATEC VCT	FCDIM	√	√	√	√
2012.75	B-Max	1.6L	DURATEC VCT	FDSM	√	√	√	√
2012.75	B-Max	1.6L	DURATEC VCT	GPSM	√	√	√	√
2012.75	B-Max	1.6L	DURATEC VCT	GWM	√	√	√	√
2012.75	B-Max	1.6L	DURATEC VCT	HVAC	√	√	√	√
2012.75	B-Max	1.6L	DURATEC VCT	IPC	√	√	√	√
2012.75	B-Max	1.6L	DURATEC VCT	PCM	√	√	√	√
2012.75	B-Max	1.6L	DURATEC VCT	PCM	√	√	√	√

2012.75	B-Max	1.6L	DURATEC VCT	PDM	✓	✓	✓	✓
2012.75	B-Max	1.6L	DURATEC VCT	PSCM	✓	✓	✓	✓
2012.75	B-Max	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓
2012.75	B-Max	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓
2012.75	B-Max	1.6L	DURATEC VCT	RFA	✓	✓	✓	✓
2012.75	B-Max	1.6L	DURATEC VCT	TCM	✓	✓	✓	✓
2012.75	B-Max	1.6L	TDCi ECO II	ABS	✓	✓	✓	✓
2012.75	B-Max	1.6L	TDCi ECO II	ABS	✓	✓	✓	✓
2012.75	B-Max	1.6L	TDCi ECO II	ACM	✓	✓	✓	✓
2012.75	B-Max	1.6L	TDCi ECO II	APIM	✓	✓	✓	✓
2012.75	B-Max	1.6L	TDCi ECO II	BCMii	✓	✓	✓	✓
2012.75	B-Max	1.6L	TDCi ECO II	DDM	✓	✓	✓	✓
2012.75	B-Max	1.6L	TDCi ECO II	FCDIM	✓	✓	✓	✓
2012.75	B-Max	1.6L	TDCi ECO II	FDSM	✓	✓	✓	✓
2012.75	B-Max	1.6L	TDCi ECO II	GPSM	✓	✓	✓	✓
2012.75	B-Max	1.6L	TDCi ECO II	GWM	✓	✓	✓	✓
2012.75	B-Max	1.6L	TDCi ECO II	HVAC	✓	✓	✓	✓
2012.75	B-Max	1.6L	TDCi ECO II	IPC	✓	✓	✓	✓
2012.75	B-Max	1.6L	TDCi ECO II	PCM	✓	✓	✓	✓
2012.75	B-Max	1.6L	TDCi ECO II	PDM	✓	✓	✓	✓
2012.75	B-Max	1.6L	TDCi ECO II	PSCM	✓	✓	✓	✓
2012.75	B-Max	1.6L	TDCi ECO II	PSCM	✓	✓	✓	✓
2012.75	B-Max	1.6L	TDCi ECO II	RCM	✓	✓	✓	✓
2012.75	B-Max	1.6L	TDCi ECO II	RFA	✓	✓	✓	✓
1996	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.2L	F2	PCM	✓	✓	✓	✓
1996	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.6L	G6	PCM	✓	✓	✓	✓
1999	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.2L	F2	PCM	✓	✓	✓	✓
1999	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.6L	G6	ABS	✓	✓	✓	✓
1999	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.6L	G6	PCM	✓	✓	✓	✓
2001	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL	ABS	✓	✓	✓	✓
2001	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL	PCM	✓	✓	✓	✓
2001	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL_T	PCM	✓	✓	✓	✓
2002	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL	ABS	✓	✓	✓	✓
2002	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL_T	ABS	✓	✓	✓	✓
2002	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.9L	W9	ABS	✓	✓	✓	✓
2005	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL_T	ABS	✓	✓	✓	✓
2005	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL_T	PCM	✓	✓	✓	✓
2005	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL_T	TCM	✓	✓	✓	✓
Other	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.2L	F2	PCM	✓	✓	✓	✓
1999	BONGO / BONGO BRAUNY / SPECTRON	1.8L	F8	ABS	✓	✓	✓	✓
1999	BONGO / BONGO BRAUNY / SPECTRON	1.8L	F8	PCM	✓	✓	✓	✓
1999	BONGO / BONGO BRAUNY / SPECTRON	2.2L	R2	ABS	✓	✓	✓	✓
1999	BONGO / BONGO BRAUNY / SPECTRON	2.2L	R2	PCM	✓	✓	✓	✓
2002	BONGO / BONGO BRAUNY / SPECTRON	1.8L	F8	ABS/TCS	✓	✓	✓	✓
2002	BONGO / BONGO BRAUNY / SPECTRON	1.8L	F8	PCM	✓	✓	✓	✓

2002	BONGO / BONGO BRAUNY / SPECTRON	1.8L	F8	TCM	√	√	√	√
2003	BONGO / BONGO BRAUNY / SPECTRON	2.0L	RF-T	ABS/TCS	√	√	√	√
2003	BONGO / BONGO BRAUNY / SPECTRON	2.0L	RF-T	PCM	√	√	√	√
2003	BONGO / BONGO BRAUNY / SPECTRON	2.0L	RF-T	TCM	√	√	√	√
2004	BONGO / BONGO BRAUNY / SPECTRON	2.0L	RF-T	ABS/TCS	√	√	√	√
2004	BONGO / BONGO BRAUNY / SPECTRON	2.0L	RF-T	PCM	√	√	√	√
2004	BONGO / BONGO BRAUNY / SPECTRON	2.0L	RF-T	TCM	√	√	√	√
2007	BONGO / BONGO BRAUNY / SPECTRON	2.0L	RF-T	ABS/TCS	√	√	√	√
2007	BONGO / BONGO BRAUNY / SPECTRON	2.0L	RF-T	PCM	√	√	√	√
2007	BONGO / BONGO BRAUNY / SPECTRON	2.0L	RF-T	PCM	√	√	√	√
2007	BONGO / BONGO BRAUNY / SPECTRON	2.0L	RF-T	TCM	√	√	√	√
2010	BONGO / BONGO BRAUNY / SPECTRON	1.8L	L8	ABS	√	√	√	√
2010	BONGO / BONGO BRAUNY / SPECTRON	1.8L	L8	IC	√	√	√	√
2010	BONGO / BONGO BRAUNY / SPECTRON	1.8L	L8	PCM	√	√	√	√
2010	BONGO / BONGO BRAUNY / SPECTRON	1.8L	L8	TCM	√	√	√	√
1997	BONGO BRAUNY / ECONOVAN / MAZDA E- SERIES	2.0L	FE	ABS	√	√	√	√
1997	BONGO BRAUNY / ECONOVAN / MAZDA E- SERIES	2.0L	FE	PCM	√	√	√	√
1998	BONGO BRAUNY / ECONOVAN / MAZDA E- SERIES	2.0L	FE	ABS	√	√	√	√
1998	BONGO BRAUNY / ECONOVAN / MAZDA E- SERIES	2.0L	FE	PCM	√	√	√	√
1999	BONGO BRAUNY / ECONOVAN / MAZDA E- SERIES	1.8L	F8	ABS	√	√	√	√
1999	BONGO BRAUNY / ECONOVAN / MAZDA E- SERIES	1.8L	F8	PCM	√	√	√	√
1999	BONGO BRAUNY / ECONOVAN / MAZDA E- SERIES	2.0L	FE	ABS	√	√	√	√
1999	BONGO BRAUNY / ECONOVAN / MAZDA E- SERIES	2.0L	FE	PCM	√	√	√	√
1999	BONGO BRAUNY / ECONOVAN / MAZDA E- SERIES	2.2L	R2	ABS	√	√	√	√
1999	BONGO BRAUNY / ECONOVAN / MAZDA E- SERIES	2.2L	R2	PCM	√	√	√	√
1999	BONGO BRAUNY / ECONOVAN / MAZDA E- SERIES	2.5L	WL	ABS	√	√	√	√
1999	BONGO BRAUNY / ECONOVAN / MAZDA E- SERIES	2.5L	WL	PCM	√	√	√	√
2002	BONGO BRAUNY / ECONOVAN / MAZDA E- SERIES	2.0L	FE	ABS/TCS	√	√	√	√
2002	BONGO BRAUNY / ECONOVAN / MAZDA E- SERIES	2.0L	FE	PCM	√	√	√	√
2002	BONGO BRAUNY / ECONOVAN / MAZDA E- SERIES	2.0L	FE	TCM	√	√	√	√
2007	BT-50 / Ranger	2.2L	F2	ABS/TCS	√	√	√	√
2007	BT-50 / Ranger	2.2L	F2	PCM	√	√	√	√
2007	BT-50 / Ranger	2.2L	F2	RCM	√	√	√	√
2007	BT-50 / Ranger	2.5L	WL	ABS/TCS	√	√	√	√
2007	BT-50 / Ranger	2.5L	WL	PCM	√	√	√	√
2007	BT-50 / Ranger	2.5L	WL	RCM	√	√	√	√
2007	BT-50 / Ranger	2.5L	WL-CD	ABS/TCS	√	√	√	√
2007	BT-50 / Ranger	2.5L	WL-CD	PCM	√	√	√	√
2007	BT-50 / Ranger	2.5L	WL-CD	PCM	√	√	√	√
2007	BT-50 / Ranger	2.5L	WL-CD	RCM	√	√	√	√
2007	BT-50 / Ranger	2.5L	WL-CD	TCM	√	√	√	√
2007	BT-50 / Ranger	2.5L	WL-CD	TCM	√	√	√	√
2007	BT-50 / Ranger	2.6L	G6	ABS/TCS	√	√	√	√
2007	BT-50 / Ranger	2.6L	G6	PCM	√	√	√	√
2007	BT-50 / Ranger	2.6L	G6	RCM	√	√	√	√

2007	BT-50 / Ranger	3.0L	WE-CD	ABS/TCS	✓	✓	✓	✓
2007	BT-50 / Ranger	3.0L	WE-CD	PCM	✓	✓	✓	✓
2007	BT-50 / Ranger	3.0L	WE-CD	PCM	✓	✓	✓	✓
2007	BT-50 / Ranger	3.0L	WE-CD	RCM	✓	✓	✓	✓
2007	BT-50 / Ranger	3.0L	WE-CD	TCM	✓	✓	✓	✓
2007	BT-50 / Ranger	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓
2007	BT-50 / Ranger	4.0L	V6 SOHC	ESOF	✓	✓	✓	✓
2007	BT-50 / Ranger	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2007	BT-50 / Ranger	4.0L	V6 SOHC	RCM	✓	✓	✓	✓
2012	BT-50 / Ranger	2.5L	L5	PCM	✓	✓	✓	✓
2001	Bantam	1.3L	Zetec Rocam	PCM	✓	✓	✓	✓
2001	Bantam	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓
2006	Bantam	1.3L	Zetec Rocam	PCM	✓	✓	✓	✓
2006	Bantam	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓
2009.25	Bantam	1.4L	Duratorq Turbo Diesel Common Rail	IC	✓	✓	✓	✓
2009.25	Bantam	1.4L	Duratorq Turbo Diesel Common Rail	PCM	✓	✓	✓	✓
2009.25	Bantam	1.4L	Duratorq Turbo Diesel Common Rail	RCM	✓	✓	✓	✓
2002	Blackwood	5.4L	4V	ABS/TCS	✓	✓	✓	✓
2002	Blackwood	5.4L	4V	DSM	✓	✓	✓	✓
2002	Blackwood	5.4L	4V	EATC	✓	✓	✓	✓
2002	Blackwood	5.4L	4V	GEM	✓	✓	✓	✓
2002	Blackwood	5.4L	4V	HEC	✓	✓	✓	✓
2002	Blackwood	5.4L	4V	LTM	✓	✓	✓	✓
2002	Blackwood	5.4L	4V	PAM	✓	✓	✓	✓
2002	Blackwood	5.4L	4V	PCM	✓	✓	✓	✓
2002	Blackwood	5.4L	4V	RAP	✓	✓	✓	✓
2002	Blackwood	5.4L	4V	RASM	✓	✓	✓	✓
2002	Blackwood	5.4L	4V	RCM	✓	✓	✓	✓
2003	Blackwood	5.4L	4V	ABS/TCS	✓	✓	✓	✓
2003	Blackwood	5.4L	4V	DSM	✓	✓	✓	✓
2003	Blackwood	5.4L	4V	EATC	✓	✓	✓	✓
2003	Blackwood	5.4L	4V	GEM	✓	✓	✓	✓
2003	Blackwood	5.4L	4V	HEC	✓	✓	✓	✓
2003	Blackwood	5.4L	4V	LTM	✓	✓	✓	✓
2003	Blackwood	5.4L	4V	PAM	✓	✓	✓	✓
2003	Blackwood	5.4L	4V	PCM	✓	✓	✓	✓
2003	Blackwood	5.4L	4V	RAP	✓	✓	✓	✓
2003	Blackwood	5.4L	4V	RASM	✓	✓	✓	✓
2003	Blackwood	5.4L	4V	RCM	✓	✓	✓	✓
2012	Blue Bird C-Class Vision	6.8L	3V	PCM	✓	✓	✓	✓
1996	Bronco	5.0L	Other	PCM	✓	✓	✓	✓
1996	Bronco	5.8L	Other	PCM	✓	✓	✓	✓
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	ABS	✓	✓	✓	✓
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	ACCM#2	✓	✓	✓	✓
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	ACM	✓	✓	✓	✓



2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	APIM	√	√	√	√
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	BCM#1	√	√	√	√
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	BECM	√	√	√	√
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	DACM-C	√	√	√	√
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	DCDC	√	√	√	√
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	DDM	√	√	√	√
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	FCDIM	√	√	√	√
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	FCIM	√	√	√	√
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	GPSM	√	√	√	√
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	GWM	√	√	√	√
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	HVAC	√	√	√	√
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	IPC	√	√	√	√
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	IPM-B	√	√	√	√
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	OCSM	√	√	√	√
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	PAM	√	√	√	√
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	PCM	√	√	√	√
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	PDM	√	√	√	√
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	PSCM	√	√	√	√
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	RCM	√	√	√	√
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	RFA	√	√	√	√
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	RGTM	√	√	√	√
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	SOBDM-C	√	√	√	√
2013	C-MAX	2.0L	PHEV	ABS	√	√	√	√
2013	C-MAX	2.0L	PHEV	ACCM#2	√	√	√	√
2013	C-MAX	2.0L	PHEV	ACM	√	√	√	√
2013	C-MAX	2.0L	PHEV	APIM	√	√	√	√
2013	C-MAX	2.0L	PHEV	BCM#1	√	√	√	√
2013	C-MAX	2.0L	PHEV	BECM	√	√	√	√
2013	C-MAX	2.0L	PHEV	DACM-C	√	√	√	√
2013	C-MAX	2.0L	PHEV	DCDC	√	√	√	√
2013	C-MAX	2.0L	PHEV	DDM	√	√	√	√
2013	C-MAX	2.0L	PHEV	FCDIM	√	√	√	√
2013	C-MAX	2.0L	PHEV	FCIM	√	√	√	√
2013	C-MAX	2.0L	PHEV	GFM	√	√	√	√
2013	C-MAX	2.0L	PHEV	GPSM	√	√	√	√
2013	C-MAX	2.0L	PHEV	GWM	√	√	√	√
2013	C-MAX	2.0L	PHEV	HVAC	√	√	√	√
2013	C-MAX	2.0L	PHEV	IPC	√	√	√	√
2013	C-MAX	2.0L	PHEV	IPM-B	√	√	√	√
2013	C-MAX	2.0L	PHEV	OCSM	√	√	√	√
2013	C-MAX	2.0L	PHEV	PAM	√	√	√	√
2013	C-MAX	2.0L	PHEV	PCM	√	√	√	√
2013	C-MAX	2.0L	PHEV	PDM	√	√	√	√
2013	C-MAX	2.0L	PHEV	PSCM	√	√	√	√
2013	C-MAX	2.0L	PHEV	RCM	√	√	√	√

2013	C-MAX	2.0L	PHEV	RFA	√	√	√	√
2013	C-MAX	2.0L	PHEV	RGTM	√	√	√	√
2013	C-MAX	2.0L	PHEV	SASM	√	√	√	√
2013	C-MAX	2.0L	PHEV	SOBDM	√	√	√	√
2013	C-MAX	2.0L	PHEV	SOBDM-C	√	√	√	√
2013	C-MAX	2.0L	PHEV	TCU#1	√	√	√	√
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	ABS	√	√	√	√
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	ACCM#2	√	√	√	√
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	ACM	√	√	√	√
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	APIM	√	√	√	√
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	BCM#1	√	√	√	√
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	BECM	√	√	√	√
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	DACM-C	√	√	√	√
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	DCDC	√	√	√	√
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	DDM	√	√	√	√
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	FCDIM	√	√	√	√
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	FCIM	√	√	√	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	GPSM	√	√	√	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	GWM	√	√	√	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	HVAC	√	√	√	√
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	IPC	√	√	√	√
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	IPM-B	√	√	√	√
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	OCSM	√	√	√	√
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	PAM	√	√	√	√
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	PCM	√	√	√	√
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	PDM	√	√	√	√
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	PSCM	√	√	√	√
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	RCM	√	√	√	√
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	RFA	√	√	√	√
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	RGTM	√	√	√	√
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	SASM	√	√	√	√
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	SOBDM-C	√	√	√	√
2014	C-MAX	2.0L	PHEV	ABS	√	√	√	√
2014	C-MAX	2.0L	PHEV	ACCM#2	√	√	√	√
2014	C-MAX	2.0L	PHEV	ACM	√	√	√	√
2014	C-MAX	2.0L	PHEV	APIM	√	√	√	√
2014	C-MAX	2.0L	PHEV	BECM	√	√	√	√
2014	C-MAX	2.0L	PHEV	DACM-C	√	√	√	√
2014	C-MAX	2.0L	PHEV	DCDC	√	√	√	√
2014	C-MAX	2.0L	PHEV	DDM	√	√	√	√
2014	C-MAX	2.0L	PHEV	FCDIM	√	√	√	√
2014	C-MAX	2.0L	PHEV	FCIM	√	√	√	
2014	C-MAX	2.0L	PHEV	GFM	√	√	√	
2014	C-MAX	2.0L	PHEV	GPSM	√	√	√	
2014	C-MAX	2.0L	PHEV	GWM	√	√	√	

2014	C-MAX	2.0L	PHEV	HVAC	√	√	√	√
2014	C-MAX	2.0L	PHEV	IPC	√	√	√	√
2014	C-MAX	2.0L	PHEV	IPM-B	√	√	√	√
2014	C-MAX	2.0L	PHEV	OCSM	√	√	√	√
2014	C-MAX	2.0L	PHEV	PAM	√	√	√	√
2014	C-MAX	2.0L	PHEV	PCM	√	√	√	√
2014	C-MAX	2.0L	PHEV	PDM	√	√	√	√
2014	C-MAX	2.0L	PHEV	PSCM	√	√	√	√
2014	C-MAX	2.0L	PHEV	RCM	√	√	√	√
2014	C-MAX	2.0L	PHEV	RFA	√	√	√	√
2014	C-MAX	2.0L	PHEV	RGTM	√	√	√	√
2014	C-MAX	2.0L	PHEV	SASM	√	√	√	√
2014	C-MAX	2.0L	PHEV	SOBDM	√	√	√	√
2014	C-MAX	2.0L	PHEV	SOBDM-C	√	√	√	√
2014	C-MAX	2.0L	PHEV	TCU#1	√	√	√	√
1997	CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	1.8L	FP	PCM	√	√	√	√
1997	CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	2.0L	FS	PCM	√	√	√	√
1997	CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	2.0L	RF	PCM	√	√	√	√
1999	CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	1.8L	FP	ABS	√	√	√	√
1999	CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	1.8L	FP	PCM	√	√	√	√
1999	CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	2.0L	FS	ABS	√	√	√	√
1999	CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	2.0L	FS	PCM	√	√	√	√
1999	CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	2.5L	KL	ABS	√	√	√	√
2006	CF/LCF	4.5L	Direct Injection -	ABS	√	√	√	√
2006	CF/LCF	4.5L	Direct Injection -	ABS	√	√	√	√
2006	CF/LCF	4.5L	Direct Injection -	TCM	√	√	√	√
2007	CF/LCF	4.5L	Direct Injection -	ABS	√	√	√	√
2007	CF/LCF	4.5L	Direct Injection -	TCM	√	√	√	√
2008	CF/LCF	4.5L	Direct Injection -	ABS	√	√	√	√
2008	CF/LCF	4.5L	Direct Injection -	ABS	√	√	√	√
2008	CF/LCF	4.5L	Direct Injection -	TCM	√	√	√	√
2009	CF/LCF	4.5L	Direct Injection -	ABS	√	√	√	√
2009	CF/LCF	4.5L	Direct Injection -	TCM	√	√	√	√
2004	Cargo	7.3L	ECOTORQ	PCM	√	√	√	√
2009	Cargo	Other	ISBe	TBM	√	√	√	√
2009	Cargo	Other	ISCe	TBM	√	√	√	√
2009	Cargo	Other	Mechanical	TBM	√	√	√	√
2012	Cargo	Other	ISBe	HEC	√	√	√	√
2012	Cargo	Other	ISBe	RKE	√	√	√	√
2012	Cargo	Other	ISBe	TBM	√	√	√	√
2012	Cargo	Other	ISCe	HEC	√	√	√	√
2012	Cargo	Other	ISCe	RKE	√	√	√	√
2012	Cargo	Other	ISCe	TBM	√	√	√	√
2012	Cargo	Other	Mechanical	HEC	√	√	√	√
2012	Cargo	Other	Mechanical	RKE	√	√	√	√

2012	Cargo		Mechanical	TBM	√	√	√	√
1995	Continental	4.6L	4V	ABS/TCS	√	√	√	
1995	Continental	4.6L	4V	ACM	√	√	√	√
1995	Continental	4.6L	4V	CPM	√	√	√	√
1995	Continental	4.6L	4V	DDM	√	√	√	
1995	Continental	4.6L	4V	DSM	√	√	√	
1995	Continental	4.6L	4V	EATC	√	√	√	
1995	Continental	4.6L	4V	LCM	√	√	√	√
1995	Continental	4.6L	4V	PCM	√	√	√	√
1995	Continental	4.6L	4V	VDM	√	√	√	√
1995	Continental	4.6L	4V	VIC	√	√	√	√
1996	Continental	4.6L	4V	ABS/TCS	√	√	√	√
1996	Continental	4.6L	4V	ACM	√	√	√	√
1996	Continental	4.6L	4V	CPM	√	√	√	√
1996	Continental	4.6L	4V	DDM	√	√	√	√
1996	Continental	4.6L	4V	DSM	√	√	√	√
1996	Continental	4.6L	4V	EATC	√	√	√	√
1996	Continental	4.6L	4V	IAB	√	√	√	√
1996	Continental	4.6L	4V	LCM	√	√	√	√
1996	Continental	4.6L	4V	PCM	√	√	√	√
1996	Continental	4.6L	4V	RESCU	√	√	√	√
1996	Continental	4.6L	4V	VDM	√	√	√	√
1996	Continental	4.6L	4V	VIC	√	√	√	√
1997	Continental	4.6L	4V	ACM	√	√	√	√
1997	Continental	4.6L	4V	CPM	√	√	√	√
1997	Continental	4.6L	4V	DDM	√	√	√	√
1997	Continental	4.6L	4V	DSM	√	√	√	√
1997	Continental	4.6L	4V	EATC	√	√	√	√
1997	Continental	4.6L	4V	IAB	√	√	√	√
1997	Continental	4.6L	4V	LCM	√	√	√	√
1997	Continental	4.6L	4V	PCM	√	√	√	√
1997	Continental	4.6L	4V	RESCU	√	√	√	√
1997	Continental	4.6L	4V	VDM	√	√	√	√
1997	Continental	4.6L	4V	VIC	√	√	√	√
1998	Continental	4.6L	4V	ABS/TCS	√	√	√	√
1998	Continental	4.6L	4V	ACM	√	√	√	√
1998	Continental	4.6L	4V	CPM	√	√	√	√
1998	Continental	4.6L	4V	DDM	√	√	√	√
1998	Continental	4.6L	4V	DSM	√	√	√	√
1998	Continental	4.6L	4V	EATC	√	√	√	√
1998	Continental	4.6L	4V	ECS	√	√	√	√
1998	Continental	4.6L	4V	LCM	√	√	√	√
1998	Continental	4.6L	4V	NGSC	√	√	√	√
1998	Continental	4.6L	4V	PCM	√	√	√	√
1998	Continental	4.6L	4V	RESCU	√	√	√	√

1998	Continental	4.6L	4V	VDM	✓	✓	✓	✓
1998	Continental	4.6L	4V	VIC	✓	✓	✓	✓
1999	Continental	4.6L	4V	ABS/TCS	✓	✓	✓	✓
1999	Continental	4.6L	4V	ACM	✓	✓	✓	✓
1999	Continental	4.6L	4V	CPM	✓	✓	✓	✓
1999	Continental	4.6L	4V	DDM	✓	✓	✓	✓
1999	Continental	4.6L	4V	DSM	✓	✓	✓	✓
1999	Continental	4.6L	4V	EATC	✓	✓	✓	✓
1999	Continental	4.6L	4V	LCM	✓	✓	✓	✓
1999	Continental	4.6L	4V	NGSC	✓	✓	✓	✓
1999	Continental	4.6L	4V	PCM	✓	✓	✓	✓
1999	Continental	4.6L	4V	RCM	✓	✓	✓	✓
1999	Continental	4.6L	4V	RESCU	✓	✓	✓	✓
1999	Continental	4.6L	4V	VDM	✓	✓	✓	✓
1999	Continental	4.6L	4V	VIC	✓	✓	✓	✓
2000	Continental	4.6L	4V	ABS/TCS	✓	✓	✓	✓
2000	Continental	4.6L	4V	ACM	✓	✓	✓	✓
2000	Continental	4.6L	4V	CPM	✓	✓	✓	✓
2000	Continental	4.6L	4V	DDM	✓	✓	✓	✓
2000	Continental	4.6L	4V	DSM	✓	✓	✓	✓
2000	Continental	4.6L	4V	EATC	✓	✓	✓	✓
2000	Continental	4.6L	4V	LCM	✓	✓	✓	✓
2000	Continental	4.6L	4V	NGSC	✓	✓	✓	✓
2000	Continental	4.6L	4V	PCM	✓	✓	✓	✓
2000	Continental	4.6L	4V	RCM	✓	✓	✓	✓
2000	Continental	4.6L	4V	RESCU	✓	✓	✓	✓
2000	Continental	4.6L	4V	VDM	✓	✓	✓	✓
2000	Continental	4.6L	4V	VIC	✓	✓	✓	✓
2002	Continental	4.6L	4V	ABS/TCS	✓	✓	✓	✓
2002	Continental	4.6L	4V	ACM	✓	✓	✓	✓
2002	Continental	4.6L	4V	CPM	✓	✓	✓	✓
2002	Continental	4.6L	4V	DDM	✓	✓	✓	✓
2002	Continental	4.6L	4V	DSM	✓	✓	✓	✓
2002	Continental	4.6L	4V	EATC	✓	✓	✓	✓
2002	Continental	4.6L	4V	LCM	✓	✓	✓	✓
2002	Continental	4.6L	4V	NGSC	✓	✓	✓	✓
2002	Continental	4.6L	4V	PCM	✓	✓	✓	✓
2002	Continental	4.6L	4V	RCM	✓	✓	✓	✓
2002	Continental	4.6L	4V	VDM	✓	✓	✓	✓
2002	Continental	4.6L	4V	VIC	✓	✓	✓	✓
1996	Contour	2.0L	GFP	ABS/TCS	✓	✓	✓	✓
1996	Contour	2.0L	GFP	PCM	✓	✓	✓	✓
1996	Contour	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓
1996	Contour	2.0L	Zetec	PCM	✓	✓	✓	✓
1996	Contour	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓

1996	Contour	2.5L	Duratec-VE	PCM	√	√	√	√
1997	Contour	2.0L	GFP	ABS/TCS	√	√	√	√
1997	Contour	2.0L	GFP	PCM	√	√	√	√
1997	Contour	2.0L	Zetec	ABS/TCS	√	√	√	√
1997	Contour	2.0L	Zetec	PCM	√	√	√	√
1997	Contour	2.5L	Duratec-VE	ABS/TCS	√	√	√	√
1997	Contour	2.5L	Duratec-VE	PCM	√	√	√	√
1998	Contour	2.0L	GFP	ABS/TCS	√	√	√	√
1998	Contour	2.0L	GFP	ABS/TCS	√	√	√	√
1998	Contour	2.0L	GFP	CSM	√	√	√	√
1998	Contour	2.0L	GFP	PATS	√	√	√	√
1998	Contour	2.0L	GFP	PCM	√	√	√	√
1998	Contour	2.0L	GFP	PCM	√	√	√	√
1998	Contour	2.0L	Zetec	ABS/TCS	√	√	√	√
1998	Contour	2.0L	Zetec	ABS/TCS	√	√	√	√
1998	Contour	2.0L	Zetec	CSM	√	√	√	√
1998	Contour	2.0L	Zetec	PATS	√	√	√	√
1998	Contour	2.0L	Zetec	PCM	√	√	√	√
1998	Contour	2.5L	Duratec-VE	ABS/TCS	√	√	√	√
1998	Contour	2.5L	Duratec-VE	ABS/TCS	√	√	√	√
1998	Contour	2.5L	Duratec-VE	CSM	√	√	√	√
1998	Contour	2.5L	Duratec-VE	PCM	√	√	√	√
1998	Contour	2.5L	HO	ABS/TCS	√	√	√	√
1998	Contour	2.5L	HO	ABS/TCS	√	√	√	√
1998	Contour	2.5L	HO	CSM	√	√	√	√
1998	Contour	2.5L	HO	PATS	√	√	√	√
1998	Contour	2.5L	HO	PCM	√	√	√	√
1998	Contour	2.5L	HO	PCM	√	√	√	√
1999	Contour	2.0L	GFP	ABS/TCS	√	√	√	√
1999	Contour	2.0L	GFP	CSM	√	√	√	√
1999	Contour	2.0L	GFP	PCM	√	√	√	√
1999	Contour	2.0L	GFP	RCM	√	√	√	√
1999	Contour	2.0L	Zetec	ABS/TCS	√	√	√	√
1999	Contour	2.0L	Zetec	CSM	√	√	√	√
1999	Contour	2.0L	Zetec	PCM	√	√	√	√
1999	Contour	2.0L	Zetec	RCM	√	√	√	√
1999	Contour	2.5L	Duratec-VE	ABS/TCS	√	√	√	√
1999	Contour	2.5L	Duratec-VE	CSM	√	√	√	√
1999	Contour	2.5L	Duratec-VE	PCM	√	√	√	√
1999	Contour	2.5L	Duratec-VE	RCM	√	√	√	√
1999	Contour	2.5L	HO	ABS/TCS	√	√	√	√
1999	Contour	2.5L	HO	CSM	√	√	√	√
1999	Contour	2.5L	HO	PCM	√	√	√	√
1999	Contour	2.5L	HO	PCM	√	√	√	√
1999	Contour	2.5L	HO	RCM	√	√	√	√

2000	Contour	2.0L	GFP	ABS/TCS	√	√	√	√
2000	Contour	2.0L	GFP	CSM	√	√	√	√
2000	Contour	2.0L	GFP	PCM	√	√	√	√
2000	Contour	2.0L	GFP	RCM	√	√	√	√
2000	Contour	2.0L	Zetec	ABS/TCS	√	√	√	√
2000	Contour	2.0L	Zetec	CSM	√	√	√	√
2000	Contour	2.0L	Zetec	PCM	√	√	√	√
2000	Contour	2.0L	Zetec	RCM	√	√	√	√
2000	Contour	2.5L	Duratec-VE	ABS/TCS	√	√	√	√
2000	Contour	2.5L	Duratec-VE	CSM	√	√	√	√
2000	Contour	2.5L	Duratec-VE	PCM	√	√	√	√
2000	Contour	2.5L	Duratec-VE	RCM	√	√	√	√
2000	Contour	2.5L	HO	ABS/TCS	√	√	√	√
2000	Contour	2.5L	HO	CSM	√	√	√	√
2000	Contour	2.5L	HO	PCM	√	√	√	√
2000	Contour	2.5L	HO	PCM	√	√	√	√
2000	Contour	2.5L	HO	RCM	√	√	√	√
1994	Cougar	4.6L	2V	ABS/TCS	√	√	√	√
1994	Cougar	4.6L	2V	HEC	√	√	√	√
1994	Cougar	4.6L	2V	PCM	√	√	√	√
1995	Cougar	4.6L	2V	ABS/TCS	√	√	√	√
1995	Cougar	4.6L	2V	HEC	√	√	√	√
1995	Cougar	4.6L	2V	PCM	√	√	√	√
1996	Cougar	3.8L	Other	ABS/TCS	√	√	√	√
1996	Cougar	3.8L	Other	HEC	√	√	√	√
1996	Cougar	3.8L	Other	PCM	√	√	√	√
1996	Cougar	4.6L	2V	ABS/TCS	√	√	√	√
1996	Cougar	4.6L	2V	HEC	√	√	√	√
1996	Cougar	4.6L	2V	PCM	√	√	√	√
1997	Cougar	3.8L	Other	ABS/TCS	√	√	√	√
1997	Cougar	3.8L	Other	HEC	√	√	√	√
1997	Cougar	3.8L	Other	PCM	√	√	√	√
1997	Cougar	4.6L	2V	ABS/TCS	√	√	√	√
1997	Cougar	4.6L	2V	HEC	√	√	√	√
1997	Cougar	4.6L	2V	PCM	√	√	√	√
1998.75	Cougar	2.0L	Zetec	ABS/TCS	√	√	√	√
1998.75	Cougar	2.0L	Zetec	CSM	√	√	√	√
1998.75	Cougar	2.0L	Zetec	HEC	√	√	√	√
1998.75	Cougar	2.0L	Zetec	IAB	√	√	√	
1998.75	Cougar	2.0L	Zetec	PCM	√	√	√	√
1998.75	Cougar	2.5L	Duratec-VE	ABS/TCS	√	√	√	√
1998.75	Cougar	2.5L	Duratec-VE	CSM	√	√	√	√
1998.75	Cougar	2.5L	Duratec-VE	HEC	√	√	√	√
1998.75	Cougar	2.5L	Duratec-VE	IAB	√	√	√	
1998.75	Cougar	2.5L	Duratec-VE	PCM	√	√	√	√

1999	Cougar	2.0L	Zetec	ABS/TCS	√	√	√	√
1999	Cougar	2.0L	Zetec	CSM	√	√	√	√
1999	Cougar	2.0L	Zetec	HEC	√	√	√	√
1999	Cougar	2.0L	Zetec	IAB	√	√	√	
1999	Cougar	2.0L	Zetec	PCM	√	√	√	√
1999	Cougar	2.5L	Duratec-VE	ABS/TCS	√	√	√	√
1999	Cougar	2.5L	Duratec-VE	CSM	√	√	√	√
1999	Cougar	2.5L	Duratec-VE	HEC	√	√	√	√
1999	Cougar	2.5L	Duratec-VE	IAB	√	√	√	
1999	Cougar	2.5L	Duratec-VE	PCM	√	√	√	√
1999.75	Cougar	2.5L	Duratec-VE	ABS/TCS	√	√	√	√
1999.75	Cougar	2.5L	Duratec-VE	CSM	√	√	√	√
1999.75	Cougar	2.5L	Duratec-VE	HEC	√	√	√	√
1999.75	Cougar	2.5L	Duratec-VE	IAB	√	√	√	
1999.75	Cougar	2.5L	Duratec-VE	PCM	√	√	√	√
2000	Cougar	2.0L	Zetec	ABS/TCS	√	√	√	√
2000	Cougar	2.0L	Zetec	CSM	√	√	√	√
2000	Cougar	2.0L	Zetec	HEC	√	√	√	√
2000	Cougar	2.0L	Zetec	IAB	√	√	√	
2000	Cougar	2.5L	Duratec-VE	ABS/TCS	√	√	√	√
2000	Cougar	2.5L	Duratec-VE	CSM	√	√	√	√
2000	Cougar	2.5L	Duratec-VE	HEC	√	√	√	√
2000	Cougar	2.5L	Duratec-VE	IAB	√	√	√	
2000	Cougar	2.5L	Duratec-VE	PCM	√	√	√	√
2000.5	Cougar	2.0L	Zetec	ABS/TCS	√	√	√	√
2000.5	Cougar	2.0L	Zetec	CSM	√	√	√	√
2000.5	Cougar	2.0L	Zetec	HEC	√	√	√	√
2000.5	Cougar	2.0L	Zetec	IAB	√	√	√	
2000.5	Cougar	2.0L	Zetec	PCM	√	√	√	√
2000.5	Cougar	2.5L	Duratec-VE	ABS/TCS	√	√	√	√
2000.5	Cougar	2.5L	Duratec-VE	ABS/TCS	√	√	√	√
2000.5	Cougar	2.5L	Duratec-VE	CSM	√	√	√	√
2000.5	Cougar	2.5L	Duratec-VE	HEC	√	√	√	√
2000.5	Cougar	2.5L	Duratec-VE	IAB	√	√	√	
2000.5	Cougar	2.5L	Duratec-VE	PCM	√	√	√	√
2001	Cougar	2.5L	Duratec-VE	ABS	√	√	√	√
2001	Cougar	2.5L	Duratec-VE	IC	√	√	√	√
2001	Cougar	2.5L	Duratec-VE	MC	√	√	√	√
2001	Cougar	2.5L	Duratec-VE	PCM	√	√	√	√
2001	Cougar	2.5L	Duratec-VE	REM	√	√	√	
2002	Cougar	2.0L	Zetec	ABS/TCS	√	√	√	√
2002	Cougar	2.0L	Zetec	CSM	√	√	√	√
2002	Cougar	2.0L	Zetec	HEC	√	√	√	√
2002	Cougar	2.0L	Zetec	IAB	√	√	√	
2002	Cougar	2.0L	Zetec	PCM	√	√	√	√



2002	Cougar	2.5L	Duratec-VE	ABS/TCS	√	√	√	√
2002	Cougar	2.5L	Duratec-VE	CSM	√	√	√	√
2002	Cougar	2.5L	Duratec-VE	HEC	√	√	√	√
2002	Cougar	2.5L	Duratec-VE	IAB	√	√	√	
2002	Cougar	2.5L	Duratec-VE	PCM	√	√	√	√
1995	Crown Victoria	4.6L	2V	ABS/TCS	√	√	√	
1995	Crown Victoria	4.6L	2V	DDM	√	√	√	
1995	Crown Victoria	4.6L	2V	DSM	√	√	√	
1995	Crown Victoria	4.6L	2V	EATC	√	√	√	
1995	Crown Victoria	4.6L	2V	LCM	√	√	√	
1995	Crown Victoria	4.6L	2V	PCM	√	√	√	√
1995	Crown Victoria	4.6L	Other	ABS/TCS	√	√	√	
1995	Crown Victoria	4.6L	Other	PCM	√	√	√	√
1996	Crown Victoria	4.6L	2V	ABS/TCS	√	√	√	√
1996	Crown Victoria	4.6L	2V	DDM	√	√	√	√
1996	Crown Victoria	4.6L	2V	DSM	√	√	√	√
1996	Crown Victoria	4.6L	2V	EATC	√	√	√	√
1996	Crown Victoria	4.6L	2V	IAB	√	√	√	
1996	Crown Victoria	4.6L	2V	LCM	√	√	√	√
1996	Crown Victoria	4.6L	2V	PCM	√	√	√	√
1996	Crown Victoria	4.6L	2V_NGV	ABS/TCS	√	√	√	√
1996	Crown Victoria	4.6L	2V_NGV	DDM	√	√	√	√
1996	Crown Victoria	4.6L	2V_NGV	DSM	√	√	√	√
1996	Crown Victoria	4.6L	2V_NGV	FIM	√	√	√	√
1996	Crown Victoria	4.6L	2V_NGV	IAB	√	√	√	
1996	Crown Victoria	4.6L	2V_NGV	LCM	√	√	√	√
1996	Crown Victoria	4.6L	2V_NGV	PCM	√	√	√	√
1997	Crown Victoria	4.6L	2V	ABS/TCS	√	√	√	√
1997	Crown Victoria	4.6L	2V	DDM	√	√	√	√
1997	Crown Victoria	4.6L	2V	DSM	√	√	√	√
1997	Crown Victoria	4.6L	2V	EATC	√	√	√	√
1997	Crown Victoria	4.6L	2V	IAB	√	√	√	
1997	Crown Victoria	4.6L	2V	LCM	√	√	√	√
1997	Crown Victoria	4.6L	2V	PCM	√	√	√	√
1997	Crown Victoria	4.6L	2V_NGV	ABS/TCS	√	√	√	√
1997	Crown Victoria	4.6L	2V_NGV	DDM	√	√	√	√
1997	Crown Victoria	4.6L	2V_NGV	DSM	√	√	√	√
1997	Crown Victoria	4.6L	2V_NGV	FIM	√	√	√	√
1997	Crown Victoria	4.6L	2V_NGV	IAB	√	√	√	
1997	Crown Victoria	4.6L	2V_NGV	LCM	√	√	√	√
1997	Crown Victoria	4.6L	2V_NGV	PCM	√	√	√	√
1998	Crown Victoria	4.6L	2V	ABS/TCS	√	√	√	√
1998	Crown Victoria	4.6L	2V	DDM	√	√	√	√
1998	Crown Victoria	4.6L	2V	EATC	√	√	√	√
1998	Crown Victoria	4.6L	2V	ECS	√	√	√	√

1998	Crown Victoria	4.6L	2V	LCM	√	√	√	√
1998	Crown Victoria	4.6L	2V	PATS	√	√	√	√
1998	Crown Victoria	4.6L	2V	PCM	√	√	√	√
1998	Crown Victoria	4.6L	2V_NGV	ABS/TCS	√	√	√	√
1998	Crown Victoria	4.6L	2V_NGV	DDM	√	√	√	√
1998	Crown Victoria	4.6L	2V_NGV	EATC	√	√	√	√
1998	Crown Victoria	4.6L	2V_NGV	ECS	√	√	√	√
1998	Crown Victoria	4.6L	2V_NGV	FIM	√	√	√	√
1998	Crown Victoria	4.6L	2V_NGV	LCM	√	√	√	√
1998	Crown Victoria	4.6L	2V_NGV	PATS	√	√	√	√
1998	Crown Victoria	4.6L	2V_NGV	PCM	√	√	√	√
1998	Crown Victoria	4.6L	2V_NGV	PCM	√	√	√	√
1999	Crown Victoria	4.6L	2V	ABS/TCS	√	√	√	√
1999	Crown Victoria	4.6L	2V	DDM	√	√	√	√
1999	Crown Victoria	4.6L	2V	EATC	√	√	√	√
1999	Crown Victoria	4.6L	2V	ECS	√	√	√	√
1999	Crown Victoria	4.6L	2V	LCM	√	√	√	√
1999	Crown Victoria	4.6L	2V	PCM	√	√	√	√
1999	Crown Victoria	4.6L	2V_NGV	ABS/TCS	√	√	√	√
1999	Crown Victoria	4.6L	2V_NGV	DDM	√	√	√	√
1999	Crown Victoria	4.6L	2V_NGV	EATC	√	√	√	√
1999	Crown Victoria	4.6L	2V_NGV	ECS	√	√	√	√
1999	Crown Victoria	4.6L	2V_NGV	FIM	√	√	√	√
1999	Crown Victoria	4.6L	2V_NGV	LCM	√	√	√	√
1999	Crown Victoria	4.6L	2V_NGV	PATS	√	√	√	√
1999	Crown Victoria	4.6L	2V_NGV	PCM	√	√	√	√
2000	Crown Victoria	4.6L	2V	ABS/TCS	√	√	√	√
2000	Crown Victoria	4.6L	2V	ABS/TCS	√	√	√	√
2000	Crown Victoria	4.6L	2V	ABS/TCS	√	√	√	√
2000	Crown Victoria	4.6L	2V	DDM	√	√	√	√
2000	Crown Victoria	4.6L	2V	EATC	√	√	√	√
2000	Crown Victoria	4.6L	2V	ECS	√	√	√	√
2000	Crown Victoria	4.6L	2V	LCM	√	√	√	√
2000	Crown Victoria	4.6L	2V	PATS	√	√	√	√
2000	Crown Victoria	4.6L	2V	PCM	√	√	√	√
2000	Crown Victoria	4.6L	2V	RCM	√	√	√	√
2000	Crown Victoria	4.6L	2V	RCM	√	√	√	√
2000	Crown Victoria	4.6L	2V_NGV	ABS/TCS	√	√	√	√
2000	Crown Victoria	4.6L	2V_NGV	ABS/TCS	√	√	√	√
2000	Crown Victoria	4.6L	2V_NGV	DDM	√	√	√	√
2000	Crown Victoria	4.6L	2V_NGV	EATC	√	√	√	√
2000	Crown Victoria	4.6L	2V_NGV	ECS	√	√	√	√
2000	Crown Victoria	4.6L	2V_NGV	ECS	√	√	√	√
2000	Crown Victoria	4.6L	2V_NGV	FIM	√	√	√	√
2000	Crown Victoria	4.6L	2V_NGV	LCM	√	√	√	√

2000	Crown Victoria	4.6L	2V_NGV	PATS	√	√	√	√
2000	Crown Victoria	4.6L	2V_NGV	PCM	√	√	√	√
2000	Crown Victoria	4.6L	2V_NGV	RCM	√	√	√	√
2002	Crown Victoria	4.6L	2V	ABS/TCS	√	√	√	√
2002	Crown Victoria	4.6L	2V	ABS/TCS	√	√	√	√
2002	Crown Victoria	4.6L	2V	ABS/TCS	√	√	√	√
2002	Crown Victoria	4.6L	2V	DDM	√	√	√	√
2002	Crown Victoria	4.6L	2V	EATC	√	√	√	√
2002	Crown Victoria	4.6L	2V	LCM	√	√	√	√
2002	Crown Victoria	4.6L	2V	PATS	√	√	√	√
2002	Crown Victoria	4.6L	2V	PCM	√	√	√	√
2002	Crown Victoria	4.6L	2V	RCM	√	√	√	√
2003	Crown Victoria	4.6L	2V	ABS/TCS	√	√	√	√
2003	Crown Victoria	4.6L	2V	ABS/TCS	√	√	√	√
2003	Crown Victoria	4.6L	2V	DDM	√	√	√	√
2003	Crown Victoria	4.6L	2V	EATC	√	√	√	√
2003	Crown Victoria	4.6L	2V	FIM	√	√	√	√
2003	Crown Victoria	4.6L	2V	LCM	√	√	√	√
2003	Crown Victoria	4.6L	2V	PCM	√	√	√	√
2003	Crown Victoria	4.6L	2V	RASM	√	√	√	√
2003	Crown Victoria	4.6L	2V	RASM	√	√	√	√
2003	Crown Victoria	4.6L	2V	RCM	√	√	√	√
2003	Crown Victoria	4.6L	2V	VAPS	√	√	√	√
2004	Crown Victoria	4.6L	2V	ABS/TCS	√	√	√	√
2004	Crown Victoria	4.6L	2V	ABS/TCS	√	√	√	√
2004	Crown Victoria	4.6L	2V	DDM	√	√	√	√
2004	Crown Victoria	4.6L	2V	EATC	√	√	√	√
2004	Crown Victoria	4.6L	2V	FIM	√	√	√	√
2004	Crown Victoria	4.6L	2V	LCM	√	√	√	√
2004	Crown Victoria	4.6L	2V	MC	√	√	√	√
2004	Crown Victoria	4.6L	2V	PCM	√	√	√	√
2004	Crown Victoria	4.6L	2V	RASM	√	√	√	√
2004	Crown Victoria	4.6L	2V	RCM	√	√	√	√
2004	Crown Victoria	4.6L	2V	VAPS	√	√	√	√
2005	Crown Victoria	4.6L	2V	ABS	√	√	√	√
2005	Crown Victoria	4.6L	2V	DDM	√	√	√	√
2005	Crown Victoria	4.6L	2V	EATC	√	√	√	√
2005	Crown Victoria	4.6L	2V	FSSM	√	√	√	√
2005	Crown Victoria	4.6L	2V	LCM	√	√	√	√
2005	Crown Victoria	4.6L	2V	MC	√	√	√	√
2005	Crown Victoria	4.6L	2V	PCM	√	√	√	√
2005	Crown Victoria	4.6L	2V	RASM	√	√	√	√
2005	Crown Victoria	4.6L	2V	RCM	√	√	√	√
2005	Crown Victoria	4.6L	2V	VAPS	√	√	√	√
2006	Crown Victoria	4.6L	2V	ABS	√	√	√	√

2006	Crown Victoria	4.6L	2V	DDM	√	√	√	√
2006	Crown Victoria	4.6L	2V	EATC	√	√	√	√
2006	Crown Victoria	4.6L	2V	FSSM	√	√	√	√
2006	Crown Victoria	4.6L	2V	IC	√	√	√	√
2006	Crown Victoria	4.6L	2V	LCM	√	√	√	√
2006	Crown Victoria	4.6L	2V	MC	√	√	√	√
2006	Crown Victoria	4.6L	2V	PCM	√	√	√	√
2006	Crown Victoria	4.6L	2V	PCM	√	√	√	√
2006	Crown Victoria	4.6L	2V	RASM	√	√	√	√
2006	Crown Victoria	4.6L	2V	RCM	√	√	√	√
2006	Crown Victoria	4.6L	2V	VAPS	√	√	√	√
2007	Crown Victoria	4.6L	2V	ABS	√	√	√	√
2007	Crown Victoria	4.6L	2V	DDM	√	√	√	√
2007	Crown Victoria	4.6L	2V	EATC	√	√	√	√
2007	Crown Victoria	4.6L	2V	IC	√	√	√	√
2007	Crown Victoria	4.6L	2V	LCM	√	√	√	√
2007	Crown Victoria	4.6L	2V	MC	√	√	√	√
2007	Crown Victoria	4.6L	2V	PCM	√	√	√	√
2007	Crown Victoria	4.6L	2V	PCM	√	√	√	√
2007	Crown Victoria	4.6L	2V	RCM	√	√	√	√
2007	Crown Victoria	4.6L	2V	VDM	√	√	√	√
2008	Crown Victoria	4.6L	2V	ABS	√	√	√	√
2008	Crown Victoria	4.6L	2V	DDM	√	√	√	√
2008	Crown Victoria	4.6L	2V	DDM	√	√	√	√
2008	Crown Victoria	4.6L	2V	FSSM	√	√	√	√
2008	Crown Victoria	4.6L	2V	HVAC	√	√	√	√
2008	Crown Victoria	4.6L	2V	IC	√	√	√	√
2008	Crown Victoria	4.6L	2V	LCM	√	√	√	√
2008	Crown Victoria	4.6L	2V	MC	√	√	√	√
2008	Crown Victoria	4.6L	2V	PCM	√	√	√	√
2008	Crown Victoria	4.6L	2V	PCM	√	√	√	√
2008	Crown Victoria	4.6L	2V	RCM	√	√	√	√
2008	Crown Victoria	4.6L	2V	VDM	√	√	√	√
2009	Crown Victoria	4.6L	2V	ABS	√	√	√	√
2009	Crown Victoria	4.6L	2V	DDM	√	√	√	√
2009	Crown Victoria	4.6L	2V	FSSM	√	√	√	√
2009	Crown Victoria	4.6L	2V	HVAC	√	√	√	√
2009	Crown Victoria	4.6L	2V	IC	√	√	√	√
2009	Crown Victoria	4.6L	2V	LCM	√	√	√	√
2009	Crown Victoria	4.6L	2V	MC	√	√	√	√
2009	Crown Victoria	4.6L	2V	PCM	√	√	√	√
2009	Crown Victoria	4.6L	2V	PCM	√	√	√	√
2009	Crown Victoria	4.6L	2V	RCM	√	√	√	√
2009	Crown Victoria	4.6L	2V	VDM	√	√	√	√
2010	Crown Victoria	4.6L	2V	ABS	√	√	√	√

2010	Crown Victoria	4.6L	2V	DDM	√	√	√	√
2010	Crown Victoria	4.6L	2V	FSSM	√	√	√	√
2010	Crown Victoria	4.6L	2V	HVAC	√	√	√	√
2010	Crown Victoria	4.6L	2V	IC	√	√	√	√
2010	Crown Victoria	4.6L	2V	LCM	√	√	√	√
2010	Crown Victoria	4.6L	2V	MC	√	√	√	√
2010	Crown Victoria	4.6L	2V	PCM	√	√	√	√
2010	Crown Victoria	4.6L	2V	PCM	√	√	√	√
2010	Crown Victoria	4.6L	2V	RCM	√	√	√	√
2010	Crown Victoria	4.6L	2V	VDM	√	√	√	√
2011	Crown Victoria	4.6L	2V	ABS	√	√	√	
2011	Crown Victoria	4.6L	2V	DDM	√	√	√	√
2011	Crown Victoria	4.6L	2V	FSSM	√	√	√	√
2011	Crown Victoria	4.6L	2V	HVAC	√	√	√	√
2011	Crown Victoria	4.6L	2V	IC	√	√	√	√
2011	Crown Victoria	4.6L	2V	LCM	√	√	√	√
2011	Crown Victoria	4.6L	2V	PCM	√	√	√	√
2011	Crown Victoria	4.6L	2V	RCM	√	√	√	√
2011	Crown Victoria	4.6L	2V	VDM	√	√	√	√
1996	DEMIO / FESTIVA MINI WAGON	1.3L	B3	ABS	√	√	√	√
1996	DEMIO / FESTIVA MINI WAGON	1.3L	B3	PCM	√	√	√	√
1996	DEMIO / FESTIVA MINI WAGON	1.5L	B5	ABS	√	√	√	√
1999	DEMIO / FESTIVA MINI WAGON	1.3L	B3	ABS	√	√	√	√
1999	DEMIO / FESTIVA MINI WAGON	1.3L	B3	PCM	√	√	√	√
1999	DEMIO / FESTIVA MINI WAGON	1.5L	B5	ABS	√	√	√	√
2000	DEMIO / FESTIVA MINI WAGON	1.3L	B3	ABS/TCS	√	√	√	√
2000	DEMIO / FESTIVA MINI WAGON	1.3L	B3	PCM	√	√	√	√
Other	DEMIO / FESTIVA MINI WAGON	1.3L	B3	PCM	√	√	√	√
1995	E-Series	7.3L	Direct Injection -	ABS/TCS	√	√	√	
1995	E-Series	7.3L	Direct Injection -	PCM	√	√	√	√
1995	E-Series	7.3L	Direct Injection -	PCM	√	√	√	√
1996	E-Series	4.9L	GFP	ABS/TCS	√	√	√	
1996	E-Series	4.9L	GFP	PCM	√	√	√	√
1996	E-Series	4.9L	Other	ABS/TCS	√	√	√	
1996	E-Series	4.9L	Other	PCM	√	√	√	√
1996	E-Series	5.0L	Other	ABS/TCS	√	√	√	
1996	E-Series	5.0L	Other	PCM	√	√	√	√
1996	E-Series	5.8L	Other	ABS/TCS	√	√	√	
1996	E-Series	5.8L	Other	PCM	√	√	√	√
1996	E-Series	7.3L	Direct Injection -	ABS/TCS	√	√	√	
1996	E-Series	7.3L	Direct Injection -	PCM	√	√	√	√
1996	E-Series	7.3L	Direct Injection -	PCM	√	√	√	√
1996	E-Series	7.5L	Other	ABS/TCS	√	√	√	
1996	E-Series	7.5L	Other	PCM	√	√	√	√
1997	E-Series	4.2L	Other	ABS/TCS	√	√	√	√

1997	E-Series	4.2L	Other	ECS	√	√	√	√
1997	E-Series	4.2L	Other	PCM	√	√	√	√
1997	E-Series	4.6L	Other	ABS/TCS	√	√	√	√
1997	E-Series	4.6L	Other	ECS	√	√	√	√
1997	E-Series	4.6L	Other	PCM	√	√	√	√
1997	E-Series	5.4L	NGV	ABS/TCS	√	√	√	√
1997	E-Series	5.4L	NGV	ECS	√	√	√	√
1997	E-Series	5.4L	Other	ABS/TCS	√	√	√	√
1997	E-Series	5.4L	Other	ECS	√	√	√	√
1997	E-Series	5.4L	Other	PCM	√	√	√	√
1997	E-Series	6.8L	Other	ABS/TCS	√	√	√	√
1997	E-Series	6.8L	Other	ECS	√	√	√	√
1997	E-Series	6.8L	Other	PCM	√	√	√	√
1997	E-Series	7.3L	Direct Injection -	ABS/TCS	√	√	√	√
1997	E-Series	7.3L	Direct Injection -	ECS	√	√	√	√
1997	E-Series	7.3L	Direct Injection -	PCM	√	√	√	√
1998	E-Series	4.2L	Other	ABS/TCS	√	√	√	√
1998	E-Series	4.2L	Other	ECS	√	√	√	√
1998	E-Series	4.2L	Other	PCM	√	√	√	√
1998	E-Series	4.6L	Other	ABS/TCS	√	√	√	√
1998	E-Series	4.6L	Other	ECS	√	√	√	√
1998	E-Series	4.6L	Other	PCM	√	√	√	√
1998	E-Series	5.4L	NGV	ABS/TCS	√	√	√	√
1998	E-Series	5.4L	NGV	ECS	√	√	√	√
1998	E-Series	5.4L	NGV	FIM	√	√	√	√
1998	E-Series	5.4L	NGV	PCM	√	√	√	√
1998	E-Series	5.4L	NGV	PCM	√	√	√	√
1998	E-Series	5.4L	Other	ABS/TCS	√	√	√	√
1998	E-Series	5.4L	Other	ECS	√	√	√	√
1998	E-Series	5.4L	Other	PCM	√	√	√	√
1998	E-Series	6.8L	Other	ABS/TCS	√	√	√	√
1998	E-Series	6.8L	Other	ECS	√	√	√	√
1998	E-Series	6.8L	Other	PCM	√	√	√	√
1998	E-Series	7.3L	Direct Injection -	ABS/TCS	√	√	√	√
1998	E-Series	7.3L	Direct Injection -	ECS	√	√	√	√
1998	E-Series	7.3L	Direct Injection -	PCM	√	√	√	√
1999	E-Series	4.2L	Other	ABS/TCS	√	√	√	√
1999	E-Series	4.2L	Other	ECS	√	√	√	√
1999	E-Series	4.2L	Other	PCM	√	√	√	√
1999	E-Series	4.6L	Other	ABS/TCS	√	√	√	√
1999	E-Series	4.6L	Other	ECS	√	√	√	√
1999	E-Series	4.6L	Other	PCM	√	√	√	√
1999	E-Series	5.4L	BIF	ABS/TCS	√	√	√	√
1999	E-Series	5.4L	BIF	AFCM	√	√	√	√
1999	E-Series	5.4L	BIF	ECS	√	√	√	√

1999	E-Series	5.4L	BIF	PCM	√	√	√	√
1999	E-Series	5.4L	BIF	PCM	√	√	√	√
1999	E-Series	5.4L	NGV	ABS/TCS	√	√	√	√
1999	E-Series	5.4L	NGV	ECS	√	√	√	√
1999	E-Series	5.4L	NGV	FIM	√	√	√	√
1999	E-Series	5.4L	NGV	PCM	√	√	√	√
1999	E-Series	5.4L	Other	ABS/TCS	√	√	√	√
1999	E-Series	5.4L	Other	ECS	√	√	√	√
1999	E-Series	5.4L	Other	PCM	√	√	√	√
1999	E-Series	6.8L	Other	ABS/TCS	√	√	√	√
1999	E-Series	6.8L	Other	ECS	√	√	√	√
1999	E-Series	6.8L	Other	PCM	√	√	√	√
1999	E-Series	7.3L	Direct Injection -	ABS/TCS	√	√	√	√
1999	E-Series	7.3L	Direct Injection -	ECS	√	√	√	√
1999	E-Series	7.3L	Direct Injection -	PCM	√	√	√	√
1999	E-Series	7.3L	Direct Injection -	PCM	√	√	√	√
2000	E-Series	4.2L	Other	ABS/TCS	√	√	√	√
2000	E-Series	4.2L	Other	ECS	√	√	√	√
2000	E-Series	4.2L	Other	PCM	√	√	√	√
2000	E-Series	4.6L	Other	ABS/TCS	√	√	√	√
2000	E-Series	4.6L	Other	ECS	√	√	√	√
2000	E-Series	4.6L	Other	PCM	√	√	√	√
2000	E-Series	5.4L	NGV	ABS/TCS	√	√	√	√
2000	E-Series	5.4L	NGV	ECS	√	√	√	√
2000	E-Series	5.4L	NGV	FIM	√	√	√	√
2000	E-Series	5.4L	NGV	PCM	√	√	√	√
2000	E-Series	5.4L	Other	ABS/TCS	√	√	√	√
2000	E-Series	5.4L	Other	ECS	√	√	√	√
2000	E-Series	5.4L	Other	PCM	√	√	√	√
2000	E-Series	6.8L	Other	ABS/TCS	√	√	√	√
2000	E-Series	6.8L	Other	ECS	√	√	√	√
2000	E-Series	6.8L	Other	PCM	√	√	√	√
2000	E-Series	7.3L	Direct Injection -	ABS/TCS	√	√	√	√
2000	E-Series	7.3L	Direct Injection -	ECS	√	√	√	√
2000	E-Series	7.3L	Direct Injection -	PCM	√	√	√	√
2002	E-Series	4.2L	Other	ABS/TCS	√	√	√	√
2002	E-Series	4.2L	Other	ECS	√	√	√	√
2002	E-Series	4.2L	Other	PCM	√	√	√	√
2002	E-Series	4.6L	Other	ABS/TCS	√	√	√	√
2002	E-Series	4.6L	Other	ECS	√	√	√	√
2002	E-Series	4.6L	Other	PCM	√	√	√	√
2002	E-Series	5.4L	Other	ABS/TCS	√	√	√	√
2002	E-Series	5.4L	Other	AFCM	√	√	√	√
2002	E-Series	5.4L	Other	ECS	√	√	√	√
2002	E-Series	5.4L	Other	FIM	√	√	√	√

2002	E-Series	5.4L	Other	PCM	√	√	√	√
2002	E-Series	6.8L	Other	ABS/TCS	√	√	√	√
2002	E-Series	6.8L	Other	ECS	√	√	√	√
2002	E-Series	6.8L	Other	PCM	√	√	√	√
2002	E-Series	7.3L	Direct Injection -	ABS/TCS	√	√	√	√
2002	E-Series	7.3L	Direct Injection -	PCM	√	√	√	√
2003	E-Series	4.2L	Other	ABS/TCS	√	√	√	√
2003	E-Series	4.2L	Other	ECS	√	√	√	√
2003	E-Series	4.2L	Other	PCM	√	√	√	√
2003	E-Series	4.6L	2V	ABS/TCS	√	√	√	√
2003	E-Series	4.6L	2V	ECS	√	√	√	√
2003	E-Series	4.6L	2V	PCM	√	√	√	√
2003	E-Series	5.4L	Other	ABS/TCS	√	√	√	√
2003	E-Series	5.4L	Other	AFCM	√	√	√	√
2003	E-Series	5.4L	Other	ECS	√	√	√	√
2003	E-Series	5.4L	Other	FIM	√	√	√	√
2003	E-Series	5.4L	Other	PCM	√	√	√	√
2003	E-Series	6.8L	Other	ABS/TCS	√	√	√	√
2003	E-Series	6.8L	Other	ECS	√	√	√	√
2003	E-Series	6.8L	Other	PCM	√	√	√	√
2003	E-Series	7.3L	Direct Injection -	ABS/TCS	√	√	√	√
2003	E-Series	7.3L	Direct Injection -	ECS	√	√	√	√
2003	E-Series	7.3L	Direct Injection -	PCM	√	√	√	√
2004	E-Series	4.6L	2V	ABS/TCS	√	√	√	√
2004	E-Series	4.6L	2V	IC	√	√	√	√
2004	E-Series	4.6L	2V	PCM	√	√	√	√
2004	E-Series	4.6L	2V	RAP	√	√	√	√
2004	E-Series	4.6L	2V	RCM	√	√	√	
2004	E-Series	5.4L	2V	ABS/TCS	√	√	√	√
2004	E-Series	5.4L	2V	ABS/TCS	√	√	√	√
2004	E-Series	5.4L	2V	AFCM	√	√	√	√
2004	E-Series	5.4L	2V	IC	√	√	√	√
2004	E-Series	5.4L	2V	PCM	√	√	√	√
2004	E-Series	5.4L	2V	PCM	√	√	√	√
2004	E-Series	5.4L	2V	RAP	√	√	√	√
2004	E-Series	5.4L	2V	RCM	√	√	√	
2004	E-Series	6.0L	Direct Injection -	ABS/TCS	√	√	√	√
2004	E-Series	6.0L	Direct Injection -	ABS/TCS	√	√	√	√
2004	E-Series	6.0L	Direct Injection -	IC	√	√	√	√
2004	E-Series	6.0L	Direct Injection -	PCM	√	√	√	√
2004	E-Series	6.0L	Direct Injection -	PCM	√	√	√	√
2004	E-Series	6.0L	Direct Injection - Turbo	PCM	√	√	√	√
2004	E-Series	6.0L	Direct Injection -	RAP	√	√	√	√
2004	E-Series	6.0L	Direct Injection -	RCM	√	√	√	
2004	E-Series	6.0L	Direct Injection -	TCM	√	√	√	√



2004	E-Series	6.8L	2V	ABS/TCS	✓	✓	✓	✓
2004	E-Series	6.8L	2V	IC	✓	✓	✓	✓
2004	E-Series	6.8L	2V	PCM	✓	✓	✓	✓
2004	E-Series	6.8L	2V	RAP	✓	✓	✓	✓
2004	E-Series	6.8L	2V	RCM	✓	✓	✓	
2005	E-Series	4.6L	2V	ABS/TCS	✓	✓	✓	✓
2005	E-Series	4.6L	2V	IC	✓	✓	✓	✓
2005	E-Series	4.6L	2V	PCM	✓	✓	✓	✓
2005	E-Series	4.6L	2V	PCM	✓	✓	✓	✓
2005	E-Series	4.6L	2V	RAP	✓	✓	✓	✓
2005	E-Series	4.6L	2V	RCM	✓	✓	✓	
2005	E-Series	5.4L	2V	ABS/TCS	✓	✓	✓	✓
2005	E-Series	5.4L	2V	IC	✓	✓	✓	✓
2005	E-Series	5.4L	2V	PCM	✓	✓	✓	✓
2005	E-Series	5.4L	2V	PCM	✓	✓	✓	✓
2005	E-Series	5.4L	2V	RAP	✓	✓	✓	✓
2005	E-Series	5.4L	2V	RCM	✓	✓	✓	
2005	E-Series	6.0L	Direct Injection -	ABS/TCS	✓	✓	✓	✓
2005	E-Series	6.0L	Direct Injection -	ABS/TCS	✓	✓	✓	✓
2005	E-Series	6.0L	Direct Injection -	IC	✓	✓	✓	✓
2005	E-Series	6.0L	Direct Injection -	IC	✓	✓	✓	✓
2005	E-Series	6.0L	Direct Injection -	PCM	✓	✓	✓	✓
2005	E-Series	6.0L	Direct Injection - Turbo	PCM	✓	✓	✓	✓
2005	E-Series	6.0L	Direct Injection -	RAP	✓	✓	✓	✓
2005	E-Series	6.0L	Direct Injection -	RCM	✓	✓	✓	
2005	E-Series	6.0L	Direct Injection -	TCM	✓	✓	✓	✓
2005	E-Series	6.8L	2V	ABS/TCS	✓	✓	✓	✓
2005	E-Series	6.8L	2V	IC	✓	✓	✓	✓
2005	E-Series	6.8L	2V	PCM	✓	✓	✓	✓
2005	E-Series	6.8L	2V	PCM	✓	✓	✓	✓
2005	E-Series	6.8L	2V	RAP	✓	✓	✓	✓
2005	E-Series	6.8L	2V	RCM	✓	✓	✓	
2006	E-Series	4.6L	2V	ABS	✓	✓	✓	✓
2006	E-Series	4.6L	2V	ABS/TCS	✓	✓	✓	✓
2006	E-Series	4.6L	2V	IC	✓	✓	✓	✓
2006	E-Series	4.6L	2V	PCM	✓	✓	✓	✓
2006	E-Series	4.6L	2V	PCM	✓	✓	✓	✓
2006	E-Series	4.6L	2V	RAP	✓	✓	✓	✓
2006	E-Series	4.6L	2V	RCM	✓	✓	✓	
2006	E-Series	5.4L	2V	ABS	✓	✓	✓	✓
2006	E-Series	5.4L	2V	ABS/TCS	✓	✓	✓	✓
2006	E-Series	5.4L	2V	IC	✓	✓	✓	✓
2006	E-Series	5.4L	2V	PCM	✓	✓	✓	✓
2006	E-Series	5.4L	2V	PCM	✓	✓	✓	✓
2006	E-Series	5.4L	2V	RAP	✓	✓	✓	✓

2006	E-Series	6.0L	Direct Injection -	ABS	√	√	√	√
2006	E-Series	6.0L	Direct Injection -	ABS	√	√	√	√
2006	E-Series	6.0L	Direct Injection -	ABS/TCS	√	√	√	√
2006	E-Series	6.0L	Direct Injection -	ABS/TCS	√	√	√	√
2006	E-Series	6.0L	Direct Injection -	IC	√	√	√	√
2006	E-Series	6.0L	Direct Injection -	IC	√	√	√	√
2006	E-Series	6.0L	Direct Injection -	PCM	√	√	√	√
2006	E-Series	6.0L	Direct Injection - Turbo	PCM	√	√	√	√
2006	E-Series	6.0L	Direct Injection -	RAP	√	√	√	√
2006	E-Series	6.0L	Direct Injection -	RCM	√	√	√	
2006	E-Series	6.0L	Direct Injection -	TCM	√	√	√	√
2006	E-Series	6.8L	2V	ABS	√	√	√	√
2006	E-Series	6.8L	2V	ABS/TCS	√	√	√	√
2006	E-Series	6.8L	2V	IC	√	√	√	√
2006	E-Series	6.8L	2V	PCM	√	√	√	√
2006	E-Series	6.8L	2V	PCM	√	√	√	√
2006	E-Series	6.8L	2V	RAP	√	√	√	√
2006	E-Series	6.8L	2V	RCM	√	√	√	
2007	E-Series	4.6L	2V	ABS	√	√	√	√
2007	E-Series	4.6L	2V	ABS/TCS	√	√	√	√
2007	E-Series	4.6L	2V	IC	√	√	√	√
2007	E-Series	4.6L	2V	PAM	√	√	√	√
2007	E-Series	4.6L	2V	PCM	√	√	√	√
2007	E-Series	4.6L	2V	PCM	√	√	√	√
2007	E-Series	4.6L	2V	RCM	√	√	√	
2007	E-Series	4.6L	2V	VSM	√	√	√	√
2007	E-Series	5.4L	2V	ABS	√	√	√	√
2007	E-Series	5.4L	2V	ABS	√	√	√	√
2007	E-Series	5.4L	2V	ABS/TCS	√	√	√	√
2007	E-Series	5.4L	2V	IC	√	√	√	√
2007	E-Series	5.4L	2V	IC	√	√	√	√
2007	E-Series	5.4L	2V	PAM	√	√	√	√
2007	E-Series	5.4L	2V	PCM	√	√	√	√
2007	E-Series	5.4L	2V	PCM	√	√	√	√
2007	E-Series	5.4L	2V	PCM	√	√	√	√
2007	E-Series	5.4L	2V	RCM	√	√	√	
2007	E-Series	5.4L	2V	VSM	√	√	√	√
2007	E-Series	5.4L	2V	VSM	√	√	√	√
2007	E-Series	6.0L	Direct Injection -	ABS	√	√	√	√
2007	E-Series	6.0L	Direct Injection -	ABS	√	√	√	√
2007	E-Series	6.0L	Direct Injection -	ABS/TCS	√	√	√	√
2007	E-Series	6.0L	Direct Injection -	ABS/TCS	√	√	√	√
2007	E-Series	6.0L	Direct Injection -	IC	√	√	√	√
2007	E-Series	6.0L	Direct Injection -	IC	√	√	√	√
2007	E-Series	6.0L	Direct Injection -	PAM	√	√	√	√

2007	E-Series	6.0L	Direct Injection -	PCM	√	√	√	√
2007	E-Series	6.0L	Direct Injection - Turbo	PCM	√	√	√	√
2007	E-Series	6.0L	Direct Injection -	RCM	√	√	√	
2007	E-Series	6.0L	Direct Injection -	TCM	√	√	√	√
2007	E-Series	6.0L	Direct Injection -	VSM	√	√	√	√
2007	E-Series	6.8L	2V	ABS	√	√	√	√
2007	E-Series	6.8L	2V	ABS/TCS	√	√	√	√
2007	E-Series	6.8L	2V	IC	√	√	√	√
2007	E-Series	6.8L	2V	PAM	√	√	√	√
2007	E-Series	6.8L	2V	PCM	√	√	√	√
2007	E-Series	6.8L	2V	PCM	√	√	√	√
2007	E-Series	6.8L	2V	RCM	√	√	√	
2007	E-Series	6.8L	2V	VSM	√	√	√	√
2008	E-Series	4.6L	2V	ABS	√	√	√	√
2008	E-Series	4.6L	2V	IC	√	√	√	√
2008	E-Series	4.6L	2V	PAM	√	√	√	√
2008	E-Series	4.6L	2V	PCM	√	√	√	√
2008	E-Series	4.6L	2V	PCM	√	√	√	√
2008	E-Series	4.6L	2V	RCM	√	√	√	√
2008	E-Series	4.6L	2V	VSM	√	√	√	√
2008	E-Series	5.4L	2V	ABS	√	√	√	√
2008	E-Series	5.4L	2V	ABS	√	√	√	√
2008	E-Series	5.4L	2V	IC	√	√	√	√
2008	E-Series	5.4L	2V	IC	√	√	√	√
2008	E-Series	5.4L	2V	PAM	√	√	√	√
2008	E-Series	5.4L	2V	PCM	√	√	√	√
2008	E-Series	5.4L	2V	PCM	√	√	√	√
2008	E-Series	5.4L	2V	PCM	√	√	√	√
2008	E-Series	5.4L	2V	PCM	√	√	√	√
2008	E-Series	5.4L	2V	PCM	√	√	√	√
2008	E-Series	5.4L	2V	PCM	√	√	√	√
2008	E-Series	5.4L	2V	PCM	√	√	√	√
2008	E-Series	5.4L	2V	RCM	√	√	√	√
2008	E-Series	5.4L	2V	RCM	√	√	√	√
2008	E-Series	5.4L	2V	VSM	√	√	√	√
2008	E-Series	5.4L	2V	VSM	√	√	√	√
2008	E-Series	6.0L	Direct Injection -	ABS	√	√	√	√
2008	E-Series	6.0L	Direct Injection -	IC	√	√	√	√
2008	E-Series	6.0L	Direct Injection -	PAM	√	√	√	√
2008	E-Series	6.0L	Direct Injection -	PCM	√	√	√	√
2008	E-Series	6.0L	Direct Injection -	PCM	√	√	√	√
2008	E-Series	6.0L	Direct Injection - Turbo	PCM	√	√	√	√
2008	E-Series	6.0L	Direct Injection -	RCM	√	√	√	√
2008	E-Series	6.0L	Direct Injection -	TCM	√	√	√	√
2008	E-Series	6.0L	Direct Injection -	VSM	√	√	√	√

2008	E-Series	6.0L	Direct Injection -	VSM	✓	✓	✓	✓
2008	E-Series	6.8L	2V	ABS	✓	✓	✓	✓
2008	E-Series	6.8L	2V	IC	✓	✓	✓	✓
2008	E-Series	6.8L	2V	PAM	✓	✓	✓	✓
2008	E-Series	6.8L	2V	PCM	✓	✓	✓	✓
2008	E-Series	6.8L	2V	PCM	✓	✓	✓	✓
2008	E-Series	6.8L	2V	RCM	✓	✓	✓	✓
2008	E-Series	6.8L	2V	VSM	✓	✓	✓	✓
2009	E-Series	4.6L	2V	ABS	✓	✓	✓	✓
2009	E-Series	4.6L	2V	ABS	✓	✓	✓	✓
2009	E-Series	4.6L	2V	ACM	✓	✓	✓	
2009	E-Series	4.6L	2V	ACM	✓	✓	✓	✓
2009	E-Series	4.6L	2V	GEM / SJB	✓	✓	✓	✓
2009	E-Series	4.6L	2V	IPC	✓	✓	✓	✓
2009	E-Series	4.6L	2V	PAM	✓	✓	✓	✓
2009	E-Series	4.6L	2V	PCM	✓	✓	✓	✓
2009	E-Series	4.6L	2V	PCM	✓	✓	✓	✓
2009	E-Series	4.6L	2V	RCM	✓	✓	✓	✓
2009	E-Series	4.6L	2V	TBC	✓	✓	✓	✓
2009	E-Series	5.4L	2V	ABS	✓	✓	✓	✓
2009	E-Series	5.4L	2V	ABS	✓	✓	✓	✓
2009	E-Series	5.4L	2V	ACM	✓	✓	✓	
2009	E-Series	5.4L	2V	ACM	✓	✓	✓	✓
2009	E-Series	5.4L	2V	GEM / SJB	✓	✓	✓	✓
2009	E-Series	5.4L	2V	GEM / SJB	✓	✓	✓	✓
2009	E-Series	5.4L	2V	IPC	✓	✓	✓	✓
2009	E-Series	5.4L	2V	PAM	✓	✓	✓	✓
2009	E-Series	5.4L	2V	PCM	✓	✓	✓	✓
2009	E-Series	5.4L	2V	PCM	✓	✓	✓	✓
2009	E-Series	5.4L	2V	PCM	✓	✓	✓	✓
2009	E-Series	5.4L	2V	PCM	✓	✓	✓	✓
2009	E-Series	5.4L	2V	PCM	✓	✓	✓	✓
2009	E-Series	5.4L	2V	PCM	✓	✓	✓	✓
2009	E-Series	5.4L	2V	RCM	✓	✓	✓	✓
2009	E-Series	5.4L	2V	TBC	✓	✓	✓	✓
2009	E-Series	6.0L	Direct Injection -	ABS	✓	✓	✓	✓
2009	E-Series	6.0L	Direct Injection -	ABS	✓	✓	✓	✓
2009	E-Series	6.0L	Direct Injection -	ACM	✓	✓	✓	
2009	E-Series	6.0L	Direct Injection -	ACM	✓	✓	✓	
2009	E-Series	6.0L	Direct Injection -	ACM	✓	✓	✓	✓
2009	E-Series	6.0L	Direct Injection -	ACM	✓	✓	✓	✓
2009	E-Series	6.0L	Direct Injection -	GEM / SJB	✓	✓	✓	✓
2009	E-Series	6.0L	Direct Injection - Turbo	GEM / SJB	✓	✓	✓	✓
2009	E-Series	6.0L	Direct Injection -	IPC	✓	✓	✓	✓
2009	E-Series	6.0L	Direct Injection -	PAM	✓	✓	✓	✓

2009	E-Series	6.0L	Direct Injection -	PCM	✓	✓	✓	✓
2009	E-Series	6.0L	Direct Injection - Turbo	PCM	✓	✓	✓	✓
2009	E-Series	6.0L	Direct Injection - Turbo	PCM	✓	✓	✓	✓
2009	E-Series	6.0L	Direct Injection -	RCM	✓	✓	✓	✓
2009	E-Series	6.0L	Direct Injection -	TBC	✓	✓	✓	✓
2009	E-Series	6.0L	Direct Injection -	TCM	✓	✓	✓	✓
2009	E-Series	6.8L	2V	ABS	✓	✓	✓	✓
2009	E-Series	6.8L	2V	ABS	✓	✓	✓	✓
2009	E-Series	6.8L	2V	ACM	✓	✓	✓	
2009	E-Series	6.8L	2V	ACM	✓	✓	✓	✓
2009	E-Series	6.8L	2V	GEM / SJB	✓	✓	✓	✓
2009	E-Series	6.8L	2V	GEM / SJB	✓	✓	✓	✓
2009	E-Series	6.8L	2V	IPC	✓	✓	✓	✓
2009	E-Series	6.8L	2V	PAM	✓	✓	✓	✓
2009	E-Series	6.8L	2V	PCM	✓	✓	✓	✓
2009	E-Series	6.8L	2V	PCM	✓	✓	✓	✓
2009	E-Series	6.8L	2V	PCM	✓	✓	✓	✓
2009	E-Series	6.8L	2V	PCM	✓	✓	✓	✓
2009	E-Series	6.8L	2V	PCM	✓	✓	✓	✓
2009	E-Series	6.8L	2V	PCM	✓	✓	✓	✓
2009	E-Series	6.8L	2V	RCM	✓	✓	✓	✓
2009	E-Series	6.8L	2V	TBC	✓	✓	✓	✓
2010	E-Series	4.6L	2V	ABS	✓	✓	✓	✓
2010	E-Series	4.6L	2V	ABS	✓	✓	✓	✓
2010	E-Series	4.6L	2V	ACM	✓	✓	✓	
2010	E-Series	4.6L	2V	ACM	✓	✓	✓	✓
2010	E-Series	4.6L	2V	APIM	✓	✓	✓	✓
2010	E-Series	4.6L	2V	GPSM	✓	✓	✓	✓
2010	E-Series	4.6L	2V	IPC	✓	✓	✓	✓
2010	E-Series	4.6L	2V	PAM	✓	✓	✓	✓
2010	E-Series	4.6L	2V	PCM	✓	✓	✓	✓
2010	E-Series	4.6L	2V	PCM	✓	✓	✓	✓
2010	E-Series	4.6L	2V	RCM	✓	✓	✓	✓
2010	E-Series	4.6L	2V	SDARS	✓	✓	✓	✓
2010	E-Series	4.6L	2V	TBC	✓	✓	✓	✓
2010	E-Series	5.4L	2V	ABS	✓	✓	✓	✓
2010	E-Series	5.4L	2V	ABS	✓	✓	✓	✓
2010	E-Series	5.4L	2V	ACM	✓	✓	✓	
2010	E-Series	5.4L	2V	ACM	✓	✓	✓	
2010	E-Series	5.4L	2V	ACM	✓	✓	✓	✓
2010	E-Series	5.4L	2V	ACM	✓	✓	✓	✓
2010	E-Series	5.4L	2V	APIM	✓	✓	✓	✓
2010	E-Series	5.4L	2V	APIM	✓	✓	✓	✓
2010	E-Series	5.4L	2V	GEM / SJB	✓	✓	✓	✓
2010	E-Series	5.4L	2V	GEM / SJB	✓	✓	✓	✓
2010	E-Series	5.4L	2V	GPSM	✓	✓	✓	✓
2010	E-Series	5.4L	2V	IPC	✓	✓	✓	✓

2010	E-Series	5.4L	2V	PAM	√	√	√	√
2010	E-Series	5.4L	2V	PCM	√	√	√	√
2010	E-Series	5.4L	2V	PCM	√	√	√	√
2010	E-Series	5.4L	2V	PCM	√	√	√	√
2010	E-Series	5.4L	2V	PCM	√	√	√	√
2010	E-Series	5.4L	2V	PCM	√	√	√	√
2010	E-Series	5.4L	2V	PCM	√	√	√	√
2010	E-Series	5.4L	2V	RCM	√	√	√	√
2010	E-Series	5.4L	2V	SDARS	√	√	√	√
2010	E-Series	5.4L	2V	TBC	√	√	√	√
2010	E-Series	6.0L	Direct Injection -	ABS	√	√	√	√
2010	E-Series	6.0L	Direct Injection -	ABS	√	√	√	√
2010	E-Series	6.0L	Direct Injection -	ACM	√	√	√	
2010	E-Series	6.0L	Direct Injection -	ACM	√	√	√	
2010	E-Series	6.0L	Direct Injection -	ACM	√	√	√	√
2010	E-Series	6.0L	Direct Injection -	ACM	√	√	√	√
2010	E-Series	6.0L	Direct Injection -	APIM	√	√	√	√
2010	E-Series	6.0L	Direct Injection -	APIM	√	√	√	√
2010	E-Series	6.0L	Direct Injection -	GEM / SJB	√	√	√	√
2010	E-Series	6.0L	Direct Injection - Turbo	GEM / SJB	√	√	√	√
2010	E-Series	6.0L	Direct Injection -	GPSM	√	√	√	√
2010	E-Series	6.0L	Direct Injection -	IPC	√	√	√	√
2010	E-Series	6.0L	Direct Injection -	PAM	√	√	√	√
2010	E-Series	6.0L	Direct Injection -	PCM	√	√	√	√
2010	E-Series	6.0L	Direct Injection - Turbo	PCM	√	√	√	√
2010	E-Series	6.0L	Direct Injection - Turbo	PCM	√	√	√	√
2010	E-Series	6.0L	Direct Injection -	RCM	√	√	√	√
2010	E-Series	6.0L	Direct Injection -	SDARS	√	√	√	√
2010	E-Series	6.0L	Direct Injection -	TBC	√	√	√	√
2010	E-Series	6.0L	Direct Injection -	TCM	√	√	√	√
2010	E-Series	6.8L	2V	ABS	√	√	√	√
2010	E-Series	6.8L	2V	ABS	√	√	√	√
2010	E-Series	6.8L	2V	ABS	√	√	√	√
2010	E-Series	6.8L	2V	ACM	√	√	√	
2010	E-Series	6.8L	2V	ACM	√	√	√	√
2010	E-Series	6.8L	2V	APIM	√	√	√	√
2010	E-Series	6.8L	2V	GEM / SJB	√	√	√	√
2010	E-Series	6.8L	2V	GEM / SJB	√	√	√	√
2010	E-Series	6.8L	2V	GPSM	√	√	√	√
2010	E-Series	6.8L	2V	IPC	√	√	√	√
2010	E-Series	6.8L	2V	PAM	√	√	√	√
2010	E-Series	6.8L	2V	PCM	√	√	√	√
2010	E-Series	6.8L	2V	PCM	√	√	√	√
2010	E-Series	6.8L	2V	PCM	√	√	√	√
2010	E-Series	6.8L	2V	RCM	√	√	√	√

2010	E-Series	6.8L	2V	SDARS	✓	✓	✓	✓
2010	E-Series	6.8L	2V	TBC	✓	✓	✓	✓
2011	E-Series	4.6L	2V	ABS	✓	✓	✓	✓
2011	E-Series	4.6L	2V	ABS	✓	✓	✓	✓
2011	E-Series	4.6L	2V	ACM	✓	✓	✓	
2011	E-Series	4.6L	2V	ACM	✓	✓	✓	✓
2011	E-Series	4.6L	2V	APIM	✓	✓	✓	✓
2011	E-Series	4.6L	2V	GEM / SJB	✓	✓	✓	✓
2011	E-Series	4.6L	2V	GPSM	✓	✓	✓	✓
2011	E-Series	4.6L	2V	IPC	✓	✓	✓	✓
2011	E-Series	4.6L	2V	PAM	✓	✓	✓	✓
2011	E-Series	4.6L	2V	PCM	✓	✓	✓	✓
2011	E-Series	4.6L	2V	RCM	✓	✓	✓	✓
2011	E-Series	4.6L	2V	SDARS	✓	✓	✓	✓
2011	E-Series	4.6L	2V	TBC	✓	✓	✓	✓
2011	E-Series	5.4L	2V	ABS	✓	✓	✓	✓
2011	E-Series	5.4L	2V	ABS	✓	✓	✓	✓
2011	E-Series	5.4L	2V	ACM	✓	✓	✓	
2011	E-Series	5.4L	2V	ACM	✓	✓	✓	
2011	E-Series	5.4L	2V	ACM	✓	✓	✓	✓
2011	E-Series	5.4L	2V	ACM	✓	✓	✓	✓
2011	E-Series	5.4L	2V	APIM	✓	✓	✓	✓
2011	E-Series	5.4L	2V	APIM	✓	✓	✓	✓
2011	E-Series	5.4L	2V	GEM / SJB	✓	✓	✓	✓
2011	E-Series	5.4L	2V	GEM / SJB	✓	✓	✓	✓
2011	E-Series	5.4L	2V	GPSM	✓	✓	✓	✓
2011	E-Series	5.4L	2V	IPC	✓	✓	✓	✓
2011	E-Series	5.4L	2V	PAM	✓	✓	✓	✓
2011	E-Series	5.4L	2V	PCM	✓	✓	✓	✓
2011	E-Series	5.4L	2V	PCM	✓	✓	✓	✓
2011	E-Series	5.4L	2V	PCM	✓	✓	✓	✓
2011	E-Series	5.4L	2V	PCM	✓	✓	✓	✓
2011	E-Series	5.4L	2V	PCM	✓	✓	✓	✓
2011	E-Series	5.4L	2V	PCM	✓	✓	✓	✓
2011	E-Series	5.4L	2V	PCM	✓	✓	✓	✓
2011	E-Series	5.4L	2V	PCM	✓	✓	✓	✓
2011	E-Series	5.4L	2V	PCM	✓	✓	✓	✓
2011	E-Series	5.4L	2V	RCM	✓	✓	✓	✓
2011	E-Series	5.4L	2V	SDARS	✓	✓	✓	✓
2011	E-Series	5.4L	2V	TBC	✓	✓	✓	✓
2011	E-Series	6.8L	2V	ABS	✓	✓	✓	✓
2011	E-Series	6.8L	2V	ABS	✓	✓	✓	✓
2011	E-Series	6.8L	2V	ABS	✓	✓	✓	✓
2011	E-Series	6.8L	2V	ACM	✓	✓	✓	
2011	E-Series	6.8L	2V	ACM	✓	✓	✓	✓
2011	E-Series	6.8L	2V	APIM	✓	✓	✓	✓

2011	E-Series	6.8L	2V	APIM	✓	✓	✓	✓
2011	E-Series	6.8L	2V	GEM / SJB	✓	✓	✓	✓
2011	E-Series	6.8L	2V	GEM / SJB	✓	✓	✓	✓
2011	E-Series	6.8L	2V	GPSM	✓	✓	✓	✓
2011	E-Series	6.8L	2V	IPC	✓	✓	✓	✓
2011	E-Series	6.8L	2V	PAM	✓	✓	✓	✓
2011	E-Series	6.8L	2V	PCM	✓	✓	✓	✓
2011	E-Series	6.8L	2V	PCM	✓	✓	✓	✓
2011	E-Series	6.8L	2V	PCM	✓	✓	✓	✓
2011	E-Series	6.8L	2V	PCM	✓	✓	✓	✓
2011	E-Series	6.8L	2V	RCM	✓	✓	✓	✓
2011	E-Series	6.8L	2V	SDARS	✓	✓	✓	✓
2011	E-Series	6.8L	2V	TBC	✓	✓	✓	✓
2012	E-Series	5.4L	2V	ABS	✓	✓	✓	✓
2012	E-Series	5.4L	2V	ABS	✓	✓	✓	✓
2012	E-Series	5.4L	2V	ACM	✓	✓	✓	
2012	E-Series	5.4L	2V	ACM	✓	✓	✓	✓
2012	E-Series	5.4L	2V	APIM	✓	✓	✓	✓
2012	E-Series	5.4L	2V	GEM / SJB	✓	✓	✓	✓
2012	E-Series	5.4L	2V	GEM / SJB	✓	✓	✓	✓
2012	E-Series	5.4L	2V	GPSM	✓	✓	✓	✓
2012	E-Series	5.4L	2V	IPC	✓	✓	✓	✓
2012	E-Series	5.4L	2V	PAM	✓	✓	✓	✓
2012	E-Series	5.4L	2V	PCM	✓	✓	✓	✓
2012	E-Series	5.4L	2V	PCM	✓	✓	✓	✓
2012	E-Series	5.4L	2V	PCM	✓	✓	✓	✓
2012	E-Series	5.4L	2V	PCM	✓	✓	✓	✓
2012	E-Series	5.4L	2V	PCM	✓	✓	✓	✓
2012	E-Series	5.4L	2V	PCM	✓	✓	✓	✓
2012	E-Series	5.4L	2V	RCM	✓	✓	✓	✓
2012	E-Series	5.4L	2V	SDARS	✓	✓	✓	✓
2012	E-Series	5.4L	2V	TBC	✓	✓	✓	✓
2012	E-Series	6.8L	2V	ABS	✓	✓	✓	✓
2012	E-Series	6.8L	2V	ABS	✓	✓	✓	✓
2012	E-Series	6.8L	2V	ACM	✓	✓	✓	
2012	E-Series	6.8L	2V	ACM	✓	✓	✓	✓
2012	E-Series	6.8L	2V	APIM	✓	✓	✓	✓
2012	E-Series	6.8L	2V	APIM	✓	✓	✓	✓
2012	E-Series	6.8L	2V	GEM / SJB	✓	✓	✓	✓
2012	E-Series	6.8L	2V	GEM / SJB	✓	✓	✓	✓
2012	E-Series	6.8L	2V	GPSM	✓	✓	✓	✓
2012	E-Series	6.8L	2V	IPC	✓	✓	✓	✓
2012	E-Series	6.8L	2V	PAM	✓	✓	✓	✓
2012	E-Series	6.8L	2V	PCM	✓	✓	✓	✓
2012	E-Series	6.8L	2V	PCM	✓	✓	✓	✓



2012	E-Series	6.8L	2V	PCM	✓	✓	✓	✓
2012	E-Series	6.8L	2V	RCM	✓	✓	✓	✓
2012	E-Series	6.8L	2V	SDARS	✓	✓	✓	✓
2012	E-Series	6.8L	2V	TBC	✓	✓	✓	✓
2012	E-Series	Other	Other	ABS	✓	✓	✓	✓
2012	E-Series	Other	Other	ACM	✓	✓	✓	
2012	E-Series	Other	Other	ACM	✓	✓	✓	✓
2012	E-Series	Other	Other	APIM	✓	✓	✓	✓
2012	E-Series	Other	Other	GEM / SJB	✓	✓	✓	✓
2012	E-Series	Other	Other	GPSM	✓	✓	✓	✓
2012	E-Series	Other	Other	IPC	✓	✓	✓	✓
2012	E-Series	Other	Other	PAM	✓	✓	✓	✓
2012	E-Series	Other	Other	PCM	✓	✓	✓	✓
2012	E-Series	Other	Other	RCM	✓	✓	✓	✓
2012	E-Series	Other	Other	SDARS	✓	✓	✓	✓
2012	E-Series	Other	Other	TBC	✓	✓	✓	✓
2013	E-Series	4.6L	2V	ABS	✓	✓	✓	
2013	E-Series	4.6L	2V	ABS	✓	✓	✓	✓
2013	E-Series	4.6L	2V	ACM	✓	✓	✓	
2013	E-Series	4.6L	2V	ACM	✓	✓	✓	✓
2013	E-Series	4.6L	2V	APIM	✓	✓	✓	✓
2013	E-Series	4.6L	2V	GEM / SJB	✓	✓	✓	✓
2013	E-Series	4.6L	2V	GPSM	✓	✓	✓	✓
2013	E-Series	4.6L	2V	IPC	✓	✓	✓	
2013	E-Series	4.6L	2V	PAM	✓	✓	✓	
2013	E-Series	4.6L	2V	PCM	✓	✓	✓	
2013	E-Series	4.6L	2V	PCM	✓	✓	✓	✓
2013	E-Series	4.6L	2V	RCM	✓	✓	✓	✓
2013	E-Series	4.6L	2V	SDARS	✓	✓	✓	
2013	E-Series	4.6L	2V	TBC	✓	✓	✓	
2013	E-Series	5.4L	2V	ABS	✓	✓	✓	
2013	E-Series	5.4L	2V	ABS	✓	✓	✓	✓
2013	E-Series	5.4L	2V	ACM	✓	✓	✓	
2013	E-Series	5.4L	2V	ACM	✓	✓	✓	
2013	E-Series	5.4L	2V	ACM	✓	✓	✓	✓
2013	E-Series	5.4L	2V	ACM	✓	✓	✓	✓
2013	E-Series	5.4L	2V	APIM	✓	✓	✓	✓
2013	E-Series	5.4L	2V	GEM / SJB	✓	✓	✓	✓
2013	E-Series	5.4L	2V	GPSM	✓	✓	✓	✓
2013	E-Series	5.4L	2V	IPC	✓	✓	✓	
2013	E-Series	5.4L	2V	IPC	✓	✓	✓	✓
2013	E-Series	5.4L	2V	PAM	✓	✓	✓	
2013	E-Series	5.4L	2V	PCM	✓	✓	✓	
2013	E-Series	5.4L	2V	PCM	✓	✓	✓	✓
2013	E-Series	5.4L	2V	PCM	✓	✓	✓	✓

2013	E-Series	5.4L	2V	PCM	✓	✓	✓	✓
2013	E-Series	5.4L	2V	RCM	✓	✓	✓	✓
2013	E-Series	5.4L	2V	SDARS	✓	✓	✓	
2013	E-Series	5.4L	2V	TBC	✓	✓	✓	
2013	E-Series	5.4L	2V	TBC	✓	✓	✓	✓
2013	E-Series	6.8L	2V	ABS	✓	✓	✓	
2013	E-Series	6.8L	2V	ABS	✓	✓	✓	✓
2013	E-Series	6.8L	2V	ACM	✓	✓	✓	
2013	E-Series	6.8L	2V	ACM	✓	✓	✓	✓
2013	E-Series	6.8L	2V	APIM	✓	✓	✓	✓
2013	E-Series	6.8L	2V	GEM / SJB	✓	✓	✓	✓
2013	E-Series	6.8L	2V	GPSM	✓	✓	✓	✓
2013	E-Series	6.8L	2V	IPC	✓	✓	✓	
2013	E-Series	6.8L	2V	IPC	✓	✓	✓	✓
2013	E-Series	6.8L	2V	PAM	✓	✓	✓	
2013	E-Series	6.8L	2V	PCM	✓	✓	✓	
2013	E-Series	6.8L	2V	PCM	✓	✓	✓	✓
2013	E-Series	6.8L	2V	PCM	✓	✓	✓	✓
2013	E-Series	6.8L	2V	PCM	✓	✓	✓	✓
2013	E-Series	6.8L	2V	RCM	✓	✓	✓	✓
2013	E-Series	6.8L	2V	SDARS	✓	✓	✓	
2013	E-Series	6.8L	2V	TBC	✓	✓	✓	
2013	E-Series	6.8L	2V	TBC	✓	✓	✓	✓
2014	E-Series	4.6L	2V	ABS	✓	✓	✓	✓
2014	E-Series	4.6L	2V	ACM	✓	✓	✓	✓
2014	E-Series	4.6L	2V	APIM	✓	✓	✓	✓
2014	E-Series	4.6L	2V	GEM / SJB	✓	✓	✓	✓
2014	E-Series	4.6L	2V	GPSM	✓	✓	✓	✓
2014	E-Series	4.6L	2V	IPC	✓	✓	✓	✓
2014	E-Series	4.6L	2V	PAM	✓	✓	✓	
2014	E-Series	4.6L	2V	PCM	✓	✓	✓	✓
2014	E-Series	4.6L	2V	PCM	✓	✓	✓	✓
2014	E-Series	4.6L	2V	RCM	✓	✓	✓	✓
2014	E-Series	4.6L	2V	TBC	✓	✓	✓	✓
2014	E-Series	5.4L	2V	ABS	✓	✓	✓	✓
2014	E-Series	5.4L	2V	ACM	✓	✓	✓	✓
2014	E-Series	5.4L	2V	APIM	✓	✓	✓	✓
2014	E-Series	5.4L	2V	APIM	✓	✓	✓	✓
2014	E-Series	5.4L	2V	GEM / SJB	✓	✓	✓	✓
2014	E-Series	5.4L	2V	GPSM	✓	✓	✓	✓
2014	E-Series	5.4L	2V	IPC	✓	✓	✓	✓
2014	E-Series	5.4L	2V	PAM	✓	✓	✓	
2014	E-Series	5.4L	2V	PCM	✓	✓	✓	✓
2014	E-Series	5.4L	2V	PCM	✓	✓	✓	✓
2014	E-Series	5.4L	2V	RCM	✓	✓	✓	✓

2014	E-Series	5.4L	2V	TBC	✓	✓	✓	✓
2014	E-Series	6.8L	2V	ABS	✓	✓	✓	✓
2014	E-Series	6.8L	2V	ACM	✓	✓	✓	✓
2014	E-Series	6.8L	2V	APIM	✓	✓	✓	✓
2014	E-Series	6.8L	2V	GEM / SJB	✓	✓	✓	✓
2014	E-Series	6.8L	2V	GPSM	✓	✓	✓	✓
2014	E-Series	6.8L	2V	IPC	✓	✓	✓	✓
2014	E-Series	6.8L	2V	PAM	✓	✓	✓	
2014	E-Series	6.8L	2V	PCM	✓	✓	✓	✓
2014	E-Series	6.8L	2V	PCM	✓	✓	✓	✓
2014	E-Series	6.8L	2V	RCM	✓	✓	✓	✓
2014	E-Series	6.8L	2V	TBC	✓	✓	✓	✓
2006	E-Series Shuttle Bus	6.8L	H2ICE	ABS/TCS	✓	✓	✓	✓
2006	E-Series Shuttle Bus	6.8L	H2ICE	AFCM	✓	✓	✓	✓
2006	E-Series Shuttle Bus	6.8L	H2ICE	EMM	✓	✓	✓	✓
2006	E-Series Shuttle Bus	6.8L	H2ICE	IC	✓	✓	✓	✓
2006	E-Series Shuttle Bus	6.8L	H2ICE	PCM	✓	✓	✓	✓
2006	E-Series Shuttle Bus	6.8L	H2ICE	RCM	✓	✓	✓	
2003.25	EcoSport	1.0L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓
2003.25	EcoSport	1.0L	Zetec Rocam	GEM	✓	✓	✓	✓
2003.25	EcoSport	1.0L	Zetec Rocam	IC	✓	✓	✓	✓
2003.25	EcoSport	1.0L	Zetec Rocam	PCM	✓	✓	✓	✓
2003.25	EcoSport	1.0L	Zetec Rocam	RCM	✓	✓	✓	✓
2003.25	EcoSport	1.0L	Zetec Rocam	RKE	✓	✓	✓	✓
2003.25	EcoSport	1.4L	Duratorq Turbo Diesel Common Rail	ABS/TCS	✓	✓	✓	✓
2003.25	EcoSport	1.4L	Duratorq Turbo Diesel Common Rail	GEM	✓	✓	✓	✓
2003.25	EcoSport	1.4L	Duratorq Turbo Diesel Common Rail	IC	✓	✓	✓	✓
2003.25	EcoSport	1.4L	Duratorq Turbo Diesel Common Rail	PCM	✓	✓	✓	
2003.25	EcoSport	1.4L	Duratorq Turbo Diesel Common Rail	RCM	✓	✓	✓	✓
2003.25	EcoSport	1.4L	Duratorq Turbo Diesel Common Rail	RKE	✓	✓	✓	✓
2003.25	EcoSport	1.6L	FFV	ABS/TCS	✓	✓	✓	✓
2003.25	EcoSport	1.6L	FFV	GEM	✓	✓	✓	✓
2003.25	EcoSport	1.6L	FFV	IC	✓	✓	✓	✓
2003.25	EcoSport	1.6L	FFV	PCM	✓	✓	✓	✓
2003.25	EcoSport	1.6L	FFV	RCM	✓	✓	✓	✓
2003.25	EcoSport	1.6L	FFV	RKE	✓	✓	✓	✓
2003.25	EcoSport	1.6L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓
2003.25	EcoSport	1.6L	Zetec Rocam	GEM	✓	✓	✓	✓
2003.25	EcoSport	1.6L	Zetec Rocam	IC	✓	✓	✓	✓
2003.25	EcoSport	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓
2003.25	EcoSport	1.6L	Zetec Rocam	RCM	✓	✓	✓	✓
2003.25	EcoSport	1.6L	Zetec Rocam	RKE	✓	✓	✓	✓
2003.25	EcoSport	2.0L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓
2003.25	EcoSport	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓
2003.25	EcoSport	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓

2003.25	EcoSport	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2003.25	EcoSport	2.0L	DURATEC-HE / I4	RCM	√	√	√	√
2003.25	EcoSport	2.0L	DURATEC-HE / I4	RKE	√	√	√	√
2006	EcoSport	1.6L	FFV	ABS/TCS	√	√	√	√
2006	EcoSport	1.6L	FFV	GEM	√	√	√	√
2006	EcoSport	1.6L	FFV	IC	√	√	√	√
2006	EcoSport	1.6L	FFV	PCM	√	√	√	√
2006	EcoSport	1.6L	FFV	RCM	√	√	√	√
2006	EcoSport	1.6L	FFV	RKE	√	√	√	√
2006	EcoSport	2.0L	DURATEC-HE / I4	ABS/TCS	√	√	√	√
2006	EcoSport	2.0L	DURATEC-HE / I4	GEM	√	√	√	√
2006	EcoSport	2.0L	DURATEC-HE / I4	IC	√	√	√	√
2006	EcoSport	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2006	EcoSport	2.0L	DURATEC-HE / I4	RCM	√	√	√	√
2006	EcoSport	2.0L	DURATEC-HE / I4	RKE	√	√	√	√
2007	EcoSport	2.0L	DURATEC-HE / I4	ABS/TCS	√	√	√	√
2007	EcoSport	2.0L	DURATEC-HE / I4	IC	√	√	√	√
2007	EcoSport	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2007	EcoSport	2.0L	DURATEC-HE / I4	RCM	√	√	√	√
2007	EcoSport	2.0L	DURATEC-HE / I4	RKE	√	√	√	√
2009	EcoSport	1.6L	FFV	ABS/TCS	√	√	√	√
2009	EcoSport	1.6L	FFV	IC	√	√	√	
2009	EcoSport	1.6L	FFV	IC	√	√	√	√
2009	EcoSport	1.6L	FFV	PCM	√	√	√	√
2009	EcoSport	1.6L	FFV	RCM	√	√	√	√
2009	EcoSport	1.6L	Zetec Rocam	ABS/TCS	√	√	√	√
2009	EcoSport	1.6L	Zetec Rocam	IC	√	√	√	
2009	EcoSport	1.6L	Zetec Rocam	IC	√	√	√	√
2009	EcoSport	1.6L	Zetec Rocam	PCM	√	√	√	√
2009	EcoSport	1.6L	Zetec Rocam	RCM	√	√	√	√
2009	EcoSport	1.6L	Zetec Rocam	RKE	√	√	√	√
2009	EcoSport	2.0L	FFV	ABS/TCS	√	√	√	√
2009	EcoSport	2.0L	FFV	IC	√	√	√	
2009	EcoSport	2.0L	FFV	IC	√	√	√	√
2009	EcoSport	2.0L	FFV	PCM	√	√	√	√
2009	EcoSport	2.0L	FFV	PCM	√	√	√	√
2009	EcoSport	2.0L	FFV	RCM	√	√	√	√
2009	EcoSport	2.0L	FFV	RKE	√	√	√	√
2009	EcoSport	2.0L	FFV	TCM	√	√	√	√
2009	EcoSport	2.0L	Zetec Rocam	ABS/TCS	√	√	√	√
2009	EcoSport	2.0L	Zetec Rocam	IC	√	√	√	
2009	EcoSport	2.0L	Zetec Rocam	IC	√	√	√	√
2009	EcoSport	2.0L	Zetec Rocam	PCM	√	√	√	√
2009	EcoSport	2.0L	Zetec Rocam	RCM	√	√	√	√
2009	EcoSport	2.0L	Zetec Rocam	RKE	√	√	√	√

2009	EcoSport	2.0L	Zetec Rocam	TCM	√	√	√	√
2011	EcoSport	1.6L	FFV	ABS/TCS	√	√	√	√
2011	EcoSport	1.6L	FFV	IC	√	√	√	
2011	EcoSport	1.6L	FFV	IC	√	√	√	√
2011	EcoSport	1.6L	FFV	PCM	√	√	√	√
2011	EcoSport	1.6L	FFV	RCM	√	√	√	√
2011	EcoSport	1.6L	FFV	RKE	√	√	√	√
2011	EcoSport	1.6L	FFV	TBM	√	√	√	√
2011	EcoSport	2.0L	FFV	ABS/TCS	√	√	√	√
2011	EcoSport	2.0L	FFV	IC	√	√	√	
2011	EcoSport	2.0L	FFV	IC	√	√	√	√
2011	EcoSport	2.0L	FFV	PCM	√	√	√	√
2011	EcoSport	2.0L	FFV	PCM	√	√	√	√
2011	EcoSport	2.0L	FFV	RCM	√	√	√	√
2011	EcoSport	2.0L	FFV	RKE	√	√	√	√
2011	EcoSport	2.0L	FFV	TBM	√	√	√	√
2011	EcoSport	2.0L	FFV	TCM	√	√	√	√
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail	APIM	√	√	√	√
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail	BCM#1	√	√	√	√
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail	DDM	√	√	√	√
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail	FCDIM	√	√	√	√
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail	HVAC	√	√	√	√
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail	IPC	√	√	√	√
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail	PSCM	√	√	√	√
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail	RFA	√	√	√	√
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail	TBM	√	√	√	√
2012	EcoSport	1.5L	TiVCT	ABS	√	√	√	√
2012	EcoSport	1.5L	TiVCT	ACM	√	√	√	√
2012	EcoSport	1.5L	TiVCT	APIM	√	√	√	√
2012	EcoSport	1.5L	TiVCT	BCM#1	√	√	√	√
2012	EcoSport	1.5L	TiVCT	DDM	√	√	√	√
2012	EcoSport	1.5L	TiVCT	FCDIM	√	√	√	√
2012	EcoSport	1.5L	TiVCT	HVAC	√	√	√	√
2012	EcoSport	1.5L	TiVCT	IPC	√	√	√	√
2012	EcoSport	1.5L	TiVCT	PCM	√	√	√	√
2012	EcoSport	1.5L	TiVCT	PSCM	√	√	√	√
2012	EcoSport	1.5L	TiVCT	RCM	√	√	√	√
2012	EcoSport	1.5L	TiVCT	RFA	√	√	√	√
2012	EcoSport	1.5L	TiVCT	TCM	√	√	√	√
2012	EcoSport	1.6L	Sigma	ABS	√	√	√	√
2012	EcoSport	1.6L	Sigma	ACM	√	√	√	√

2012	EcoSport	1.6L	Sigma	APIM	✓	✓	✓	✓
2012	EcoSport	1.6L	Sigma	BCM#1	✓	✓	✓	✓
2012	EcoSport	1.6L	Sigma	DDM	✓	✓	✓	✓
2012	EcoSport	1.6L	Sigma	FCDIM	✓	✓	✓	✓
2012	EcoSport	1.6L	Sigma	HVAC	✓	✓	✓	✓
2012	EcoSport	1.6L	Sigma	IPC	✓	✓	✓	✓
2012	EcoSport	1.6L	Sigma	PCM	✓	✓	✓	✓
2012	EcoSport	1.6L	Sigma	PSCM	✓	✓	✓	✓
2012	EcoSport	1.6L	Sigma	RCM	✓	✓	✓	✓
2012	EcoSport	1.6L	Sigma	TBM	✓	✓	✓	✓
2012	EcoSport	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓
2012	EcoSport	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓
2012	EcoSport	2.0L	DURATEC-HE / I4	APIM	✓	✓	✓	✓
2012	EcoSport	2.0L	DURATEC-HE / I4	BCM#1	✓	✓	✓	✓
2012	EcoSport	2.0L	DURATEC-HE / I4	DDM	✓	✓	✓	✓
2012	EcoSport	2.0L	DURATEC-HE / I4	FCDIM	✓	✓	✓	✓
2012	EcoSport	2.0L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓
2012	EcoSport	2.0L	DURATEC-HE / I4	IPC	✓	✓	✓	✓
2012	EcoSport	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓
2012	EcoSport	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓
2012	EcoSport	2.0L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓
2012	EcoSport	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓
2012	EcoSport	2.0L	DURATEC-HE / I4	RFA	✓	✓	✓	✓
2012	EcoSport	2.0L	DURATEC-HE / I4	TBM	✓	✓	✓	✓
2012	EcoSport	2.0L	DURATEC-HE / I4	TBM	✓	✓	✓	✓
2012	EcoSport	Other	Other	ABS	✓	✓	✓	
2012	EcoSport	Other	Other	ACM	✓	✓	✓	
2012	EcoSport	Other	Other	APIM	✓	✓	✓	
2012	EcoSport	Other	Other	BCM#1	✓	✓	✓	✓
2012	EcoSport	Other	Other	DDM	✓	✓	✓	✓
2012	EcoSport	Other	Other	FCDIM	✓	✓	✓	✓
2012	EcoSport	Other	Other	HVAC	✓	✓	✓	✓
2012	EcoSport	Other	Other	IPC	✓	✓	✓	✓
2012	EcoSport	Other	Other	PSCM	✓	✓	✓	✓
2012	EcoSport	Other	Other	RCM	✓	✓	✓	✓
2013	EcoSport	1.0L	EcoBoost - Gas Turbocharged Direct	ABS	✓	✓	✓	✓
2013	EcoSport	1.0L	EcoBoost - Gas Turbocharged Direct	ACM	✓	✓	✓	✓
2013	EcoSport	1.0L	EcoBoost - Gas Turbocharged Direct	APIM	✓	✓	✓	✓
2013	EcoSport	1.0L	EcoBoost - Gas Turbocharged Direct	BCM#1	✓	✓	✓	✓
2013	EcoSport	1.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	
2013	EcoSport	1.0L	EcoBoost - Gas Turbocharged Direct	FCDIM	✓	✓	✓	✓
2013	EcoSport	1.0L	EcoBoost - Gas Turbocharged Direct	GPSM	✓	✓	✓	✓
2013	EcoSport	1.0L	EcoBoost - Gas Turbocharged Direct	HVAC	✓	✓	✓	✓
2013	EcoSport	1.0L	EcoBoost - Gas Turbocharged Direct	IPC	✓	✓	✓	✓

2013	EcoSport	1.0L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2013	EcoSport	1.0L	EcoBoost - Gas Turbocharged Direct	PSCM	✓	✓	✓	✓
2013	EcoSport	1.0L	EcoBoost - Gas Turbocharged Direct	RCM	✓	✓	✓	✓
2013	EcoSport	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓
2013	EcoSport	2.0L	DURATEC	ABS	✓	✓	✓	✓
2013	EcoSport	2.0L	DURATEC	ACM	✓	✓	✓	✓
2013	EcoSport	2.0L	DURATEC	APIM	✓	✓	✓	✓
2013	EcoSport	2.0L	DURATEC	BCM#1	✓	✓	✓	✓
2013	EcoSport	2.0L	DURATEC	DDM	✓	✓	✓	✓
2013	EcoSport	2.0L	DURATEC	FCDIM	✓	✓	✓	✓
2013	EcoSport	2.0L	DURATEC	GPSM	✓	✓	✓	✓
2013	EcoSport	2.0L	DURATEC	HVAC	✓	✓	✓	✓
2013	EcoSport	2.0L	DURATEC	IPC	✓	✓	✓	✓
2013	EcoSport	2.0L	DURATEC	PCM	✓	✓	✓	✓
2013	EcoSport	2.0L	DURATEC	PCM	✓	✓	✓	✓
2013	EcoSport	2.0L	DURATEC	PSCM	✓	✓	✓	✓
2013	EcoSport	2.0L	DURATEC	PSCM	✓	✓	✓	✓
2013	EcoSport	2.0L	DURATEC	RCM	✓	✓	✓	✓
2013	EcoSport	2.0L	DURATEC	RFA	✓	✓	✓	✓
2013	EcoSport	2.0L	DURATEC	TBM	✓	✓	✓	✓
2013	EcoSport	2.0L	DURATEC	TBM	✓	✓	✓	✓
2013	EcoSport	2.0L	DURATEC	TCM	✓	✓	✓	✓
2014	EcoSport	1.0L	EcoBoost - Gas Turbocharged Direct	ABS	✓	✓	✓	✓
2014	EcoSport	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓
2014	EcoSport	1.0L	EcoBoost - Gas Turbocharged Direct	BCMii	✓	✓	✓	✓
2014	EcoSport	1.0L	EcoBoost - Gas Turbocharged Direct	GPSM	✓	✓	✓	✓
2014	EcoSport	1.0L	EcoBoost - Gas Turbocharged Direct	HVAC	✓	✓	✓	✓
2014	EcoSport	1.0L	EcoBoost - Gas Turbocharged Direct	IPC	✓	✓	✓	✓
2014	EcoSport	1.0L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2014	EcoSport	1.0L	EcoBoost - Gas Turbocharged Direct	PSCM	✓	✓	✓	✓
2014	EcoSport	1.0L	EcoBoost - Gas Turbocharged Direct	RCM	✓	✓	✓	✓
2014	EcoSport	1.0L	EcoBoost - Gas Turbocharged Direct	RFA	✓	✓	✓	✓
2014	EcoSport	1.5L	DURATEC VCT	ABS	✓	✓	✓	✓
2014	EcoSport	1.5L	DURATEC VCT	ACM	✓	✓	✓	✓
2014	EcoSport	1.5L	DURATEC VCT	APIM	✓	✓	✓	✓
2014	EcoSport	1.5L	DURATEC VCT	BCMii	✓	✓	✓	✓
2014	EcoSport	1.5L	DURATEC VCT	GPSM	✓	✓	✓	✓
2014	EcoSport	1.5L	DURATEC VCT	HVAC	✓	✓	✓	✓
2014	EcoSport	1.5L	DURATEC VCT	IPC	✓	✓	✓	✓
2014	EcoSport	1.5L	DURATEC VCT	PCM	✓	✓	✓	✓
2014	EcoSport	1.5L	DURATEC VCT	PSCM	✓	✓	✓	✓
2014	EcoSport	1.5L	DURATEC VCT	RCM	✓	✓	✓	✓
2014	EcoSport	1.5L	DURATEC VCT	RFA	✓	✓	✓	✓

2014	EcoSport	1.5L	DURATEC VCT	TCM	✓	✓	✓	✓
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail	ABS	✓	✓	✓	✓
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail	ACM	✓	✓	✓	✓
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail	APIM	✓	✓	✓	✓
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail	BCMii	✓	✓	✓	✓
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail	GPSM	✓	✓	✓	✓
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail	HVAC	✓	✓	✓	✓
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail	IPC	✓	✓	✓	✓
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail	PCM	✓	✓	✓	✓
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail	RCM	✓	✓	✓	✓
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail	RFA	✓	✓	✓	✓
2008	Econovan	2.0L	OHC	IC	✓	✓	✓	✓
2008	Econovan	2.0L	OHC	PCM	✓	✓	✓	✓
2007	Edge	3.5L	4V	4X4	✓	✓	✓	✓
2007	Edge	3.5L	4V	ABS	✓	✓	✓	✓
2007	Edge	3.5L	4V	ACM	✓	✓	✓	✓
2007	Edge	3.5L	4V	DSM	✓	✓	✓	✓
2007	Edge	3.5L	4V	EATC	✓	✓	✓	✓
2007	Edge	3.5L	4V	GEM	✓	✓	✓	✓
2007	Edge	3.5L	4V	IC	✓	✓	✓	✓
2007	Edge	3.5L	4V	OCSM	✓	✓	✓	✓
2007	Edge	3.5L	4V	PAM	✓	✓	✓	✓
2007	Edge	3.5L	4V	PCM	✓	✓	✓	✓
2007	Edge	3.5L	4V	RCM	✓	✓	✓	✓
2007	Edge	3.5L	4V	RETM	✓	✓	✓	✓
2007	Edge	3.5L	4V	SASM	✓	✓	✓	✓
2007	Edge	3.5L	4V	SDARS	✓	✓	✓	✓
2007	Edge	3.5L	4V	TBM	✓	✓	✓	✓
2008	Edge	3.5L	4V	ABS	✓	✓	✓	✓
2008	Edge	3.5L	4V	ABS	✓	✓	✓	✓
2008	Edge	3.5L	4V	ACM	✓	✓	✓	✓
2008	Edge	3.5L	4V	APIM	✓	✓	✓	✓
2008	Edge	3.5L	4V	DSM	✓	✓	✓	✓
2008	Edge	3.5L	4V	GEM / SJB	✓	✓	✓	✓
2008	Edge	3.5L	4V	HVAC	✓	✓	✓	✓
2008	Edge	3.5L	4V	IC	✓	✓	✓	✓
2008	Edge	3.5L	4V	LTM	✓	✓	✓	✓
2008	Edge	3.5L	4V	OCSM	✓	✓	✓	✓
2008	Edge	3.5L	4V	PAM	✓	✓	✓	✓
2008	Edge	3.5L	4V	PCM	✓	✓	✓	✓
2008	Edge	3.5L	4V	RCM	✓	✓	✓	✓
2008	Edge	3.5L	4V	RETM	✓	✓	✓	✓
2008	Edge	3.5L	4V	SASM	✓	✓	✓	✓



2008	Edge	3.5L	4V	SDARS	√	√	√	√
2008	Edge	3.5L	4V	TBM	√	√	√	√
2009	Edge	3.5L	4V	4X4	√	√	√	√
2009	Edge	3.5L	4V	ABS	√	√	√	√
2009	Edge	3.5L	4V	ABS	√	√	√	√
2009	Edge	3.5L	4V	ACM	√	√	√	√
2009	Edge	3.5L	4V	ACM	√	√	√	√
2009	Edge	3.5L	4V	APIM	√	√	√	√
2009	Edge	3.5L	4V	DSM	√	√	√	√
2009	Edge	3.5L	4V	DSM	√	√	√	√
2009	Edge	3.5L	4V	GEM / SJB	√	√	√	√
2009	Edge	3.5L	4V	HVAC	√	√	√	√
2009	Edge	3.5L	4V	IC	√	√	√	√
2009	Edge	3.5L	4V	IC	√	√	√	√
2009	Edge	3.5L	4V	LTM	√	√	√	√
2009	Edge	3.5L	4V	OCSM	√	√	√	√
2009	Edge	3.5L	4V	OCSM	√	√	√	√
2009	Edge	3.5L	4V	PAM	√	√	√	√
2009	Edge	3.5L	4V	PAM	√	√	√	√
2009	Edge	3.5L	4V	PCM	√	√	√	√
2009	Edge	3.5L	4V	PCM	√	√	√	√
2009	Edge	3.5L	4V	RCM	√	√	√	√
2009	Edge	3.5L	4V	RCM	√	√	√	√
2009	Edge	3.5L	4V	RETM	√	√	√	√
2009	Edge	3.5L	4V	SASM	√	√	√	√
2009	Edge	3.5L	4V	SDARS	√	√	√	√
2009	Edge	3.5L	4V	SDARS	√	√	√	√
2009	Edge	3.5L	4V	SDARS	√	√	√	√
2009	Edge	3.5L	4V	TBM	√	√	√	√
2010	Edge	3.5L	4V	4X4	√	√	√	√
2010	Edge	3.5L	4V	ABS	√	√	√	√
2010	Edge	3.5L	4V	ACM	√	√	√	√
2010	Edge	3.5L	4V	ACM	√	√	√	√
2010	Edge	3.5L	4V	APIM	√	√	√	√
2010	Edge	3.5L	4V	DSM	√	√	√	√
2010	Edge	3.5L	4V	DSM	√	√	√	√
2010	Edge	3.5L	4V	GEM / SJB	√	√	√	√
2010	Edge	3.5L	4V	GPSM	√	√	√	√
2010	Edge	3.5L	4V	HVAC	√	√	√	√
2010	Edge	3.5L	4V	IC	√	√	√	√
2010	Edge	3.5L	4V	LTM	√	√	√	√
2010	Edge	3.5L	4V	OCSM	√	√	√	√
2010	Edge	3.5L	4V	PAM	√	√	√	√
2010	Edge	3.5L	4V	PAM	√	√	√	√
2010	Edge	3.5L	4V	PCM	√	√	√	√

2010	Edge	3.5L	4V	PCM	√	√	√	√
2010	Edge	3.5L	4V	RCM	√	√	√	√
2010	Edge	3.5L	4V	RETM	√	√	√	√
2010	Edge	3.5L	4V	SASM	√	√	√	√
2010	Edge	3.5L	4V	SDARS	√	√	√	√
2010	Edge	3.5L	4V	SDARS	√	√	√	√
2010	Edge	3.5L	4V	TBM	√	√	√	√
2011	Edge	3.5L	TiVCT	ABS	√	√	√	√
2011	Edge	3.5L	TiVCT	ACM	√	√	√	√
2011	Edge	3.5L	TiVCT	APIM	√	√	√	√
2011	Edge	3.5L	TiVCT	BCM#1	√	√	√	√
2011	Edge	3.5L	TiVCT	C-CM	√	√	√	√
2011	Edge	3.5L	TiVCT	DCSM	√	√	√	√
2011	Edge	3.5L	TiVCT	DSM	√	√	√	√
2011	Edge	3.5L	TiVCT	DSP	√	√	√	
2011	Edge	3.5L	TiVCT	FCDIM	√	√	√	√
2011	Edge	3.5L	TiVCT	FCIM	√	√	√	√
2011	Edge	3.5L	TiVCT	FLM	√	√	√	√
2011	Edge	3.5L	TiVCT	GPSM	√	√	√	√
2011	Edge	3.5L	TiVCT	HUD	√	√	√	√
2011	Edge	3.5L	TiVCT	HVAC	√	√	√	√
2011	Edge	3.5L	TiVCT	LTM	√	√	√	√
2011	Edge	3.5L	TiVCT	OCSM	√	√	√	√
2011	Edge	3.5L	TiVCT	PAM	√	√	√	
2011	Edge	3.5L	TiVCT	PCM	√	√	√	√
2011	Edge	3.5L	TiVCT	RCM	√	√	√	√
2011	Edge	3.5L	TiVCT	RFA	√	√	√	√
2011	Edge	3.5L	TiVCT	RLCM-A	√	√	√	√
2011	Edge	3.5L	TiVCT	SCCM	√	√	√	√
2011	Edge	3.5L	TiVCT	SOD-L	√	√	√	√
2011	Edge	3.5L	TiVCT	SOD-R	√	√	√	√
2011	Edge	3.5L	TiVCT	TBM	√	√	√	√
2011	Edge	3.5L	TiVCT	TPM	√	√	√	√
2011	Edge	3.7L	TiVCT	ABS	√	√	√	√
2011	Edge	3.7L	TiVCT	ACM	√	√	√	√
2011	Edge	3.7L	TiVCT	APIM	√	√	√	√
2011	Edge	3.7L	TiVCT	BCM#1	√	√	√	√
2011	Edge	3.7L	TiVCT	BCM#1	√	√	√	√
2011	Edge	3.7L	TiVCT	C-CM	√	√	√	√
2011	Edge	3.7L	TiVCT	DCSM	√	√	√	√
2011	Edge	3.7L	TiVCT	DSM	√	√	√	√
2011	Edge	3.7L	TiVCT	DSP	√	√	√	
2011	Edge	3.7L	TiVCT	FCDIM	√	√	√	√
2011	Edge	3.7L	TiVCT	FCIM	√	√	√	√
2011	Edge	3.7L	TiVCT	FLM	√	√	√	√

2011	Edge	3.7L	TiVCT	GPSM	✓	✓	✓	✓
2011	Edge	3.7L	TiVCT	HUD	✓	✓	✓	✓
2011	Edge	3.7L	TiVCT	HVAC	✓	✓	✓	✓
2011	Edge	3.7L	TiVCT	IPC	✓	✓	✓	✓
2011	Edge	3.7L	TiVCT	LTM	✓	✓	✓	✓
2011	Edge	3.7L	TiVCT	OCSM	✓	✓	✓	✓
2011	Edge	3.7L	TiVCT	OCSM	✓	✓	✓	✓
2011	Edge	3.7L	TiVCT	PAM	✓	✓	✓	
2011	Edge	3.7L	TiVCT	PCM	✓	✓	✓	✓
2011	Edge	3.7L	TiVCT	RCM	✓	✓	✓	✓
2011	Edge	3.7L	TiVCT	RFA	✓	✓	✓	✓
2011	Edge	3.7L	TiVCT	RLCM-A	✓	✓	✓	✓
2011	Edge	3.7L	TiVCT	SCCM	✓	✓	✓	✓
2011	Edge	3.7L	TiVCT	SOD-L	✓	✓	✓	✓
2011	Edge	3.7L	TiVCT	SOD-R	✓	✓	✓	✓
2011	Edge	3.7L	TiVCT	TBM	✓	✓	✓	✓
2011	Edge	3.7L	TiVCT	TPM	✓	✓	✓	✓
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	ABS	✓	✓	✓	✓
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	ABS	✓	✓	✓	✓
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	ACM	✓	✓	✓	✓
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	APIM	✓	✓	✓	✓
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	BCM#1	✓	✓	✓	✓
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	BCM#1	✓	✓	✓	✓
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	C-CM	✓	✓	✓	✓
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	DCSM	✓	✓	✓	✓
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	DSM	✓	✓	✓	✓
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	DSP	✓	✓	✓	
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	FCDIM	✓	✓	✓	✓
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	FCIM	✓	✓	✓	✓
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	FLM	✓	✓	✓	✓
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	GPSM	✓	✓	✓	✓
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	HVAC	✓	✓	✓	✓
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	IPC	✓	✓	✓	✓
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	LTM	✓	✓	✓	✓
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	OCSM	✓	✓	✓	✓
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	OCSM	✓	✓	✓	✓
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	PAM	✓	✓	✓	✓
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	RCM	✓	✓	✓	✓
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	RFA	✓	✓	✓	✓
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	RLCM-A	✓	✓	✓	✓
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	SCCM	✓	✓	✓	✓

2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	√
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	TBM	√	√	√	√
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	TBM	√	√	√	√
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	TCM	√	√	√	√
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	TCM	√	√	√	√
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	TPM	√	√	√	√
2012	Edge	3.5L	TiVCT	ABS	√	√	√	√
2012	Edge	3.5L	TiVCT	ACM	√	√	√	√
2012	Edge	3.5L	TiVCT	APIM	√	√	√	√
2012	Edge	3.5L	TiVCT	BCM#1	√	√	√	√
2012	Edge	3.5L	TiVCT	C-CM	√	√	√	√
2012	Edge	3.5L	TiVCT	DCSM	√	√	√	√
2012	Edge	3.5L	TiVCT	DSM	√	√	√	√
2012	Edge	3.5L	TiVCT	DSP	√	√	√	
2012	Edge	3.5L	TiVCT	FCDIM	√	√	√	√
2012	Edge	3.5L	TiVCT	FCIM	√	√	√	√
2012	Edge	3.5L	TiVCT	FLM	√	√	√	√
2012	Edge	3.5L	TiVCT	GPSM	√	√	√	√
2012	Edge	3.5L	TiVCT	HUD	√	√	√	√
2012	Edge	3.5L	TiVCT	HVAC	√	√	√	√
2012	Edge	3.5L	TiVCT	IPC	√	√	√	√
2012	Edge	3.5L	TiVCT	LTM	√	√	√	√
2012	Edge	3.5L	TiVCT	OCSM	√	√	√	√
2012	Edge	3.5L	TiVCT	PAM	√	√	√	√
2012	Edge	3.5L	TiVCT	PCM	√	√	√	√
2012	Edge	3.5L	TiVCT	RCM	√	√	√	√
2012	Edge	3.5L	TiVCT	RFA	√	√	√	√
2012	Edge	3.5L	TiVCT	RLCM-A	√	√	√	√
2012	Edge	3.5L	TiVCT	SCCM	√	√	√	√
2012	Edge	3.5L	TiVCT	SOD-L	√	√	√	√
2012	Edge	3.5L	TiVCT	SOD-R	√	√	√	√
2012	Edge	3.5L	TiVCT	TBM	√	√	√	√
2012	Edge	3.5L	TiVCT	TPM	√	√	√	√
2012	Edge	3.7L	TiVCT	ABS	√	√	√	
2012	Edge	3.7L	TiVCT	ACM	√	√	√	
2012	Edge	3.7L	TiVCT	BCM#1	√	√	√	√
2012	Edge	3.7L	TiVCT	C-CM	√	√	√	√
2012	Edge	3.7L	TiVCT	DCSM	√	√	√	√
2012	Edge	3.7L	TiVCT	DSM	√	√	√	
2012	Edge	3.7L	TiVCT	DSP	√	√	√	
2012	Edge	3.7L	TiVCT	FCDIM	√	√	√	
2012	Edge	3.7L	TiVCT	FCIM	√	√	√	
2012	Edge	3.7L	TiVCT	FLM	√	√	√	
2012	Edge	3.7L	TiVCT	GPSM	√	√	√	

2012	Edge	3.7L	TiVCT	HUD	✓	✓	✓	
2012	Edge	3.7L	TiVCT	HVAC	✓	✓	✓	
2012	Edge	3.7L	TiVCT	IPC	✓	✓	✓	
2012	Edge	3.7L	TiVCT	LTM	✓	✓	✓	
2012	Edge	3.7L	TiVCT	OCSM	✓	✓	✓	
2012	Edge	3.7L	TiVCT	OCSM	✓	✓	✓	
2012	Edge	3.7L	TiVCT	PAM	✓	✓	✓	
2012	Edge	3.7L	TiVCT	PCM	✓	✓	✓	✓
2012	Edge	3.7L	TiVCT	RCM	✓	✓	✓	✓
2012	Edge	3.7L	TiVCT	RFA	✓	✓	✓	✓
2012	Edge	3.7L	TiVCT	RLCM-A	✓	✓	✓	✓
2012	Edge	3.7L	TiVCT	SCCM	✓	✓	✓	✓
2012	Edge	3.7L	TiVCT	SOD-L	✓	✓	✓	
2012	Edge	3.7L	TiVCT	SOD-R	✓	✓	✓	
2012	Edge	3.7L	TiVCT	TBM	✓	✓	✓	
2012	Edge	3.7L	TiVCT	TPM	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	ABS	✓	✓	✓	✓
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	ABS	✓	✓	✓	✓
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	ACM	✓	✓	✓	✓
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	APIM	✓	✓	✓	✓
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	BCM#1	✓	✓	✓	✓
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	C-CM	✓	✓	✓	✓
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	C-CM	✓	✓	✓	✓
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	DCSM	✓	✓	✓	✓
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	DSM	✓	✓	✓	✓
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	DSP	✓	✓	✓	✓
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	FCDIM	✓	✓	✓	✓
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	FLM	✓	✓	✓	✓
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	GPSM	✓	✓	✓	✓
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	HUD	✓	✓	✓	✓
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	HVAC	✓	✓	✓	✓
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	IPC	✓	✓	✓	✓
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	LTM	✓	✓	✓	✓
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	OCSM	✓	✓	✓	✓
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	PAM	✓	✓	✓	✓
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	RCM	✓	✓	✓	✓
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	RFA	✓	✓	✓	✓

2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	RLCM-A	√	√	√	√
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	RTM	√	√	√	√
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	SCCM	√	√	√	√
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	√
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	TBM	√	√	√	√
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	TBM	√	√	√	√
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	TCM	√	√	√	√
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	TCM	√	√	√	√
2013	Edge	3.5L	TiVCT	ABS	√	√	√	√
2013	Edge	3.5L	TiVCT	ACM	√	√	√	√
2013	Edge	3.5L	TiVCT	APIM	√	√	√	√
2013	Edge	3.5L	TiVCT	BCM#1	√	√	√	√
2013	Edge	3.5L	TiVCT	C-CM	√	√	√	√
2013	Edge	3.5L	TiVCT	DCSM	√	√	√	√
2013	Edge	3.5L	TiVCT	DSM	√	√	√	√
2013	Edge	3.5L	TiVCT	DSP	√	√	√	√
2013	Edge	3.5L	TiVCT	FCDIM	√	√	√	√
2013	Edge	3.5L	TiVCT	FCIM	√	√	√	√
2013	Edge	3.5L	TiVCT	FLM	√	√	√	√
2013	Edge	3.5L	TiVCT	GPSM	√	√	√	√
2013	Edge	3.5L	TiVCT	HUD	√	√	√	√
2013	Edge	3.5L	TiVCT	HVAC	√	√	√	√
2013	Edge	3.5L	TiVCT	IPC	√	√	√	√
2013	Edge	3.5L	TiVCT	LTM	√	√	√	√
2013	Edge	3.5L	TiVCT	OCSM	√	√	√	√
2013	Edge	3.5L	TiVCT	OCSM	√	√	√	√
2013	Edge	3.5L	TiVCT	PAM	√	√	√	√
2013	Edge	3.5L	TiVCT	PCM	√	√	√	√
2013	Edge	3.5L	TiVCT	RCM	√	√	√	√
2013	Edge	3.5L	TiVCT	RFA	√	√	√	√
2013	Edge	3.5L	TiVCT	RLCM-A	√	√	√	√
2013	Edge	3.5L	TiVCT	RTM	√	√	√	√
2013	Edge	3.5L	TiVCT	SCCM	√	√	√	√
2013	Edge	3.5L	TiVCT	SOD-L	√	√	√	√
2013	Edge	3.5L	TiVCT	SOD-R	√	√	√	√
2013	Edge	3.5L	TiVCT	TBM	√	√	√	√
2013	Edge	3.7L	TiVCT	ABS	√	√	√	√
2013	Edge	3.7L	TiVCT	ACM	√	√	√	√
2013	Edge	3.7L	TiVCT	APIM	√	√	√	√
2013	Edge	3.7L	TiVCT	BCM#1	√	√	√	√
2013	Edge	3.7L	TiVCT	C-CM	√	√	√	√
2013	Edge	3.7L	TiVCT	DCSM	√	√	√	√
2013	Edge	3.7L	TiVCT	DSM	√	√	√	√
2013	Edge	3.7L	TiVCT	DSP	√	√	√	√

2013	Edge	3.7L	TiVCT	FCDIM	✓	✓	✓	✓
2013	Edge	3.7L	TiVCT	FCIM	✓	✓	✓	✓
2013	Edge	3.7L	TiVCT	FLM	✓	✓	✓	✓
2013	Edge	3.7L	TiVCT	GPSM	✓	✓	✓	✓
2013	Edge	3.7L	TiVCT	HUD	✓	✓	✓	✓
2013	Edge	3.7L	TiVCT	HVAC	✓	✓	✓	✓
2013	Edge	3.7L	TiVCT	IPC	✓	✓	✓	✓
2013	Edge	3.7L	TiVCT	LTM	✓	✓	✓	✓
2013	Edge	3.7L	TiVCT	OCSM	✓	✓	✓	✓
2013	Edge	3.7L	TiVCT	PAM	✓	✓	✓	✓
2013	Edge	3.7L	TiVCT	PCM	✓	✓	✓	✓
2013	Edge	3.7L	TiVCT	PCM	✓	✓	✓	✓
2013	Edge	3.7L	TiVCT	RCM	✓	✓	✓	✓
2013	Edge	3.7L	TiVCT	RFA	✓	✓	✓	✓
2013	Edge	3.7L	TiVCT	RLCM-A	✓	✓	✓	✓
2013	Edge	3.7L	TiVCT	RTM	✓	✓	✓	✓
2013	Edge	3.7L	TiVCT	SCCM	✓	✓	✓	✓
2013	Edge	3.7L	TiVCT	SOD-L	✓	✓	✓	✓
2013	Edge	3.7L	TiVCT	SOD-R	✓	✓	✓	✓
2013	Edge	3.7L	TiVCT	TBM	✓	✓	✓	✓
2014	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	ABS	✓	✓	✓	✓
2014	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	ACM	✓	✓	✓	✓
2014	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	APIM	✓	✓	✓	✓
2014	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	BCM#1	✓	✓	✓	✓
2014	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	C-CM	✓	✓	✓	✓
2014	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	DCSM	✓	✓	✓	✓
2014	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	DSM	✓	✓	✓	✓
2014	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	DSP	✓	✓	✓	✓
2014	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	FCDIM	✓	✓	✓	✓
2014	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	FCIM	✓	✓	✓	✓
2014	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	FLM	✓	✓	✓	✓
2014	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	GPSM	✓	✓	✓	✓
2014	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	HUD	✓	✓	✓	✓
2014	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	HVAC	✓	✓	✓	✓
2014	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	IPC	✓	✓	✓	✓
2014	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	LTM	✓	✓	✓	✓
2014	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓
2014	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	PAM	✓	✓	✓	✓
2014	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2014	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	RCM	✓	✓	✓	✓
2014	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	RFA	✓	✓	✓	✓
2014	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	RLCM-A	✓	✓	✓	✓
2014	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	RTM	✓	✓	✓	✓
2014	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	SCCM	✓	✓	✓	✓

2014	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L	√	√	√	√
2014	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	TBM	√	√	√	√
2014	Edge	2.0L	EcoBoost - Gas Turbocharged Direct	TCM	√	√	√	√
2014	Edge	3.5L	TiVCT	ABS	√	√	√	√
2014	Edge	3.5L	TiVCT	ACM	√	√	√	√
2014	Edge	3.5L	TiVCT	APIM	√	√	√	√
2014	Edge	3.5L	TiVCT	BCM#1	√	√	√	√
2014	Edge	3.5L	TiVCT	C-CM	√	√	√	√
2014	Edge	3.5L	TiVCT	DCSM	√	√	√	√
2014	Edge	3.5L	TiVCT	DSM	√	√	√	√
2014	Edge	3.5L	TiVCT	DSP	√	√	√	√
2014	Edge	3.5L	TiVCT	FCDIM	√	√	√	√
2014	Edge	3.5L	TiVCT	FCIM	√	√	√	√
2014	Edge	3.5L	TiVCT	FLM	√	√	√	√
2014	Edge	3.5L	TiVCT	GPSM	√	√	√	√
2014	Edge	3.5L	TiVCT	HUD	√	√	√	√
2014	Edge	3.5L	TiVCT	HVAC	√	√	√	√
2014	Edge	3.5L	TiVCT	IPC	√	√	√	√
2014	Edge	3.5L	TiVCT	LTM	√	√	√	√
2014	Edge	3.5L	TiVCT	OCSM	√	√	√	√
2014	Edge	3.5L	TiVCT	PAM	√	√	√	√
2014	Edge	3.5L	TiVCT	PCM	√	√	√	√
2014	Edge	3.5L	TiVCT	RCM	√	√	√	√
2014	Edge	3.5L	TiVCT	RFA	√	√	√	√
2014	Edge	3.5L	TiVCT	RLCM-A	√	√	√	√
2014	Edge	3.5L	TiVCT	RTM	√	√	√	√
2014	Edge	3.5L	TiVCT	SCCM	√	√	√	√
2014	Edge	3.5L	TiVCT	SOD-L	√	√	√	√
2014	Edge	3.5L	TiVCT	SOD-R	√	√	√	√
2014	Edge	3.5L	TiVCT	TBM	√	√	√	√
2014	Edge	3.7L	TiVCT	ABS	√	√	√	√
2014	Edge	3.7L	TiVCT	ACM	√	√	√	√
2014	Edge	3.7L	TiVCT	APIM	√	√	√	√
2014	Edge	3.7L	TiVCT	BCM#1	√	√	√	√
2014	Edge	3.7L	TiVCT	C-CM	√	√	√	√
2014	Edge	3.7L	TiVCT	DCSM	√	√	√	√
2014	Edge	3.7L	TiVCT	DSM	√	√	√	√
2014	Edge	3.7L	TiVCT	DSP	√	√	√	√
2014	Edge	3.7L	TiVCT	FCDIM	√	√	√	√
2014	Edge	3.7L	TiVCT	FCIM	√	√	√	√
2014	Edge	3.7L	TiVCT	FLM	√	√	√	√
2014	Edge	3.7L	TiVCT	GPSM	√	√	√	√
2014	Edge	3.7L	TiVCT	HUD	√	√	√	√
2014	Edge	3.7L	TiVCT	HVAC	√	√	√	√



2014	Edge	3.7L	TiVCT	IPC	√	√	√	√
2014	Edge	3.7L	TiVCT	LTM	√	√	√	√
2014	Edge	3.7L	TiVCT	OCSM	√	√	√	√
2014	Edge	3.7L	TiVCT	PAM	√	√	√	√
2014	Edge	3.7L	TiVCT	PCM	√	√	√	√
2014	Edge	3.7L	TiVCT	RCM	√	√	√	√
2014	Edge	3.7L	TiVCT	RFA	√	√	√	√
2014	Edge	3.7L	TiVCT	RLCM-A	√	√	√	√
2014	Edge	3.7L	TiVCT	RTM	√	√	√	√
2014	Edge	3.7L	TiVCT	SCCM	√	√	√	√
2014	Edge	3.7L	TiVCT	SOD-L	√	√	√	√
2014	Edge	3.7L	TiVCT	SOD-R	√	√	√	√
2014	Edge	3.7L	TiVCT	TBM	√	√	√	√
2014	Edge	Other	Other	ABS	√	√	√	√
2014	Edge	Other	Other	ACM	√	√	√	√
2014	Edge	Other	Other	APIM	√	√	√	√
2014	Edge	Other	Other	BCM#1	√	√	√	√
2014	Edge	Other	Other	C-CM	√	√	√	√
2014	Edge	Other	Other	DCSM	√	√	√	√
2014	Edge	Other	Other	DSM	√	√	√	√
2014	Edge	Other	Other	DSP	√	√	√	√
2014	Edge	Other	Other	FCDIM	√	√	√	√
2014	Edge	Other	Other	FCIM	√	√	√	√
2014	Edge	Other	Other	FLM	√	√	√	√
2014	Edge	Other	Other	GPSM	√	√	√	√
2014	Edge	Other	Other	HUD	√	√	√	√
2014	Edge	Other	Other	HVAC	√	√	√	√
2014	Edge	Other	Other	IPC	√	√	√	√
2014	Edge	Other	Other	LTM	√	√	√	√
2014	Edge	Other	Other	OCSM	√	√	√	√
2014	Edge	Other	Other	PAM	√	√	√	√
2014	Edge	Other	Other	RCM	√	√	√	√
2014	Edge	Other	Other	RFA	√	√	√	√
2014	Edge	Other	Other	RLCM-A	√	√	√	√
2014	Edge	Other	Other	RTM	√	√	√	√
2014	Edge	Other	Other	SCCM	√	√	√	√
2014	Edge	Other	Other	SOD-L	√	√	√	√
2014	Edge	Other	Other	TBM	√	√	√	√
2005	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	4X4	√	√	√	√
2005	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	ABS	√	√	√	√
2005	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	ABS	√	√	√	√
2005	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	BCM	√	√	√	√
2005	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	BCM	√	√	√	√
2005	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	EPS	√	√	√	√
2005	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	GEM	√	√	√	√

2005	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	IC	√	√	√	√
2005	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	PAM	√	√	√	√
2005	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	PCM	√	√	√	√
2005	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	PCM	√	√	√	√
2005	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	RCM	√	√	√	√
2005	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	RCM	√	√	√	√
2005	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	TCM	√	√	√	√
2006	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	4X4	√	√	√	√
2006	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	ABS	√	√	√	√
2006	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	BCM	√	√	√	√
2006	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	EPS	√	√	√	√
2006	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	GEM	√	√	√	√
2006	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	IC	√	√	√	√
2006	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	PAM	√	√	√	√
2006	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	PCM	√	√	√	√
2006	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	RCM	√	√	√	√
2006	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	TCM	√	√	√	√
2007	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	4X4	√	√	√	√
2007	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	ABS	√	√	√	√
2007	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	BCM	√	√	√	√
2007	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	EPS	√	√	√	√
2007	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	GEM	√	√	√	√
2007	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	IC	√	√	√	√
2007	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	PAM	√	√	√	√
2007	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	PCM	√	√	√	√
2007	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	RCM	√	√	√	√
2007	Escape / Mariner Hybrid	2.3L	HEV / ATKINSON 4V	TCM	√	√	√	√
2006	Escape / Tribute ( 2006/4 - )	2.3L	L3	ABS	√	√	√	√
2006	Escape / Tribute ( 2006/4 - )	2.3L	L3	GEM	√	√	√	√
2006	Escape / Tribute ( 2006/4 - )	2.3L	L3	IC	√	√	√	√
2006	Escape / Tribute ( 2006/4 - )	2.3L	L3	PCM	√	√	√	√
2006	Escape / Tribute ( 2006/4 - )	2.3L	L3	PCM	√	√	√	√
2006	Escape / Tribute ( 2006/4 - )	2.3L	L3	RCM	√	√	√	√
2003	Escape / Tribute (2006/3)	2.3L	L3	ABS	√	√	√	√
2003	Escape / Tribute (2006/3)	2.3L	L3	GEM	√	√	√	√
2003	Escape / Tribute (2006/3)	2.3L	L3	IC	√	√	√	√
2003	Escape / Tribute (2006/3)	2.3L	L3	PCM	√	√	√	√
2003	Escape / Tribute (2006/3)	2.3L	L3	PCM	√	√	√	√
2003	Escape / Tribute (2006/3)	2.3L	L3	RCM	√	√	√	√
2008	Escape / Tribute / Mariner	2.3L	DURATEC-HE / I4	4X4	√	√	√	√
2008	Escape / Tribute / Mariner	2.3L	DURATEC-HE / I4	ABS	√	√	√	√
2008	Escape / Tribute / Mariner	2.3L	DURATEC-HE / I4	ACM	√	√	√	√
2008	Escape / Tribute / Mariner	2.3L	DURATEC-HE / I4	ACM	√	√	√	√
2008	Escape / Tribute / Mariner	2.3L	DURATEC-HE / I4	FCIM	√	√	√	√
2008	Escape / Tribute / Mariner	2.3L	DURATEC-HE / I4	FDIM	√	√	√	√

2008	Escape / Tribute / Mariner	2.3L	DURATEC-HE / I4	FDIM	√	√	√	√
2008	Escape / Tribute / Mariner	2.3L	DURATEC-HE / I4	GEM / SJB	√	√	√	√
2008	Escape / Tribute / Mariner	2.3L	DURATEC-HE / I4	HVAC	√	√	√	√
2008	Escape / Tribute / Mariner	2.3L	DURATEC-HE / I4	IC	√	√	√	√
2008	Escape / Tribute / Mariner	2.3L	DURATEC-HE / I4	OCSM	√	√	√	√
2008	Escape / Tribute / Mariner	2.3L	DURATEC-HE / I4	PAM	√	√	√	√
2008	Escape / Tribute / Mariner	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2008	Escape / Tribute / Mariner	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2008	Escape / Tribute / Mariner	2.3L	DURATEC-HE / I4	PSCM	√	√	√	√
2008	Escape / Tribute / Mariner	2.3L	DURATEC-HE / I4	RCM	√	√	√	√
2008	Escape / Tribute / Mariner	2.3L	DURATEC-HE / I4	SDARS	√	√	√	√
2008	Escape / Tribute / Mariner	2.3L	HEV / ATKINSON 4V	4X4	√	√	√	√
2008	Escape / Tribute / Mariner	2.3L	HEV / ATKINSON 4V	ABS	√	√	√	√
2008	Escape / Tribute / Mariner	2.3L	HEV / ATKINSON 4V	ACM	√	√	√	√
2008	Escape / Tribute / Mariner	2.3L	HEV / ATKINSON 4V	BCM	√	√	√	√
2008	Escape / Tribute / Mariner	2.3L	HEV / ATKINSON 4V	FCIM	√	√	√	√
2008	Escape / Tribute / Mariner	2.3L	HEV / ATKINSON 4V	FDIM	√	√	√	√
2008	Escape / Tribute / Mariner	2.3L	HEV / ATKINSON 4V	GEM / SJB	√	√	√	√
2008	Escape / Tribute / Mariner	2.3L	HEV / ATKINSON 4V	HVAC	√	√	√	√
2008	Escape / Tribute / Mariner	2.3L	HEV / ATKINSON 4V	IC	√	√	√	√
2008	Escape / Tribute / Mariner	2.3L	HEV / ATKINSON 4V	OCSM	√	√	√	√
2008	Escape / Tribute / Mariner	2.3L	HEV / ATKINSON 4V	PAM	√	√	√	√
2008	Escape / Tribute / Mariner	2.3L	HEV / ATKINSON 4V	PCM	√	√	√	√
2008	Escape / Tribute / Mariner	2.3L	HEV / ATKINSON 4V	PSCM	√	√	√	√
2008	Escape / Tribute / Mariner	2.3L	HEV / ATKINSON 4V	RCM	√	√	√	√
2008	Escape / Tribute / Mariner	2.3L	HEV / ATKINSON 4V	TCM	√	√	√	√
2008	Escape / Tribute / Mariner	3.0L	4V	4X4	√	√	√	√
2008	Escape / Tribute / Mariner	3.0L	4V	ABS	√	√	√	√
2008	Escape / Tribute / Mariner	3.0L	4V	ACM	√	√	√	√
2008	Escape / Tribute / Mariner	3.0L	4V	ACM	√	√	√	√
2008	Escape / Tribute / Mariner	3.0L	4V	FCIM	√	√	√	√
2008	Escape / Tribute / Mariner	3.0L	4V	FDIM	√	√	√	√
2008	Escape / Tribute / Mariner	3.0L	4V	FDIM	√	√	√	√
2008	Escape / Tribute / Mariner	3.0L	4V	GEM / SJB	√	√	√	√
2008	Escape / Tribute / Mariner	3.0L	4V	HVAC	√	√	√	√
2008	Escape / Tribute / Mariner	3.0L	4V	IC	√	√	√	√
2008	Escape / Tribute / Mariner	3.0L	4V	IC	√	√	√	√
2008	Escape / Tribute / Mariner	3.0L	4V	OCSM	√	√	√	√
2008	Escape / Tribute / Mariner	3.0L	4V	PAM	√	√	√	√
2008	Escape / Tribute / Mariner	3.0L	4V	PCM	√	√	√	√
2008	Escape / Tribute / Mariner	3.0L	4V	PSCM	√	√	√	√
2008	Escape / Tribute / Mariner	3.0L	4V	RCM	√	√	√	√
2008	Escape / Tribute / Mariner	3.0L	4V	RCM	√	√	√	√
2008	Escape / Tribute / Mariner	3.0L	4V	SDARS	√	√	√	√
2009	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	4X4	√	√	√	√



2009	Escape / Tribute / Mariner	3.0L	4V	FDIM	✓	✓	✓	✓
2009	Escape / Tribute / Mariner	3.0L	4V	FDIM	✓	✓	✓	✓
2009	Escape / Tribute / Mariner	3.0L	4V	GEM / SJB	✓	✓	✓	✓
2009	Escape / Tribute / Mariner	3.0L	4V	GEM / SJB	✓	✓	✓	✓
2009	Escape / Tribute / Mariner	3.0L	4V	HVAC	✓	✓	✓	✓
2009	Escape / Tribute / Mariner	3.0L	4V	HVAC	✓	✓	✓	✓
2009	Escape / Tribute / Mariner	3.0L	4V	IC	✓	✓	✓	✓
2009	Escape / Tribute / Mariner	3.0L	4V	IC	✓	✓	✓	✓
2009	Escape / Tribute / Mariner	3.0L	4V	OCSM	✓	✓	✓	✓
2009	Escape / Tribute / Mariner	3.0L	4V	PAM	✓	✓	✓	✓
2009	Escape / Tribute / Mariner	3.0L	4V	PCM	✓	✓	✓	✓
2009	Escape / Tribute / Mariner	3.0L	4V	PSCM	✓	✓	✓	✓
2009	Escape / Tribute / Mariner	3.0L	4V	PSCM	✓	✓	✓	✓
2009	Escape / Tribute / Mariner	3.0L	4V	RCM	✓	✓	✓	✓
2009	Escape / Tribute / Mariner	3.0L	4V	RCM	✓	✓	✓	✓
2009	Escape / Tribute / Mariner	3.0L	4V	SDARS	✓	✓	✓	✓
2009	Escape / Tribute / Mariner	3.0L	4V	SDARS	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	4X4	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	ABS	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	ACM	✓	✓	✓	
2010	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	APIM	✓	✓	✓	
2010	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	FCIM	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	FDIM	✓	✓	✓	
2010	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	GPSM	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	IC	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	PAM	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	RCM	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	4X4	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	ABS	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	ACCM#2	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	
2010	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	APIM	✓	✓	✓	
2010	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	BCM	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	FDIM	✓	✓	✓	
2010	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	GEM / SJB	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	GPSM	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	HVAC	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	IC	✓	✓	✓	✓

2010	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	OCSM	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	PAM	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	PSCM	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	RCM	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	TCM	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	3.0L	4V	4X4	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	3.0L	4V	ABS	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	3.0L	4V	ACM	✓	✓	✓	
2010	Escape / Tribute / Mariner	3.0L	4V	APIM	✓	✓	✓	
2010	Escape / Tribute / Mariner	3.0L	4V	FCIM	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	3.0L	4V	FDIM	✓	✓	✓	
2010	Escape / Tribute / Mariner	3.0L	4V	GEM / SJB	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	3.0L	4V	GPSM	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	3.0L	4V	HVAC	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	3.0L	4V	IC	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	3.0L	4V	OCSM	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	3.0L	4V	PAM	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	3.0L	4V	PCM	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	3.0L	4V	PSCM	✓	✓	✓	✓
2010	Escape / Tribute / Mariner	3.0L	4V	RCM	✓	✓	✓	✓
2011	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	4X4	✓	✓	✓	✓
2011	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	ABS	✓	✓	✓	✓
2011	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	ACM	✓	✓	✓	✓
2011	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	APIM	✓	✓	✓	✓
2011	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	FCIM	✓	✓	✓	✓
2011	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	FDIM	✓	✓	✓	
2011	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓
2011	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	GPSM	✓	✓	✓	✓
2011	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓
2011	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	IC	✓	✓	✓	✓
2011	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓
2011	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	PAM	✓	✓	✓	✓
2011	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓
2011	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓
2011	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓
2011	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	RCM	✓	✓	✓	✓
2011	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	4X4	✓	✓	✓	✓
2011	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	ABS	✓	✓	✓	✓
2011	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	ACCM#2	✓	✓	✓	✓
2011	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓
2011	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	APIM	✓	✓	✓	✓
2011	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	BCM	✓	✓	✓	✓
2011	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	✓
2011	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	FDIM	✓	✓	✓	

2011	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	GEM / SJB	√	√	√	√
2011	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	GPSM	√	√	√	√
2011	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	HVAC	√	√	√	√
2011	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	IC	√	√	√	√
2011	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	OCSM	√	√	√	√
2011	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	PAM	√	√	√	√
2011	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	PCM	√	√	√	√
2011	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	PSCM	√	√	√	√
2011	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	RCM	√	√	√	√
2011	Escape / Tribute / Mariner	3.0L	4V	4X4	√	√	√	√
2011	Escape / Tribute / Mariner	3.0L	4V	ABS	√	√	√	√
2011	Escape / Tribute / Mariner	3.0L	4V	ACM	√	√	√	√
2011	Escape / Tribute / Mariner	3.0L	4V	APIM	√	√	√	√
2011	Escape / Tribute / Mariner	3.0L	4V	FCIM	√	√	√	√
2011	Escape / Tribute / Mariner	3.0L	4V	FDIM	√	√	√	
2011	Escape / Tribute / Mariner	3.0L	4V	GEM / SJB	√	√	√	√
2011	Escape / Tribute / Mariner	3.0L	4V	GPSM	√	√	√	√
2011	Escape / Tribute / Mariner	3.0L	4V	HVAC	√	√	√	√
2011	Escape / Tribute / Mariner	3.0L	4V	IC	√	√	√	√
2011	Escape / Tribute / Mariner	3.0L	4V	OCSM	√	√	√	√
2011	Escape / Tribute / Mariner	3.0L	4V	PAM	√	√	√	√
2011	Escape / Tribute / Mariner	3.0L	4V	PCM	√	√	√	√
2011	Escape / Tribute / Mariner	3.0L	4V	PSCM	√	√	√	√
2011	Escape / Tribute / Mariner	3.0L	4V	RCM	√	√	√	√
2012	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	4X4	√	√	√	√
2012	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	ABS	√	√	√	√
2012	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	ACM	√	√	√	√
2012	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	APIM	√	√	√	√
2012	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	FCIM	√	√	√	√
2012	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	FDIM	√	√	√	
2012	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	GEM / SJB	√	√	√	√
2012	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	GPSM	√	√	√	√
2012	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	HVAC	√	√	√	√
2012	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	IC	√	√	√	√
2012	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	OCSM	√	√	√	√
2012	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	PAM	√	√	√	√
2012	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	PCM	√	√	√	√
2012	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	PCM	√	√	√	√
2012	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	PSCM	√	√	√	√
2012	Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	RCM	√	√	√	√
2012	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	4X4	√	√	√	√
2012	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	ABS	√	√	√	√
2012	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	ACCM#2	√	√	√	√
2012	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	ACM	√	√	√	√
2012	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	APIM	√	√	√	√

2012	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	BCM	√	√	√	√
2012	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	FCIM	√	√	√	√
2012	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	FDIM	√	√	√	
2012	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	GEM / SJB	√	√	√	√
2012	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	GPSM	√	√	√	√
2012	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	HVAC	√	√	√	√
2012	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	IC	√	√	√	√
2012	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	OCSM	√	√	√	√
2012	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	PAM	√	√	√	√
2012	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	PCM	√	√	√	√
2012	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	PSCM	√	√	√	√
2012	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	RCM	√	√	√	√
2012	Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	TCM	√	√	√	√
2012	Escape / Tribute / Mariner	3.0L	4V	4X4	√	√	√	√
2012	Escape / Tribute / Mariner	3.0L	4V	ABS	√	√	√	√
2012	Escape / Tribute / Mariner	3.0L	4V	ACM	√	√	√	√
2012	Escape / Tribute / Mariner	3.0L	4V	APIM	√	√	√	√
2012	Escape / Tribute / Mariner	3.0L	4V	FCIM	√	√	√	√
2012	Escape / Tribute / Mariner	3.0L	4V	FDIM	√	√	√	
2012	Escape / Tribute / Mariner	3.0L	4V	GEM / SJB	√	√	√	√
2012	Escape / Tribute / Mariner	3.0L	4V	GPSM	√	√	√	√
2012	Escape / Tribute / Mariner	3.0L	4V	HVAC	√	√	√	√
2012	Escape / Tribute / Mariner	3.0L	4V	IC	√	√	√	√
2012	Escape / Tribute / Mariner	3.0L	4V	OCSM	√	√	√	√
2012	Escape / Tribute / Mariner	3.0L	4V	OCSM	√	√	√	√
2012	Escape / Tribute / Mariner	3.0L	4V	PAM	√	√	√	√
2012	Escape / Tribute / Mariner	3.0L	4V	PCM	√	√	√	√
2012	Escape / Tribute / Mariner	3.0L	4V	PSCM	√	√	√	√
2012	Escape / Tribute / Mariner	3.0L	4V	RCM	√	√	√	√
2012	Escape / Tribute / Mariner	Other	Other	4X4	√	√	√	√
2012	Escape / Tribute / Mariner	Other	Other	ABS	√	√	√	
2012	Escape / Tribute / Mariner	Other	Other	ACM	√	√	√	
2012	Escape / Tribute / Mariner	Other	Other	APIM	√	√	√	
2012	Escape / Tribute / Mariner	Other	Other	FCIM	√	√	√	√
2012	Escape / Tribute / Mariner	Other	Other	FDIM	√	√	√	
2012	Escape / Tribute / Mariner	Other	Other	GEM / SJB	√	√	√	√
2012	Escape / Tribute / Mariner	Other	Other	GPSM	√	√	√	√
2012	Escape / Tribute / Mariner	Other	Other	HVAC	√	√	√	√
2012	Escape / Tribute / Mariner	Other	Other	IC	√	√	√	√
2012	Escape / Tribute / Mariner	Other	Other	OCSM	√	√	√	√
2012	Escape / Tribute / Mariner	Other	Other	PAM	√	√	√	√
2012	Escape / Tribute / Mariner	Other	Other	PSCM	√	√	√	√
2012	Escape / Tribute / Mariner	Other	Other	RCM	√	√	√	√
2001	Escape / Tribute / Maverick	2.0L	Zetec	ABS/TCS	√	√	√	√
2001	Escape / Tribute / Maverick	2.0L	Zetec	GEM	√	√	√	√



2001	Escape / Tribute / Maverick	2.0L	Zetec	IC	✓	✓	✓	✓
2001	Escape / Tribute / Maverick	2.0L	Zetec	PCM	✓	✓	✓	✓
2001	Escape / Tribute / Maverick	2.0L	Zetec	RCM	✓	✓	✓	✓
2001	Escape / Tribute / Maverick	3.0L	4V	ABS/TCS	✓	✓	✓	✓
2001	Escape / Tribute / Maverick	3.0L	4V	GEM	✓	✓	✓	✓
2001	Escape / Tribute / Maverick	3.0L	4V	IC	✓	✓	✓	✓
2001	Escape / Tribute / Maverick	3.0L	4V	PCM	✓	✓	✓	✓
2002	Escape / Tribute / Maverick	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓
2002	Escape / Tribute / Maverick	2.0L	Zetec	GEM	✓	✓	✓	✓
2002	Escape / Tribute / Maverick	2.0L	Zetec	IC	✓	✓	✓	✓
2002	Escape / Tribute / Maverick	2.0L	Zetec	PCM	✓	✓	✓	✓
2002	Escape / Tribute / Maverick	2.0L	Zetec	RCM	✓	✓	✓	✓
2002	Escape / Tribute / Maverick	3.0L	4V	ABS/TCS	✓	✓	✓	✓
2002	Escape / Tribute / Maverick	3.0L	4V	GEM	✓	✓	✓	✓
2002	Escape / Tribute / Maverick	3.0L	4V	IC	✓	✓	✓	✓
2002	Escape / Tribute / Maverick	3.0L	4V	PCM	✓	✓	✓	✓
2002	Escape / Tribute / Maverick	3.0L	4V	RCM	✓	✓	✓	✓
2003	Escape / Tribute / Maverick	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓
2003	Escape / Tribute / Maverick	2.0L	Zetec	GEM	✓	✓	✓	✓
2003	Escape / Tribute / Maverick	2.0L	Zetec	IC	✓	✓	✓	✓
2003	Escape / Tribute / Maverick	2.0L	Zetec	PAM	✓	✓	✓	✓
2003	Escape / Tribute / Maverick	2.0L	Zetec	PCM	✓	✓	✓	✓
2003	Escape / Tribute / Maverick	2.0L	Zetec	RCM	✓	✓	✓	✓
2003	Escape / Tribute / Maverick	3.0L	4V	ABS/TCS	✓	✓	✓	✓
2003	Escape / Tribute / Maverick	3.0L	4V	GEM	✓	✓	✓	✓
2003	Escape / Tribute / Maverick	3.0L	4V	IC	✓	✓	✓	✓
2003	Escape / Tribute / Maverick	3.0L	4V	PAM	✓	✓	✓	✓
2003	Escape / Tribute / Maverick	3.0L	4V	PCM	✓	✓	✓	✓
2003	Escape / Tribute / Maverick	3.0L	4V	RCM	✓	✓	✓	✓
2004	Escape / Tribute / Maverick	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓
2004	Escape / Tribute / Maverick	2.0L	Zetec	GEM	✓	✓	✓	✓
2004	Escape / Tribute / Maverick	2.0L	Zetec	IC	✓	✓	✓	✓
2004	Escape / Tribute / Maverick	2.0L	Zetec	PAM	✓	✓	✓	✓
2004	Escape / Tribute / Maverick	2.0L	Zetec	PCM	✓	✓	✓	✓
2004	Escape / Tribute / Maverick	2.0L	Zetec	RCM	✓	✓	✓	✓
2004	Escape / Tribute / Maverick	3.0L	4V	ABS/TCS	✓	✓	✓	✓
2004	Escape / Tribute / Maverick	3.0L	4V	GEM	✓	✓	✓	✓
2004	Escape / Tribute / Maverick	3.0L	4V	IC	✓	✓	✓	✓
2004	Escape / Tribute / Maverick	3.0L	4V	PAM	✓	✓	✓	✓
2004	Escape / Tribute / Maverick	3.0L	4V	PCM	✓	✓	✓	✓
2004	Escape / Tribute / Maverick	3.0L	4V	RCM	✓	✓	✓	✓
2006	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓
2006	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓
2006	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓
2006	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	IC	✓	✓	✓	✓

2006	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	PAM	√	√	√	√
2006	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2006	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	RCM	√	√	√	√
2006	Escape / Tribute / Maverick	3.0L	4V	4X4	√	√	√	√
2006	Escape / Tribute / Maverick	3.0L	4V	ABS	√	√	√	√
2006	Escape / Tribute / Maverick	3.0L	4V	GEM	√	√	√	√
2006	Escape / Tribute / Maverick	3.0L	4V	GEM	√	√	√	√
2006	Escape / Tribute / Maverick	3.0L	4V	IC	√	√	√	√
2006	Escape / Tribute / Maverick	3.0L	4V	PAM	√	√	√	√
2006	Escape / Tribute / Maverick	3.0L	4V	PCM	√	√	√	√
2006	Escape / Tribute / Maverick	3.0L	4V	RCM	√	√	√	√
2007	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	4X4	√	√	√	√
2007	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	ABS	√	√	√	√
2007	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	GEM	√	√	√	√
2007	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	IC	√	√	√	√
2007	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	PAM	√	√	√	√
2007	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2007	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2007	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	RCM	√	√	√	√
2007	Escape / Tribute / Maverick	3.0L	4V	4X4	√	√	√	√
2007	Escape / Tribute / Maverick	3.0L	4V	ABS	√	√	√	√
2007	Escape / Tribute / Maverick	3.0L	4V	GEM	√	√	√	√
2007	Escape / Tribute / Maverick	3.0L	4V	IC	√	√	√	√
2007	Escape / Tribute / Maverick	3.0L	4V	PAM	√	√	√	√
2007	Escape / Tribute / Maverick	3.0L	4V	PCM	√	√	√	√
2007	Escape / Tribute / Maverick	3.0L	4V	RCM	√	√	√	√
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	BCM#1	√	√	√	√
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	√	√	√	√
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	DSM	√	√	√	√
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	DSP	√	√	√	√
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	FCDIM	√	√	√	√
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	HCM	√	√	√	
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	√
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	IPM-B	√	√	√	√
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	OCSM	√	√	√	√
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	PDM	√	√	√	√

2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	RGTM	√	√	√	
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	SASM	√	√	√	
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	√
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TRM	√	√	√	√
2013	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2013	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2013	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2013	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	BCM#1	√	√	√	√
2013	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	BCM#1	√	√	√	√
2013	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	√
2013	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	DSM	√	√	√	√
2013	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP	√	√	√	√
2013	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	
2013	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	
2013	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	HCM	√	√	√	
2013	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	√
2013	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2013	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	IPM-B	√	√	√	√
2013	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	OCSM	√	√	√	√
2013	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2013	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2013	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	PDM	√	√	√	√
2013	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2013	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2013	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	
2013	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	RGTM	√	√	√	
2013	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	SASM	√	√	√	
2013	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	√
2013	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2013	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	TRM	√	√	√	√
2013	Escape/Kuga	2.5L	IVCT	ABS	√	√	√	√
2013	Escape/Kuga	2.5L	IVCT	ACM	√	√	√	√
2013	Escape/Kuga	2.5L	IVCT	APIM	√	√	√	√
2013	Escape/Kuga	2.5L	IVCT	BCM#1	√	√	√	√
2013	Escape/Kuga	2.5L	IVCT	BCM#1	√	√	√	√
2013	Escape/Kuga	2.5L	IVCT	DDM	√	√	√	√
2013	Escape/Kuga	2.5L	IVCT	DSM	√	√	√	√
2013	Escape/Kuga	2.5L	IVCT	DSP	√	√	√	√
2013	Escape/Kuga	2.5L	IVCT	FCDIM	√	√	√	√

2013	Escape/Kuga	2.5L	IVCT	FCIM	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	GPSM	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	HCM	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	HVAC	✓	✓	✓	✓
2013	Escape/Kuga	2.5L	IVCT	IPC	✓	✓	✓	✓
2013	Escape/Kuga	2.5L	IVCT	IPM-B	✓	✓	✓	✓
2013	Escape/Kuga	2.5L	IVCT	OCSM	✓	✓	✓	✓
2013	Escape/Kuga	2.5L	IVCT	PAM	✓	✓	✓	✓
2013	Escape/Kuga	2.5L	IVCT	PCM	✓	✓	✓	✓
2013	Escape/Kuga	2.5L	IVCT	PDM	✓	✓	✓	✓
2013	Escape/Kuga	2.5L	IVCT	PSCM	✓	✓	✓	✓
2013	Escape/Kuga	2.5L	IVCT	RCM	✓	✓	✓	✓
2013	Escape/Kuga	2.5L	IVCT	RFA	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	RGTM	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	SASM	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	SOD-L	✓	✓	✓	✓
2013	Escape/Kuga	2.5L	IVCT	SOD-R	✓	✓	✓	✓
2013	Escape/Kuga	2.5L	IVCT	TRM	✓	✓	✓	✓
2014	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	ABS	✓	✓	✓	✓
2014	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓
2014	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	BCM#1	✓	✓	✓	✓
2014	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	DDM	✓	✓	✓	✓
2014	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	DSM	✓	✓	✓	✓
2014	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	DSP	✓	✓	✓	✓
2014	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	FCDIM	✓	✓	✓	✓
2014	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	FCIM	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	GPSM	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	HCM	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	HVAC	✓	✓	✓	✓
2014	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	IPC	✓	✓	✓	✓
2014	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	OCSM	✓	✓	✓	✓
2014	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	PAM	✓	✓	✓	✓
2014	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2014	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	PDM	✓	✓	✓	✓
2014	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	PSCM	✓	✓	✓	✓
2014	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	RCM	✓	✓	✓	✓
2014	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	RFA	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	RGTM	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	SASM	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	SOD-L	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	TRM	✓	✓	✓	✓
2014	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	ABS	✓	✓	✓	✓

2014	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2014	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2014	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	BCM#1	√	√	√	√
2014	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	√
2014	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	DSM	√	√	√	√
2014	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP	√	√	√	√
2014	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	
2014	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	
2014	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	HCM	√	√	√	
2014	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	√
2014	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2014	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	OCSM	√	√	√	√
2014	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2014	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2014	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	PDM	√	√	√	√
2014	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2014	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2014	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	
2014	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	RGTM	√	√	√	
2014	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	SASM	√	√	√	
2014	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	
2014	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	
2014	Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	TRM	√	√	√	√
2014	Escape/Kuga	2.5L	IVCT	ABS	√	√	√	√
2014	Escape/Kuga	2.5L	IVCT	ACM	√	√	√	√
2014	Escape/Kuga	2.5L	IVCT	APIM	√	√	√	√
2014	Escape/Kuga	2.5L	IVCT	BCM#1	√	√	√	√
2014	Escape/Kuga	2.5L	IVCT	DDM	√	√	√	√
2014	Escape/Kuga	2.5L	IVCT	DSM	√	√	√	√
2014	Escape/Kuga	2.5L	IVCT	DSP	√	√	√	√
2014	Escape/Kuga	2.5L	IVCT	FCDIM	√	√	√	√
2014	Escape/Kuga	2.5L	IVCT	FCIM	√	√	√	
2014	Escape/Kuga	2.5L	IVCT	GPSM	√	√	√	
2014	Escape/Kuga	2.5L	IVCT	HCM	√	√	√	
2014	Escape/Kuga	2.5L	IVCT	HVAC	√	√	√	√
2014	Escape/Kuga	2.5L	IVCT	IPC	√	√	√	√
2014	Escape/Kuga	2.5L	IVCT	OCSM	√	√	√	√
2014	Escape/Kuga	2.5L	IVCT	PAM	√	√	√	√
2014	Escape/Kuga	2.5L	IVCT	PCM	√	√	√	√
2014	Escape/Kuga	2.5L	IVCT	PDM	√	√	√	√
2014	Escape/Kuga	2.5L	IVCT	PSCM	√	√	√	√
2014	Escape/Kuga	2.5L	IVCT	RCM	√	√	√	√
2014	Escape/Kuga	2.5L	IVCT	RFA	√	√	√	
2014	Escape/Kuga	2.5L	IVCT	RGTM	√	√	√	

2014	Escape/Kuga	2.5L	IVCT	SASM	√	√	√	
2014	Escape/Kuga	2.5L	IVCT	SOD-L	√	√	√	
2014	Escape/Kuga	2.5L	IVCT	SOD-R	√	√	√	
2014	Escape/Kuga	2.5L	IVCT	TRM	√	√	√	√
1992	Escort	1.8L	Zetec	ABS/TCS	√	√	√	√
1992	Escort	1.8L	Zetec	CSM	√	√	√	√
1992	Escort	1.8L	Zetec	HEC	√	√	√	√
1992	Escort	1.8L	Zetec	PATS	√	√	√	√
1992	Escort	1.8L	Zetec	PCM	√	√	√	√
1993	Escort	1.6L	Zetec	ABS/TCS	√	√	√	√
1993	Escort	1.6L	Zetec	CSM	√	√	√	√
1993	Escort	1.6L	Zetec	HEC	√	√	√	√
1993	Escort	1.6L	Zetec	PATS	√	√	√	√
1993	Escort	1.6L	Zetec	PCM	√	√	√	√
1993.5	Escort	1.6L	Zetec	ABS/TCS	√	√	√	√
1993.5	Escort	1.6L	Zetec	HEC	√	√	√	√
1993.5	Escort	1.6L	Zetec	PATS	√	√	√	√
1993.5	Escort	1.6L	Zetec	PCM	√	√	√	√
1994	Escort	1.4L	1.4 PT-E SFI	ABS/TCS	√	√	√	√
1994	Escort	1.4L	1.4 PT-E SFI	CSM	√	√	√	√
1994	Escort	1.4L	1.4 PT-E SFI	HEC	√	√	√	√
1994	Escort	1.4L	1.4 PT-E SFI	PATS			√	√
1994	Escort	1.4L	1.4 PT-E SFI	PATS	√	√	√	√
1994	Escort	1.4L	1.4 PT-E SFI	PCM	√	√	√	√
1994	Escort	1.6L	Zetec	ABS/TCS	√	√	√	√
1994	Escort	1.6L	Zetec	CSM	√	√	√	√
1994	Escort	1.6L	Zetec	HEC	√	√	√	√
1994	Escort	1.6L	Zetec	PATS	√	√	√	√
1994	Escort	1.8L	Zetec	ABS/TCS	√	√	√	√
1994	Escort	1.8L	Zetec	CSM	√	√	√	√
1994	Escort	1.8L	Zetec	HEC	√	√	√	√
1994	Escort	1.8L	Zetec	PATS	√	√	√	√
1994.5	Escort	1.4L	1.4 PT-E SFI	ABS/TCS	√	√	√	√
1994.5	Escort	1.4L	1.4 PT-E SFI	CSM	√	√	√	√
1994.5	Escort	1.4L	1.4 PT-E SFI	HEC	√	√	√	√
1994.5	Escort	1.4L	1.4 PT-E SFI	PATS			√	√
1994.5	Escort	1.4L	1.4 PT-E SFI	PATS	√	√	√	√
1994.5	Escort	1.4L	1.4 PT-E SFI	PCM	√	√	√	√
1994.5	Escort	1.6L	Zetec	ABS/TCS	√	√	√	√
1994.5	Escort	1.6L	Zetec	CSM	√	√	√	√
1994.5	Escort	1.6L	Zetec	HEC	√	√	√	√
1994.5	Escort	1.6L	Zetec	PATS	√	√	√	√
1994.75	Escort	2.0L	DOHC Cosworth	ABS/TCS	√	√	√	√
1994.75	Escort	2.0L	DOHC Cosworth	PATS	√	√	√	√
1994.75	Escort	2.0L	DOHC Cosworth	PCM	√	√	√	√

1995	Escort	1.4L	1.4 PT-E SFI	ABS	✓	✓	✓	✓
1995	Escort	1.4L	1.4 PT-E SFI	ABS/TCS	✓	✓	✓	✓
1995	Escort	1.4L	1.4 PT-E SFI	CSM	✓	✓	✓	✓
1995	Escort	1.4L	1.4 PT-E SFI	HEC	✓	✓	✓	✓
1995	Escort	1.4L	1.4 PT-E SFI	PATS			✓	✓
1995	Escort	1.4L	1.4 PT-E SFI	PCM	✓	✓	✓	✓
1995	Escort	1.6L	Zetec	ABS	✓	✓	✓	✓
1995	Escort	1.6L	Zetec	ABS/TCS	✓	✓	✓	✓
1995	Escort	1.6L	Zetec	CSM	✓	✓	✓	✓
1995	Escort	1.6L	Zetec	HEC	✓	✓	✓	✓
1995	Escort	1.6L	Zetec	PATS	✓	✓	✓	✓
1995	Escort	1.8L	Zetec	ABS	✓	✓	✓	✓
1995	Escort	1.8L	Zetec	ABS/TCS	✓	✓	✓	✓
1995	Escort	1.8L	Zetec	CSM	✓	✓	✓	✓
1995	Escort	1.8L	Zetec	HEC	✓	✓	✓	✓
1995	Escort	1.8L	Zetec	PATS	✓	✓	✓	✓
1995	Escort	2.0L	DOHC Cosworth	ABS	✓	✓	✓	✓
1995	Escort	2.0L	DOHC Cosworth	ABS/TCS	✓	✓	✓	✓
1995	Escort	2.0L	DOHC Cosworth	PATS	✓	✓	✓	✓
1995	Escort	2.0L	DOHC Cosworth	PCM	✓	✓	✓	✓
1995.5	Escort	1.3L	Endura-E	ABS	✓	✓	✓	✓
1995.5	Escort	1.3L	Endura-E	ABS/TCS	✓	✓	✓	✓
1995.5	Escort	1.3L	Endura-E	CSM	✓	✓	✓	✓
1995.5	Escort	1.3L	Endura-E	HEC	✓	✓	✓	✓
1995.5	Escort	1.3L	Endura-E	PATS	✓	✓	✓	✓
1995.5	Escort	1.3L	Endura-E	PCM	✓	✓	✓	✓
1995.5	Escort	1.6L	Zetec	ABS	✓	✓	✓	✓
1995.5	Escort	1.6L	Zetec	ABS/TCS	✓	✓	✓	✓
1995.5	Escort	1.6L	Zetec	CSM	✓	✓	✓	✓
1995.5	Escort	1.6L	Zetec	HEC	✓	✓	✓	✓
1995.5	Escort	1.6L	Zetec	PATS	✓	✓	✓	✓
1995.5	Escort	1.6L	Zetec	PCM	✓	✓	✓	✓
1995.5	Escort	1.8L	Zetec	ABS	✓	✓	✓	✓
1995.5	Escort	1.8L	Zetec	ABS/TCS	✓	✓	✓	✓
1995.5	Escort	1.8L	Zetec	CSM	✓	✓	✓	✓
1995.5	Escort	1.8L	Zetec	HEC	✓	✓	✓	✓
1995.5	Escort	1.8L	Zetec	PATS	✓	✓	✓	✓
1996	Escort	1.3L	Endura-E	ABS/TCS	✓	✓	✓	✓
1996	Escort	1.3L	Endura-E	CSM	✓	✓	✓	✓
1996	Escort	1.3L	Endura-E	HEC	✓	✓	✓	✓
1996	Escort	1.3L	Endura-E	PATS	✓	✓	✓	✓
1996	Escort	1.3L	Endura-E	PCM	✓	✓	✓	✓
1996	Escort	1.6L	Zetec	ABS/TCS	✓	✓	✓	✓
1996	Escort	1.6L	Zetec	CSM	✓	✓	✓	✓
1996	Escort	1.6L	Zetec	HEC	✓	✓	✓	✓

1996	Escort	1.6L	Zetec	PATS	√	√	√	√
1996	Escort	1.6L	Zetec	PCM	√	√	√	√
1996	Escort	1.8L	Endura-DE	ABS/TCS	√	√	√	√
1996	Escort	1.8L	Endura-DE	CSM	√	√	√	√
1996	Escort	1.8L	Endura-DE	HEC	√	√	√	√
1996	Escort	1.8L	Endura-DE	PATS	√	√	√	√
1996	Escort	1.8L	Endura-DE	PCM			√	√
1996	Escort	1.8L	Endura-DE	PCM	√	√	√	
1996	Escort	1.8L	Endura-DE	PCM	√	√	√	√
1996	Escort	1.8L	Other	ABS/TCS	√	√	√	√
1996	Escort	1.8L	Other	CSM	√	√	√	√
1996	Escort	1.8L	Other	HEC	√	√	√	√
1996	Escort	1.8L	Other	PATS	√	√	√	√
1996	Escort	1.8L	Zetec	ABS/TCS	√	√	√	√
1996	Escort	1.8L	Zetec	CSM	√	√	√	√
1996	Escort	1.8L	Zetec	HEC	√	√	√	√
1996	Escort	1.8L	Zetec	PATS	√	√	√	√
1996	Escort	1.8L	Zetec	PCM	√	√	√	√
1996	Escort	1.9L	Other	ABS/TCS	√	√	√	√
1996	Escort	1.9L	Other	PATS	√	√	√	√
1996	Escort	1.9L	Other	PCM	√	√	√	√
1996.5	Escort	1.6L	Zetec	ABS	√	√	√	√
1996.5	Escort	1.6L	Zetec	ABS/TCS	√	√	√	√
1996.5	Escort	1.6L	Zetec	CSM	√	√	√	√
1996.5	Escort	1.6L	Zetec	HEC	√	√	√	√
1996.5	Escort	1.6L	Zetec	PATS	√	√	√	√
1997	Escort	1.3L	Endura-E	ABS/TCS	√	√	√	√
1997	Escort	1.3L	Endura-E	CSM	√	√	√	√
1997	Escort	1.3L	Endura-E	HEC	√	√	√	√
1997	Escort	1.3L	Endura-E	PATS	√	√	√	√
1997	Escort	1.3L	Endura-E	PCM	√	√	√	√
1997	Escort	1.6L	Zetec	ABS/TCS	√	√	√	√
1997	Escort	1.6L	Zetec	CSM	√	√	√	√
1997	Escort	1.6L	Zetec	HEC	√	√	√	√
1997	Escort	1.6L	Zetec	PATS	√	√	√	√
1997	Escort	1.6L	Zetec	PCM	√	√	√	√
1997	Escort	1.8L	Endura-DE	ABS/TCS	√	√	√	√
1997	Escort	1.8L	Endura-DE	CSM	√	√	√	√
1997	Escort	1.8L	Endura-DE	HEC	√	√	√	√
1997	Escort	1.8L	Endura-DE	PATS	√	√	√	√
1997	Escort	1.8L	Endura-DE	PCM			√	√
1997	Escort	1.8L	Endura-DE	PCM	√	√	√	√
1997	Escort	1.8L	Zetec	ABS/TCS	√	√	√	√
1997	Escort	1.8L	Zetec	CSM	√	√	√	√
1997	Escort	1.8L	Zetec	HEC	√	√	√	√



1997	Escort	1.8L	Zetec	PATS	√	√	√	√
1997	Escort	1.8L	Zetec	PCM	√	√	√	√
1997	Escort	2.0L	SPI	ABS/TCS	√	√	√	√
1997	Escort	2.0L	SPI	PATS	√	√	√	√
1997	Escort	2.0L	SPI	PCM	√	√	√	√
1997	Escort	2.0L	SPI	RAP	√	√	√	√
1997.5	Escort	1.8L	Endura-DE	ABS	√	√	√	√
1997.5	Escort	1.8L	Endura-DE	ABS/TCS	√	√	√	√
1997.5	Escort	1.8L	Endura-DE	CSM	√	√	√	√
1997.5	Escort	1.8L	Endura-DE	HEC	√	√	√	√
1997.5	Escort	1.8L	Endura-DE	PATS	√	√	√	√
1997.5	Escort	1.8L	Endura-DE	PCM			√	√
1997.5	Escort	1.8L	Endura-DE	PCM	√	√	√	√
1997.75	Escort	1.4L	1.4 PT-E SFI	ABS	√	√	√	√
1997.75	Escort	1.4L	1.4 PT-E SFI	ABS/TCS	√	√	√	√
1997.75	Escort	1.4L	1.4 PT-E SFI	CSM	√	√	√	√
1997.75	Escort	1.4L	1.4 PT-E SFI	HEC	√	√	√	√
1997.75	Escort	1.4L	1.4 PT-E SFI	PATS			√	√
1997.75	Escort	1.4L	1.4 PT-E SFI	PATS	√	√	√	√
1997.75	Escort	1.4L	1.4 PT-E SFI	PCM	√	√	√	√
1997.75	Escort	1.6L	Zetec	ABS	√	√	√	√
1997.75	Escort	1.6L	Zetec	ABS/TCS	√	√	√	√
1997.75	Escort	1.6L	Zetec	CSM	√	√	√	√
1997.75	Escort	1.6L	Zetec	HEC	√	√	√	√
1997.75	Escort	1.6L	Zetec	PATS	√	√	√	√
1997.75	Escort	1.8L	Zetec	ABS	√	√	√	√
1997.75	Escort	1.8L	Zetec	ABS/TCS	√	√	√	√
1997.75	Escort	1.8L	Zetec	CSM	√	√	√	√
1997.75	Escort	1.8L	Zetec	HEC	√	√	√	√
1997.75	Escort	1.8L	Zetec	PATS	√	√	√	√
1997.75	Escort	1.8L	Zetec	PCM	√	√	√	√
1998	Escort	1.3L	Endura-E	ABS	√	√	√	√
1998	Escort	1.3L	Endura-E	ABS/TCS	√	√	√	√
1998	Escort	1.3L	Endura-E	CSM	√	√	√	√
1998	Escort	1.3L	Endura-E	HEC	√	√	√	√
1998	Escort	1.3L	Endura-E	PATS	√	√	√	√
1998	Escort	1.3L	Endura-E	PCM	√	√	√	√
1998	Escort	1.4L	1.4 PT-E SFI	ABS	√	√	√	√
1998	Escort	1.4L	1.4 PT-E SFI	ABS/TCS	√	√	√	√
1998	Escort	1.4L	1.4 PT-E SFI	CSM	√	√	√	√
1998	Escort	1.4L	1.4 PT-E SFI	HEC	√	√	√	√
1998	Escort	1.4L	1.4 PT-E SFI	PATS			√	√
1998	Escort	1.4L	1.4 PT-E SFI	PATS	√	√	√	√
1998	Escort	1.4L	1.4 PT-E SFI	PCM	√	√	√	√
1998	Escort	1.6L	Zetec	ABS	√	√	√	√

1998	Escort	1.6L	Zetec	ABS/TCS	√	√	√	√
1998	Escort	1.6L	Zetec	CSM	√	√	√	√
1998	Escort	1.6L	Zetec	HEC	√	√	√	√
1998	Escort	1.6L	Zetec	PATS	√	√	√	√
1998	Escort	1.6L	Zetec	PCM	√	√	√	√
1998	Escort	1.8L	Zetec	ABS	√	√	√	√
1998	Escort	1.8L	Zetec	ABS/TCS	√	√	√	√
1998	Escort	1.8L	Zetec	CSM	√	√	√	√
1998	Escort	1.8L	Zetec	HEC	√	√	√	√
1998	Escort	1.8L	Zetec	PATS	√	√	√	√
1998	Escort	1.8L	Zetec	PCM	√	√	√	√
1998	Escort	2.0L	SPI	ABS/TCS	√	√	√	√
1998	Escort	2.0L	SPI	ECS	√	√	√	√
1998	Escort	2.0L	SPI	PATS	√	√	√	√
1998	Escort	2.0L	SPI	PCM	√	√	√	√
1998	Escort	2.0L	SPI	RAP	√	√	√	√
1998	Escort	2.0L	Zetec	ABS	√	√	√	√
1998	Escort	2.0L	Zetec	ABS/TCS	√	√	√	√
1998	Escort	2.0L	Zetec	ECS	√	√	√	√
1998	Escort	2.0L	Zetec	PATS	√	√	√	√
1998	Escort	2.0L	Zetec	PCM	√	√	√	√
1998	Escort	2.0L	Zetec	RAP	√	√	√	√
1999	Escort	2.0L	SPI	ABS	√	√	√	√
1999	Escort	2.0L	SPI	ABS/TCS	√	√	√	√
1999	Escort	2.0L	SPI	ECS	√	√	√	√
1999	Escort	2.0L	SPI	PATS	√	√	√	√
1999	Escort	2.0L	SPI	PCM	√	√	√	√
1999	Escort	2.0L	SPI	PCM	√	√	√	√
1999	Escort	2.0L	SPI	RAP	√	√	√	√
1999	Escort	2.0L	Zetec	ABS	√	√	√	√
1999	Escort	2.0L	Zetec	ABS/TCS	√	√	√	√
1999	Escort	2.0L	Zetec	ECS	√	√	√	√
1999	Escort	2.0L	Zetec	PATS	√	√	√	√
1999	Escort	2.0L	Zetec	PCM	√	√	√	√
1999	Escort	2.0L	Zetec	PCM	√	√	√	√
1999	Escort	2.0L	Zetec	RAP	√	√	√	√
2000	Escort	2.0L	SPI	ABS/TCS	√	√	√	√
2000	Escort	2.0L	SPI	ECS	√	√	√	√
2000	Escort	2.0L	SPI	PATS	√	√	√	√
2000	Escort	2.0L	SPI	PCM	√	√	√	√
2000	Escort	2.0L	SPI	RAP	√	√	√	√
2000	Escort	2.0L	Zetec	ABS/TCS	√	√	√	√
2000	Escort	2.0L	Zetec	ABS/TCS	√	√	√	√
2000	Escort	2.0L	Zetec	ECS	√	√	√	√
2000	Escort	2.0L	Zetec	PATS	√	√	√	√

2000	Escort	2.0L	Zetec	PCM	✓	✓	✓	✓
2000	Escort	2.0L	Zetec	RAP	✓	✓	✓	✓
2000.5	Escort	1.6L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓
2000.5	Escort	1.6L	Zetec Rocam	CSM	✓	✓	✓	✓
2000.5	Escort	1.6L	Zetec Rocam	HEC	✓	✓	✓	✓
2000.5	Escort	1.6L	Zetec Rocam	PATS	✓	✓	✓	✓
2000.5	Escort	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓
2002	Escort	2.0L	SPI	ABS/TCS	✓	✓	✓	✓
2002	Escort	2.0L	SPI	ECS	✓	✓	✓	✓
2002	Escort	2.0L	SPI	PATS	✓	✓	✓	✓
2002	Escort	2.0L	SPI	PCM	✓	✓	✓	✓
2002	Escort	2.0L	SPI	RAP	✓	✓	✓	✓
2002	Escort	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓
2002	Escort	2.0L	Zetec	ECS	✓	✓	✓	✓
2002	Escort	2.0L	Zetec	PATS	✓	✓	✓	✓
2002	Escort	2.0L	Zetec	PCM	✓	✓	✓	✓
2002	Escort	2.0L	Zetec	RAP	✓	✓	✓	✓
2003	Escort	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓
2003	Escort	2.0L	Zetec	ECS	✓	✓	✓	✓
2003	Escort	2.0L	Zetec	PATS	✓	✓	✓	✓
2003	Escort	2.0L	Zetec	PCM	✓	✓	✓	✓
2003	Escort	2.0L	Zetec	RAP	✓	✓	✓	✓
Other	Escort	1.6L	PT-E	ABS/TCS	✓	✓	✓	✓
Other	Escort	1.6L	PT-E	CSM	✓	✓	✓	✓
Other	Escort	1.6L	PT-E	HEC	✓	✓	✓	✓
Other	Escort	1.6L	PT-E	PATS	✓	✓	✓	✓
Other	Escort	1.6L	PT-E	PCM	✓	✓	✓	✓
Other	Escort	1.8L	Endura-DE	ABS/TCS	✓	✓	✓	✓
Other	Escort	1.8L	Endura-DE	CSM	✓	✓	✓	✓
Other	Escort	1.8L	Endura-DE	HEC	✓	✓	✓	✓
Other	Escort	1.8L	Endura-DE	PATS	✓	✓	✓	✓
Other	Escort	1.8L	Endura-DE	PCM			✓	✓
Other	Escort	1.8L	Endura-DE	PCM	✓	✓	✓	✓
2007	Everest / Endeavour	2.5L	WL-CD	ABS/TCS	✓	✓	✓	✓
2007	Everest / Endeavour	2.5L	WL-CD	PCM	✓	✓	✓	✓
2007	Everest / Endeavour	2.5L	WL-CD	PCM	✓	✓	✓	✓
2007	Everest / Endeavour	2.5L	WL-CD	PCM	✓	✓	✓	✓
2007	Everest / Endeavour	2.5L	WL-CD	RCM	✓	✓	✓	✓
2007	Everest / Endeavour	2.5L	WL-CD	TCM	✓	✓	✓	✓
2007	Everest / Endeavour	2.5L	WL-CD	TCM	✓	✓	✓	✓
2007	Everest / Endeavour	2.6L	G6	ABS/TCS	✓	✓	✓	✓
2007	Everest / Endeavour	2.6L	G6	PCM	✓	✓	✓	✓
2007	Everest / Endeavour	2.6L	G6	RCM	✓	✓	✓	✓
2007	Everest / Endeavour	3.0L	WE-CD	ABS/TCS	✓	✓	✓	✓
2007	Everest / Endeavour	3.0L	WE-CD	PCM	✓	✓	✓	✓

2007	Everest / Endeavour	3.0L	WE-CD	PCM	√	√	√	√
2007	Everest / Endeavour	3.0L	WE-CD	PCM	√	√	√	√
2007	Everest / Endeavour	3.0L	WE-CD	RCM	√	√	√	√
2007	Everest / Endeavour	3.0L	WE-CD	TCM	√	√	√	√
2007	Everest / Endeavour	3.0L	WE-CD	TCM	√	√	√	√
2007	Everest / Endeavour	3.0L	WE-CD	TCM	√	√	√	√
2000	Excursion	5.4L	Other	ABS/TCS	√	√	√	√
2000	Excursion	5.4L	Other	ECS	√	√	√	√
2000	Excursion	5.4L	Other	GEM	√	√	√	√
2000	Excursion	5.4L	Other	PAM	√	√	√	√
2000	Excursion	5.4L	Other	PATS	√	√	√	√
2000	Excursion	5.4L	Other	PCM	√	√	√	√
2000	Excursion	6.8L	Other	ABS/TCS	√	√	√	√
2000	Excursion	6.8L	Other	ECS	√	√	√	√
2000	Excursion	6.8L	Other	GEM	√	√	√	√
2000	Excursion	6.8L	Other	MC	√	√	√	
2000	Excursion	6.8L	Other	PAM	√	√	√	√
2000	Excursion	6.8L	Other	PATS	√	√	√	√
2000	Excursion	6.8L	Other	PCM	√	√	√	√
2000	Excursion	7.3L	Direct Injection -	ABS/TCS	√	√	√	√
2000	Excursion	7.3L	Direct Injection -	ECS	√	√	√	√
2000	Excursion	7.3L	Direct Injection -	GEM	√	√	√	√
2000	Excursion	7.3L	Direct Injection -	MC	√	√	√	
2000	Excursion	7.3L	Direct Injection -	PAM	√	√	√	√
2000	Excursion	7.3L	Direct Injection -	PATS	√	√	√	√
2000	Excursion	7.3L	Direct Injection -	PCM	√	√	√	√
2002	Excursion	5.4L	Other	ABS/TCS	√	√	√	√
2002	Excursion	5.4L	Other	CSM	√	√	√	√
2002	Excursion	5.4L	Other	DSM	√	√	√	√
2002	Excursion	5.4L	Other	EATC	√	√	√	√
2002	Excursion	5.4L	Other	ECS	√	√	√	√
2002	Excursion	5.4L	Other	GEM	√	√	√	√
2002	Excursion	5.4L	Other	HEC	√	√	√	√
2002	Excursion	5.4L	Other	OTC	√	√	√	√
2002	Excursion	5.4L	Other	PAM	√	√	√	
2002	Excursion	5.4L	Other	PATS	√	√	√	√
2002	Excursion	5.4L	Other	PCM	√	√	√	√
2002	Excursion	6.8L	Other	ABS/TCS	√	√	√	√
2002	Excursion	6.8L	Other	CSM	√	√	√	√
2002	Excursion	6.8L	Other	DSM	√	√	√	√
2002	Excursion	6.8L	Other	EATC	√	√	√	√
2002	Excursion	6.8L	Other	ECS	√	√	√	√
2002	Excursion	6.8L	Other	GEM	√	√	√	√
2002	Excursion	6.8L	Other	HEC	√	√	√	√
2002	Excursion	6.8L	Other	OTC	√	√	√	√

2002	Excursion	6.8L	Other	PAM	√	√	√	
2002	Excursion	6.8L	Other	PATS	√	√	√	√
2002	Excursion	6.8L	Other	PCM	√	√	√	√
2002	Excursion	7.3L	Direct Injection -	ABS/TCS	√	√	√	√
2002	Excursion	7.3L	Direct Injection -	CSM	√	√	√	√
2002	Excursion	7.3L	Direct Injection -	DSM	√	√	√	√
2002	Excursion	7.3L	Direct Injection -	EATC	√	√	√	√
2002	Excursion	7.3L	Direct Injection -	ECS	√	√	√	√
2002	Excursion	7.3L	Direct Injection -	GEM	√	√	√	√
2002	Excursion	7.3L	Direct Injection -	HEC	√	√	√	√
2002	Excursion	7.3L	Direct Injection -	OTC	√	√	√	√
2002	Excursion	7.3L	Direct Injection -	PAM	√	√	√	
2002	Excursion	7.3L	Direct Injection -	PATS	√	√	√	√
2002	Excursion	7.3L	Direct Injection -	PCM	√	√	√	√
2003	Excursion	5.4L	Other	ABS/TCS	√	√	√	√
2003	Excursion	5.4L	Other	DSM	√	√	√	√
2003	Excursion	5.4L	Other	EATC	√	√	√	√
2003	Excursion	5.4L	Other	ECS	√	√	√	√
2003	Excursion	5.4L	Other	FOH	√	√	√	√
2003	Excursion	5.4L	Other	GEM	√	√	√	√
2003	Excursion	5.4L	Other	HEC	√	√	√	√
2003	Excursion	5.4L	Other	OTC	√	√	√	√
2003	Excursion	5.4L	Other	PAM	√	√	√	
2003	Excursion	5.4L	Other	PATS	√	√	√	√
2003	Excursion	5.4L	Other	PCM	√	√	√	√
2003	Excursion	5.4L	Other	VSM	√	√	√	√
2003	Excursion	6.0L	Direct Injection -	ABS/TCS	√	√	√	√
2003	Excursion	6.0L	Direct Injection -	ABS/TCS	√	√	√	√
2003	Excursion	6.0L	Direct Injection -	DSM	√	√	√	√
2003	Excursion	6.0L	Direct Injection -	EATC	√	√	√	√
2003	Excursion	6.0L	Direct Injection -	ECS	√	√	√	√
2003	Excursion	6.0L	Direct Injection -	FOH	√	√	√	√
2003	Excursion	6.0L	Direct Injection -	GEM	√	√	√	√
2003	Excursion	6.0L	Direct Injection -	HEC	√	√	√	√
2003	Excursion	6.0L	Direct Injection -	OTC	√	√	√	√
2003	Excursion	6.0L	Direct Injection -	PAM	√	√	√	
2003	Excursion	6.0L	Direct Injection -	PATS	√	√	√	√
2003	Excursion	6.0L	Direct Injection -	PCM	√	√	√	√
2003	Excursion	6.0L	Direct Injection - Turbo	PCM	√	√	√	√
2003	Excursion	6.0L	Direct Injection - Turbo	PCM	√	√	√	√
2003	Excursion	6.0L	Direct Injection -	TCM	√	√	√	√
2003	Excursion	6.0L	Direct Injection -	VSM	√	√	√	√
2003	Excursion	6.8L	Other	ABS/TCS	√	√	√	√
2003	Excursion	6.8L	Other	DSM	√	√	√	√
2003	Excursion	6.8L	Other	EATC	√	√	√	√

2003	Excursion	6.8L	Other	ECS	√	√	√	√
2003	Excursion	6.8L	Other	FOH	√	√	√	√
2003	Excursion	6.8L	Other	GEM	√	√	√	√
2003	Excursion	6.8L	Other	HEC	√	√	√	√
2003	Excursion	6.8L	Other	OTC	√	√	√	√
2003	Excursion	6.8L	Other	PATS	√	√	√	√
2003	Excursion	6.8L	Other	PCM	√	√	√	√
2003	Excursion	6.8L	Other	VSM	√	√	√	√
2003	Excursion	7.3L	Direct Injection -	ABS/TCS	√	√	√	√
2003	Excursion	7.3L	Direct Injection -	DSM	√	√	√	√
2003	Excursion	7.3L	Direct Injection -	EATC	√	√	√	√
2003	Excursion	7.3L	Direct Injection -	ECS	√	√	√	√
2003	Excursion	7.3L	Direct Injection -	FOH	√	√	√	√
2003	Excursion	7.3L	Direct Injection -	GEM	√	√	√	√
2003	Excursion	7.3L	Direct Injection -	HEC	√	√	√	√
2003	Excursion	7.3L	Direct Injection -	OTC	√	√	√	√
2003	Excursion	7.3L	Direct Injection -	PAM	√	√	√	
2003	Excursion	7.3L	Direct Injection -	PATS	√	√	√	√
2003	Excursion	7.3L	Direct Injection -	PCM	√	√	√	√
2003	Excursion	7.3L	Direct Injection -	VSM	√	√	√	√
2004	Excursion	5.4L	2V	ABS/TCS	√	√	√	√
2004	Excursion	5.4L	2V	DSM	√	√	√	√
2004	Excursion	5.4L	2V	EATC	√	√	√	√
2004	Excursion	5.4L	2V	ECS	√	√	√	√
2004	Excursion	5.4L	2V	GEM	√	√	√	√
2004	Excursion	5.4L	2V	HEC	√	√	√	√
2004	Excursion	5.4L	2V	OTC	√	√	√	√
2004	Excursion	5.4L	2V	PAM	√	√	√	
2004	Excursion	5.4L	2V	PATS	√	√	√	√
2004	Excursion	5.4L	2V	PCM	√	√	√	√
2004	Excursion	5.4L	2V	VSM	√	√	√	√
2004	Excursion	6.0L	Direct Injection -	ABS/TCS	√	√	√	√
2004	Excursion	6.0L	Direct Injection -	ABS/TCS	√	√	√	√
2004	Excursion	6.0L	Direct Injection -	DSM	√	√	√	√
2004	Excursion	6.0L	Direct Injection -	EATC	√	√	√	√
2004	Excursion	6.0L	Direct Injection -	ECS	√	√	√	√
2004	Excursion	6.0L	Direct Injection -	GEM	√	√	√	√
2004	Excursion	6.0L	Direct Injection -	HEC	√	√	√	√
2004	Excursion	6.0L	Direct Injection -	OTC	√	√	√	√
2004	Excursion	6.0L	Direct Injection -	PAM	√	√	√	
2004	Excursion	6.0L	Direct Injection -	PATS	√	√	√	√
2004	Excursion	6.0L	Direct Injection -	PCM	√	√	√	√
2004	Excursion	6.0L	Direct Injection -	PCM	√	√	√	√
2004	Excursion	6.0L	Direct Injection - Turbo	PCM	√	√	√	√
2004	Excursion	6.0L	Direct Injection -	TCM	√	√	√	√

2004	Excursion	6.0L	Direct Injection -	VSM	√	√	√	√
2004	Excursion	6.8L	2V	ABS/TCS	√	√	√	√
2004	Excursion	6.8L	2V	DSM	√	√	√	√
2004	Excursion	6.8L	2V	EATC	√	√	√	√
2004	Excursion	6.8L	2V	ECS	√	√	√	√
2004	Excursion	6.8L	2V	GEM	√	√	√	√
2004	Excursion	6.8L	2V	HEC	√	√	√	√
2004	Excursion	6.8L	2V	OTC	√	√	√	√
2004	Excursion	6.8L	2V	PAM	√	√	√	
2004	Excursion	6.8L	2V	PATS	√	√	√	√
2004	Excursion	6.8L	2V	PCM	√	√	√	√
2004	Excursion	6.8L	2V	VSM	√	√	√	√
2005	Excursion	5.4L	2V	ABS/TCS	√	√	√	√
2005	Excursion	5.4L	2V	DSM	√	√	√	√
2005	Excursion	5.4L	2V	EATC	√	√	√	√
2005	Excursion	5.4L	2V	GEM	√	√	√	√
2005	Excursion	5.4L	2V	HEC	√	√	√	√
2005	Excursion	5.4L	2V	OTC	√	√	√	√
2005	Excursion	5.4L	2V	PAM	√	√	√	√
2005	Excursion	5.4L	2V	PATS	√	√	√	√
2005	Excursion	5.4L	2V	PCM	√	√	√	√
2005	Excursion	5.4L	2V	RCM	√	√	√	√
2005	Excursion	5.4L	2V	VSM	√	√	√	√
2005	Excursion	6.0L	Direct Injection -	ABS/TCS	√	√	√	√
2005	Excursion	6.0L	Direct Injection -	ABS/TCS	√	√	√	√
2005	Excursion	6.0L	Direct Injection -	DSM	√	√	√	√
2005	Excursion	6.0L	Direct Injection -	EATC	√	√	√	√
2005	Excursion	6.0L	Direct Injection -	GEM	√	√	√	√
2005	Excursion	6.0L	Direct Injection -	HEC	√	√	√	√
2005	Excursion	6.0L	Direct Injection -	OTC	√	√	√	√
2005	Excursion	6.0L	Direct Injection -	PAM	√	√	√	√
2005	Excursion	6.0L	Direct Injection -	PATS	√	√	√	√
2005	Excursion	6.0L	Direct Injection -	PCM	√	√	√	√
2005	Excursion	6.0L	Direct Injection - Turbo	PCM	√	√	√	√
2005	Excursion	6.0L	Direct Injection -	RCM	√	√	√	√
2005	Excursion	6.0L	Direct Injection -	TCM	√	√	√	√
2005	Excursion	6.0L	Direct Injection -	VSM	√	√	√	√
2005	Excursion	6.8L	2V	ABS/TCS	√	√	√	√
2005	Excursion	6.8L	2V	DSM	√	√	√	√
2005	Excursion	6.8L	2V	EATC	√	√	√	√
2005	Excursion	6.8L	2V	GEM	√	√	√	√
2005	Excursion	6.8L	2V	HEC	√	√	√	√
2005	Excursion	6.8L	2V	OTC	√	√	√	√
2005	Excursion	6.8L	2V	PAM	√	√	√	√
2005	Excursion	6.8L	2V	PATS	√	√	√	√

2005	Excursion	6.8L	2V	PCM	√	√	√	√
2005	Excursion	6.8L	2V	VSM	√	√	√	√
1997	Expedition	4.6L	Other	4WAS	√	√	√	√
1997	Expedition	4.6L	Other	ABS/TCS	√	√	√	√
1997	Expedition	4.6L	Other	GEM	√	√	√	√
1997	Expedition	4.6L	Other	IAB	√	√	√	√
1997	Expedition	4.6L	Other	PATS	√	√	√	√
1997	Expedition	4.6L	Other	PCM	√	√	√	√
1997	Expedition	4.6L	Other	RAP	√	√	√	√
1997	Expedition	5.4L	Other	4WAS	√	√	√	√
1997	Expedition	5.4L	Other	ABS/TCS	√	√	√	√
1997	Expedition	5.4L	Other	GEM	√	√	√	√
1997	Expedition	5.4L	Other	IAB	√	√	√	√
1997	Expedition	5.4L	Other	PATS	√	√	√	√
1997	Expedition	5.4L	Other	PCM	√	√	√	√
1997	Expedition	5.4L	Other	RAP	√	√	√	√
1998	Expedition	4.6L	Other	4WAS	√	√	√	√
1998	Expedition	4.6L	Other	ABS/TCS	√	√	√	√
1998	Expedition	4.6L	Other	GEM	√	√	√	√
1998	Expedition	4.6L	Other	IAB	√	√	√	√
1998	Expedition	4.6L	Other	PATS	√	√	√	√
1998	Expedition	4.6L	Other	PCM	√	√	√	√
1998	Expedition	4.6L	Other	RAP	√	√	√	√
1998	Expedition	4.6L	Other	RCC	√	√	√	√
1998	Expedition	5.4L	Other	4WAS	√	√	√	√
1998	Expedition	5.4L	Other	ABS/TCS	√	√	√	√
1998	Expedition	5.4L	Other	GEM	√	√	√	√
1998	Expedition	5.4L	Other	IAB	√	√	√	√
1998	Expedition	5.4L	Other	PATS	√	√	√	√
1998	Expedition	5.4L	Other	PCM	√	√	√	√
1998	Expedition	5.4L	Other	RAP	√	√	√	√
1998	Expedition	5.4L	Other	RCC	√	√	√	√
1999	Expedition	4.6L	Other	4WAS	√	√	√	√
1999	Expedition	4.6L	Other	4WAS	√	√	√	√
1999	Expedition	4.6L	Other	ABS/TCS	√	√	√	√
1999	Expedition	4.6L	Other	ABS/TCS	√	√	√	√
1999	Expedition	4.6L	Other	EATC	√	√	√	√
1999	Expedition	4.6L	Other	GEM	√	√	√	√
1999	Expedition	4.6L	Other	HEC	√	√	√	√
1999	Expedition	4.6L	Other	PCM	√	√	√	√
1999	Expedition	4.6L	Other	PCM	√	√	√	√
1999	Expedition	4.6L	Other	RAP	√	√	√	√
1999	Expedition	4.6L	Other	RCM	√	√	√	√
1999	Expedition	5.4L	Other	4WAS	√	√	√	√
1999	Expedition	5.4L	Other	4WAS	√	√	√	√



1999	Expedition	5.4L	Other	ABS/TCS	√	√	√	√
1999	Expedition	5.4L	Other	EATC	√	√	√	√
1999	Expedition	5.4L	Other	GEM	√	√	√	√
1999	Expedition	5.4L	Other	HEC	√	√	√	√
1999	Expedition	5.4L	Other	PCM	√	√	√	√
1999	Expedition	5.4L	Other	PCM	√	√	√	√
1999	Expedition	5.4L	Other	RAP	√	√	√	√
1999	Expedition	5.4L	Other	RCM	√	√	√	√
2000	Expedition	4.6L	Other	4WAS	√	√	√	√
2000	Expedition	4.6L	Other	ABS/TCS	√	√	√	√
2000	Expedition	4.6L	Other	DSM	√	√	√	√
2000	Expedition	4.6L	Other	EATC	√	√	√	√
2000	Expedition	4.6L	Other	GEM	√	√	√	√
2000	Expedition	4.6L	Other	HEC	√	√	√	√
2000	Expedition	4.6L	Other	PAM	√	√	√	√
2000	Expedition	4.6L	Other	PCM	√	√	√	√
2000	Expedition	4.6L	Other	PCM	√	√	√	√
2000	Expedition	4.6L	Other	RAP	√	√	√	√
2000	Expedition	4.6L	Other	RCM	√	√	√	√
2000	Expedition	5.4L	Other	4WAS	√	√	√	√
2000	Expedition	5.4L	Other	ABS/TCS	√	√	√	√
2000	Expedition	5.4L	Other	DSM	√	√	√	√
2000	Expedition	5.4L	Other	EATC	√	√	√	√
2000	Expedition	5.4L	Other	GEM	√	√	√	√
2000	Expedition	5.4L	Other	HEC	√	√	√	√
2000	Expedition	5.4L	Other	PAM	√	√	√	√
2000	Expedition	5.4L	Other	PCM	√	√	√	√
2000	Expedition	5.4L	Other	RAP	√	√	√	√
2000	Expedition	5.4L	Other	RCM	√	√	√	√
2003	Expedition	4.6L	2V	4X4	√	√	√	√
2003	Expedition	4.6L	2V	ABS/TCS	√	√	√	√
2003	Expedition	4.6L	2V	DCSM	√	√	√	√
2003	Expedition	4.6L	2V	DSM	√	√	√	√
2003	Expedition	4.6L	2V	EATC	√	√	√	√
2003	Expedition	4.6L	2V	HEC	√	√	√	√
2003	Expedition	4.6L	2V	PAM	√	√	√	√
2003	Expedition	4.6L	2V	PAM	√	√	√	√
2003	Expedition	4.6L	2V	PCM	√	√	√	√
2003	Expedition	4.6L	2V	PCM	√	√	√	√
2003	Expedition	4.6L	2V	PCSM	√	√	√	√
2003	Expedition	4.6L	2V	RCM	√	√	√	√
2003	Expedition	4.6L	2V	TPM	√	√	√	√
2003	Expedition	4.6L	2V	VDM	√	√	√	√
2003	Expedition	4.6L	2V	VSM	√	√	√	√
2003	Expedition	5.4L	2V	ABS/TCS	√	√	√	√

2003	Expedition	5.4L	2V	DCSM	✓	✓	✓	✓
2003	Expedition	5.4L	2V	DSM	✓	✓	✓	✓
2003	Expedition	5.4L	2V	EATC	✓	✓	✓	✓
2003	Expedition	5.4L	2V	HEC	✓	✓	✓	✓
2003	Expedition	5.4L	2V	PAM	✓	✓	✓	
2003	Expedition	5.4L	2V	PAM	✓	✓	✓	✓
2003	Expedition	5.4L	2V	PCM	✓	✓	✓	✓
2003	Expedition	5.4L	2V	PCM	✓	✓	✓	✓
2003	Expedition	5.4L	2V	PCM	✓	✓	✓	✓
2003	Expedition	5.4L	2V	PCSM	✓	✓	✓	✓
2003	Expedition	5.4L	2V	RCM	✓	✓	✓	✓
2003	Expedition	5.4L	2V	TPM	✓	✓	✓	✓
2003	Expedition	5.4L	2V	VDM	✓	✓	✓	✓
2003	Expedition	5.4L	2V	VSM	✓	✓	✓	✓
2004	Expedition	4.6L	2V	4X4	✓	✓	✓	✓
2004	Expedition	4.6L	2V	ABS/TCS	✓	✓	✓	✓
2004	Expedition	4.6L	2V	DCSM	✓	✓	✓	✓
2004	Expedition	4.6L	2V	DSM	✓	✓	✓	✓
2004	Expedition	4.6L	2V	EATC	✓	✓	✓	✓
2004	Expedition	4.6L	2V	HEC	✓	✓	✓	✓
2004	Expedition	4.6L	2V	PAM	✓	✓	✓	
2004	Expedition	4.6L	2V	PCM	✓	✓	✓	✓
2004	Expedition	4.6L	2V	PCM	✓	✓	✓	✓
2004	Expedition	4.6L	2V	PCSM	✓	✓	✓	✓
2004	Expedition	4.6L	2V	RCM	✓	✓	✓	✓
2004	Expedition	4.6L	2V	TPM	✓	✓	✓	✓
2004	Expedition	4.6L	2V	VDM	✓	✓	✓	✓
2004	Expedition	4.6L	2V	VSM	✓	✓	✓	✓
2004	Expedition	5.4L	2V	4X4	✓	✓	✓	✓
2004	Expedition	5.4L	2V	ABS/TCS	✓	✓	✓	✓
2004	Expedition	5.4L	2V	DCSM	✓	✓	✓	✓
2004	Expedition	5.4L	2V	DSM	✓	✓	✓	✓
2004	Expedition	5.4L	2V	EATC	✓	✓	✓	✓
2004	Expedition	5.4L	2V	HEC	✓	✓	✓	✓
2004	Expedition	5.4L	2V	PAM	✓	✓	✓	
2004	Expedition	5.4L	2V	PCM	✓	✓	✓	✓
2004	Expedition	5.4L	2V	PCM	✓	✓	✓	✓
2004	Expedition	5.4L	2V	PCSM	✓	✓	✓	✓
2004	Expedition	5.4L	2V	RCM	✓	✓	✓	✓
2004	Expedition	5.4L	2V	TPM	✓	✓	✓	✓
2004	Expedition	5.4L	2V	VDM	✓	✓	✓	✓
2004	Expedition	5.4L	2V	VSM	✓	✓	✓	✓
2005	Expedition	5.4L	3V	4X4	✓	✓	✓	✓
2005	Expedition	5.4L	3V	ABS	✓	✓	✓	✓

2005	Expedition	5.4L	3V	DCSM	√	√	√	√
2005	Expedition	5.4L	3V	DSM	√	√	√	√
2005	Expedition	5.4L	3V	EATC	√	√	√	√
2005	Expedition	5.4L	3V	IC	√	√	√	√
2005	Expedition	5.4L	3V	PAM	√	√	√	
2005	Expedition	5.4L	3V	PCM	√	√	√	
2005	Expedition	5.4L	3V	PCM	√	√	√	√
2005	Expedition	5.4L	3V	PCM	√	√	√	√
2005	Expedition	5.4L	3V	RCM	√	√	√	√
2005	Expedition	5.4L	3V	VDM	√	√	√	√
2005	Expedition	5.4L	3V	VDM	√	√	√	√
2005	Expedition	5.4L	3V	VSM	√	√	√	√
2006	Expedition	5.4L	3V	4X4	√	√	√	√
2006	Expedition	5.4L	3V	ABS	√	√	√	√
2006	Expedition	5.4L	3V	DCSM	√	√	√	√
2006	Expedition	5.4L	3V	DSM	√	√	√	√
2006	Expedition	5.4L	3V	EATC	√	√	√	√
2006	Expedition	5.4L	3V	IC	√	√	√	√
2006	Expedition	5.4L	3V	PAM	√	√	√	
2006	Expedition	5.4L	3V	PCM	√	√	√	
2006	Expedition	5.4L	3V	PCM	√	√	√	√
2006	Expedition	5.4L	3V	PCM	√	√	√	√
2006	Expedition	5.4L	3V	RCM	√	√	√	√
2006	Expedition	5.4L	3V	VDM	√	√	√	√
2006	Expedition	5.4L	3V	VDM	√	√	√	√
2006	Expedition	5.4L	3V	VSM	√	√	√	√
2007	Expedition	5.4L	3V	4X4	√	√	√	√
2007	Expedition	5.4L	3V	ABS	√	√	√	√
2007	Expedition	5.4L	3V	ABS	√	√	√	√
2007	Expedition	5.4L	3V	ACM	√	√	√	√
2007	Expedition	5.4L	3V	ACM	√	√	√	√
2007	Expedition	5.4L	3V	DCSM	√	√	√	√
2007	Expedition	5.4L	3V	DCSM	√	√	√	√
2007	Expedition	5.4L	3V	DSM	√	√	√	√
2007	Expedition	5.4L	3V	DSM	√	√	√	√
2007	Expedition	5.4L	3V	DSP	√	√	√	√
2007	Expedition	5.4L	3V	EATC	√	√	√	√
2007	Expedition	5.4L	3V	GEM	√	√	√	√
2007	Expedition	5.4L	3V	IC	√	√	√	√
2007	Expedition	5.4L	3V	IC	√	√	√	√
2007	Expedition	5.4L	3V	LTM	√	√	√	√
2007	Expedition	5.4L	3V	PAM	√	√	√	
2007	Expedition	5.4L	3V	PCM	√	√	√	√
2007	Expedition	5.4L	3V	PCM	√	√	√	√
2007	Expedition	5.4L	3V	PCM	√	√	√	√

2007	Expedition	5.4L	3V	PCM	✓	✓	✓	✓
2007	Expedition	5.4L	3V	PCM	✓	✓	✓	✓
2007	Expedition	5.4L	3V	RCM	✓	✓	✓	✓
2007	Expedition	5.4L	3V	RCM	✓	✓	✓	✓
2007	Expedition	5.4L	3V	RCU	✓	✓	✓	
2007	Expedition	5.4L	3V	RCU	✓	✓	✓	
2007	Expedition	5.4L	3V	RETM	✓	✓	✓	
2007	Expedition	5.4L	3V	RETM	✓	✓	✓	
2007	Expedition	5.4L	3V	SDARS	✓	✓	✓	✓
2007	Expedition	5.4L	3V	SDARS	✓	✓	✓	✓
2007	Expedition	5.4L	3V	TCM	✓	✓	✓	✓
2007	Expedition	5.4L	3V	TCM	✓	✓	✓	✓
2007	Expedition	5.4L	3V	VDM	✓	✓	✓	✓
2007	Expedition	5.4L	3V	VDM	✓	✓	✓	✓
2008	Expedition	5.4L	3V	4X4	✓	✓	✓	✓
2008	Expedition	5.4L	3V	ABS	✓	✓	✓	✓
2008	Expedition	5.4L	3V	ABS	✓	✓	✓	✓
2008	Expedition	5.4L	3V	ACM	✓	✓	✓	✓
2008	Expedition	5.4L	3V	ACM	✓	✓	✓	✓
2008	Expedition	5.4L	3V	DCSM	✓	✓	✓	✓
2008	Expedition	5.4L	3V	DSM	✓	✓	✓	✓
2008	Expedition	5.4L	3V	DSM	✓	✓	✓	✓
2008	Expedition	5.4L	3V	DSP	✓	✓	✓	✓
2008	Expedition	5.4L	3V	GEM / SJB	✓	✓	✓	✓
2008	Expedition	5.4L	3V	HVAC	✓	✓	✓	✓
2008	Expedition	5.4L	3V	IC	✓	✓	✓	✓
2008	Expedition	5.4L	3V	IC	✓	✓	✓	✓
2008	Expedition	5.4L	3V	LTM	✓	✓	✓	✓
2008	Expedition	5.4L	3V	PAM	✓	✓	✓	
2008	Expedition	5.4L	3V	PAM	✓	✓	✓	
2008	Expedition	5.4L	3V	PCM	✓	✓	✓	✓
2008	Expedition	5.4L	3V	PCM	✓	✓	✓	✓
2008	Expedition	5.4L	3V	PCM	✓	✓	✓	✓
2008	Expedition	5.4L	3V	PCM	✓	✓	✓	✓
2008	Expedition	5.4L	3V	PRB	✓	✓	✓	✓
2008	Expedition	5.4L	3V	RCM	✓	✓	✓	✓
2008	Expedition	5.4L	3V	RCM	✓	✓	✓	✓
2008	Expedition	5.4L	3V	RCU	✓	✓	✓	✓
2008	Expedition	5.4L	3V	RETM	✓	✓	✓	
2008	Expedition	5.4L	3V	RETM	✓	✓	✓	
2008	Expedition	5.4L	3V	SDARS	✓	✓	✓	✓
2008	Expedition	5.4L	3V	SDARS	✓	✓	✓	✓
2008	Expedition	5.4L	3V	TCM	✓	✓	✓	✓
2008	Expedition	5.4L	3V	TCM	✓	✓	✓	✓
2008	Expedition	5.4L	3V	VDM	✓	✓	✓	✓

2008	Expedition	5.4L	3V	VDM	✓	✓	✓	✓
2009	Expedition	5.4L	3V	4X4	✓	✓	✓	✓
2009	Expedition	5.4L	3V	ABS	✓	✓	✓	✓
2009	Expedition	5.4L	3V	ABS	✓	✓	✓	✓
2009	Expedition	5.4L	3V	ACM	✓	✓	✓	✓
2009	Expedition	5.4L	3V	ACM	✓	✓	✓	✓
2009	Expedition	5.4L	3V	APIM	✓	✓	✓	✓
2009	Expedition	5.4L	3V	APIM	✓	✓	✓	✓
2009	Expedition	5.4L	3V	DCSM	✓	✓	✓	✓
2009	Expedition	5.4L	3V	DSM	✓	✓	✓	✓
2009	Expedition	5.4L	3V	DSP	✓	✓	✓	✓
2009	Expedition	5.4L	3V	GEM / SJB	✓	✓	✓	✓
2009	Expedition	5.4L	3V	GEM / SJB	✓	✓	✓	✓
2009	Expedition	5.4L	3V	HVAC	✓	✓	✓	✓
2009	Expedition	5.4L	3V	IC	✓	✓	✓	✓
2009	Expedition	5.4L	3V	LTM	✓	✓	✓	✓
2009	Expedition	5.4L	3V	PAM	✓	✓	✓	
2009	Expedition	5.4L	3V	PCM	✓	✓	✓	✓
2009	Expedition	5.4L	3V	PCM	✓	✓	✓	✓
2009	Expedition	5.4L	3V	PRB	✓	✓	✓	✓
2009	Expedition	5.4L	3V	RCM	✓	✓	✓	✓
2009	Expedition	5.4L	3V	RCU	✓	✓	✓	✓
2009	Expedition	5.4L	3V	RETM	✓	✓	✓	
2009	Expedition	5.4L	3V	SDARS	✓	✓	✓	✓
2009	Expedition	5.4L	3V	TCM	✓	✓	✓	✓
2009	Expedition	5.4L	3V	TCM	✓	✓	✓	✓
2009	Expedition	5.4L	3V	VDM	✓	✓	✓	✓
2010	Expedition	5.4L	3V	4X4	✓	✓	✓	✓
2010	Expedition	5.4L	3V	ABS	✓	✓	✓	✓
2010	Expedition	5.4L	3V	ABS	✓	✓	✓	✓
2010	Expedition	5.4L	3V	ACM	✓	✓	✓	✓
2010	Expedition	5.4L	3V	ACM	✓	✓	✓	✓
2010	Expedition	5.4L	3V	APIM	✓	✓	✓	✓
2010	Expedition	5.4L	3V	APIM	✓	✓	✓	✓
2010	Expedition	5.4L	3V	DCSM	✓	✓	✓	✓
2010	Expedition	5.4L	3V	DSM	✓	✓	✓	✓
2010	Expedition	5.4L	3V	DSP	✓	✓	✓	✓
2010	Expedition	5.4L	3V	GEM / SJB	✓	✓	✓	✓
2010	Expedition	5.4L	3V	GEM / SJB	✓	✓	✓	✓
2010	Expedition	5.4L	3V	GPSM	✓	✓	✓	✓
2010	Expedition	5.4L	3V	HVAC	✓	✓	✓	✓
2010	Expedition	5.4L	3V	IC	✓	✓	✓	✓
2010	Expedition	5.4L	3V	LTM	✓	✓	✓	✓
2010	Expedition	5.4L	3V	PAM	✓	✓	✓	
2010	Expedition	5.4L	3V	PCM	✓	✓	✓	✓

2010	Expedition	5.4L	3V	PCM	√	√	√	√
2010	Expedition	5.4L	3V	PCM	√	√	√	√
2010	Expedition	5.4L	3V	PRB	√	√	√	√
2010	Expedition	5.4L	3V	RCM	√	√	√	√
2010	Expedition	5.4L	3V	RCU	√	√	√	√
2010	Expedition	5.4L	3V	RETM	√	√	√	√
2010	Expedition	5.4L	3V	SDARS	√	√	√	√
2010	Expedition	5.4L	3V	TCCM	√	√	√	√
2010	Expedition	5.4L	3V	TCM	√	√	√	√
2010	Expedition	5.4L	3V	VDM	√	√	√	√
2010	Expedition	5.4L	3V	VDM	√	√	√	√
2011	Expedition	5.4L	3V	ABS	√	√	√	√
2011	Expedition	5.4L	3V	ABS	√	√	√	√
2011	Expedition	5.4L	3V	ACM	√	√	√	√
2011	Expedition	5.4L	3V	ACM	√	√	√	√
2011	Expedition	5.4L	3V	ACM	√	√	√	√
2011	Expedition	5.4L	3V	APIM	√	√	√	√
2011	Expedition	5.4L	3V	APIM	√	√	√	√
2011	Expedition	5.4L	3V	DCSM	√	√	√	√
2011	Expedition	5.4L	3V	DSM	√	√	√	√
2011	Expedition	5.4L	3V	DSP	√	√	√	√
2011	Expedition	5.4L	3V	GEM / SJB	√	√	√	√
2011	Expedition	5.4L	3V	GEM / SJB	√	√	√	√
2011	Expedition	5.4L	3V	GPSM	√	√	√	√
2011	Expedition	5.4L	3V	HVAC	√	√	√	√
2011	Expedition	5.4L	3V	IC	√	√	√	√
2011	Expedition	5.4L	3V	LTM	√	√	√	√
2011	Expedition	5.4L	3V	PAM	√	√	√	√
2011	Expedition	5.4L	3V	PCM	√	√	√	√
2011	Expedition	5.4L	3V	PCM	√	√	√	√
2011	Expedition	5.4L	3V	PCM	√	√	√	√
2011	Expedition	5.4L	3V	PRB	√	√	√	√
2011	Expedition	5.4L	3V	RCM	√	√	√	√
2011	Expedition	5.4L	3V	RCU	√	√	√	√
2011	Expedition	5.4L	3V	RETM	√	√	√	
2011	Expedition	5.4L	3V	SDARS	√	√	√	√
2011	Expedition	5.4L	3V	TCCM	√	√	√	√
2011	Expedition	5.4L	3V	TCM	√	√	√	√
2011	Expedition	5.4L	3V	VDM	√	√	√	√
2011	Expedition	5.4L	3V	VDM	√	√	√	√
2012	Expedition	5.4L	3V	ABS	√	√	√	
2012	Expedition	5.4L	3V	ABS	√	√	√	√
2012	Expedition	5.4L	3V	ABS	√	√	√	√
2012	Expedition	5.4L	3V	ACM	√	√	√	
2012	Expedition	5.4L	3V	ACM	√	√	√	√

2012	Expedition	5.4L	3V	APIM	✓	✓	✓	
2012	Expedition	5.4L	3V	APIM	✓	✓	✓	✓
2012	Expedition	5.4L	3V	DCSM	✓	✓	✓	✓
2012	Expedition	5.4L	3V	DSM	✓	✓	✓	✓
2012	Expedition	5.4L	3V	DSP	✓	✓	✓	✓
2012	Expedition	5.4L	3V	GEM / SJB	✓	✓	✓	✓
2012	Expedition	5.4L	3V	GPSM	✓	✓	✓	✓
2012	Expedition	5.4L	3V	HVAC	✓	✓	✓	
2012	Expedition	5.4L	3V	HVAC	✓	✓	✓	✓
2012	Expedition	5.4L	3V	IC	✓	✓	✓	✓
2012	Expedition	5.4L	3V	LTM	✓	✓	✓	✓
2012	Expedition	5.4L	3V	PAM	✓	✓	✓	
2012	Expedition	5.4L	3V	PAM	✓	✓	✓	✓
2012	Expedition	5.4L	3V	PCM	✓	✓	✓	✓
2012	Expedition	5.4L	3V	PCM	✓	✓	✓	✓
2012	Expedition	5.4L	3V	PCM	✓	✓	✓	✓
2012	Expedition	5.4L	3V	PCM	✓	✓	✓	✓
2012	Expedition	5.4L	3V	PCM	✓	✓	✓	✓
2012	Expedition	5.4L	3V	PCM	✓	✓	✓	✓
2012	Expedition	5.4L	3V	RCM	✓	✓	✓	✓
2012	Expedition	5.4L	3V	RCU	✓	✓	✓	
2012	Expedition	5.4L	3V	RCU	✓	✓	✓	✓
2012	Expedition	5.4L	3V	RETM	✓	✓	✓	
2012	Expedition	5.4L	3V	SDARS	✓	✓	✓	✓
2012	Expedition	5.4L	3V	TCCM	✓	✓	✓	✓
2012	Expedition	5.4L	3V	VDM	✓	✓	✓	✓
2012	Expedition	5.4L	3V	VDM	✓	✓	✓	✓
2013	Expedition	5.4L	3V	ABS	✓	✓	✓	✓
2013	Expedition	5.4L	3V	ACM	✓	✓	✓	✓
2013	Expedition	5.4L	3V	ACM	✓	✓	✓	✓
2013	Expedition	5.4L	3V	APIM	✓	✓	✓	✓
2013	Expedition	5.4L	3V	APIM	✓	✓	✓	✓
2013	Expedition	5.4L	3V	DCSM	✓	✓	✓	✓
2013	Expedition	5.4L	3V	DSM	✓	✓	✓	✓
2013	Expedition	5.4L	3V	DSP	✓	✓	✓	✓
2013	Expedition	5.4L	3V	GEM / SJB	✓	✓	✓	✓
2013	Expedition	5.4L	3V	GEM / SJB	✓	✓	✓	✓
2013	Expedition	5.4L	3V	GPSM	✓	✓	✓	✓
2013	Expedition	5.4L	3V	HVAC	✓	✓	✓	✓
2013	Expedition	5.4L	3V	IC	✓	✓	✓	✓
2013	Expedition	5.4L	3V	LTM	✓	✓	✓	✓
2013	Expedition	5.4L	3V	PAM	✓	✓	✓	✓
2013	Expedition	5.4L	3V	PCM	✓	✓	✓	✓
2013	Expedition	5.4L	3V	PCM	✓	✓	✓	✓
2013	Expedition	5.4L	3V	PCM	✓	✓	✓	✓
2013	Expedition	5.4L	3V	PCM	✓	✓	✓	✓

2013	Expedition	5.4L	3V	PRB	√	√	√	√
2013	Expedition	5.4L	3V	RCM	√	√	√	√
2013	Expedition	5.4L	3V	RCU	√	√	√	√
2013	Expedition	5.4L	3V	SDARS	√	√	√	√
2013	Expedition	5.4L	3V	TBC	√	√	√	√
2013	Expedition	5.4L	3V	TCCM	√	√	√	√
2013	Expedition	5.4L	3V	VDM	√	√	√	√
2013	Expedition	Other	Other	ABS	√	√	√	√
2013	Expedition	Other	Other	ACM	√	√	√	√
2013	Expedition	Other	Other	APIM	√	√	√	√
2013	Expedition	Other	Other	DCSM	√	√	√	√
2013	Expedition	Other	Other	DSM	√	√	√	√
2013	Expedition	Other	Other	DSP	√	√	√	√
2013	Expedition	Other	Other	GEM / SJB	√	√	√	√
2013	Expedition	Other	Other	GPSM	√	√	√	√
2013	Expedition	Other	Other	HVAC	√	√	√	√
2013	Expedition	Other	Other	IC	√	√	√	√
2013	Expedition	Other	Other	LTM	√	√	√	√
2013	Expedition	Other	Other	PAM	√	√	√	√
2013	Expedition	Other	Other	PCM	√	√	√	
2013	Expedition	Other	Other	PCM	√	√	√	√
2013	Expedition	Other	Other	PRB	√	√	√	√
2013	Expedition	Other	Other	RCM	√	√	√	√
2013	Expedition	Other	Other	RCU	√	√	√	√
2013	Expedition	Other	Other	SDARS	√	√	√	√
2013	Expedition	Other	Other	TBC	√	√	√	√
2013	Expedition	Other	Other	TCCM	√	√	√	√
2013	Expedition	Other	Other	VDM	√	√	√	√
2014	Expedition	5.4L	3V	ABS	√	√	√	√
2014	Expedition	5.4L	3V	ACM	√	√	√	√
2014	Expedition	5.4L	3V	ACM	√	√	√	√
2014	Expedition	5.4L	3V	APIM	√	√	√	√
2014	Expedition	5.4L	3V	APIM	√	√	√	√
2014	Expedition	5.4L	3V	DCSM	√	√	√	√
2014	Expedition	5.4L	3V	DSM	√	√	√	√
2014	Expedition	5.4L	3V	DSP	√	√	√	√
2014	Expedition	5.4L	3V	GEM / SJB	√	√	√	√
2014	Expedition	5.4L	3V	GEM / SJB	√	√	√	√
2014	Expedition	5.4L	3V	GPSM	√	√	√	√
2014	Expedition	5.4L	3V	HVAC	√	√	√	√
2014	Expedition	5.4L	3V	IC	√	√	√	√
2014	Expedition	5.4L	3V	LTM	√	√	√	√
2014	Expedition	5.4L	3V	PAM	√	√	√	√
2014	Expedition	5.4L	3V	PCM	√	√	√	√
2014	Expedition	5.4L	3V	PCM	√	√	√	√



2014	Expedition	5.4L	3V	PCM	✓	✓	✓	✓
2014	Expedition	5.4L	3V	PCM	✓	✓	✓	✓
2014	Expedition	5.4L	3V	PRB	✓	✓	✓	✓
2014	Expedition	5.4L	3V	RCM	✓	✓	✓	✓
2014	Expedition	5.4L	3V	SDARS	✓	✓	✓	✓
2014	Expedition	5.4L	3V	TBC	✓	✓	✓	✓
2014	Expedition	5.4L	3V	TCCM	✓	✓	✓	✓
2014	Expedition	5.4L	3V	VDM	✓	✓	✓	✓
2007	Expedition EL	5.4L	3V	4X4	✓	✓	✓	✓
2007	Expedition EL	5.4L	3V	ABS	✓	✓	✓	✓
2007	Expedition EL	5.4L	3V	ABS	✓	✓	✓	✓
2007	Expedition EL	5.4L	3V	ACM	✓	✓	✓	✓
2007	Expedition EL	5.4L	3V	ACM	✓	✓	✓	✓
2007	Expedition EL	5.4L	3V	DCSM	✓	✓	✓	✓
2007	Expedition EL	5.4L	3V	DSM	✓	✓	✓	✓
2007	Expedition EL	5.4L	3V	DSP	✓	✓	✓	✓
2007	Expedition EL	5.4L	3V	EATC	✓	✓	✓	✓
2007	Expedition EL	5.4L	3V	GEM	✓	✓	✓	✓
2007	Expedition EL	5.4L	3V	IC	✓	✓	✓	✓
2007	Expedition EL	5.4L	3V	LTM	✓	✓	✓	✓
2007	Expedition EL	5.4L	3V	PAM	✓	✓	✓	
2007	Expedition EL	5.4L	3V	PCM	✓	✓	✓	✓
2007	Expedition EL	5.4L	3V	PCM	✓	✓	✓	✓
2007	Expedition EL	5.4L	3V	RCM	✓	✓	✓	✓
2007	Expedition EL	5.4L	3V	RCU	✓	✓	✓	
2007	Expedition EL	5.4L	3V	RETM	✓	✓	✓	
2007	Expedition EL	5.4L	3V	SDARS	✓	✓	✓	✓
2007	Expedition EL	5.4L	3V	SDARS	✓	✓	✓	✓
2007	Expedition EL	5.4L	3V	TCM	✓	✓	✓	✓
2007	Expedition EL	5.4L	3V	TCM	✓	✓	✓	✓
2007	Expedition EL	5.4L	3V	VDM	✓	✓	✓	✓
2007	Expedition EL	5.4L	3V	VDM	✓	✓	✓	✓
2008	Expedition EL	5.4L	3V	4X4	✓	✓	✓	✓
2008	Expedition EL	5.4L	3V	ABS	✓	✓	✓	✓
2008	Expedition EL	5.4L	3V	ABS	✓	✓	✓	✓
2008	Expedition EL	5.4L	3V	ACM	✓	✓	✓	✓
2008	Expedition EL	5.4L	3V	ACM	✓	✓	✓	✓
2008	Expedition EL	5.4L	3V	DCSM	✓	✓	✓	✓
2008	Expedition EL	5.4L	3V	DSM	✓	✓	✓	✓
2008	Expedition EL	5.4L	3V	DSP	✓	✓	✓	✓
2008	Expedition EL	5.4L	3V	GEM / SJB	✓	✓	✓	✓
2008	Expedition EL	5.4L	3V	HVAC	✓	✓	✓	✓
2008	Expedition EL	5.4L	3V	IC	✓	✓	✓	✓
2008	Expedition EL	5.4L	3V	LTM	✓	✓	✓	✓
2008	Expedition EL	5.4L	3V	PAM	✓	✓	✓	

2008	Expedition EL	5.4L	3V	PCM	√	√	√	√
2008	Expedition EL	5.4L	3V	PCM	√	√	√	√
2008	Expedition EL	5.4L	3V	PRB	√	√	√	√
2008	Expedition EL	5.4L	3V	RCM	√	√	√	√
2008	Expedition EL	5.4L	3V	RCU	√	√	√	√
2008	Expedition EL	5.4L	3V	RETM	√	√	√	
2008	Expedition EL	5.4L	3V	SDARS	√	√	√	√
2008	Expedition EL	5.4L	3V	SDARS	√	√	√	√
2008	Expedition EL	5.4L	3V	TCM	√	√	√	√
2008	Expedition EL	5.4L	3V	TCM	√	√	√	√
2008	Expedition EL	5.4L	3V	VDM	√	√	√	√
2008	Expedition EL	5.4L	3V	VDM	√	√	√	√
2009	Expedition EL	5.4L	3V	4X4	√	√	√	√
2009	Expedition EL	5.4L	3V	ABS	√	√	√	√
2009	Expedition EL	5.4L	3V	ABS	√	√	√	√
2009	Expedition EL	5.4L	3V	ACM	√	√	√	√
2009	Expedition EL	5.4L	3V	ACM	√	√	√	√
2009	Expedition EL	5.4L	3V	APIM	√	√	√	√
2009	Expedition EL	5.4L	3V	APIM	√	√	√	√
2009	Expedition EL	5.4L	3V	DCSM	√	√	√	√
2009	Expedition EL	5.4L	3V	DSM	√	√	√	√
2009	Expedition EL	5.4L	3V	DSP	√	√	√	√
2009	Expedition EL	5.4L	3V	GEM / SJB	√	√	√	√
2009	Expedition EL	5.4L	3V	GEM / SJB	√	√	√	√
2009	Expedition EL	5.4L	3V	HVAC	√	√	√	√
2009	Expedition EL	5.4L	3V	IC	√	√	√	√
2009	Expedition EL	5.4L	3V	LTM	√	√	√	√
2009	Expedition EL	5.4L	3V	PAM	√	√	√	
2009	Expedition EL	5.4L	3V	PCM	√	√	√	√
2009	Expedition EL	5.4L	3V	PCM	√	√	√	√
2009	Expedition EL	5.4L	3V	PRB	√	√	√	√
2009	Expedition EL	5.4L	3V	RCM	√	√	√	√
2009	Expedition EL	5.4L	3V	RCU	√	√	√	√
2009	Expedition EL	5.4L	3V	RETM	√	√	√	
2009	Expedition EL	5.4L	3V	SDARS	√	√	√	√
2009	Expedition EL	5.4L	3V	TCM	√	√	√	√
2009	Expedition EL	5.4L	3V	VDM	√	√	√	√
2009	Expedition EL	5.4L	3V	VDM	√	√	√	√
2010	Expedition EL	5.4L	3V	4X4	√	√	√	√
2010	Expedition EL	5.4L	3V	ABS	√	√	√	√
2010	Expedition EL	5.4L	3V	ABS	√	√	√	√
2010	Expedition EL	5.4L	3V	ACM	√	√	√	√
2010	Expedition EL	5.4L	3V	ACM	√	√	√	√
2010	Expedition EL	5.4L	3V	APIM	√	√	√	√
2010	Expedition EL	5.4L	3V	APIM	√	√	√	√

2010	Expedition EL	5.4L	3V	DSM	√	√	√	√
2010	Expedition EL	5.4L	3V	DSP	√	√	√	√
2010	Expedition EL	5.4L	3V	GEM / SJB	√	√	√	√
2010	Expedition EL	5.4L	3V	GEM / SJB	√	√	√	√
2010	Expedition EL	5.4L	3V	GPSM	√	√	√	√
2010	Expedition EL	5.4L	3V	HVAC	√	√	√	√
2010	Expedition EL	5.4L	3V	IC	√	√	√	√
2010	Expedition EL	5.4L	3V	LTM	√	√	√	√
2010	Expedition EL	5.4L	3V	PAM	√	√	√	
2010	Expedition EL	5.4L	3V	PCM	√	√	√	√
2010	Expedition EL	5.4L	3V	PCM	√	√	√	√
2010	Expedition EL	5.4L	3V	PRB	√	√	√	√
2010	Expedition EL	5.4L	3V	RCM	√	√	√	√
2010	Expedition EL	5.4L	3V	RCU	√	√	√	√
2010	Expedition EL	5.4L	3V	RETM	√	√	√	√
2010	Expedition EL	5.4L	3V	SDARS	√	√	√	√
2010	Expedition EL	5.4L	3V	TCCM	√	√	√	√
2010	Expedition EL	5.4L	3V	TCM	√	√	√	√
2010	Expedition EL	5.4L	3V	VDM	√	√	√	√
2010	Expedition EL	5.4L	3V	VDM	√	√	√	√
2011	Expedition EL	5.4L	3V	ABS	√	√	√	√
2011	Expedition EL	5.4L	3V	ABS	√	√	√	√
2011	Expedition EL	5.4L	3V	ACM	√	√	√	√
2011	Expedition EL	5.4L	3V	ACM	√	√	√	√
2011	Expedition EL	5.4L	3V	APIM	√	√	√	√
2011	Expedition EL	5.4L	3V	APIM	√	√	√	√
2011	Expedition EL	5.4L	3V	DCSM	√	√	√	√
2011	Expedition EL	5.4L	3V	DSM	√	√	√	√
2011	Expedition EL	5.4L	3V	DSP	√	√	√	√
2011	Expedition EL	5.4L	3V	GEM / SJB	√	√	√	√
2011	Expedition EL	5.4L	3V	GEM / SJB	√	√	√	√
2011	Expedition EL	5.4L	3V	GPSM	√	√	√	√
2011	Expedition EL	5.4L	3V	HVAC	√	√	√	√
2011	Expedition EL	5.4L	3V	IC	√	√	√	√
2011	Expedition EL	5.4L	3V	LTM	√	√	√	√
2011	Expedition EL	5.4L	3V	PAM	√	√	√	√
2011	Expedition EL	5.4L	3V	PCM	√	√	√	√
2011	Expedition EL	5.4L	3V	PCM	√	√	√	√
2011	Expedition EL	5.4L	3V	PRB	√	√	√	√
2011	Expedition EL	5.4L	3V	RCM	√	√	√	√
2011	Expedition EL	5.4L	3V	RCU	√	√	√	√
2011	Expedition EL	5.4L	3V	RETM	√	√	√	
2011	Expedition EL	5.4L	3V	SDARS	√	√	√	√
2011	Expedition EL	5.4L	3V	TCCM	√	√	√	√
2011	Expedition EL	5.4L	3V	TCM	√	√	√	√

2011	Expedition EL	5.4L	3V	VDM	√	√	√	√
2011	Expedition EL	5.4L	3V	VDM	√	√	√	√
2012	Expedition EL	5.4L	3V	ABS	√	√	√	
2012	Expedition EL	5.4L	3V	ABS	√	√	√	√
2012	Expedition EL	5.4L	3V	ACM	√	√	√	
2012	Expedition EL	5.4L	3V	ACM	√	√	√	√
2012	Expedition EL	5.4L	3V	APIM	√	√	√	
2012	Expedition EL	5.4L	3V	APIM	√	√	√	√
2012	Expedition EL	5.4L	3V	DCSM	√	√	√	√
2012	Expedition EL	5.4L	3V	DSM	√	√	√	√
2012	Expedition EL	5.4L	3V	DSP	√	√	√	√
2012	Expedition EL	5.4L	3V	GEM / SJB	√	√	√	√
2012	Expedition EL	5.4L	3V	GPSM	√	√	√	√
2012	Expedition EL	5.4L	3V	HVAC	√	√	√	
2012	Expedition EL	5.4L	3V	HVAC	√	√	√	√
2012	Expedition EL	5.4L	3V	IC	√	√	√	√
2012	Expedition EL	5.4L	3V	LTM	√	√	√	√
2012	Expedition EL	5.4L	3V	PAM	√	√	√	
2012	Expedition EL	5.4L	3V	PAM	√	√	√	√
2012	Expedition EL	5.4L	3V	PCM	√	√	√	√
2012	Expedition EL	5.4L	3V	PCM	√	√	√	√
2012	Expedition EL	5.4L	3V	PRB	√	√	√	√
2012	Expedition EL	5.4L	3V	RCM	√	√	√	√
2012	Expedition EL	5.4L	3V	RCU	√	√	√	
2012	Expedition EL	5.4L	3V	RCU	√	√	√	√
2012	Expedition EL	5.4L	3V	RETM	√	√	√	
2012	Expedition EL	5.4L	3V	SDARS	√	√	√	√
2012	Expedition EL	5.4L	3V	TCCM	√	√	√	√
2012	Expedition EL	5.4L	3V	VDM	√	√	√	√
2012	Expedition EL	5.4L	3V	VDM	√	√	√	√
2013	Expedition EL	5.4L	3V	ABS	√	√	√	√
2013	Expedition EL	5.4L	3V	ACM	√	√	√	√
2013	Expedition EL	5.4L	3V	ACM	√	√	√	√
2013	Expedition EL	5.4L	3V	APIM	√	√	√	√
2013	Expedition EL	5.4L	3V	APIM	√	√	√	√
2013	Expedition EL	5.4L	3V	DCSM	√	√	√	√
2013	Expedition EL	5.4L	3V	DSM	√	√	√	√
2013	Expedition EL	5.4L	3V	DSP	√	√	√	√
2013	Expedition EL	5.4L	3V	GEM / SJB	√	√	√	√
2013	Expedition EL	5.4L	3V	GEM / SJB	√	√	√	√
2013	Expedition EL	5.4L	3V	GPSM	√	√	√	√
2013	Expedition EL	5.4L	3V	HVAC	√	√	√	√
2013	Expedition EL	5.4L	3V	IC	√	√	√	√
2013	Expedition EL	5.4L	3V	PAM	√	√	√	√
2013	Expedition EL	5.4L	3V	PCM	√	√	√	√

2013	Expedition EL	5.4L	3V	PRB	√	√	√	√
2013	Expedition EL	5.4L	3V	RCM	√	√	√	√
2013	Expedition EL	5.4L	3V	RCU	√	√	√	√
2013	Expedition EL	5.4L	3V	SDARS	√	√	√	√
2013	Expedition EL	5.4L	3V	TBC	√	√	√	√
2013	Expedition EL	5.4L	3V	TCCM	√	√	√	√
2013	Expedition EL	5.4L	3V	VDM	√	√	√	√
2013	Expedition EL	Other	Other	ABS	√	√	√	√
2013	Expedition EL	Other	Other	ACM	√	√	√	√
2013	Expedition EL	Other	Other	APIM	√	√	√	√
2013	Expedition EL	Other	Other	DCSM	√	√	√	√
2013	Expedition EL	Other	Other	DSM	√	√	√	√
2013	Expedition EL	Other	Other	DSP	√	√	√	√
2013	Expedition EL	Other	Other	GEM / SJB	√	√	√	√
2013	Expedition EL	Other	Other	GPSM	√	√	√	√
2013	Expedition EL	Other	Other	HVAC	√	√	√	√
2013	Expedition EL	Other	Other	IC	√	√	√	√
2013	Expedition EL	Other	Other	LTM	√	√	√	√
2013	Expedition EL	Other	Other	PAM	√	√	√	√
2013	Expedition EL	Other	Other	PCM	√	√	√	
2013	Expedition EL	Other	Other	PRB	√	√	√	√
2013	Expedition EL	Other	Other	RCM	√	√	√	√
2013	Expedition EL	Other	Other	RCU	√	√	√	√
2013	Expedition EL	Other	Other	SDARS	√	√	√	√
2013	Expedition EL	Other	Other	TBC	√	√	√	√
2013	Expedition EL	Other	Other	TCCM	√	√	√	√
2013	Expedition EL	Other	Other	VDM	√	√	√	√
2014	Expedition EL	5.4L	3V	ABS	√	√	√	√
2014	Expedition EL	5.4L	3V	ACM	√	√	√	√
2014	Expedition EL	5.4L	3V	ACM	√	√	√	√
2014	Expedition EL	5.4L	3V	APIM	√	√	√	√
2014	Expedition EL	5.4L	3V	APIM	√	√	√	√
2014	Expedition EL	5.4L	3V	DCSM	√	√	√	√
2014	Expedition EL	5.4L	3V	DSM	√	√	√	√
2014	Expedition EL	5.4L	3V	DSP	√	√	√	√
2014	Expedition EL	5.4L	3V	GEM / SJB	√	√	√	√
2014	Expedition EL	5.4L	3V	GEM / SJB	√	√	√	√
2014	Expedition EL	5.4L	3V	GPSM	√	√	√	√
2014	Expedition EL	5.4L	3V	HVAC	√	√	√	√
2014	Expedition EL	5.4L	3V	IC	√	√	√	√
2014	Expedition EL	5.4L	3V	LTM	√	√	√	√
2014	Expedition EL	5.4L	3V	PAM	√	√	√	√
2014	Expedition EL	5.4L	3V	PCM	√	√	√	√
2014	Expedition EL	5.4L	3V	PRB	√	√	√	√
2014	Expedition EL	5.4L	3V	RCM	√	√	√	√

2014	Expedition EL	5.4L	3V	RCU	√	√	√	√
2014	Expedition EL	5.4L	3V	SDARS	√	√	√	√
2014	Expedition EL	5.4L	3V	TBC	√	√	√	√
2014	Expedition EL	5.4L	3V	TCCM	√	√	√	√
2014	Expedition EL	5.4L	3V	VDM	√	√	√	√
1996	Explorer	4.0L	Other	ABS/TCS	√	√	√	√
1996	Explorer	4.0L	Other	ARC	√	√	√	
1996	Explorer	4.0L	Other	EATC	√	√	√	
1996	Explorer	4.0L	Other	GEM	√	√	√	√
1996	Explorer	4.0L	Other	IAB	√	√	√	
1996	Explorer	4.0L	Other	PCM	√	√	√	√
1996	Explorer	4.0L	Other	RAP	√	√	√	√
1996	Explorer	4.0L	V6 OHV	ABS/TCS	√	√	√	√
1996	Explorer	4.0L	V6 OHV	ARC	√	√	√	
1996	Explorer	4.0L	V6 OHV	EATC	√	√	√	
1996	Explorer	4.0L	V6 OHV	GEM	√	√	√	√
1996	Explorer	4.0L	V6 OHV	IAB	√	√	√	
1996	Explorer	4.0L	V6 OHV	PCM	√	√	√	√
1996	Explorer	4.0L	V6 OHV	RAP	√	√	√	√
1996	Explorer	5.0L	Other	ABS/TCS	√	√	√	√
1996	Explorer	5.0L	Other	EATC	√	√	√	√
1996	Explorer	5.0L	Other	GEM	√	√	√	√
1996	Explorer	5.0L	Other	IAB	√	√	√	
1996	Explorer	5.0L	Other	PCM	√	√	√	√
1996	Explorer	5.0L	Other	RAP	√	√	√	√
1997	Explorer	4.0L	Other	ABS/TCS	√	√	√	√
1997	Explorer	4.0L	Other	ARC	√	√	√	
1997	Explorer	4.0L	Other	EATC	√	√	√	
1997	Explorer	4.0L	Other	GEM	√	√	√	√
1997	Explorer	4.0L	Other	IAB	√	√	√	
1997	Explorer	4.0L	Other	PCM	√	√	√	√
1997	Explorer	4.0L	Other	RAP	√	√	√	√
1997	Explorer	4.0L	V6 OHV	ABS/TCS	√	√	√	√
1997	Explorer	4.0L	V6 OHV	ARC	√	√	√	
1997	Explorer	4.0L	V6 OHV	EATC	√	√	√	
1997	Explorer	4.0L	V6 OHV	GEM	√	√	√	√
1997	Explorer	4.0L	V6 OHV	IAB	√	√	√	
1997	Explorer	4.0L	V6 OHV	PCM	√	√	√	√
1997	Explorer	4.0L	V6 OHV	RAP	√	√	√	√
1997	Explorer	4.0L	V6 SOHC	ARC	√	√	√	
1997	Explorer	4.0L	V6 SOHC	EATC	√	√	√	
1997	Explorer	4.0L	V6 SOHC	GEM	√	√	√	√
1997	Explorer	4.0L	V6 SOHC	IAB	√	√	√	
1997	Explorer	4.0L	V6 SOHC	PCM	√	√	√	√
1997	Explorer	4.0L	V6 SOHC	RAP	√	√	√	√

1997	Explorer	5.0L	Other	ABS/TCS	√	√	√	√
1997	Explorer	5.0L	Other	ARC	√	√	√	
1997	Explorer	5.0L	Other	ARC	√	√	√	
1997	Explorer	5.0L	Other	EATC	√	√	√	
1997	Explorer	5.0L	Other	GEM	√	√	√	√
1997	Explorer	5.0L	Other	IAB	√	√	√	
1997	Explorer	5.0L	Other	PCM	√	√	√	√
1997	Explorer	5.0L	Other	RAP	√	√	√	√
1998	Explorer	4.0L	Other	ABS/TCS	√	√	√	√
1998	Explorer	4.0L	Other	ARC	√	√	√	√
1998	Explorer	4.0L	Other	DSM	√	√	√	√
1998	Explorer	4.0L	Other	EATC	√	√	√	√
1998	Explorer	4.0L	Other	GEM	√	√	√	√
1998	Explorer	4.0L	Other	IAB	√	√	√	√
1998	Explorer	4.0L	Other	PAM	√	√	√	√
1998	Explorer	4.0L	Other	PATS	√	√	√	√
1998	Explorer	4.0L	Other	PCM	√	√	√	√
1998	Explorer	4.0L	Other	RAP	√	√	√	√
1998	Explorer	4.0L	V6 OHV	ABS/TCS	√	√	√	√
1998	Explorer	4.0L	V6 OHV	ARC	√	√	√	√
1998	Explorer	4.0L	V6 OHV	DSM	√	√	√	√
1998	Explorer	4.0L	V6 OHV	EATC	√	√	√	√
1998	Explorer	4.0L	V6 OHV	GEM	√	√	√	√
1998	Explorer	4.0L	V6 OHV	IAB	√	√	√	√
1998	Explorer	4.0L	V6 OHV	PAM	√	√	√	√
1998	Explorer	4.0L	V6 OHV	PATS	√	√	√	√
1998	Explorer	4.0L	V6 OHV	PCM	√	√	√	√
1998	Explorer	4.0L	V6 OHV	RAP	√	√	√	√
1998	Explorer	4.0L	V6 SOHC	ABS/TCS	√	√	√	√
1998	Explorer	4.0L	V6 SOHC	ARC	√	√	√	√
1998	Explorer	4.0L	V6 SOHC	DSM	√	√	√	√
1998	Explorer	4.0L	V6 SOHC	EATC	√	√	√	√
1998	Explorer	4.0L	V6 SOHC	GEM	√	√	√	√
1998	Explorer	4.0L	V6 SOHC	IAB	√	√	√	√
1998	Explorer	4.0L	V6 SOHC	PAM	√	√	√	√
1998	Explorer	4.0L	V6 SOHC	PATS	√	√	√	√
1998	Explorer	4.0L	V6 SOHC	PCM	√	√	√	√
1998	Explorer	4.0L	V6 SOHC	RAP	√	√	√	√
1998	Explorer	5.0L	Other	ABS/TCS	√	√	√	√
1998	Explorer	5.0L	Other	ARC	√	√	√	√
1998	Explorer	5.0L	Other	DSM	√	√	√	√
1998	Explorer	5.0L	Other	EATC	√	√	√	√
1998	Explorer	5.0L	Other	GEM	√	√	√	√
1998	Explorer	5.0L	Other	IAB	√	√	√	√
1998	Explorer	5.0L	Other	PAM	√	√	√	√

1998	Explorer	5.0L	Other	PATS	√	√	√	√
1998	Explorer	5.0L	Other	PCM	√	√	√	√
1998	Explorer	5.0L	Other	RAP	√	√	√	√
1999	Explorer	4.0L	Other	ABS/TCS	√	√	√	√
1999	Explorer	4.0L	Other	ARC	√	√	√	√
1999	Explorer	4.0L	Other	DSM	√	√	√	√
1999	Explorer	4.0L	Other	EATC	√	√	√	√
1999	Explorer	4.0L	Other	GEM	√	√	√	√
1999	Explorer	4.0L	Other	PAM	√	√	√	√
1999	Explorer	4.0L	Other	PATS	√	√	√	√
1999	Explorer	4.0L	Other	PCM	√	√	√	√
1999	Explorer	4.0L	Other	PCM	√	√	√	√
1999	Explorer	4.0L	Other	RAP	√	√	√	√
1999	Explorer	4.0L	Other	RCM	√	√	√	√
1999	Explorer	4.0L	V6 OHV	ABS/TCS	√	√	√	√
1999	Explorer	4.0L	V6 OHV	ARC	√	√	√	√
1999	Explorer	4.0L	V6 OHV	DSM	√	√	√	√
1999	Explorer	4.0L	V6 OHV	EATC	√	√	√	√
1999	Explorer	4.0L	V6 OHV	GEM	√	√	√	√
1999	Explorer	4.0L	V6 OHV	PAM	√	√	√	√
1999	Explorer	4.0L	V6 OHV	PATS	√	√	√	√
1999	Explorer	4.0L	V6 OHV	PCM	√	√	√	√
1999	Explorer	4.0L	V6 OHV	RAP	√	√	√	√
1999	Explorer	4.0L	V6 OHV	RCM	√	√	√	√
1999	Explorer	4.0L	V6 SOHC	ABS/TCS	√	√	√	√
1999	Explorer	4.0L	V6 SOHC	ARC	√	√	√	√
1999	Explorer	4.0L	V6 SOHC	DSM	√	√	√	√
1999	Explorer	4.0L	V6 SOHC	EATC	√	√	√	√
1999	Explorer	4.0L	V6 SOHC	GEM	√	√	√	√
1999	Explorer	4.0L	V6 SOHC	MC	√	√	√	√
1999	Explorer	4.0L	V6 SOHC	PAM	√	√	√	√
1999	Explorer	4.0L	V6 SOHC	PATS	√	√	√	√
1999	Explorer	4.0L	V6 SOHC	PCM	√	√	√	√
1999	Explorer	4.0L	V6 SOHC	PCM	√	√	√	√
1999	Explorer	4.0L	V6 SOHC	RAP	√	√	√	√
1999	Explorer	5.0L	Other	ABS/TCS	√	√	√	√
1999	Explorer	5.0L	Other	ARC	√	√	√	√
1999	Explorer	5.0L	Other	DSM	√	√	√	√
1999	Explorer	5.0L	Other	EATC	√	√	√	√
1999	Explorer	5.0L	Other	GEM	√	√	√	√
1999	Explorer	5.0L	Other	GEM	√	√	√	√
1999	Explorer	5.0L	Other	PAM	√	√	√	√
1999	Explorer	5.0L	Other	PATS	√	√	√	√
1999	Explorer	5.0L	Other	PCM	√	√	√	√
1999	Explorer	5.0L	Other	PCM	√	√	√	√



1999	Explorer	5.0L	Other	RAP	√	√	√	√
1999	Explorer	5.0L	Other	RAP	√	√	√	√
1999	Explorer	5.0L	Other	RCM	√	√	√	√
2000	Explorer	4.0L	Other	ABS/TCS	√	√	√	√
2000	Explorer	4.0L	Other	ARC	√	√	√	√
2000	Explorer	4.0L	Other	DSM	√	√	√	√
2000	Explorer	4.0L	Other	EATC	√	√	√	√
2000	Explorer	4.0L	Other	GEM	√	√	√	√
2000	Explorer	4.0L	Other	PAM	√	√	√	√
2000	Explorer	4.0L	Other	PATS	√	√	√	√
2000	Explorer	4.0L	Other	PCM	√	√	√	√
2000	Explorer	4.0L	Other	PCM	√	√	√	√
2000	Explorer	4.0L	Other	RAP	√	√	√	√
2000	Explorer	4.0L	Other	RCM	√	√	√	√
2000	Explorer	4.0L	V6 SOHC	ABS/TCS	√	√	√	√
2000	Explorer	4.0L	V6 SOHC	ARC	√	√	√	√
2000	Explorer	4.0L	V6 SOHC	DSM	√	√	√	√
2000	Explorer	4.0L	V6 SOHC	EATC	√	√	√	√
2000	Explorer	4.0L	V6 SOHC	GEM	√	√	√	√
2000	Explorer	4.0L	V6 SOHC	PAM	√	√	√	√
2000	Explorer	4.0L	V6 SOHC	PATS	√	√	√	√
2000	Explorer	4.0L	V6 SOHC	PCM	√	√	√	√
2000	Explorer	4.0L	V6 SOHC	RAP	√	√	√	√
2000	Explorer	4.0L	V6 SOHC	RCM	√	√	√	√
2000	Explorer	5.0L	Other	ABS/TCS	√	√	√	√
2000	Explorer	5.0L	Other	ABS/TCS	√	√	√	√
2000	Explorer	5.0L	Other	ARC	√	√	√	√
2000	Explorer	5.0L	Other	DSM	√	√	√	√
2000	Explorer	5.0L	Other	EATC	√	√	√	√
2000	Explorer	5.0L	Other	GEM	√	√	√	√
2000	Explorer	5.0L	Other	GEM	√	√	√	√
2000	Explorer	5.0L	Other	PAM	√	√	√	√
2000	Explorer	5.0L	Other	PATS	√	√	√	√
2000	Explorer	5.0L	Other	PCM	√	√	√	√
2000	Explorer	5.0L	Other	PCM	√	√	√	√
2000	Explorer	5.0L	Other	RAP	√	√	√	√
2000	Explorer	5.0L	Other	RAP	√	√	√	√
2000	Explorer	5.0L	Other	RCM	√	√	√	√
2002	Explorer	4.0L	V6 SOHC	4X4	√	√	√	√
2002	Explorer	4.0L	V6 SOHC	ABS/TCS	√	√	√	√
2002	Explorer	4.0L	V6 SOHC	CSM	√	√	√	√
2002	Explorer	4.0L	V6 SOHC	DSM	√	√	√	√
2002	Explorer	4.0L	V6 SOHC	EATC	√	√	√	√
2002	Explorer	4.0L	V6 SOHC	GEM	√	√	√	√
2002	Explorer	4.0L	V6 SOHC	IC	√	√	√	√

2002	Explorer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓
2002	Explorer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2002	Explorer	4.0L	V6 SOHC	RCM	✓	✓	✓	
2002	Explorer	4.6L	2V	4X4	✓	✓	✓	✓
2002	Explorer	4.6L	2V	ABS/TCS	✓	✓	✓	✓
2002	Explorer	4.6L	2V	CSM	✓	✓	✓	✓
2002	Explorer	4.6L	2V	DSM	✓	✓	✓	✓
2002	Explorer	4.6L	2V	EATC	✓	✓	✓	✓
2002	Explorer	4.6L	2V	GEM	✓	✓	✓	✓
2002	Explorer	4.6L	2V	IC	✓	✓	✓	✓
2002	Explorer	4.6L	2V	PAM	✓	✓	✓	✓
2002	Explorer	4.6L	2V	PCM	✓	✓	✓	✓
2002	Explorer	4.6L	2V	RCM	✓	✓	✓	
2002.5	Explorer	4.0L	V6 SOHC	4X4	✓	✓	✓	✓
2002.5	Explorer	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓
2002.5	Explorer	4.0L	V6 SOHC	CSM	✓	✓	✓	✓
2002.5	Explorer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓
2002.5	Explorer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓
2002.5	Explorer	4.0L	V6 SOHC	HEC	✓	✓	✓	✓
2002.5	Explorer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓
2002.5	Explorer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2002.5	Explorer	4.0L	V6 SOHC	RCM	✓	✓	✓	✓
2002.5	Explorer	4.0L	V6 SOHC	TPM	✓	✓	✓	✓
2002.5	Explorer	4.6L	2V	4X4	✓	✓	✓	✓
2002.5	Explorer	4.6L	2V	ABS/TCS	✓	✓	✓	✓
2002.5	Explorer	4.6L	2V	CSM	✓	✓	✓	✓
2002.5	Explorer	4.6L	2V	DSM	✓	✓	✓	✓
2002.5	Explorer	4.6L	2V	HEC	✓	✓	✓	✓
2002.5	Explorer	4.6L	2V	PAM	✓	✓	✓	✓
2002.5	Explorer	4.6L	2V	PCM	✓	✓	✓	✓
2002.5	Explorer	4.6L	2V	RCM	✓	✓	✓	✓
2002.5	Explorer	4.6L	2V	TPM	✓	✓	✓	✓
2003	Explorer	4.0L	V6 SOHC	4X4	✓	✓	✓	✓
2003	Explorer	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓
2003	Explorer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓
2003	Explorer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓
2003	Explorer	4.0L	V6 SOHC	HEC	✓	✓	✓	✓
2003	Explorer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓
2003	Explorer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2003	Explorer	4.0L	V6 SOHC	RCM	✓	✓	✓	✓
2003	Explorer	4.0L	V6 SOHC	TPM	✓	✓	✓	✓
2003	Explorer	4.0L	V6 SOHC	VSM	✓	✓	✓	✓
2003	Explorer	4.6L	2V	4X4	✓	✓	✓	✓
2003	Explorer	4.6L	2V	ABS/TCS	✓	✓	✓	✓
2003	Explorer	4.6L	2V	DSM	✓	✓	✓	✓

2003	Explorer	4.6L	2V	EATC	✓	✓	✓	✓
2003	Explorer	4.6L	2V	HEC	✓	✓	✓	✓
2003	Explorer	4.6L	2V	PAM	✓	✓	✓	✓
2003	Explorer	4.6L	2V	PCM	✓	✓	✓	✓
2003	Explorer	4.6L	2V	RCM	✓	✓	✓	✓
2003	Explorer	4.6L	2V	TPM	✓	✓	✓	✓
2003	Explorer	4.6L	2V	VSM	✓	✓	✓	✓
2004	Explorer	4.0L	V6 SOHC	4X4	✓	✓	✓	✓
2004	Explorer	4.0L	V6 SOHC	ABS	✓	✓	✓	✓
2004	Explorer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓
2004	Explorer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓
2004	Explorer	4.0L	V6 SOHC	IC	✓	✓	✓	✓
2004	Explorer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓
2004	Explorer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2004	Explorer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2004	Explorer	4.0L	V6 SOHC	RCM	✓	✓	✓	✓
2004	Explorer	4.0L	V6 SOHC	TPM	✓	✓	✓	✓
2004	Explorer	4.0L	V6 SOHC	VSM	✓	✓	✓	✓
2004	Explorer	4.6L	2V	4X4	✓	✓	✓	✓
2004	Explorer	4.6L	2V	ABS	✓	✓	✓	✓
2004	Explorer	4.6L	2V	DSM	✓	✓	✓	✓
2004	Explorer	4.6L	2V	EATC	✓	✓	✓	✓
2004	Explorer	4.6L	2V	IC	✓	✓	✓	✓
2004	Explorer	4.6L	2V	PAM	✓	✓	✓	✓
2004	Explorer	4.6L	2V	PCM	✓	✓	✓	✓
2004	Explorer	4.6L	2V	RCM	✓	✓	✓	✓
2004	Explorer	4.6L	2V	TPM	✓	✓	✓	✓
2004	Explorer	4.6L	2V	VSM	✓	✓	✓	✓
2005	Explorer	4.0L	V6 SOHC	4X4	✓	✓	✓	✓
2005	Explorer	4.0L	V6 SOHC	4X4	✓	✓	✓	✓
2005	Explorer	4.0L	V6 SOHC	ABS	✓	✓	✓	✓
2005	Explorer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓
2005	Explorer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓
2005	Explorer	4.0L	V6 SOHC	IC	✓	✓	✓	✓
2005	Explorer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓
2005	Explorer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2005	Explorer	4.0L	V6 SOHC	RCM	✓	✓	✓	✓
2005	Explorer	4.0L	V6 SOHC	TPM	✓	✓	✓	✓
2005	Explorer	4.0L	V6 SOHC	VSM	✓	✓	✓	✓
2005	Explorer	4.6L	2V	4X4	✓	✓	✓	✓
2005	Explorer	4.6L	2V	ABS	✓	✓	✓	✓
2005	Explorer	4.6L	2V	DSM	✓	✓	✓	✓
2005	Explorer	4.6L	2V	EATC	✓	✓	✓	✓
2005	Explorer	4.6L	2V	IC	✓	✓	✓	✓
2005	Explorer	4.6L	2V	PAM	✓	✓	✓	✓

2005	Explorer	4.6L	2V	PCM	✓	✓	✓	✓
2005	Explorer	4.6L	2V	RCM	✓	✓	✓	✓
2005	Explorer	4.6L	2V	TPM	✓	✓	✓	✓
2005	Explorer	4.6L	2V	VSM	✓	✓	✓	✓
2006	Explorer	4.0L	2V	4X4	✓	✓	✓	✓
2006	Explorer	4.0L	2V	ABS	✓	✓	✓	✓
2006	Explorer	4.0L	2V	ABS	✓	✓	✓	✓
2006	Explorer	4.0L	2V	ACM	✓	✓	✓	✓
2006	Explorer	4.0L	2V	ACM	✓	✓	✓	✓
2006	Explorer	4.0L	2V	DSM	✓	✓	✓	✓
2006	Explorer	4.0L	2V	EATC	✓	✓	✓	✓
2006	Explorer	4.0L	2V	GEM	✓	✓	✓	✓
2006	Explorer	4.0L	2V	GEM	✓	✓	✓	✓
2006	Explorer	4.0L	2V	IC	✓	✓	✓	✓
2006	Explorer	4.0L	2V	IC	✓	✓	✓	✓
2006	Explorer	4.0L	2V	OCSM	✓	✓	✓	✓
2006	Explorer	4.0L	2V	PAM	✓	✓	✓	✓
2006	Explorer	4.0L	2V	PCM	✓	✓	✓	✓
2006	Explorer	4.0L	2V	PCM	✓	✓	✓	✓
2006	Explorer	4.0L	2V	RCM	✓	✓	✓	✓
2006	Explorer	4.0L	2V	RCM	✓	✓	✓	✓
2006	Explorer	4.0L	2V	RETM	✓	✓	✓	✓
2006	Explorer	4.0L	2V	RETM	✓	✓	✓	✓
2006	Explorer	4.0L	2V	SDARS	✓	✓	✓	✓
2006	Explorer	4.0L	2V	SDARS	✓	✓	✓	✓
2006	Explorer	4.6L	3V	4X4	✓	✓	✓	✓
2006	Explorer	4.6L	3V	4X4	✓	✓	✓	✓
2006	Explorer	4.6L	3V	ABS	✓	✓	✓	✓
2006	Explorer	4.6L	3V	ABS	✓	✓	✓	✓
2006	Explorer	4.6L	3V	ACM	✓	✓	✓	✓
2006	Explorer	4.6L	3V	ACM	✓	✓	✓	✓
2006	Explorer	4.6L	3V	DSM	✓	✓	✓	✓
2006	Explorer	4.6L	3V	EATC	✓	✓	✓	✓
2006	Explorer	4.6L	3V	EATC	✓	✓	✓	✓
2006	Explorer	4.6L	3V	GEM	✓	✓	✓	✓
2006	Explorer	4.6L	3V	GEM	✓	✓	✓	✓
2006	Explorer	4.6L	3V	IC	✓	✓	✓	✓
2006	Explorer	4.6L	3V	OCSM	✓	✓	✓	✓
2006	Explorer	4.6L	3V	OCSM	✓	✓	✓	✓
2006	Explorer	4.6L	3V	PAM	✓	✓	✓	✓
2006	Explorer	4.6L	3V	PAM	✓	✓	✓	✓
2006	Explorer	4.6L	3V	PCM	✓	✓	✓	✓
2006	Explorer	4.6L	3V	PCM	✓	✓	✓	✓
2006	Explorer	4.6L	3V	PCM	✓	✓	✓	✓
2006	Explorer	4.6L	3V	PRB	✓	✓	✓	✓

2006	Explorer	4.6L	3V	RCM	√	√	√	√
2006	Explorer	4.6L	3V	RCM	√	√	√	√
2006	Explorer	4.6L	3V	RETM	√	√	√	√
2006	Explorer	4.6L	3V	RETM	√	√	√	√
2006	Explorer	4.6L	3V	SDARS	√	√	√	√
2006	Explorer	4.6L	3V	SDARS	√	√	√	√
2006	Explorer	4.6L	3V	TCM	√	√	√	√
2006	Explorer	4.6L	3V	TCM	√	√	√	√
2007	Explorer	4.0L	2V	4X4	√	√	√	√
2007	Explorer	4.0L	2V	ABS	√	√	√	√
2007	Explorer	4.0L	2V	ACM	√	√	√	√
2007	Explorer	4.0L	2V	DSM	√	√	√	√
2007	Explorer	4.0L	2V	EATC	√	√	√	√
2007	Explorer	4.0L	2V	GEM	√	√	√	√
2007	Explorer	4.0L	2V	IC	√	√	√	√
2007	Explorer	4.0L	2V	OCSM	√	√	√	√
2007	Explorer	4.0L	2V	PAM	√	√	√	√
2007	Explorer	4.0L	2V	PCM	√	√	√	√
2007	Explorer	4.0L	2V	PCM	√	√	√	√
2007	Explorer	4.0L	2V	PRB	√	√	√	√
2007	Explorer	4.0L	2V	RCM	√	√	√	√
2007	Explorer	4.0L	2V	RETM	√	√	√	
2007	Explorer	4.0L	2V	SDARS	√	√	√	√
2007	Explorer	4.6L	3V	4X4	√	√	√	√
2007	Explorer	4.6L	3V	4X4	√	√	√	√
2007	Explorer	4.6L	3V	ABS	√	√	√	√
2007	Explorer	4.6L	3V	ABS	√	√	√	√
2007	Explorer	4.6L	3V	ACM	√	√	√	√
2007	Explorer	4.6L	3V	ACM	√	√	√	√
2007	Explorer	4.6L	3V	DSM	√	√	√	√
2007	Explorer	4.6L	3V	EATC	√	√	√	√
2007	Explorer	4.6L	3V	EATC	√	√	√	√
2007	Explorer	4.6L	3V	GEM	√	√	√	√
2007	Explorer	4.6L	3V	GEM	√	√	√	√
2007	Explorer	4.6L	3V	IC	√	√	√	√
2007	Explorer	4.6L	3V	IC	√	√	√	√
2007	Explorer	4.6L	3V	OCSM	√	√	√	√
2007	Explorer	4.6L	3V	OCSM	√	√	√	√
2007	Explorer	4.6L	3V	PAM	√	√	√	√
2007	Explorer	4.6L	3V	PAM	√	√	√	√
2007	Explorer	4.6L	3V	PCM	√	√	√	√
2007	Explorer	4.6L	3V	PCM	√	√	√	√
2007	Explorer	4.6L	3V	PCM	√	√	√	√
2007	Explorer	4.6L	3V	PRB	√	√	√	√
2007	Explorer	4.6L	3V	RCM	√	√	√	√

2007	Explorer	4.6L	3V	RCM	√	√	√	√
2007	Explorer	4.6L	3V	RETM	√	√	√	
2007	Explorer	4.6L	3V	RETM	√	√	√	
2007	Explorer	4.6L	3V	SDARS	√	√	√	√
2007	Explorer	4.6L	3V	SDARS	√	√	√	√
2007	Explorer	4.6L	3V	TCM	√	√	√	√
2007	Explorer	4.6L	3V	TCM	√	√	√	√
2008	Explorer	4.0L	2V	4X4	√	√	√	√
2008	Explorer	4.0L	2V	4X4	√	√	√	√
2008	Explorer	4.0L	2V	ABS	√	√	√	√
2008	Explorer	4.0L	2V	APIM	√	√	√	√
2008	Explorer	4.0L	2V	DSM	√	√	√	√
2008	Explorer	4.0L	2V	GEM / SJB	√	√	√	√
2008	Explorer	4.0L	2V	HVAC	√	√	√	√
2008	Explorer	4.0L	2V	IC	√	√	√	√
2008	Explorer	4.0L	2V	OCSM	√	√	√	√
2008	Explorer	4.0L	2V	PAM	√	√	√	√
2008	Explorer	4.0L	2V	PCM	√	√	√	√
2008	Explorer	4.0L	2V	PRB	√	√	√	√
2008	Explorer	4.0L	2V	RCM	√	√	√	√
2008	Explorer	4.0L	2V	RETM	√	√	√	
2008	Explorer	4.0L	2V	SDARS	√	√	√	√
2008	Explorer	4.6L	3V	4X4	√	√	√	√
2008	Explorer	4.6L	3V	4X4	√	√	√	√
2008	Explorer	4.6L	3V	ABS	√	√	√	√
2008	Explorer	4.6L	3V	ABS	√	√	√	√
2008	Explorer	4.6L	3V	ACM	√	√	√	√
2008	Explorer	4.6L	3V	ACM	√	√	√	√
2008	Explorer	4.6L	3V	APIM	√	√	√	√
2008	Explorer	4.6L	3V	APIM	√	√	√	√
2008	Explorer	4.6L	3V	DSM	√	√	√	√
2008	Explorer	4.6L	3V	DSM	√	√	√	√
2008	Explorer	4.6L	3V	GEM / SJB	√	√	√	√
2008	Explorer	4.6L	3V	GEM / SJB	√	√	√	√
2008	Explorer	4.6L	3V	GEM / SJB	√	√	√	√
2008	Explorer	4.6L	3V	HVAC	√	√	√	√
2008	Explorer	4.6L	3V	IC	√	√	√	√
2008	Explorer	4.6L	3V	OCSM	√	√	√	√
2008	Explorer	4.6L	3V	OCSM	√	√	√	√
2008	Explorer	4.6L	3V	OCSM	√	√	√	√
2008	Explorer	4.6L	3V	PAM	√	√	√	√
2008	Explorer	4.6L	3V	PCM	√	√	√	√
2008	Explorer	4.6L	3V	PCM	√	√	√	√
2008	Explorer	4.6L	3V	PCM	√	√	√	√
2008	Explorer	4.6L	3V	PRB	√	√	√	√

2008	Explorer	4.6L	3V	RCM	✓	✓	✓	✓
2008	Explorer	4.6L	3V	RCM	✓	✓	✓	✓
2008	Explorer	4.6L	3V	RETM	✓	✓	✓	
2008	Explorer	4.6L	3V	RETM	✓	✓	✓	
2008	Explorer	4.6L	3V	SDARS	✓	✓	✓	✓
2008	Explorer	4.6L	3V	TCM	✓	✓	✓	✓
2008	Explorer	4.6L	3V	TCM	✓	✓	✓	✓
2009	Explorer	4.0L	2V	4X4	✓	✓	✓	✓
2009	Explorer	4.0L	2V	4X4	✓	✓	✓	✓
2009	Explorer	4.0L	2V	ABS	✓	✓	✓	✓
2009	Explorer	4.0L	2V	ABS	✓	✓	✓	✓
2009	Explorer	4.0L	2V	ACM	✓	✓	✓	
2009	Explorer	4.0L	2V	ACM	✓	✓	✓	✓
2009	Explorer	4.0L	2V	APIM	✓	✓	✓	
2009	Explorer	4.0L	2V	DSM	✓	✓	✓	✓
2009	Explorer	4.0L	2V	DSM	✓	✓	✓	✓
2009	Explorer	4.0L	2V	GEM / SJB	✓	✓	✓	✓
2009	Explorer	4.0L	2V	GEM / SJB	✓	✓	✓	✓
2009	Explorer	4.0L	2V	HVAC	✓	✓	✓	✓
2009	Explorer	4.0L	2V	HVAC	✓	✓	✓	✓
2009	Explorer	4.0L	2V	IC	✓	✓	✓	✓
2009	Explorer	4.0L	2V	IC	✓	✓	✓	✓
2009	Explorer	4.0L	2V	OCSM	✓	✓	✓	✓
2009	Explorer	4.0L	2V	PAM	✓	✓	✓	✓
2009	Explorer	4.0L	2V	PCM	✓	✓	✓	✓
2009	Explorer	4.0L	2V	PCM	✓	✓	✓	✓
2009	Explorer	4.0L	2V	PRB	✓	✓	✓	✓
2009	Explorer	4.0L	2V	RCM	✓	✓	✓	✓
2009	Explorer	4.0L	2V	RCM	✓	✓	✓	✓
2009	Explorer	4.0L	2V	RETM	✓	✓	✓	✓
2009	Explorer	4.0L	2V	RETM	✓	✓	✓	✓
2009	Explorer	4.0L	2V	SDARS	✓	✓	✓	✓
2009	Explorer	4.0L	2V	SDARS	✓	✓	✓	✓
2009	Explorer	4.6L	3V	4X4	✓	✓	✓	✓
2009	Explorer	4.6L	3V	ABS	✓	✓	✓	✓
2009	Explorer	4.6L	3V	ABS	✓	✓	✓	✓
2009	Explorer	4.6L	3V	ACM	✓	✓	✓	
2009	Explorer	4.6L	3V	ACM	✓	✓	✓	
2009	Explorer	4.6L	3V	ACM	✓	✓	✓	✓
2009	Explorer	4.6L	3V	ACM	✓	✓	✓	✓
2009	Explorer	4.6L	3V	APIM	✓	✓	✓	
2009	Explorer	4.6L	3V	APIM	✓	✓	✓	
2009	Explorer	4.6L	3V	DSM	✓	✓	✓	✓
2009	Explorer	4.6L	3V	DSM	✓	✓	✓	✓
2009	Explorer	4.6L	3V	GEM / SJB	✓	✓	✓	✓

2009	Explorer	4.6L	3V	HVAC	√	√	√	√
2009	Explorer	4.6L	3V	HVAC	√	√	√	√
2009	Explorer	4.6L	3V	IC	√	√	√	√
2009	Explorer	4.6L	3V	IC	√	√	√	√
2009	Explorer	4.6L	3V	OCSM	√	√	√	√
2009	Explorer	4.6L	3V	OCSM	√	√	√	√
2009	Explorer	4.6L	3V	PAM	√	√	√	√
2009	Explorer	4.6L	3V	PCM	√	√	√	√
2009	Explorer	4.6L	3V	PCM	√	√	√	√
2009	Explorer	4.6L	3V	PRB	√	√	√	√
2009	Explorer	4.6L	3V	RCM	√	√	√	√
2009	Explorer	4.6L	3V	RCM	√	√	√	√
2009	Explorer	4.6L	3V	RETM	√	√	√	√
2009	Explorer	4.6L	3V	RETM	√	√	√	√
2009	Explorer	4.6L	3V	SDARS	√	√	√	√
2009	Explorer	4.6L	3V	TCM	√	√	√	√
2009	Explorer	4.6L	3V	TCM	√	√	√	√
2010	Explorer	4.0L	2V	4X4	√	√	√	√
2010	Explorer	4.0L	2V	4X4	√	√	√	√
2010	Explorer	4.0L	2V	ABS	√	√	√	√
2010	Explorer	4.0L	2V	ACM	√	√	√	
2010	Explorer	4.0L	2V	ACM	√	√	√	√
2010	Explorer	4.0L	2V	APIM	√	√	√	
2010	Explorer	4.0L	2V	DSM	√	√	√	√
2010	Explorer	4.0L	2V	GEM / SJB	√	√	√	√
2010	Explorer	4.0L	2V	GPSM	√	√	√	√
2010	Explorer	4.0L	2V	HVAC	√	√	√	√
2010	Explorer	4.0L	2V	IC	√	√	√	√
2010	Explorer	4.0L	2V	OCSM	√	√	√	√
2010	Explorer	4.0L	2V	PAM	√	√	√	√
2010	Explorer	4.0L	2V	PCM	√	√	√	√
2010	Explorer	4.0L	2V	PCM	√	√	√	√
2010	Explorer	4.0L	2V	PRB	√	√	√	√
2010	Explorer	4.0L	2V	RCM	√	√	√	√
2010	Explorer	4.0L	2V	RETM	√	√	√	√
2010	Explorer	4.0L	2V	SDARS	√	√	√	√
2010	Explorer	4.6L	3V	4X4	√	√	√	√
2010	Explorer	4.6L	3V	ABS	√	√	√	√
2010	Explorer	4.6L	3V	ABS	√	√	√	√
2010	Explorer	4.6L	3V	ACM	√	√	√	
2010	Explorer	4.6L	3V	ACM	√	√	√	
2010	Explorer	4.6L	3V	ACM	√	√	√	√
2010	Explorer	4.6L	3V	ACM	√	√	√	√
2010	Explorer	4.6L	3V	APIM	√	√	√	
2010	Explorer	4.6L	3V	APIM	√	√	√	



2010	Explorer	4.6L	3V	DSM	√	√	√	√
2010	Explorer	4.6L	3V	DSM	√	√	√	√
2010	Explorer	4.6L	3V	GEM / SJB	√	√	√	√
2010	Explorer	4.6L	3V	GEM / SJB	√	√	√	√
2010	Explorer	4.6L	3V	GPSM	√	√	√	√
2010	Explorer	4.6L	3V	HVAC	√	√	√	√
2010	Explorer	4.6L	3V	HVAC	√	√	√	√
2010	Explorer	4.6L	3V	IC	√	√	√	√
2010	Explorer	4.6L	3V	IC	√	√	√	√
2010	Explorer	4.6L	3V	OCSM	√	√	√	√
2010	Explorer	4.6L	3V	OCSM	√	√	√	√
2010	Explorer	4.6L	3V	PAM	√	√	√	√
2010	Explorer	4.6L	3V	PCM	√	√	√	√
2010	Explorer	4.6L	3V	PCM	√	√	√	√
2010	Explorer	4.6L	3V	PRB	√	√	√	√
2010	Explorer	4.6L	3V	RCM	√	√	√	√
2010	Explorer	4.6L	3V	RETM	√	√	√	√
2010	Explorer	4.6L	3V	RETM	√	√	√	√
2010	Explorer	4.6L	3V	SDARS	√	√	√	√
2010	Explorer	4.6L	3V	TCM	√	√	√	√
2010	Explorer	4.6L	3V	TCM	√	√	√	√
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	ATCM	√	√	√	√
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	C-CM	√	√	√	√
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	CLM#1	√	√	√	√
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	DCSM	√	√	√	√
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	DSM	√	√	√	√
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	DSP	√	√	√	
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	FCDIM	√	√	√	√
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	√
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	FLM	√	√	√	√
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	√
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	HSWM	√	√	√	√
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	HUD	√	√	√	√
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	√
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	LTM	√	√	√	√
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	OCSM	√	√	√	√
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	√

2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A	√	√	√	√
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	SCCM	√	√	√	√
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	√
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	TCM	√	√	√	√
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	TPM	√	√	√	√
2011	Explorer	3.5L	TiVCT	ABS	√	√	√	√
2011	Explorer	3.5L	TiVCT	ACM	√	√	√	√
2011	Explorer	3.5L	TiVCT	APIM	√	√	√	√
2011	Explorer	3.5L	TiVCT	ATCM	√	√	√	√
2011	Explorer	3.5L	TiVCT	BCM#1	√	√	√	√
2011	Explorer	3.5L	TiVCT	C-CM	√	√	√	√
2011	Explorer	3.5L	TiVCT	CLM#1	√	√	√	√
2011	Explorer	3.5L	TiVCT	DCSM	√	√	√	√
2011	Explorer	3.5L	TiVCT	DSM	√	√	√	√
2011	Explorer	3.5L	TiVCT	FCDIM	√	√	√	√
2011	Explorer	3.5L	TiVCT	FCIM	√	√	√	√
2011	Explorer	3.5L	TiVCT	FLM	√	√	√	√
2011	Explorer	3.5L	TiVCT	GPSM	√	√	√	√
2011	Explorer	3.5L	TiVCT	HSWM	√	√	√	√
2011	Explorer	3.5L	TiVCT	HUD	√	√	√	√
2011	Explorer	3.5L	TiVCT	HVAC	√	√	√	√
2011	Explorer	3.5L	TiVCT	IPC	√	√	√	√
2011	Explorer	3.5L	TiVCT	LTM	√	√	√	√
2011	Explorer	3.5L	TiVCT	OCSM	√	√	√	√
2011	Explorer	3.5L	TiVCT	PAM	√	√	√	√
2011	Explorer	3.5L	TiVCT	PCM	√	√	√	√
2011	Explorer	3.5L	TiVCT	PSCM	√	√	√	√
2011	Explorer	3.5L	TiVCT	RCM	√	√	√	√
2011	Explorer	3.5L	TiVCT	RFA	√	√	√	√
2011	Explorer	3.5L	TiVCT	RLCM-A	√	√	√	√
2011	Explorer	3.5L	TiVCT	SCCM	√	√	√	√
2011	Explorer	3.5L	TiVCT	SOD-L	√	√	√	√
2011	Explorer	3.5L	TiVCT	SOD-R	√	√	√	√
2011	Explorer	3.5L	TiVCT	TPM	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	ATCM	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	BCM#1	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	BCM#1	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	C-CM	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	C-CM	√	√	√	√

2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	CLM#1	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	DCSM	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	DSM	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	DSP	√	√	√	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	FCDIM	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	FLM	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	HUD	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	LTM	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	OCSM	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	RLCM-A	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	SCCM	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	TCM	√	√	√	√
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	TPM	√	√	√	√
2012	Explorer	3.5L	TiVCT	ABS	√	√	√	√
2012	Explorer	3.5L	TiVCT	ACM	√	√	√	√
2012	Explorer	3.5L	TiVCT	APIM	√	√	√	√
2012	Explorer	3.5L	TiVCT	ATCM	√	√	√	√
2012	Explorer	3.5L	TiVCT	BCM#1	√	√	√	√
2012	Explorer	3.5L	TiVCT	C-CM	√	√	√	√
2012	Explorer	3.5L	TiVCT	CLM#1	√	√	√	√
2012	Explorer	3.5L	TiVCT	DCSM	√	√	√	√
2012	Explorer	3.5L	TiVCT	DSM	√	√	√	√
2012	Explorer	3.5L	TiVCT	DSP	√	√	√	
2012	Explorer	3.5L	TiVCT	FCDIM	√	√	√	√
2012	Explorer	3.5L	TiVCT	FCIM	√	√	√	√
2012	Explorer	3.5L	TiVCT	FLM	√	√	√	√
2012	Explorer	3.5L	TiVCT	GPSM	√	√	√	√
2012	Explorer	3.5L	TiVCT	HUD	√	√	√	√
2012	Explorer	3.5L	TiVCT	HVAC	√	√	√	√
2012	Explorer	3.5L	TiVCT	IPC	√	√	√	√

2012	Explorer	3.5L	TiVCT	LTM	√	√	√	√
2012	Explorer	3.5L	TiVCT	OCSM	√	√	√	√
2012	Explorer	3.5L	TiVCT	PAM	√	√	√	√
2012	Explorer	3.5L	TiVCT	PCM	√	√	√	√
2012	Explorer	3.5L	TiVCT	PSCM	√	√	√	√
2012	Explorer	3.5L	TiVCT	RCM	√	√	√	√
2012	Explorer	3.5L	TiVCT	RFA	√	√	√	√
2012	Explorer	3.5L	TiVCT	RLCM-A	√	√	√	√
2012	Explorer	3.5L	TiVCT	SCCM	√	√	√	√
2012	Explorer	3.5L	TiVCT	SOD-L	√	√	√	√
2012	Explorer	3.5L	TiVCT	SOD-R	√	√	√	√
2012	Explorer	3.5L	TiVCT	TPM	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	ATCM	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	BCM#1	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	C-CM	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	CLM#1	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	DCSM	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	DSM	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	DSP	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	FCDIM	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	FLM	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	GFM	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	HSWM	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	HUD	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	IPM-A	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	IPM-A	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	LTM	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	OCSM	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	OCSM	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√

2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	RLCM-A	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	RTM	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	SCCM	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	TCM	√	√	√	√
2013	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	TCM	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	ATCM	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	BCM#1	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	BCM#1	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	C-CM	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	CLM#1	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	DCSM	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	DSM	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	DSP	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	FCDIM	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	FLM	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	GFM	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	HSWM	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HUD	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	IPM-A	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	LTM	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	OCSM	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	RLCM-A	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	RTM	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	SCCM	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	√
2013	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2013	Explorer	3.5L	TiVCT	ABS	√	√	√	√

2013	Explorer	3.5L	TiVCT	ABS	√	√	√	√
2013	Explorer	3.5L	TiVCT	ACM	√	√	√	√
2013	Explorer	3.5L	TiVCT	APIM	√	√	√	√
2013	Explorer	3.5L	TiVCT	ATCM	√	√	√	√
2013	Explorer	3.5L	TiVCT	BCM#1	√	√	√	√
2013	Explorer	3.5L	TiVCT	C-CM	√	√	√	√
2013	Explorer	3.5L	TiVCT	CLM#1	√	√	√	√
2013	Explorer	3.5L	TiVCT	DCSM	√	√	√	√
2013	Explorer	3.5L	TiVCT	DSM	√	√	√	√
2013	Explorer	3.5L	TiVCT	DSP	√	√	√	√
2013	Explorer	3.5L	TiVCT	FCDIM	√	√	√	√
2013	Explorer	3.5L	TiVCT	FCIM	√	√	√	√
2013	Explorer	3.5L	TiVCT	FLM	√	√	√	√
2013	Explorer	3.5L	TiVCT	GFM	√	√	√	√
2013	Explorer	3.5L	TiVCT	GPSM	√	√	√	√
2013	Explorer	3.5L	TiVCT	HSWM	√	√	√	√
2013	Explorer	3.5L	TiVCT	HUD	√	√	√	√
2013	Explorer	3.5L	TiVCT	HVAC	√	√	√	√
2013	Explorer	3.5L	TiVCT	IPC	√	√	√	√
2013	Explorer	3.5L	TiVCT	IPM-A	√	√	√	√
2013	Explorer	3.5L	TiVCT	LTM	√	√	√	√
2013	Explorer	3.5L	TiVCT	OCSM	√	√	√	√
2013	Explorer	3.5L	TiVCT	PAM	√	√	√	√
2013	Explorer	3.5L	TiVCT	PCM	√	√	√	√
2013	Explorer	3.5L	TiVCT	PSCM	√	√	√	√
2013	Explorer	3.5L	TiVCT	RCM	√	√	√	√
2013	Explorer	3.5L	TiVCT	RFA	√	√	√	√
2013	Explorer	3.5L	TiVCT	RLCM-A	√	√	√	√
2013	Explorer	3.5L	TiVCT	RTM	√	√	√	√
2013	Explorer	3.5L	TiVCT	SCCM	√	√	√	√
2013	Explorer	3.5L	TiVCT	SOD-L	√	√	√	√
2013	Explorer	3.5L	TiVCT	SOD-R	√	√	√	√
2013	Explorer	3.7L	TiVCT	ABS	√	√	√	√
2013	Explorer	3.7L	TiVCT	ABS	√	√	√	√
2013	Explorer	3.7L	TiVCT	ACM	√	√	√	√
2013	Explorer	3.7L	TiVCT	APIM	√	√	√	√
2013	Explorer	3.7L	TiVCT	ATCM	√	√	√	√
2013	Explorer	3.7L	TiVCT	BCM#1	√	√	√	√
2013	Explorer	3.7L	TiVCT	C-CM	√	√	√	√
2013	Explorer	3.7L	TiVCT	CLM#1	√	√	√	√
2013	Explorer	3.7L	TiVCT	DCSM	√	√	√	√
2013	Explorer	3.7L	TiVCT	DSM	√	√	√	√
2013	Explorer	3.7L	TiVCT	DSP	√	√	√	√
2013	Explorer	3.7L	TiVCT	FCDIM	√	√	√	√
2013	Explorer	3.7L	TiVCT	FCIM	√	√	√	√

2013	Explorer	3.7L	TiVCT	FLM	✓	✓	✓	✓
2013	Explorer	3.7L	TiVCT	GFM	✓	✓	✓	✓
2013	Explorer	3.7L	TiVCT	GPSM	✓	✓	✓	✓
2013	Explorer	3.7L	TiVCT	HSWM	✓	✓	✓	✓
2013	Explorer	3.7L	TiVCT	HUD	✓	✓	✓	✓
2013	Explorer	3.7L	TiVCT	HVAC	✓	✓	✓	✓
2013	Explorer	3.7L	TiVCT	IPC	✓	✓	✓	✓
2013	Explorer	3.7L	TiVCT	IPM-A	✓	✓	✓	✓
2013	Explorer	3.7L	TiVCT	LTM	✓	✓	✓	✓
2013	Explorer	3.7L	TiVCT	OCSM	✓	✓	✓	✓
2013	Explorer	3.7L	TiVCT	PAM	✓	✓	✓	✓
2013	Explorer	3.7L	TiVCT	PCM	✓	✓	✓	✓
2013	Explorer	3.7L	TiVCT	PSCM	✓	✓	✓	✓
2013	Explorer	3.7L	TiVCT	RCM	✓	✓	✓	✓
2013	Explorer	3.7L	TiVCT	RFA	✓	✓	✓	✓
2013	Explorer	3.7L	TiVCT	RLCM-A	✓	✓	✓	✓
2013	Explorer	3.7L	TiVCT	RTM	✓	✓	✓	✓
2013	Explorer	3.7L	TiVCT	SOD-L	✓	✓	✓	✓
2013	Explorer	3.7L	TiVCT	SOD-R	✓	✓	✓	✓
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	ABS	✓	✓	✓	✓
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	ACM	✓	✓	✓	✓
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	APIM	✓	✓	✓	✓
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	ATCM	✓	✓	✓	✓
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	BCM#1	✓	✓	✓	✓
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	C-CM	✓	✓	✓	✓
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	CLM#1	✓	✓	✓	✓
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	DCSM	✓	✓	✓	✓
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	DSM	✓	✓	✓	✓
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	DSP	✓	✓	✓	✓
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	FCDIM	✓	✓	✓	✓
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	FCIM	✓	✓	✓	✓
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	FLM	✓	✓	✓	✓
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	GFM	✓	✓	✓	✓
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	GPSM	✓	✓	✓	✓
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	HSWM	✓	✓	✓	✓
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	HUD	✓	✓	✓	✓
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	HVAC	✓	✓	✓	✓
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	IPC	✓	✓	✓	✓
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	IPM-A	✓	✓	✓	✓
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	OCSM	✓	✓	✓	✓
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	PAM	✓	✓	✓	✓
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	PSCM	✓	✓	✓	✓

2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	√
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	RLCM-A	√	√	√	√
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM	√	√	√	√
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	√
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct	TCM	√	√	√	√
2014	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2014	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2014	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2014	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	ATCM	√	√	√	√
2014	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	BCM#1	√	√	√	√
2014	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	C-CM	√	√	√	√
2014	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	CLM#1	√	√	√	√
2014	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	DCSM	√	√	√	√
2014	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	DSM	√	√	√	√
2014	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	DSP	√	√	√	√
2014	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	FCDIM	√	√	√	√
2014	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	√
2014	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	FLM	√	√	√	√
2014	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	GFM	√	√	√	√
2014	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	√
2014	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	HSWM	√	√	√	√
2014	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	HUD	√	√	√	√
2014	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	√	√	√	√
2014	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2014	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	IPM-A	√	√	√	√
2014	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	LTM	√	√	√	√
2014	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	OCSM	√	√	√	√
2014	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2014	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2014	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2014	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM	√	√	√	√
2014	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	RLCM-A	√	√	√	√
2014	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	RTM	√	√	√	√
2014	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	SCCM	√	√	√	√
2014	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	√
2014	Explorer	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2014	Explorer	3.5L	TiVCT	ABS	√	√	√	√
2014	Explorer	3.5L	TiVCT	ACM	√	√	√	√
2014	Explorer	3.5L	TiVCT	APIM	√	√	√	√
2014	Explorer	3.5L	TiVCT	ATCM	√	√	√	√



2014	Explorer	3.5L	TiVCT	BCM#1	√	√	√	√
2014	Explorer	3.5L	TiVCT	C-CM	√	√	√	√
2014	Explorer	3.5L	TiVCT	CLM#1	√	√	√	√
2014	Explorer	3.5L	TiVCT	DCSM	√	√	√	√
2014	Explorer	3.5L	TiVCT	DSM	√	√	√	√
2014	Explorer	3.5L	TiVCT	DSP	√	√	√	√
2014	Explorer	3.5L	TiVCT	FCDIM	√	√	√	√
2014	Explorer	3.5L	TiVCT	FCIM	√	√	√	√
2014	Explorer	3.5L	TiVCT	FLM	√	√	√	√
2014	Explorer	3.5L	TiVCT	GFM	√	√	√	√
2014	Explorer	3.5L	TiVCT	GPSM	√	√	√	√
2014	Explorer	3.5L	TiVCT	HSWM	√	√	√	√
2014	Explorer	3.5L	TiVCT	HUD	√	√	√	√
2014	Explorer	3.5L	TiVCT	HVAC	√	√	√	√
2014	Explorer	3.5L	TiVCT	IPC	√	√	√	√
2014	Explorer	3.5L	TiVCT	IPM-A	√	√	√	√
2014	Explorer	3.5L	TiVCT	LTM	√	√	√	√
2014	Explorer	3.5L	TiVCT	OCSM	√	√	√	√
2014	Explorer	3.5L	TiVCT	PAM	√	√	√	√
2014	Explorer	3.5L	TiVCT	PCM	√	√	√	√
2014	Explorer	3.5L	TiVCT	PSCM	√	√	√	√
2014	Explorer	3.5L	TiVCT	RCM	√	√	√	√
2014	Explorer	3.5L	TiVCT	RFA	√	√	√	√
2014	Explorer	3.5L	TiVCT	RLCM-A	√	√	√	√
2014	Explorer	3.5L	TiVCT	RTM	√	√	√	√
2014	Explorer	3.5L	TiVCT	SCCM	√	√	√	√
2014	Explorer	3.5L	TiVCT	SOD-L	√	√	√	√
2014	Explorer	3.5L	TiVCT	SOD-R	√	√	√	√
2014	Explorer	3.7L	TiVCT	ABS	√	√	√	√
2014	Explorer	3.7L	TiVCT	ACM	√	√	√	√
2014	Explorer	3.7L	TiVCT	APIM	√	√	√	√
2014	Explorer	3.7L	TiVCT	ATCM	√	√	√	√
2014	Explorer	3.7L	TiVCT	BCM#1	√	√	√	√
2014	Explorer	3.7L	TiVCT	C-CM	√	√	√	√
2014	Explorer	3.7L	TiVCT	CLM#1	√	√	√	√
2014	Explorer	3.7L	TiVCT	DCSM	√	√	√	√
2014	Explorer	3.7L	TiVCT	DSM	√	√	√	√
2014	Explorer	3.7L	TiVCT	DSP	√	√	√	√
2014	Explorer	3.7L	TiVCT	FCDIM	√	√	√	√
2014	Explorer	3.7L	TiVCT	FCIM	√	√	√	√
2014	Explorer	3.7L	TiVCT	FLM	√	√	√	√
2014	Explorer	3.7L	TiVCT	GFM	√	√	√	√
2014	Explorer	3.7L	TiVCT	GPSM	√	√	√	√
2014	Explorer	3.7L	TiVCT	HSWM	√	√	√	√
2014	Explorer	3.7L	TiVCT	HUD	√	√	√	√

2014	Explorer	3.7L	TiVCT	HVAC	√	√	√	√
2014	Explorer	3.7L	TiVCT	IPC	√	√	√	√
2014	Explorer	3.7L	TiVCT	IPM-A	√	√	√	√
2014	Explorer	3.7L	TiVCT	LTM	√	√	√	√
2014	Explorer	3.7L	TiVCT	OCSM	√	√	√	√
2014	Explorer	3.7L	TiVCT	PAM	√	√	√	√
2014	Explorer	3.7L	TiVCT	PCM	√	√	√	√
2014	Explorer	3.7L	TiVCT	PSCM	√	√	√	√
2014	Explorer	3.7L	TiVCT	RCM	√	√	√	√
2014	Explorer	3.7L	TiVCT	RFA	√	√	√	√
2014	Explorer	3.7L	TiVCT	RLCM-A	√	√	√	√
2014	Explorer	3.7L	TiVCT	RTM	√	√	√	√
2014	Explorer	3.7L	TiVCT	SCCM	√	√	√	√
2014	Explorer	3.7L	TiVCT	SOD-L	√	√	√	√
2014	Explorer	3.7L	TiVCT	SOD-R	√	√	√	√
2014	Explorer	Other	Other	ABS	√	√	√	√
2014	Explorer	Other	Other	ACM	√	√	√	√
2014	Explorer	Other	Other	APIM	√	√	√	√
2014	Explorer	Other	Other	ATCM	√	√	√	√
2014	Explorer	Other	Other	BCM#1	√	√	√	√
2014	Explorer	Other	Other	CLM#1	√	√	√	√
2014	Explorer	Other	Other	DCSM	√	√	√	√
2014	Explorer	Other	Other	DSM	√	√	√	√
2014	Explorer	Other	Other	DSP	√	√	√	√
2014	Explorer	Other	Other	FCDIM	√	√	√	√
2014	Explorer	Other	Other	FCIM	√	√	√	√
2014	Explorer	Other	Other	FLM	√	√	√	√
2014	Explorer	Other	Other	GFM	√	√	√	√
2014	Explorer	Other	Other	GPSM	√	√	√	√
2014	Explorer	Other	Other	HSWM	√	√	√	√
2014	Explorer	Other	Other	HUD	√	√	√	√
2014	Explorer	Other	Other	HVAC	√	√	√	√
2014	Explorer	Other	Other	IPC	√	√	√	√
2014	Explorer	Other	Other	IPM-A	√	√	√	√
2014	Explorer	Other	Other	LTM	√	√	√	√
2014	Explorer	Other	Other	OCSM	√	√	√	√
2014	Explorer	Other	Other	PAM	√	√	√	√
2014	Explorer	Other	Other	PSCM	√	√	√	√
2014	Explorer	Other	Other	RCM	√	√	√	√
2014	Explorer	Other	Other	RFA	√	√	√	√
2014	Explorer	Other	Other	RLCM-A	√	√	√	√
2014	Explorer	Other	Other	RTM	√	√	√	√
2014	Explorer	Other	Other	SCCM	√	√	√	√
2014	Explorer	Other	Other	SOD-L	√	√	√	√
2014	Explorer	Other	Other	SOD-R	√	√	√	√

2000.5	Explorer Sport	4.0L	V6 SOHC	4X4	✓	✓	✓	✓
2000.5	Explorer Sport	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓
2000.5	Explorer Sport	4.0L	V6 SOHC	GEM	✓	✓	✓	✓
2000.5	Explorer Sport	4.0L	V6 SOHC	PATS	✓	✓	✓	✓
2000.5	Explorer Sport	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2000.5	Explorer Sport	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2000.5	Explorer Sport	4.0L	V6 SOHC	RAP	✓	✓	✓	✓
2000.5	Explorer Sport	4.0L	V6 SOHC	RCM	✓	✓	✓	✓
2001	Explorer Sport	4.0L	V6 SOHC	4X4	✓	✓	✓	✓
2001	Explorer Sport	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓
2001	Explorer Sport	4.0L	V6 SOHC	GEM	✓	✓	✓	✓
2001	Explorer Sport	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2001	Explorer Sport	4.0L	V6 SOHC	RAP	✓	✓	✓	✓
2001	Explorer Sport	4.0L	V6 SOHC	RCM	✓	✓	✓	✓
2002	Explorer Sport	4.0L	V6 SOHC	4X4	✓	✓	✓	✓
2002	Explorer Sport	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓
2002	Explorer Sport	4.0L	V6 SOHC	GEM	✓	✓	✓	✓
2002	Explorer Sport	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2002	Explorer Sport	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2002	Explorer Sport	4.0L	V6 SOHC	RAP	✓	✓	✓	✓
2002	Explorer Sport	4.0L	V6 SOHC	RCM	✓	✓	✓	✓
2003	Explorer Sport	4.0L	V6 SOHC	4X4	✓	✓	✓	✓
2003	Explorer Sport	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓
2003	Explorer Sport	4.0L	V6 SOHC	GEM	✓	✓	✓	✓
2003	Explorer Sport	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2003	Explorer Sport	4.0L	V6 SOHC	RAP	✓	✓	✓	✓
2003	Explorer Sport	4.0L	V6 SOHC	RCM	✓	✓	✓	✓
2000.5	Explorer SportTrac	4.0L	V6 SOHC	4X4	✓	✓	✓	✓
2000.5	Explorer SportTrac	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓
2000.5	Explorer SportTrac	4.0L	V6 SOHC	GEM	✓	✓	✓	✓
2000.5	Explorer SportTrac	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2000.5	Explorer SportTrac	4.0L	V6 SOHC	RAP	✓	✓	✓	✓
2000.5	Explorer SportTrac	4.0L	V6 SOHC	RCM	✓	✓	✓	✓
2001	Explorer SportTrac	4.0L	V6 SOHC	4X4	✓	✓	✓	✓
2001	Explorer SportTrac	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓
2001	Explorer SportTrac	4.0L	V6 SOHC	GEM	✓	✓	✓	✓
2001	Explorer SportTrac	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2001	Explorer SportTrac	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2001	Explorer SportTrac	4.0L	V6 SOHC	RAP	✓	✓	✓	✓
2001	Explorer SportTrac	4.0L	V6 SOHC	RCM	✓	✓	✓	✓
2001	Explorer SportTrac	4.0L	V6 SOHC	RCM	✓	✓	✓	✓
2002	Explorer SportTrac	4.0L	V6 SOHC	4X4	✓	✓	✓	✓
2002	Explorer SportTrac	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓
2002	Explorer SportTrac	4.0L	V6 SOHC	GEM	✓	✓	✓	✓
2002	Explorer SportTrac	4.0L	V6 SOHC	PCM	✓	✓	✓	✓

2002	Explorer SportTrac	4.0L	V6 SOHC	PCM	√	√	√	√
2002	Explorer SportTrac	4.0L	V6 SOHC	RAP	√	√	√	√
2002	Explorer SportTrac	4.0L	V6 SOHC	RCM	√	√	√	√
2002	Explorer SportTrac	4.0L	V6 SOHC	RCM	√	√	√	√
2003	Explorer SportTrac	4.0L	V6 SOHC	4X4	√	√	√	√
2003	Explorer SportTrac	4.0L	V6 SOHC	ABS/TCS	√	√	√	√
2003	Explorer SportTrac	4.0L	V6 SOHC	GEM	√	√	√	√
2003	Explorer SportTrac	4.0L	V6 SOHC	PCM	√	√	√	√
2003	Explorer SportTrac	4.0L	V6 SOHC	RAP	√	√	√	√
2003	Explorer SportTrac	4.0L	V6 SOHC	RCM	√	√	√	√
2004	Explorer SportTrac	4.0L	V6 SOHC	4X4	√	√	√	√
2004	Explorer SportTrac	4.0L	V6 SOHC	ABS/TCS	√	√	√	√
2004	Explorer SportTrac	4.0L	V6 SOHC	HEC	√	√	√	√
2004	Explorer SportTrac	4.0L	V6 SOHC	PCM	√	√	√	√
2004	Explorer SportTrac	4.0L	V6 SOHC	PCM	√	√	√	√
2004	Explorer SportTrac	4.0L	V6 SOHC	RAP	√	√	√	√
2005	Explorer SportTrac	4.0L	V6 SOHC	4X4	√	√	√	√
2005	Explorer SportTrac	4.0L	V6 SOHC	ABS/TCS	√	√	√	√
2005	Explorer SportTrac	4.0L	V6 SOHC	HEC	√	√	√	√
2005	Explorer SportTrac	4.0L	V6 SOHC	PCM	√	√	√	√
2005	Explorer SportTrac	4.0L	V6 SOHC	RAP	√	√	√	√
2005	Explorer SportTrac	4.0L	V6 SOHC	RCM	√	√	√	√
2007	Explorer SportTrac	4.0L	2V	4X4	√	√	√	√
2007	Explorer SportTrac	4.0L	2V	ABS	√	√	√	√
2007	Explorer SportTrac	4.0L	2V	ACM	√	√	√	√
2007	Explorer SportTrac	4.0L	2V	EATC	√	√	√	√
2007	Explorer SportTrac	4.0L	2V	GEM	√	√	√	√
2007	Explorer SportTrac	4.0L	2V	IC	√	√	√	√
2007	Explorer SportTrac	4.0L	2V	OCSM	√	√	√	√
2007	Explorer SportTrac	4.0L	2V	PAM	√	√	√	√
2007	Explorer SportTrac	4.0L	2V	PCM	√	√	√	√
2007	Explorer SportTrac	4.0L	2V	PCM	√	√	√	√
2007	Explorer SportTrac	4.0L	2V	RCM	√	√	√	√
2007	Explorer SportTrac	4.0L	2V	RETM	√	√	√	
2007	Explorer SportTrac	4.0L	2V	SDARS	√	√	√	√
2007	Explorer SportTrac	4.6L	3V	4X4	√	√	√	√
2007	Explorer SportTrac	4.6L	3V	4X4	√	√	√	√
2007	Explorer SportTrac	4.6L	3V	ABS	√	√	√	√
2007	Explorer SportTrac	4.6L	3V	ABS	√	√	√	√
2007	Explorer SportTrac	4.6L	3V	ACM	√	√	√	√
2007	Explorer SportTrac	4.6L	3V	ACM	√	√	√	√
2007	Explorer SportTrac	4.6L	3V	EATC	√	√	√	√
2007	Explorer SportTrac	4.6L	3V	EATC	√	√	√	√
2007	Explorer SportTrac	4.6L	3V	GEM	√	√	√	√
2007	Explorer SportTrac	4.6L	3V	GEM	√	√	√	√

2007	Explorer SportTrac	4.6L	3V	GEM	√	√	√	√
2007	Explorer SportTrac	4.6L	3V	IC	√	√	√	√
2007	Explorer SportTrac	4.6L	3V	IC	√	√	√	√
2007	Explorer SportTrac	4.6L	3V	OCSM	√	√	√	√
2007	Explorer SportTrac	4.6L	3V	OCSM	√	√	√	√
2007	Explorer SportTrac	4.6L	3V	PAM	√	√	√	√
2007	Explorer SportTrac	4.6L	3V	PAM	√	√	√	√
2007	Explorer SportTrac	4.6L	3V	PCM	√	√	√	√
2007	Explorer SportTrac	4.6L	3V	PCM	√	√	√	√
2007	Explorer SportTrac	4.6L	3V	PCM	√	√	√	√
2007	Explorer SportTrac	4.6L	3V	RCM	√	√	√	√
2007	Explorer SportTrac	4.6L	3V	RCM	√	√	√	√
2007	Explorer SportTrac	4.6L	3V	RCM	√	√	√	√
2007	Explorer SportTrac	4.6L	3V	RETM	√	√	√	
2007	Explorer SportTrac	4.6L	3V	RETM	√	√	√	
2007	Explorer SportTrac	4.6L	3V	RETM	√	√	√	
2007	Explorer SportTrac	4.6L	3V	SDARS	√	√	√	√
2007	Explorer SportTrac	4.6L	3V	SDARS	√	√	√	√
2007	Explorer SportTrac	4.6L	3V	TCM	√	√	√	√
2007	Explorer SportTrac	4.6L	3V	TCM	√	√	√	√
2008	Explorer SportTrac	4.0L	2V	4X4	√	√	√	√
2008	Explorer SportTrac	4.0L	2V	4X4	√	√	√	√
2008	Explorer SportTrac	4.0L	2V	ABS	√	√	√	√
2008	Explorer SportTrac	4.0L	2V	ACM	√	√	√	√
2008	Explorer SportTrac	4.0L	2V	APIM	√	√	√	√
2008	Explorer SportTrac	4.0L	2V	GEM / SJB	√	√	√	√
2008	Explorer SportTrac	4.0L	2V	HVAC	√	√	√	√
2008	Explorer SportTrac	4.0L	2V	IC	√	√	√	√
2008	Explorer SportTrac	4.0L	2V	OCSM	√	√	√	√
2008	Explorer SportTrac	4.0L	2V	PAM	√	√	√	√
2008	Explorer SportTrac	4.0L	2V	PCM	√	√	√	√
2008	Explorer SportTrac	4.0L	2V	RCM	√	√	√	√
2008	Explorer SportTrac	4.0L	2V	RETM	√	√	√	
2008	Explorer SportTrac	4.0L	2V	SDARS	√	√	√	√
2008	Explorer SportTrac	4.6L	3V	4X4	√	√	√	√
2008	Explorer SportTrac	4.6L	3V	4X4	√	√	√	√
2008	Explorer SportTrac	4.6L	3V	ABS	√	√	√	√
2008	Explorer SportTrac	4.6L	3V	ABS	√	√	√	√
2008	Explorer SportTrac	4.6L	3V	ACM	√	√	√	√
2008	Explorer SportTrac	4.6L	3V	ACM	√	√	√	√
2008	Explorer SportTrac	4.6L	3V	APIM	√	√	√	√
2008	Explorer SportTrac	4.6L	3V	APIM	√	√	√	√
2008	Explorer SportTrac	4.6L	3V	GEM / SJB	√	√	√	√
2008	Explorer SportTrac	4.6L	3V	GEM / SJB	√	√	√	√
2008	Explorer SportTrac	4.6L	3V	GEM / SJB	√	√	√	√

2008	Explorer SportTrac	4.6L	3V	HVAC	√	√	√	√
2008	Explorer SportTrac	4.6L	3V	IC	√	√	√	√
2008	Explorer SportTrac	4.6L	3V	OCSM	√	√	√	√
2008	Explorer SportTrac	4.6L	3V	OCSM	√	√	√	√
2008	Explorer SportTrac	4.6L	3V	OCSM	√	√	√	√
2008	Explorer SportTrac	4.6L	3V	PAM	√	√	√	√
2008	Explorer SportTrac	4.6L	3V	PCM	√	√	√	√
2008	Explorer SportTrac	4.6L	3V	PCM	√	√	√	√
2008	Explorer SportTrac	4.6L	3V	RCM	√	√	√	√
2008	Explorer SportTrac	4.6L	3V	RCM	√	√	√	√
2008	Explorer SportTrac	4.6L	3V	RETM	√	√	√	
2008	Explorer SportTrac	4.6L	3V	RETM	√	√	√	
2008	Explorer SportTrac	4.6L	3V	SDARS	√	√	√	√
2008	Explorer SportTrac	4.6L	3V	TCM	√	√	√	√
2008	Explorer SportTrac	4.6L	3V	TCM	√	√	√	√
2009	Explorer SportTrac	4.0L	2V	4X4	√	√	√	√
2009	Explorer SportTrac	4.0L	2V	4X4	√	√	√	√
2009	Explorer SportTrac	4.0L	2V	ABS	√	√	√	√
2009	Explorer SportTrac	4.0L	2V	ACM	√	√	√	
2009	Explorer SportTrac	4.0L	2V	ACM	√	√	√	√
2009	Explorer SportTrac	4.0L	2V	APIM	√	√	√	
2009	Explorer SportTrac	4.0L	2V	GEM / SJB	√	√	√	√
2009	Explorer SportTrac	4.0L	2V	GEM / SJB	√	√	√	√
2009	Explorer SportTrac	4.0L	2V	HVAC	√	√	√	√
2009	Explorer SportTrac	4.0L	2V	HVAC	√	√	√	√
2009	Explorer SportTrac	4.0L	2V	IC	√	√	√	√
2009	Explorer SportTrac	4.0L	2V	IC	√	√	√	√
2009	Explorer SportTrac	4.0L	2V	OCSM	√	√	√	√
2009	Explorer SportTrac	4.0L	2V	PAM	√	√	√	√
2009	Explorer SportTrac	4.0L	2V	PCM	√	√	√	√
2009	Explorer SportTrac	4.0L	2V	PCM	√	√	√	√
2009	Explorer SportTrac	4.0L	2V	RCM	√	√	√	√
2009	Explorer SportTrac	4.0L	2V	RCM	√	√	√	√
2009	Explorer SportTrac	4.0L	2V	RETM	√	√	√	
2009	Explorer SportTrac	4.0L	2V	SDARS	√	√	√	√
2009	Explorer SportTrac	4.0L	2V	SDARS	√	√	√	√
2009	Explorer SportTrac	4.6L	3V	4X4	√	√	√	√
2009	Explorer SportTrac	4.6L	3V	ABS	√	√	√	√
2009	Explorer SportTrac	4.6L	3V	ABS	√	√	√	√
2009	Explorer SportTrac	4.6L	3V	ACM	√	√	√	
2009	Explorer SportTrac	4.6L	3V	ACM	√	√	√	
2009	Explorer SportTrac	4.6L	3V	ACM	√	√	√	√
2009	Explorer SportTrac	4.6L	3V	ACM	√	√	√	√
2009	Explorer SportTrac	4.6L	3V	APIM	√	√	√	
2009	Explorer SportTrac	4.6L	3V	APIM	√	√	√	

2009	Explorer SportTrac	4.6L	3V	GEM / SJB	√	√	√	√
2009	Explorer SportTrac	4.6L	3V	GEM / SJB	√	√	√	√
2009	Explorer SportTrac	4.6L	3V	HVAC	√	√	√	√
2009	Explorer SportTrac	4.6L	3V	HVAC	√	√	√	√
2009	Explorer SportTrac	4.6L	3V	IC	√	√	√	√
2009	Explorer SportTrac	4.6L	3V	IC	√	√	√	√
2009	Explorer SportTrac	4.6L	3V	OCSM	√	√	√	√
2009	Explorer SportTrac	4.6L	3V	OCSM	√	√	√	√
2009	Explorer SportTrac	4.6L	3V	PAM	√	√	√	√
2009	Explorer SportTrac	4.6L	3V	PAM	√	√	√	√
2009	Explorer SportTrac	4.6L	3V	PCM	√	√	√	√
2009	Explorer SportTrac	4.6L	3V	PCM	√	√	√	√
2009	Explorer SportTrac	4.6L	3V	RCM	√	√	√	√
2009	Explorer SportTrac	4.6L	3V	RCM	√	√	√	√
2009	Explorer SportTrac	4.6L	3V	RETM	√	√	√	
2009	Explorer SportTrac	4.6L	3V	SDARS	√	√	√	√
2009	Explorer SportTrac	4.6L	3V	TCM	√	√	√	√
2009	Explorer SportTrac	4.6L	3V	TCM	√	√	√	√
2010	Explorer SportTrac	4.0L	2V	4X4	√	√	√	√
2010	Explorer SportTrac	4.0L	2V	4X4	√	√	√	√
2010	Explorer SportTrac	4.0L	2V	ABS	√	√	√	√
2010	Explorer SportTrac	4.0L	2V	ACM	√	√	√	
2010	Explorer SportTrac	4.0L	2V	ACM	√	√	√	√
2010	Explorer SportTrac	4.0L	2V	APIM	√	√	√	
2010	Explorer SportTrac	4.0L	2V	GEM / SJB	√	√	√	√
2010	Explorer SportTrac	4.0L	2V	GPSM	√	√	√	√
2010	Explorer SportTrac	4.0L	2V	HVAC	√	√	√	√
2010	Explorer SportTrac	4.0L	2V	IC	√	√	√	√
2010	Explorer SportTrac	4.0L	2V	OCSM	√	√	√	√
2010	Explorer SportTrac	4.0L	2V	PAM	√	√	√	√
2010	Explorer SportTrac	4.0L	2V	PCM	√	√	√	√
2010	Explorer SportTrac	4.0L	2V	PCM	√	√	√	√
2010	Explorer SportTrac	4.0L	2V	RCM	√	√	√	√
2010	Explorer SportTrac	4.0L	2V	RETM	√	√	√	
2010	Explorer SportTrac	4.0L	2V	SDARS	√	√	√	√
2010	Explorer SportTrac	4.6L	3V	4X4	√	√	√	√
2010	Explorer SportTrac	4.6L	3V	ABS	√	√	√	√
2010	Explorer SportTrac	4.6L	3V	ABS	√	√	√	√
2010	Explorer SportTrac	4.6L	3V	ACM	√	√	√	
2010	Explorer SportTrac	4.6L	3V	ACM	√	√	√	
2010	Explorer SportTrac	4.6L	3V	ACM	√	√	√	√
2010	Explorer SportTrac	4.6L	3V	APIM	√	√	√	
2010	Explorer SportTrac	4.6L	3V	APIM	√	√	√	
2010	Explorer SportTrac	4.6L	3V	GEM / SJB	√	√	√	√
2010	Explorer SportTrac	4.6L	3V	GEM / SJB	√	√	√	√

2010	Explorer SportTrac	4.6L	3V	GPSM	√	√	√	√
2010	Explorer SportTrac	4.6L	3V	HVAC	√	√	√	√
2010	Explorer SportTrac	4.6L	3V	HVAC	√	√	√	√
2010	Explorer SportTrac	4.6L	3V	IC	√	√	√	√
2010	Explorer SportTrac	4.6L	3V	IC	√	√	√	√
2010	Explorer SportTrac	4.6L	3V	OCSM	√	√	√	√
2010	Explorer SportTrac	4.6L	3V	OCSM	√	√	√	√
2010	Explorer SportTrac	4.6L	3V	PAM	√	√	√	√
2010	Explorer SportTrac	4.6L	3V	PAM	√	√	√	√
2010	Explorer SportTrac	4.6L	3V	PCM	√	√	√	√
2010	Explorer SportTrac	4.6L	3V	PCM	√	√	√	√
2010	Explorer SportTrac	4.6L	3V	RCM	√	√	√	√
2010	Explorer SportTrac	4.6L	3V	RETM	√	√	√	
2010	Explorer SportTrac	4.6L	3V	SDARS	√	√	√	√
2010	Explorer SportTrac	4.6L	3V	TCM	√	√	√	√
2010	Explorer SportTrac	4.6L	3V	TCM	√	√	√	√
1997	F-150	4.2L	Other	ABS/TCS	√	√	√	√
1997	F-150	4.2L	Other	GEM	√	√	√	√
1997	F-150	4.2L	Other	IAB	√	√	√	√
1997	F-150	4.2L	Other	PCM	√	√	√	√
1997	F-150	4.2L	Other	RAP	√	√	√	√
1997	F-150	4.6L	Other	ABS/TCS	√	√	√	√
1997	F-150	4.6L	Other	GEM	√	√	√	√
1997	F-150	4.6L	Other	IAB	√	√	√	√
1997	F-150	4.6L	Other	PCM	√	√	√	√
1997	F-150	4.6L	Other	RAP	√	√	√	√
1997	F-150	5.4L	Other	ABS/TCS	√	√	√	√
1997	F-150	5.4L	Other	GEM	√	√	√	√
1997	F-150	5.4L	Other	IAB	√	√	√	√
1997	F-150	5.4L	Other	PCM	√	√	√	√
1997	F-150	5.4L	Other	RAP	√	√	√	√
1998	F-150	4.2L	Other	ABS/TCS	√	√	√	√
1998	F-150	4.2L	Other	GEM	√	√	√	√
1998	F-150	4.2L	Other	IAB	√	√	√	√
1998	F-150	4.2L	Other	PCM	√	√	√	√
1998	F-150	4.2L	Other	RAP	√	√	√	√
1998	F-150	4.6L	Other	ABS/TCS	√	√	√	√
1998	F-150	4.6L	Other	GEM	√	√	√	√
1998	F-150	4.6L	Other	IAB	√	√	√	√
1998	F-150	4.6L	Other	PCM	√	√	√	√
1998	F-150	4.6L	Other	RAP	√	√	√	√
1998	F-150	5.4L	BIF	ABS/TCS	√	√	√	√
1998	F-150	5.4L	BIF	AFCM	√	√	√	√
1998	F-150	5.4L	BIF	GEM	√	√	√	√
1998	F-150	5.4L	BIF	IAB	√	√	√	√



1998	F-150	5.4L	BIF	PCM	√	√	√	√
1998	F-150	5.4L	BIF	RAP	√	√	√	√
1998	F-150	5.4L	Other	ABS/TCS	√	√	√	√
1998	F-150	5.4L	Other	GEM	√	√	√	√
1998	F-150	5.4L	Other	IAB	√	√	√	√
1998	F-150	5.4L	Other	PCM	√	√	√	√
1998	F-150	5.4L	Other	RAP	√	√	√	√
1999	F-150	4.2L	Other	ABS/TCS	√	√	√	√
1999	F-150	4.2L	Other	GEM	√	√	√	√
1999	F-150	4.2L	Other	IAB	√	√	√	√
1999	F-150	4.2L	Other	IC	√	√	√	√
1999	F-150	4.2L	Other	PCM	√	√	√	√
1999	F-150	4.2L	Other	RAP	√	√	√	√
1999	F-150	4.6L	Other	ABS/TCS	√	√	√	√
1999	F-150	4.6L	Other	GEM	√	√	√	√
1999	F-150	4.6L	Other	IAB	√	√	√	√
1999	F-150	4.6L	Other	IC	√	√	√	√
1999	F-150	4.6L	Other	PCM	√	√	√	√
1999	F-150	4.6L	Other	RAP	√	√	√	√
1999	F-150	5.4L	BIF	ABS/TCS	√	√	√	√
1999	F-150	5.4L	BIF	AFCM	√	√	√	√
1999	F-150	5.4L	BIF	GEM	√	√	√	√
1999	F-150	5.4L	BIF	IAB	√	√	√	√
1999	F-150	5.4L	BIF	IC	√	√	√	√
1999	F-150	5.4L	BIF	PCM	√	√	√	√
1999	F-150	5.4L	BIF	RAP	√	√	√	√
1999	F-150	5.4L	Other	ABS/TCS	√	√	√	√
1999	F-150	5.4L	Other	GEM	√	√	√	√
1999	F-150	5.4L	Other	IAB	√	√	√	√
1999	F-150	5.4L	Other	IC	√	√	√	√
1999	F-150	5.4L	Other	PCM	√	√	√	√
1999	F-150	5.4L	Other	RAP	√	√	√	√
2000	F-150	4.2L	Other	ABS/TCS	√	√	√	√
2000	F-150	4.2L	Other	GEM	√	√	√	√
2000	F-150	4.2L	Other	IAB	√	√	√	√
2000	F-150	4.2L	Other	PCM	√	√	√	√
2000	F-150	4.2L	Other	RAP	√	√	√	√
2000	F-150	4.6L	Other	ABS/TCS	√	√	√	√
2000	F-150	4.6L	Other	ABS/TCS	√	√	√	√
2000	F-150	4.6L	Other	GEM	√	√	√	√
2000	F-150	4.6L	Other	IAB	√	√	√	√
2000	F-150	4.6L	Other	IC	√	√	√	√
2000	F-150	4.6L	Other	PCM	√	√	√	√
2000	F-150	4.6L	Other	RAP	√	√	√	√
2000	F-150	5.4L	BIF	ABS/TCS	√	√	√	√

2000	F-150	5.4L	BIF	AFCM	√	√	√	√
2000	F-150	5.4L	BIF	GEM	√	√	√	√
2000	F-150	5.4L	BIF	IAB	√	√	√	√
2000	F-150	5.4L	BIF	IC	√	√	√	√
2000	F-150	5.4L	BIF	PCM	√	√	√	√
2000	F-150	5.4L	BIF	PCM	√	√	√	√
2000	F-150	5.4L	BIF	RAP	√	√	√	√
2000	F-150	5.4L	NGV	ABS/TCS	√	√	√	√
2000	F-150	5.4L	NGV	ABS/TCS	√	√	√	√
2000	F-150	5.4L	NGV	FIM	√	√	√	√
2000	F-150	5.4L	NGV	GEM	√	√	√	√
2000	F-150	5.4L	NGV	IAB	√	√	√	√
2000	F-150	5.4L	NGV	IC	√	√	√	√
2000	F-150	5.4L	NGV	PCM	√	√	√	√
2000	F-150	5.4L	NGV	PCM	√	√	√	√
2000	F-150	5.4L	NGV	RAP	√	√	√	√
2000	F-150	5.4L	Other	ABS/TCS	√	√	√	√
2000	F-150	5.4L	Other	GEM	√	√	√	√
2000	F-150	5.4L	Other	IAB	√	√	√	√
2000	F-150	5.4L	Other	IC	√	√	√	√
2000	F-150	5.4L	Other	PCM	√	√	√	√
2000	F-150	5.4L	Other	RAP	√	√	√	√
2002	F-150	4.2L	Other	ABS/TCS	√	√	√	√
2002	F-150	4.2L	Other	GEM	√	√	√	√
2002	F-150	4.2L	Other	IC	√	√	√	√
2002	F-150	4.2L	Other	PCM	√	√	√	√
2002	F-150	4.2L	Other	PCM	√	√	√	√
2002	F-150	4.2L	Other	RAP	√	√	√	√
2002	F-150	4.2L	Other	RCM	√	√	√	√
2002	F-150	4.6L	Other	ABS/TCS	√	√	√	√
2002	F-150	4.6L	Other	GEM	√	√	√	√
2002	F-150	4.6L	Other	IC	√	√	√	√
2002	F-150	4.6L	Other	PCM	√	√	√	√
2002	F-150	4.6L	Other	RAP	√	√	√	√
2002	F-150	4.6L	Other	RCM	√	√	√	√
2002	F-150	5.4L	Other	ABS/TCS	√	√	√	√
2002	F-150	5.4L	Other	ABS/TCS	√	√	√	√
2002	F-150	5.4L	Other	AFCM	√	√	√	√
2002	F-150	5.4L	Other	FIM	√	√	√	√
2002	F-150	5.4L	Other	GEM	√	√	√	√
2002	F-150	5.4L	Other	IC	√	√	√	√
2002	F-150	5.4L	Other	PCM	√	√	√	√
2002	F-150	5.4L	Other	RAP	√	√	√	√
2002	F-150	5.4L	Other	RCM	√	√	√	√
2003	F-150	4.2L	Other	ABS/TCS	√	√	√	√

2003	F-150	4.2L	Other	GEM	√	√	√	√
2003	F-150	4.2L	Other	IC	√	√	√	√
2003	F-150	4.2L	Other	PCM	√	√	√	√
2003	F-150	4.2L	Other	PCM	√	√	√	√
2003	F-150	4.2L	Other	RAP	√	√	√	√
2003	F-150	4.2L	Other	RCM	√	√	√	√
2003	F-150	4.6L	2V	ABS/TCS	√	√	√	√
2003	F-150	4.6L	2V	GEM	√	√	√	√
2003	F-150	4.6L	2V	IC	√	√	√	√
2003	F-150	4.6L	2V	PCM	√	√	√	√
2003	F-150	4.6L	2V	RAP	√	√	√	√
2003	F-150	4.6L	2V	RCM	√	√	√	√
2003	F-150	5.4L	Other	ABS/TCS	√	√	√	√
2003	F-150	5.4L	Other	ABS/TCS	√	√	√	√
2003	F-150	5.4L	Other	AFCM	√	√	√	√
2003	F-150	5.4L	Other	FIM	√	√	√	√
2003	F-150	5.4L	Other	GEM	√	√	√	√
2003	F-150	5.4L	Other	IC	√	√	√	√
2003	F-150	5.4L	Other	PCM	√	√	√	√
2003	F-150	5.4L	Other	PCM	√	√	√	√
2003	F-150	5.4L	Other	RAP	√	√	√	√
2003	F-150	5.4L	Other	RCM	√	√	√	√
2004	F-150	4.2L	Other	ABS/TCS	√	√	√	√
2004	F-150	4.2L	Other	GEM	√	√	√	√
2004	F-150	4.2L	Other	IC	√	√	√	√
2004	F-150	4.2L	Other	PCM	√	√	√	√
2004	F-150	4.2L	Other	RAP	√	√	√	√
2004	F-150	4.2L	Other	RCM	√	√	√	√
2004	F-150	4.6L	2V	4X4	√	√	√	√
2004	F-150	4.6L	2V	ABS	√	√	√	√
2004	F-150	4.6L	2V	ABS/TCS	√	√	√	√
2004	F-150	4.6L	2V	DSM	√	√	√	√
2004	F-150	4.6L	2V	EATC	√	√	√	√
2004	F-150	4.6L	2V	IC	√	√	√	√
2004	F-150	4.6L	2V	PAM	√	√	√	√
2004	F-150	4.6L	2V	PCM	√	√	√	√
2004	F-150	4.6L	2V	PCM	√	√	√	√
2004	F-150	4.6L	2V	RAP	√	√	√	√
2004	F-150	4.6L	2V	RCM	√	√	√	√
2004	F-150	4.6L	2V	RCM	√	√	√	√
2004	F-150	4.6L	2V	VSM	√	√	√	√
2004	F-150	5.4L	2V	ABS/TCS	√	√	√	√
2004	F-150	5.4L	2V	AFCM	√	√	√	√
2004	F-150	5.4L	2V	FIM	√	√	√	√
2004	F-150	5.4L	2V	GEM	√	√	√	√

2004	F-150	5.4L	2V	IC	√	√	√	√
2004	F-150	5.4L	2V	PCM	√	√	√	√
2004	F-150	5.4L	2V	RAP	√	√	√	√
2004	F-150	5.4L	2V	RCM	√	√	√	√
2004	F-150	5.4L	3V	4X4	√	√	√	√
2004	F-150	5.4L	3V	4X4	√	√	√	√
2004	F-150	5.4L	3V	ABS	√	√	√	√
2004	F-150	5.4L	3V	ABS	√	√	√	√
2004	F-150	5.4L	3V	DSM	√	√	√	√
2004	F-150	5.4L	3V	EATC	√	√	√	√
2004	F-150	5.4L	3V	IC	√	√	√	√
2004	F-150	5.4L	3V	PAM	√	√	√	√
2004	F-150	5.4L	3V	PAM	√	√	√	√
2004	F-150	5.4L	3V	PCM	√	√	√	√
2004	F-150	5.4L	3V	PCM	√	√	√	√
2004	F-150	5.4L	3V	RCM	√	√	√	√
2004	F-150	5.4L	3V	VSM	√	√	√	√
2004	F-150	Other	Other	4X4	√	√	√	√
2004	F-150	Other	Other	ABS	√	√	√	√
2004	F-150	Other	Other	DSM	√	√	√	√
2004	F-150	Other	Other	EATC	√	√	√	√
2004	F-150	Other	Other	IC	√	√	√	√
2004	F-150	Other	Other	PAM	√	√	√	√
2004	F-150	Other	Other	PCM	√	√	√	√
2004	F-150	Other	Other	RCM	√	√	√	√
2004	F-150	Other	Other	VSM	√	√	√	√
2005	F-150	4.2L	2V	4X4	√	√	√	√
2005	F-150	4.2L	2V	ABS	√	√	√	√
2005	F-150	4.2L	2V	DSM	√	√	√	√
2005	F-150	4.2L	2V	EATC	√	√	√	√
2005	F-150	4.2L	2V	IC	√	√	√	√
2005	F-150	4.2L	2V	PAM	√	√	√	√
2005	F-150	4.2L	2V	PCM	√	√	√	√
2005	F-150	4.2L	2V	RCM	√	√	√	√
2005	F-150	4.2L	2V	VSM	√	√	√	√
2005	F-150	4.2L	Other	ABS/TCS	√	√	√	√
2005	F-150	4.2L	Other	GEM	√	√	√	√
2005	F-150	4.2L	Other	IC	√	√	√	√
2005	F-150	4.2L	Other	PCM	√	√	√	√
2005	F-150	4.2L	Other	RAP	√	√	√	√
2005	F-150	4.2L	Other	RCM	√	√	√	√
2005	F-150	4.6L	2V	4X4	√	√	√	√
2005	F-150	4.6L	2V	ABS	√	√	√	√
2005	F-150	4.6L	2V	ABS/TCS	√	√	√	√
2005	F-150	4.6L	2V	DSM	√	√	√	√

2005	F-150	4.6L	2V	EATC	√	√	√	√
2005	F-150	4.6L	2V	GEM	√	√	√	√
2005	F-150	4.6L	2V	IC	√	√	√	√
2005	F-150	4.6L	2V	PAM	√	√	√	√
2005	F-150	4.6L	2V	PCM	√	√	√	√
2005	F-150	4.6L	2V	PCM	√	√	√	√
2005	F-150	4.6L	2V	RAP	√	√	√	√
2005	F-150	4.6L	2V	RCM	√	√	√	√
2005	F-150	4.6L	2V	RCM	√	√	√	√
2005	F-150	4.6L	2V	VSM	√	√	√	√
2005	F-150	5.4L	3V	4X4	√	√	√	√
2005	F-150	5.4L	3V	ABS	√	√	√	√
2005	F-150	5.4L	3V	ABS	√	√	√	√
2005	F-150	5.4L	3V	DSM	√	√	√	√
2005	F-150	5.4L	3V	EATC	√	√	√	√
2005	F-150	5.4L	3V	IC	√	√	√	√
2005	F-150	5.4L	3V	PAM	√	√	√	√
2005	F-150	5.4L	3V	PAM	√	√	√	√
2005	F-150	5.4L	3V	PCM	√	√	√	√
2005	F-150	5.4L	3V	PCM	√	√	√	√
2005	F-150	5.4L	3V	RCM	√	√	√	√
2005	F-150	5.4L	3V	VSM	√	√	√	√
2006	F-150	4.2L	2V	4X4	√	√	√	√
2006	F-150	4.2L	2V	ABS	√	√	√	√
2006	F-150	4.2L	2V	DSM	√	√	√	√
2006	F-150	4.2L	2V	EATC	√	√	√	√
2006	F-150	4.2L	2V	IC	√	√	√	√
2006	F-150	4.2L	2V	PAM	√	√	√	√
2006	F-150	4.2L	2V	PCM	√	√	√	√
2006	F-150	4.2L	2V	RCM	√	√	√	√
2006	F-150	4.2L	2V	VSM	√	√	√	√
2006	F-150	4.2L	Other	GEM	√	√	√	√
2006	F-150	4.2L	Other	IC	√	√	√	√
2006	F-150	4.2L	Other	PCM	√	√	√	√
2006	F-150	4.2L	Other	RAP	√	√	√	√
2006	F-150	4.2L	Other	RCM	√	√	√	√
2006	F-150	4.6L	2V	4X4	√	√	√	√
2006	F-150	4.6L	2V	ABS	√	√	√	√
2006	F-150	4.6L	2V	ABS/TCS	√	√	√	√
2006	F-150	4.6L	2V	DSM	√	√	√	√
2006	F-150	4.6L	2V	EATC	√	√	√	√
2006	F-150	4.6L	2V	GEM	√	√	√	√
2006	F-150	4.6L	2V	IC	√	√	√	√
2006	F-150	4.6L	2V	PAM	√	√	√	√
2006	F-150	4.6L	2V	PCM	√	√	√	√

2006	F-150	4.6L	2V	PCM	√	√	√	√
2006	F-150	4.6L	2V	RAP	√	√	√	√
2006	F-150	4.6L	2V	RCM	√	√	√	√
2006	F-150	4.6L	2V	RCM	√	√	√	√
2006	F-150	4.6L	2V	VSM	√	√	√	√
2006	F-150	5.4L	3V	4X4	√	√	√	√
2006	F-150	5.4L	3V	ABS	√	√	√	√
2006	F-150	5.4L	3V	ABS	√	√	√	√
2006	F-150	5.4L	3V	DSM	√	√	√	√
2006	F-150	5.4L	3V	EATC	√	√	√	√
2006	F-150	5.4L	3V	IC	√	√	√	√
2006	F-150	5.4L	3V	PAM	√	√	√	√
2006	F-150	5.4L	3V	PAM	√	√	√	√
2006	F-150	5.4L	3V	PCM	√	√	√	√
2006	F-150	5.4L	3V	PCM	√	√	√	√
2006	F-150	5.4L	3V	RCM	√	√	√	√
2006	F-150	5.4L	3V	VSM	√	√	√	√
2007	F-150	4.2L	2V	4X4	√	√	√	√
2007	F-150	4.2L	2V	ABS	√	√	√	√
2007	F-150	4.2L	2V	DSM	√	√	√	√
2007	F-150	4.2L	2V	EATC	√	√	√	√
2007	F-150	4.2L	2V	IC	√	√	√	√
2007	F-150	4.2L	2V	PAM	√	√	√	√
2007	F-150	4.2L	2V	PCM	√	√	√	√
2007	F-150	4.2L	2V	RCM	√	√	√	√
2007	F-150	4.2L	2V	VSM	√	√	√	√
2007	F-150	4.6L	2V	4X4	√	√	√	√
2007	F-150	4.6L	2V	ABS	√	√	√	√
2007	F-150	4.6L	2V	DSM	√	√	√	√
2007	F-150	4.6L	2V	EATC	√	√	√	√
2007	F-150	4.6L	2V	IC	√	√	√	√
2007	F-150	4.6L	2V	PAM	√	√	√	√
2007	F-150	4.6L	2V	PCM	√	√	√	√
2007	F-150	4.6L	2V	PCM	√	√	√	√
2007	F-150	4.6L	2V	RCM	√	√	√	√
2007	F-150	4.6L	2V	VSM	√	√	√	√
2007	F-150	5.4L	3V	4X4	√	√	√	√
2007	F-150	5.4L	3V	ABS	√	√	√	√
2007	F-150	5.4L	3V	ABS	√	√	√	√
2007	F-150	5.4L	3V	DSM	√	√	√	√
2007	F-150	5.4L	3V	EATC	√	√	√	√
2007	F-150	5.4L	3V	IC	√	√	√	√
2007	F-150	5.4L	3V	IC	√	√	√	√
2007	F-150	5.4L	3V	PAM	√	√	√	√
2007	F-150	5.4L	3V	PAM	√	√	√	√

2007	F-150	5.4L	3V	PCM	✓	✓	✓	✓
2007	F-150	5.4L	3V	PCM	✓	✓	✓	✓
2007	F-150	5.4L	3V	RCM	✓	✓	✓	✓
2007	F-150	5.4L	3V	VSM	✓	✓	✓	✓
2008	F-150	4.2L	2V	4X4	✓	✓	✓	✓
2008	F-150	4.2L	2V	ABS	✓	✓	✓	✓
2008	F-150	4.2L	2V	DSM	✓	✓	✓	✓
2008	F-150	4.2L	2V	HVAC	✓	✓	✓	✓
2008	F-150	4.2L	2V	IC	✓	✓	✓	✓
2008	F-150	4.2L	2V	PAM	✓	✓	✓	✓
2008	F-150	4.2L	2V	PCM	✓	✓	✓	✓
2008	F-150	4.2L	2V	PCM	✓	✓	✓	✓
2008	F-150	4.2L	2V	RCM	✓	✓	✓	✓
2008	F-150	4.2L	2V	RETM	✓	✓	✓	✓
2008	F-150	4.2L	2V	VSM	✓	✓	✓	✓
2008	F-150	4.6L	2V	4X4	✓	✓	✓	✓
2008	F-150	4.6L	2V	ABS	✓	✓	✓	✓
2008	F-150	4.6L	2V	DSM	✓	✓	✓	✓
2008	F-150	4.6L	2V	HVAC	✓	✓	✓	✓
2008	F-150	4.6L	2V	IC	✓	✓	✓	✓
2008	F-150	4.6L	2V	PAM	✓	✓	✓	✓
2008	F-150	4.6L	2V	PCM	✓	✓	✓	✓
2008	F-150	4.6L	2V	RCM	✓	✓	✓	✓
2008	F-150	4.6L	2V	RETM	✓	✓	✓	✓
2008	F-150	4.6L	2V	VSM	✓	✓	✓	✓
2008	F-150	5.4L	3V	4X4	✓	✓	✓	✓
2008	F-150	5.4L	3V	ABS	✓	✓	✓	✓
2008	F-150	5.4L	3V	DSM	✓	✓	✓	✓
2008	F-150	5.4L	3V	IC	✓	✓	✓	✓
2008	F-150	5.4L	3V	PAM	✓	✓	✓	✓
2008	F-150	5.4L	3V	PAM	✓	✓	✓	✓
2008	F-150	5.4L	3V	PCM	✓	✓	✓	✓
2008	F-150	5.4L	3V	PCM	✓	✓	✓	✓
2008	F-150	5.4L	3V	RCM	✓	✓	✓	✓
2008	F-150	5.4L	3V	RETM	✓	✓	✓	✓
2008	F-150	5.4L	3V	RETM	✓	✓	✓	✓
2008	F-150	5.4L	3V	VSM	✓	✓	✓	✓
2009	F-150	4.6L	2V	ABS	✓	✓	✓	✓
2009	F-150	4.6L	2V	ACM	✓	✓	✓	✓
2009	F-150	4.6L	2V	APIM	✓	✓	✓	✓
2009	F-150	4.6L	2V	DCSM	✓	✓	✓	✓
2009	F-150	4.6L	2V	DSM	✓	✓	✓	✓
2009	F-150	4.6L	2V	DSP	✓	✓	✓	✓
2009	F-150	4.6L	2V	FCIM	✓	✓	✓	✓
2009	F-150	4.6L	2V	FDIM	✓	✓	✓	✓

2009	F-150	4.6L	2V	GEM / SJB	√	√	√	√
2009	F-150	4.6L	2V	HVAC	√	√	√	√
2009	F-150	4.6L	2V	IC	√	√	√	√
2009	F-150	4.6L	2V	OCSM	√	√	√	√
2009	F-150	4.6L	2V	PAM	√	√	√	√
2009	F-150	4.6L	2V	PCM	√	√	√	√
2009	F-150	4.6L	2V	PRB	√	√	√	√
2009	F-150	4.6L	2V	RCM	√	√	√	√
2009	F-150	4.6L	2V	TBC	√	√	√	√
2009	F-150	4.6L	2V	TCCM	√	√	√	√
2009	F-150	4.6L	3V	ABS	√	√	√	√
2009	F-150	4.6L	3V	ABS	√	√	√	√
2009	F-150	4.6L	3V	ACM	√	√	√	√
2009	F-150	4.6L	3V	ACM	√	√	√	√
2009	F-150	4.6L	3V	APIM	√	√	√	√
2009	F-150	4.6L	3V	APIM	√	√	√	√
2009	F-150	4.6L	3V	DCSM	√	√	√	√
2009	F-150	4.6L	3V	DSM	√	√	√	√
2009	F-150	4.6L	3V	DSP	√	√	√	√
2009	F-150	4.6L	3V	FCIM	√	√	√	√
2009	F-150	4.6L	3V	FDIM	√	√	√	√
2009	F-150	4.6L	3V	GEM / SJB	√	√	√	√
2009	F-150	4.6L	3V	GEM / SJB	√	√	√	√
2009	F-150	4.6L	3V	HVAC	√	√	√	√
2009	F-150	4.6L	3V	IC	√	√	√	√
2009	F-150	4.6L	3V	OCSM	√	√	√	√
2009	F-150	4.6L	3V	OCSM	√	√	√	√
2009	F-150	4.6L	3V	PAM	√	√	√	√
2009	F-150	4.6L	3V	PCM	√	√	√	√
2009	F-150	4.6L	3V	PCM	√	√	√	√
2009	F-150	4.6L	3V	PRB	√	√	√	√
2009	F-150	4.6L	3V	RCM	√	√	√	√
2009	F-150	4.6L	3V	TBC	√	√	√	√
2009	F-150	4.6L	3V	TCCM	√	√	√	√
2009	F-150	4.6L	3V	TCM	√	√	√	√
2009	F-150	5.4L	3V	ABS	√	√	√	√
2009	F-150	5.4L	3V	ABS	√	√	√	√
2009	F-150	5.4L	3V	ACM	√	√	√	√
2009	F-150	5.4L	3V	ACM	√	√	√	√
2009	F-150	5.4L	3V	APIM	√	√	√	√
2009	F-150	5.4L	3V	APIM	√	√	√	√
2009	F-150	5.4L	3V	DCSM	√	√	√	√
2009	F-150	5.4L	3V	DSM	√	√	√	√
2009	F-150	5.4L	3V	DSP	√	√	√	√
2009	F-150	5.4L	3V	FCIM	√	√	√	√



2009	F-150	5.4L	3V	FDIM	√	√	√	√
2009	F-150	5.4L	3V	GEM / SJB	√	√	√	√
2009	F-150	5.4L	3V	GEM / SJB	√	√	√	√
2009	F-150	5.4L	3V	HVAC	√	√	√	√
2009	F-150	5.4L	3V	IC	√	√	√	√
2009	F-150	5.4L	3V	OCSM	√	√	√	√
2009	F-150	5.4L	3V	OCSM	√	√	√	√
2009	F-150	5.4L	3V	PAM	√	√	√	√
2009	F-150	5.4L	3V	PCM	√	√	√	√
2009	F-150	5.4L	3V	PCM	√	√	√	√
2009	F-150	5.4L	3V	PCM	√	√	√	√
2009	F-150	5.4L	3V	PRB	√	√	√	√
2009	F-150	5.4L	3V	RCM	√	√	√	√
2009	F-150	5.4L	3V	TBC	√	√	√	√
2009	F-150	5.4L	3V	TCCM	√	√	√	√
2009	F-150	5.4L	3V	TCM	√	√	√	√
2009	F-150	5.4L	3V	TCM	√	√	√	√
2010	F-150	4.6L	2V	ABS	√	√	√	√
2010	F-150	4.6L	2V	ACM	√	√	√	√
2010	F-150	4.6L	2V	APIM	√	√	√	√
2010	F-150	4.6L	2V	DCSM	√	√	√	√
2010	F-150	4.6L	2V	DSM	√	√	√	√
2010	F-150	4.6L	2V	DSP	√	√	√	√
2010	F-150	4.6L	2V	FCIM	√	√	√	√
2010	F-150	4.6L	2V	FDIM	√	√	√	√
2010	F-150	4.6L	2V	GPSM	√	√	√	√
2010	F-150	4.6L	2V	HVAC	√	√	√	√
2010	F-150	4.6L	2V	IC	√	√	√	√
2010	F-150	4.6L	2V	ILCM	√	√	√	√
2010	F-150	4.6L	2V	OCSM	√	√	√	√
2010	F-150	4.6L	2V	PAM	√	√	√	√
2010	F-150	4.6L	2V	PCM	√	√	√	√
2010	F-150	4.6L	2V	PRB	√	√	√	√
2010	F-150	4.6L	2V	RCM	√	√	√	√
2010	F-150	4.6L	2V	TBC	√	√	√	√
2010	F-150	4.6L	2V	TCCM	√	√	√	√
2010	F-150	4.6L	3V	ABS	√	√	√	√
2010	F-150	4.6L	3V	ABS	√	√	√	√
2010	F-150	4.6L	3V	ACM	√	√	√	√
2010	F-150	4.6L	3V	ACM	√	√	√	√
2010	F-150	4.6L	3V	APIM	√	√	√	√
2010	F-150	4.6L	3V	APIM	√	√	√	√
2010	F-150	4.6L	3V	DCSM	√	√	√	√
2010	F-150	4.6L	3V	DSM	√	√	√	√
2010	F-150	4.6L	3V	DSP	√	√	√	√

2010	F-150	4.6L	3V	FCIM	√	√	√	√
2010	F-150	4.6L	3V	FDIM	√	√	√	√
2010	F-150	4.6L	3V	GEM / SJB	√	√	√	√
2010	F-150	4.6L	3V	GEM / SJB	√	√	√	√
2010	F-150	4.6L	3V	GPSM	√	√	√	√
2010	F-150	4.6L	3V	HVAC	√	√	√	√
2010	F-150	4.6L	3V	IC	√	√	√	√
2010	F-150	4.6L	3V	IILCM	√	√	√	√
2010	F-150	4.6L	3V	OCSM	√	√	√	√
2010	F-150	4.6L	3V	OCSM	√	√	√	√
2010	F-150	4.6L	3V	PAM	√	√	√	√
2010	F-150	4.6L	3V	PCM	√	√	√	√
2010	F-150	4.6L	3V	PCM	√	√	√	√
2010	F-150	4.6L	3V	PRB	√	√	√	√
2010	F-150	4.6L	3V	RCM	√	√	√	√
2010	F-150	4.6L	3V	TBC	√	√	√	√
2010	F-150	4.6L	3V	TCCM	√	√	√	√
2010	F-150	4.6L	3V	TCM	√	√	√	√
2010	F-150	5.4L	3V	ABS	√	√	√	√
2010	F-150	5.4L	3V	ABS	√	√	√	√
2010	F-150	5.4L	3V	ACM	√	√	√	√
2010	F-150	5.4L	3V	ACM	√	√	√	√
2010	F-150	5.4L	3V	APIM	√	√	√	√
2010	F-150	5.4L	3V	APIM	√	√	√	√
2010	F-150	5.4L	3V	DCSM	√	√	√	√
2010	F-150	5.4L	3V	DSM	√	√	√	√
2010	F-150	5.4L	3V	DSP	√	√	√	√
2010	F-150	5.4L	3V	FCIM	√	√	√	√
2010	F-150	5.4L	3V	FDIM	√	√	√	√
2010	F-150	5.4L	3V	GEM / SJB	√	√	√	√
2010	F-150	5.4L	3V	GEM / SJB	√	√	√	√
2010	F-150	5.4L	3V	GPSM	√	√	√	√
2010	F-150	5.4L	3V	HVAC	√	√	√	√
2010	F-150	5.4L	3V	IC	√	√	√	√
2010	F-150	5.4L	3V	IILCM	√	√	√	√
2010	F-150	5.4L	3V	OCSM	√	√	√	√
2010	F-150	5.4L	3V	OCSM	√	√	√	√
2010	F-150	5.4L	3V	PAM	√	√	√	√
2010	F-150	5.4L	3V	PCM	√	√	√	√
2010	F-150	5.4L	3V	PCM	√	√	√	√
2010	F-150	5.4L	3V	PRB	√	√	√	√
2010	F-150	5.4L	3V	RCM	√	√	√	√
2010	F-150	5.4L	3V	TBC	√	√	√	√
2010	F-150	5.4L	3V	TCCM	√	√	√	√
2010	F-150	5.4L	3V	TCM	√	√	√	√

2010	F-150	6.2L	2V	ABS	✓	✓	✓	✓
2010	F-150	6.2L	2V	ACM	✓	✓	✓	✓
2010	F-150	6.2L	2V	APIM	✓	✓	✓	✓
2010	F-150	6.2L	2V	DCSM	✓	✓	✓	✓
2010	F-150	6.2L	2V	DSM	✓	✓	✓	✓
2010	F-150	6.2L	2V	DSP	✓	✓	✓	✓
2010	F-150	6.2L	2V	FCIM	✓	✓	✓	✓
2010	F-150	6.2L	2V	FDIM	✓	✓	✓	✓
2010	F-150	6.2L	2V	GEM / SJB	✓	✓	✓	✓
2010	F-150	6.2L	2V	GPSM	✓	✓	✓	✓
2010	F-150	6.2L	2V	HVAC	✓	✓	✓	✓
2010	F-150	6.2L	2V	IC	✓	✓	✓	✓
2010	F-150	6.2L	2V	ILCM	✓	✓	✓	✓
2010	F-150	6.2L	2V	OCSM	✓	✓	✓	✓
2010	F-150	6.2L	2V	PAM	✓	✓	✓	✓
2010	F-150	6.2L	2V	PCM	✓	✓	✓	✓
2010	F-150	6.2L	2V	PRB	✓	✓	✓	✓
2010	F-150	6.2L	2V	RCM	✓	✓	✓	✓
2010	F-150	6.2L	2V	TBC	✓	✓	✓	✓
2010	F-150	6.2L	2V	TCCM	✓	✓	✓	✓
2011	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	ACM	✓	✓	✓	✓
2011	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	APIM	✓	✓	✓	✓
2011	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	BCM#1	✓	✓	✓	✓
2011	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	DCSM	✓	✓	✓	✓
2011	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	DSM	✓	✓	✓	✓
2011	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	DSM	✓	✓	✓	✓
2011	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	DSP	✓	✓	✓	✓
2011	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	FCIM	✓	✓	✓	
2011	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	FDIM	✓	✓	✓	✓
2011	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	FDIM	✓	✓	✓	✓
2011	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	GPSM	✓	✓	✓	✓
2011	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	HVAC	✓	✓	✓	✓
2011	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	HVAC	✓	✓	✓	✓
2011	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	ILCM	✓	✓	✓	✓
2011	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	IPC	✓	✓	✓	✓
2011	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	IPC	✓	✓	✓	✓
2011	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	OCSM	✓	✓	✓	✓
2011	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	PAM	✓	✓	✓	✓
2011	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2011	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2011	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PRB	✓	✓	✓	✓
2011	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	PSCM	✓	✓	✓	✓
2011	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	PSCM	✓	✓	✓	✓
2011	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	RCM	✓	✓	✓	✓

2011	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	SCCM	√	√	√	√
2011	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	SCCM	√	√	√	√
2011	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	TBC	√	√	√	√
2011	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	TCCM	√	√	√	√
2011	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TPM	√	√	√	√
2011	F-150	3.7L	TiVCT	ACM	√	√	√	√
2011	F-150	3.7L	TiVCT	APIM	√	√	√	√
2011	F-150	3.7L	TiVCT	BCM#1	√	√	√	√
2011	F-150	3.7L	TiVCT	DCSM	√	√	√	√
2011	F-150	3.7L	TiVCT	DSM	√	√	√	√
2011	F-150	3.7L	TiVCT	DSP	√	√	√	√
2011	F-150	3.7L	TiVCT	FCIM	√	√	√	
2011	F-150	3.7L	TiVCT	FDIM	√	√	√	√
2011	F-150	3.7L	TiVCT	GPSM	√	√	√	√
2011	F-150	3.7L	TiVCT	HVAC	√	√	√	√
2011	F-150	3.7L	TiVCT	ILCM	√	√	√	√
2011	F-150	3.7L	TiVCT	IPC	√	√	√	√
2011	F-150	3.7L	TiVCT	OCSM	√	√	√	√
2011	F-150	3.7L	TiVCT	PAM	√	√	√	√
2011	F-150	3.7L	TiVCT	PCM	√	√	√	√
2011	F-150	3.7L	TiVCT	PRB	√	√	√	√
2011	F-150	3.7L	TiVCT	PSCM	√	√	√	√
2011	F-150	3.7L	TiVCT	RCM	√	√	√	√
2011	F-150	3.7L	TiVCT	SCCM	√	√	√	√
2011	F-150	3.7L	TiVCT	TBC	√	√	√	√
2011	F-150	3.7L	TiVCT	TCCM	√	√	√	√
2011	F-150	3.7L	TiVCT	TPM	√	√	√	√
2011	F-150	5.0L	TiVCT	ABS	√	√	√	√
2011	F-150	5.0L	TiVCT	ACM	√	√	√	√
2011	F-150	5.0L	TiVCT	APIM	√	√	√	√
2011	F-150	5.0L	TiVCT	BCM#1	√	√	√	√
2011	F-150	5.0L	TiVCT	DCSM	√	√	√	√
2011	F-150	5.0L	TiVCT	DSM	√	√	√	√
2011	F-150	5.0L	TiVCT	DSP	√	√	√	√
2011	F-150	5.0L	TiVCT	FCIM	√	√	√	
2011	F-150	5.0L	TiVCT	FDIM	√	√	√	√
2011	F-150	5.0L	TiVCT	GPSM	√	√	√	√
2011	F-150	5.0L	TiVCT	HVAC	√	√	√	√
2011	F-150	5.0L	TiVCT	ILCM	√	√	√	√
2011	F-150	5.0L	TiVCT	IPC	√	√	√	√
2011	F-150	5.0L	TiVCT	OCSM	√	√	√	√
2011	F-150	5.0L	TiVCT	OCSM	√	√	√	√
2011	F-150	5.0L	TiVCT	PAM	√	√	√	√
2011	F-150	5.0L	TiVCT	PCM	√	√	√	√

2011	F-150	5.0L	TiVCT	PRB	√	√	√	√
2011	F-150	5.0L	TiVCT	PSCM	√	√	√	√
2011	F-150	5.0L	TiVCT	RCM	√	√	√	√
2011	F-150	5.0L	TiVCT	SCCM	√	√	√	√
2011	F-150	5.0L	TiVCT	TBC	√	√	√	√
2011	F-150	5.0L	TiVCT	TCCM	√	√	√	√
2011	F-150	5.0L	TiVCT	TPM	√	√	√	√
2011	F-150	6.2L	2V	ABS	√	√	√	√
2011	F-150	6.2L	2V	ACM	√	√	√	√
2011	F-150	6.2L	2V	APIM	√	√	√	√
2011	F-150	6.2L	2V	BCM#1	√	√	√	√
2011	F-150	6.2L	2V	DCSM	√	√	√	√
2011	F-150	6.2L	2V	DSM	√	√	√	√
2011	F-150	6.2L	2V	DSP	√	√	√	√
2011	F-150	6.2L	2V	FCIM	√	√	√	
2011	F-150	6.2L	2V	FDIM	√	√	√	√
2011	F-150	6.2L	2V	GPSM	√	√	√	√
2011	F-150	6.2L	2V	HVAC	√	√	√	√
2011	F-150	6.2L	2V	ILCM	√	√	√	√
2011	F-150	6.2L	2V	IPC	√	√	√	√
2011	F-150	6.2L	2V	OCSM	√	√	√	√
2011	F-150	6.2L	2V	PAM	√	√	√	√
2011	F-150	6.2L	2V	PCM	√	√	√	√
2011	F-150	6.2L	2V	PRB	√	√	√	√
2011	F-150	6.2L	2V	PSCM	√	√	√	√
2011	F-150	6.2L	2V	RCM	√	√	√	√
2011	F-150	6.2L	2V	SCCM	√	√	√	√
2011	F-150	6.2L	2V	TBC	√	√	√	√
2011	F-150	6.2L	2V	TCCM	√	√	√	√
2011	F-150	6.2L	2V	TPM	√	√	√	√
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	BCM#1	√	√	√	√
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	DCSM	√	√	√	√
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	DSP	√	√	√	√
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	FDIM	√	√	√	√
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	√
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	√
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	ILCM	√	√	√	√
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	OCSM	√	√	√	√
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√

2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	PRB	√	√	√	√
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	SCCM	√	√	√	√
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	TBC	√	√	√	√
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	TCCM	√	√	√	√
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	TPM	√	√	√	√
2012	F-150	3.7L	TiVCT	ABS	√	√	√	√
2012	F-150	3.7L	TiVCT	ACM	√	√	√	√
2012	F-150	3.7L	TiVCT	APIM	√	√	√	√
2012	F-150	3.7L	TiVCT	BCM#1	√	√	√	√
2012	F-150	3.7L	TiVCT	DCSM	√	√	√	√
2012	F-150	3.7L	TiVCT	DSM	√	√	√	√
2012	F-150	3.7L	TiVCT	DSP	√	√	√	√
2012	F-150	3.7L	TiVCT	FCIM	√	√	√	
2012	F-150	3.7L	TiVCT	FDIM	√	√	√	√
2012	F-150	3.7L	TiVCT	GPSM	√	√	√	√
2012	F-150	3.7L	TiVCT	HVAC	√	√	√	√
2012	F-150	3.7L	TiVCT	ILCM	√	√	√	√
2012	F-150	3.7L	TiVCT	IPC	√	√	√	√
2012	F-150	3.7L	TiVCT	OCSM	√	√	√	√
2012	F-150	3.7L	TiVCT	PAM	√	√	√	√
2012	F-150	3.7L	TiVCT	PCM	√	√	√	√
2012	F-150	3.7L	TiVCT	PRB	√	√	√	√
2012	F-150	3.7L	TiVCT	PSCM	√	√	√	√
2012	F-150	3.7L	TiVCT	RCM	√	√	√	√
2012	F-150	3.7L	TiVCT	SCCM	√	√	√	√
2012	F-150	3.7L	TiVCT	TBC	√	√	√	√
2012	F-150	3.7L	TiVCT	TCCM	√	√	√	√
2012	F-150	3.7L	TiVCT	TPM	√	√	√	√
2012	F-150	5.0L	TiVCT	ABS	√	√	√	√
2012	F-150	5.0L	TiVCT	ABS	√	√	√	√
2012	F-150	5.0L	TiVCT	ACM	√	√	√	√
2012	F-150	5.0L	TiVCT	ACM	√	√	√	√
2012	F-150	5.0L	TiVCT	APIM	√	√	√	√
2012	F-150	5.0L	TiVCT	APIM	√	√	√	√
2012	F-150	5.0L	TiVCT	BCM#1	√	√	√	√
2012	F-150	5.0L	TiVCT	BCM#1	√	√	√	√
2012	F-150	5.0L	TiVCT	DCSM	√	√	√	√
2012	F-150	5.0L	TiVCT	DSM	√	√	√	√
2012	F-150	5.0L	TiVCT	DSP	√	√	√	√
2012	F-150	5.0L	TiVCT	FDIM	√	√	√	√
2012	F-150	5.0L	TiVCT	GPSM	√	√	√	√
2012	F-150	5.0L	TiVCT	HVAC	√	√	√	√
2012	F-150	5.0L	TiVCT	ILCM	√	√	√	√

2012	F-150	5.0L	TiVCT	IPC	√	√	√	√
2012	F-150	5.0L	TiVCT	OCSM	√	√	√	√
2012	F-150	5.0L	TiVCT	PAM	√	√	√	√
2012	F-150	5.0L	TiVCT	PCM	√	√	√	√
2012	F-150	5.0L	TiVCT	PCM	√	√	√	√
2012	F-150	5.0L	TiVCT	PRB	√	√	√	√
2012	F-150	5.0L	TiVCT	PSCM	√	√	√	√
2012	F-150	5.0L	TiVCT	RCM	√	√	√	√
2012	F-150	5.0L	TiVCT	SCCM	√	√	√	√
2012	F-150	5.0L	TiVCT	TBC	√	√	√	√
2012	F-150	5.0L	TiVCT	TCCM	√	√	√	√
2012	F-150	5.0L	TiVCT	TPM	√	√	√	√
2012	F-150	6.2L	2V	ABS	√	√	√	√
2012	F-150	6.2L	2V	ACM	√	√	√	√
2012	F-150	6.2L	2V	APIM	√	√	√	√
2012	F-150	6.2L	2V	BCM#1	√	√	√	√
2012	F-150	6.2L	2V	DCSM	√	√	√	√
2012	F-150	6.2L	2V	DSM	√	√	√	√
2012	F-150	6.2L	2V	DSP	√	√	√	√
2012	F-150	6.2L	2V	FCIM	√	√	√	
2012	F-150	6.2L	2V	FDIM	√	√	√	√
2012	F-150	6.2L	2V	GPSM	√	√	√	√
2012	F-150	6.2L	2V	HVAC	√	√	√	√
2012	F-150	6.2L	2V	ILCM	√	√	√	√
2012	F-150	6.2L	2V	IPC	√	√	√	√
2012	F-150	6.2L	2V	OCSM	√	√	√	√
2012	F-150	6.2L	2V	PAM	√	√	√	√
2012	F-150	6.2L	2V	PCM	√	√	√	√
2012	F-150	6.2L	2V	PRB	√	√	√	√
2012	F-150	6.2L	2V	PSCM	√	√	√	√
2012	F-150	6.2L	2V	RCM	√	√	√	√
2012	F-150	6.2L	2V	SCCM	√	√	√	√
2012	F-150	6.2L	2V	TBC	√	√	√	√
2012	F-150	6.2L	2V	TCCM	√	√	√	√
2012	F-150	6.2L	2V	TPM	√	√	√	√
2012	F-150	Other	Other	ABS	√	√	√	
2012	F-150	Other	Other	ACM	√	√	√	
2012	F-150	Other	Other	BCM#1	√	√	√	
2012	F-150	Other	Other	DCSM	√	√	√	
2012	F-150	Other	Other	DSM	√	√	√	
2012	F-150	Other	Other	DSP	√	√	√	
2012	F-150	Other	Other	FCIM	√	√	√	
2012	F-150	Other	Other	FDIM	√	√	√	
2012	F-150	Other	Other	HVAC	√	√	√	
2012	F-150	Other	Other	ILCM	√	√	√	

2012	F-150	Other	Other	IPC	√	√	√	
2012	F-150	Other	Other	OCSM	√	√	√	
2012	F-150	Other	Other	PAM	√	√	√	
2012	F-150	Other	Other	PRB	√	√	√	
2012	F-150	Other	Other	PSCM	√	√	√	
2012	F-150	Other	Other	RCM	√	√	√	
2012	F-150	Other	Other	SCCM	√	√	√	
2012	F-150	Other	Other	TBC	√	√	√	
2012	F-150	Other	Other	TCCM	√	√	√	
2012	F-150	Other	Other	TPM	√	√	√	
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS	√	√	√	√
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	BCM#1	√	√	√	√
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	DCSM	√	√	√	√
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	DSM	√	√	√	√
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	DSP	√	√	√	√
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	FCDIM	√	√	√	√
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	√	√	√	√
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	√
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	OCSM	√	√	√	√
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	PRB	√	√	√	√
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	RTM	√	√	√	√
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	SCCM	√	√	√	√
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	TBC	√	√	√	√
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	TCCM	√	√	√	√
2013	F-150	3.7L	TiVCT	ABS	√	√	√	√
2013	F-150	3.7L	TiVCT	ACM	√	√	√	√
2013	F-150	3.7L	TiVCT	APIM	√	√	√	√
2013	F-150	3.7L	TiVCT	BCM#1	√	√	√	√
2013	F-150	3.7L	TiVCT	DCSM	√	√	√	√
2013	F-150	3.7L	TiVCT	DSM	√	√	√	√
2013	F-150	3.7L	TiVCT	DSP	√	√	√	√
2013	F-150	3.7L	TiVCT	FCDIM	√	√	√	√
2013	F-150	3.7L	TiVCT	FCIM	√	√	√	√
2013	F-150	3.7L	TiVCT	FDIM	√	√	√	√
2013	F-150	3.7L	TiVCT	GPSM	√	√	√	√
2013	F-150	3.7L	TiVCT	IPC	√	√	√	√



2013	F-150	3.7L	TiVCT	OCSM	√	√	√	√
2013	F-150	3.7L	TiVCT	PAM	√	√	√	
2013	F-150	3.7L	TiVCT	PCM	√	√	√	√
2013	F-150	3.7L	TiVCT	PRB	√	√	√	√
2013	F-150	3.7L	TiVCT	PSCM	√	√	√	√
2013	F-150	3.7L	TiVCT	RCM	√	√	√	√
2013	F-150	3.7L	TiVCT	RTM	√	√	√	√
2013	F-150	3.7L	TiVCT	SCCM	√	√	√	√
2013	F-150	3.7L	TiVCT	TBC	√	√	√	√
2013	F-150	3.7L	TiVCT	TCCM	√	√	√	√
2013	F-150	5.0L	TiVCT	ABS	√	√	√	√
2013	F-150	5.0L	TiVCT	ACM	√	√	√	√
2013	F-150	5.0L	TiVCT	APIM	√	√	√	√
2013	F-150	5.0L	TiVCT	BCM#1	√	√	√	√
2013	F-150	5.0L	TiVCT	DCSM	√	√	√	√
2013	F-150	5.0L	TiVCT	DSM	√	√	√	√
2013	F-150	5.0L	TiVCT	DSP	√	√	√	√
2013	F-150	5.0L	TiVCT	FCDIM	√	√	√	√
2013	F-150	5.0L	TiVCT	FCIM	√	√	√	√
2013	F-150	5.0L	TiVCT	FDIM	√	√	√	√
2013	F-150	5.0L	TiVCT	GPSM	√	√	√	√
2013	F-150	5.0L	TiVCT	IPC	√	√	√	√
2013	F-150	5.0L	TiVCT	OCSM	√	√	√	√
2013	F-150	5.0L	TiVCT	PAM	√	√	√	
2013	F-150	5.0L	TiVCT	PCM	√	√	√	√
2013	F-150	5.0L	TiVCT	PRB	√	√	√	√
2013	F-150	5.0L	TiVCT	PSCM	√	√	√	√
2013	F-150	5.0L	TiVCT	RCM	√	√	√	√
2013	F-150	5.0L	TiVCT	RTM	√	√	√	√
2013	F-150	5.0L	TiVCT	SCCM	√	√	√	√
2013	F-150	5.0L	TiVCT	TBC	√	√	√	√
2013	F-150	5.0L	TiVCT	TCCM	√	√	√	√
2013	F-150	6.2L	2V	ABS	√	√	√	√
2013	F-150	6.2L	2V	ACM	√	√	√	√
2013	F-150	6.2L	2V	APIM	√	√	√	√
2013	F-150	6.2L	2V	BCM#1	√	√	√	√
2013	F-150	6.2L	2V	DCSM	√	√	√	√
2013	F-150	6.2L	2V	DSM	√	√	√	√
2013	F-150	6.2L	2V	FCDIM	√	√	√	√
2013	F-150	6.2L	2V	FCIM	√	√	√	√
2013	F-150	6.2L	2V	FDIM	√	√	√	√
2013	F-150	6.2L	2V	GPSM	√	√	√	√
2013	F-150	6.2L	2V	IPC	√	√	√	√
2013	F-150	6.2L	2V	OCSM	√	√	√	√
2013	F-150	6.2L	2V	PAM	√	√	√	

2013	F-150	6.2L	2V	PCM	✓	✓	✓	✓
2013	F-150	6.2L	2V	PRB	✓	✓	✓	✓
2013	F-150	6.2L	2V	PSCM	✓	✓	✓	✓
2013	F-150	6.2L	2V	RCM	✓	✓	✓	✓
2013	F-150	6.2L	2V	RTM	✓	✓	✓	✓
2013	F-150	6.2L	2V	SCCM	✓	✓	✓	✓
2013	F-150	6.2L	2V	TBC	✓	✓	✓	✓
2013	F-150	6.2L	2V	TCCM	✓	✓	✓	✓
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	ACM	✓	✓	✓	✓
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	APIM	✓	✓	✓	✓
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	BCM#1	✓	✓	✓	✓
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	DCSM	✓	✓	✓	✓
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	DSM	✓	✓	✓	✓
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	DSP	✓	✓	✓	✓
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	FCDIM	✓	✓	✓	✓
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	FCIM	✓	✓	✓	✓
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	FDIM	✓	✓	✓	✓
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	GPSM	✓	✓	✓	✓
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	IPC	✓	✓	✓	✓
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	OCSM	✓	✓	✓	✓
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	PAM	✓	✓	✓	
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	PRB	✓	✓	✓	✓
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	PSCM	✓	✓	✓	✓
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	RCM	✓	✓	✓	✓
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	RTM	✓	✓	✓	✓
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	SCCM	✓	✓	✓	✓
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	TBC	✓	✓	✓	✓
2014	F-150	3.5L	EcoBoost - Gas Turbocharged Direct	TCCM	✓	✓	✓	✓
2014	F-150	3.7L	TiVCT	ABS	✓	✓	✓	✓
2014	F-150	3.7L	TiVCT	ACM	✓	✓	✓	✓
2014	F-150	3.7L	TiVCT	APIM	✓	✓	✓	✓
2014	F-150	3.7L	TiVCT	BCM#1	✓	✓	✓	✓
2014	F-150	3.7L	TiVCT	DCSM	✓	✓	✓	✓
2014	F-150	3.7L	TiVCT	DSM	✓	✓	✓	✓
2014	F-150	3.7L	TiVCT	DSP	✓	✓	✓	✓
2014	F-150	3.7L	TiVCT	FCIM	✓	✓	✓	✓
2014	F-150	3.7L	TiVCT	FDIM	✓	✓	✓	✓
2014	F-150	3.7L	TiVCT	GPSM	✓	✓	✓	✓
2014	F-150	3.7L	TiVCT	IPC	✓	✓	✓	✓
2014	F-150	3.7L	TiVCT	OCSM	✓	✓	✓	✓
2014	F-150	3.7L	TiVCT	PAM	✓	✓	✓	
2014	F-150	3.7L	TiVCT	PCM	✓	✓	✓	✓

2014	F-150	3.7L	TiVCT	PRB	√	√	√	√
2014	F-150	3.7L	TiVCT	PSCM	√	√	√	√
2014	F-150	3.7L	TiVCT	RCM	√	√	√	√
2014	F-150	3.7L	TiVCT	RTM	√	√	√	√
2014	F-150	3.7L	TiVCT	SCCM	√	√	√	√
2014	F-150	3.7L	TiVCT	TBC	√	√	√	√
2014	F-150	3.7L	TiVCT	TCCM	√	√	√	√
2014	F-150	5.0L	TiVCT	ABS	√	√	√	√
2014	F-150	5.0L	TiVCT	ABS	√	√	√	√
2014	F-150	5.0L	TiVCT	ACM	√	√	√	√
2014	F-150	5.0L	TiVCT	APIM	√	√	√	√
2014	F-150	5.0L	TiVCT	BCM#1	√	√	√	√
2014	F-150	5.0L	TiVCT	DCSM	√	√	√	√
2014	F-150	5.0L	TiVCT	DSM	√	√	√	√
2014	F-150	5.0L	TiVCT	DSP	√	√	√	√
2014	F-150	5.0L	TiVCT	FCDIM	√	√	√	√
2014	F-150	5.0L	TiVCT	FCIM	√	√	√	√
2014	F-150	5.0L	TiVCT	FDIM	√	√	√	√
2014	F-150	5.0L	TiVCT	GPSM	√	√	√	√
2014	F-150	5.0L	TiVCT	IPC	√	√	√	√
2014	F-150	5.0L	TiVCT	OCSM	√	√	√	√
2014	F-150	5.0L	TiVCT	PAM	√	√	√	
2014	F-150	5.0L	TiVCT	PCM	√	√	√	√
2014	F-150	5.0L	TiVCT	PRB	√	√	√	√
2014	F-150	5.0L	TiVCT	PSCM	√	√	√	√
2014	F-150	5.0L	TiVCT	RCM	√	√	√	√
2014	F-150	5.0L	TiVCT	RTM	√	√	√	√
2014	F-150	5.0L	TiVCT	SCCM	√	√	√	√
2014	F-150	5.0L	TiVCT	TBC	√	√	√	√
2014	F-150	5.0L	TiVCT	TCCM	√	√	√	√
2014	F-150	6.2L	2V	ABS	√	√	√	√
2014	F-150	6.2L	2V	ACM	√	√	√	√
2014	F-150	6.2L	2V	APIM	√	√	√	√
2014	F-150	6.2L	2V	BCM#1	√	√	√	√
2014	F-150	6.2L	2V	DCSM	√	√	√	√
2014	F-150	6.2L	2V	DSM	√	√	√	√
2014	F-150	6.2L	2V	DSP	√	√	√	√
2014	F-150	6.2L	2V	FCDIM	√	√	√	√
2014	F-150	6.2L	2V	FCIM	√	√	√	√
2014	F-150	6.2L	2V	FDIM	√	√	√	√
2014	F-150	6.2L	2V	GPSM	√	√	√	√
2014	F-150	6.2L	2V	IPC	√	√	√	√
2014	F-150	6.2L	2V	OCSM	√	√	√	√
2014	F-150	6.2L	2V	PAM	√	√	√	
2014	F-150	6.2L	2V	PCM	√	√	√	√

2014	F-150	6.2L	2V	PRB	√	√	√	√
2014	F-150	6.2L	2V	PSCM	√	√	√	√
2014	F-150	6.2L	2V	RCM	√	√	√	√
2014	F-150	6.2L	2V	RTM	√	√	√	√
2014	F-150	6.2L	2V	SCCM	√	√	√	√
2014	F-150	6.2L	2V	TBC	√	√	√	√
2014	F-150	6.2L	2V	TCCM	√	√	√	√
2001	F-150 SuperCrew (4 full size doors)	4.6L	Other	ABS/TCS	√	√	√	√
2001	F-150 SuperCrew (4 full size doors)	4.6L	Other	GEM	√	√	√	√
2001	F-150 SuperCrew (4 full size doors)	4.6L	Other	HEC	√	√	√	√
2001	F-150 SuperCrew (4 full size doors)	4.6L	Other	PCM	√	√	√	√
2001	F-150 SuperCrew (4 full size doors)	4.6L	Other	RAP	√	√	√	√
2001	F-150 SuperCrew (4 full size doors)	4.6L	Other	RCM	√	√	√	√
2001	F-150 SuperCrew (4 full size doors)	5.4L	Other	ABS/TCS	√	√	√	√
2001	F-150 SuperCrew (4 full size doors)	5.4L	Other	GEM	√	√	√	√
2001	F-150 SuperCrew (4 full size doors)	5.4L	Other	HEC	√	√	√	√
2001	F-150 SuperCrew (4 full size doors)	5.4L	Other	PCM	√	√	√	√
2001	F-150 SuperCrew (4 full size doors)	5.4L	Other	RAP	√	√	√	√
2001	F-150 SuperCrew (4 full size doors)	5.4L	Other	RCM	√	√	√	√
2002	F-150 SuperCrew (4 full size doors)	4.6L	Other	ABS/TCS	√	√	√	√
2002	F-150 SuperCrew (4 full size doors)	4.6L	Other	EATC	√	√	√	√
2002	F-150 SuperCrew (4 full size doors)	4.6L	Other	GEM	√	√	√	√
2002	F-150 SuperCrew (4 full size doors)	4.6L	Other	HEC	√	√	√	√
2002	F-150 SuperCrew (4 full size doors)	4.6L	Other	PCM	√	√	√	√
2002	F-150 SuperCrew (4 full size doors)	4.6L	Other	RAP	√	√	√	√
2002	F-150 SuperCrew (4 full size doors)	4.6L	Other	RCM	√	√	√	√
2002	F-150 SuperCrew (4 full size doors)	5.4L	Other	ABS/TCS	√	√	√	√
2002	F-150 SuperCrew (4 full size doors)	5.4L	Other	EATC	√	√	√	√
2002	F-150 SuperCrew (4 full size doors)	5.4L	Other	GEM	√	√	√	√
2002	F-150 SuperCrew (4 full size doors)	5.4L	Other	HEC	√	√	√	√
2002	F-150 SuperCrew (4 full size doors)	5.4L	Other	PCM	√	√	√	√
2002	F-150 SuperCrew (4 full size doors)	5.4L	Other	RAP	√	√	√	√
2002	F-150 SuperCrew (4 full size doors)	5.4L	Other	RCM	√	√	√	√
2003	F-150 SuperCrew (4 full size doors)	4.6L	2V	ABS/TCS	√	√	√	√
2003	F-150 SuperCrew (4 full size doors)	4.6L	2V	EATC	√	√	√	√
2003	F-150 SuperCrew (4 full size doors)	4.6L	2V	HEC	√	√	√	√
2003	F-150 SuperCrew (4 full size doors)	4.6L	2V	PCM	√	√	√	√
2003	F-150 SuperCrew (4 full size doors)	4.6L	2V	RAP	√	√	√	√
2003	F-150 SuperCrew (4 full size doors)	4.6L	2V	RCM	√	√	√	√
2003	F-150 SuperCrew (4 full size doors)	5.4L	2V	ABS/TCS	√	√	√	√
2003	F-150 SuperCrew (4 full size doors)	5.4L	2V	EATC	√	√	√	√
2003	F-150 SuperCrew (4 full size doors)	5.4L	2V	GEM	√	√	√	√
2003	F-150 SuperCrew (4 full size doors)	5.4L	2V	HEC	√	√	√	√
2003	F-150 SuperCrew (4 full size doors)	5.4L	2V	PCM	√	√	√	√
2003	F-150 SuperCrew (4 full size doors)	5.4L	2V	RAP	√	√	√	√

2003	F-150 SuperCrew (4 full size doors)	5.4L	2V	RCM	√	√	√	√
2006	F-250	3.9L	Cummins Diesel	4X4	√	√	√	√
2006	F-250	3.9L	Cummins Diesel	ABS/TCS	√	√	√	√
2006	F-250	3.9L	Cummins Diesel	GEM	√	√	√	√
2006	F-250	3.9L	Cummins Diesel	HEC	√	√	√	√
2006	F-250	3.9L	Cummins Diesel	OTC	√	√	√	√
2006	F-250	3.9L	Cummins Diesel	PAM	√	√	√	√
2006	F-250	3.9L	Cummins Diesel	RCM	√	√	√	√
2006	F-250	3.9L	Cummins Diesel	TBM	√	√	√	√
1997	F-250 Light Duty	4.6L	Other	ABS/TCS	√	√	√	√
1997	F-250 Light Duty	4.6L	Other	GEM	√	√	√	√
1997	F-250 Light Duty	4.6L	Other	IAB	√	√	√	√
1997	F-250 Light Duty	4.6L	Other	PCM	√	√	√	√
1997	F-250 Light Duty	4.6L	Other	RAP	√	√	√	√
1997	F-250 Light Duty	5.4L	NGV	ABS/TCS	√	√	√	√
1997	F-250 Light Duty	5.4L	NGV	FIM	√	√	√	√
1997	F-250 Light Duty	5.4L	NGV	GEM	√	√	√	√
1997	F-250 Light Duty	5.4L	NGV	IAB	√	√	√	√
1997	F-250 Light Duty	5.4L	NGV	PCM	√	√	√	√
1997	F-250 Light Duty	5.4L	NGV	RAP	√	√	√	√
1997	F-250 Light Duty	5.4L	Other	ABS/TCS	√	√	√	√
1997	F-250 Light Duty	5.4L	Other	GEM	√	√	√	√
1997	F-250 Light Duty	5.4L	Other	IAB	√	√	√	√
1997	F-250 Light Duty	5.4L	Other	PCM	√	√	√	√
1997	F-250 Light Duty	5.4L	Other	RAP	√	√	√	√
1998	F-250 Light Duty	4.6L	Other	ABS/TCS	√	√	√	√
1998	F-250 Light Duty	4.6L	Other	GEM	√	√	√	√
1998	F-250 Light Duty	4.6L	Other	IAB	√	√	√	√
1998	F-250 Light Duty	4.6L	Other	PCM	√	√	√	√
1998	F-250 Light Duty	4.6L	Other	RAP	√	√	√	√
1998	F-250 Light Duty	5.4L	BIF	ABS/TCS	√	√	√	√
1998	F-250 Light Duty	5.4L	BIF	AFCM	√	√	√	√
1998	F-250 Light Duty	5.4L	BIF	GEM	√	√	√	√
1998	F-250 Light Duty	5.4L	BIF	IAB	√	√	√	√
1998	F-250 Light Duty	5.4L	BIF	PCM	√	√	√	√
1998	F-250 Light Duty	5.4L	BIF	PCM	√	√	√	√
1998	F-250 Light Duty	5.4L	BIF	RAP	√	√	√	√
1998	F-250 Light Duty	5.4L	NGV	ABS/TCS	√	√	√	√
1998	F-250 Light Duty	5.4L	NGV	FIM	√	√	√	√
1998	F-250 Light Duty	5.4L	NGV	GEM	√	√	√	√
1998	F-250 Light Duty	5.4L	NGV	IAB	√	√	√	√
1998	F-250 Light Duty	5.4L	NGV	PCM	√	√	√	√
1998	F-250 Light Duty	5.4L	NGV	RAP	√	√	√	√
1998	F-250 Light Duty	5.4L	Other	ABS/TCS	√	√	√	√
1998	F-250 Light Duty	5.4L	Other	GEM	√	√	√	√

1998	F-250 Light Duty	5.4L	Other	IAB	√	√	√	√
1998	F-250 Light Duty	5.4L	Other	PCM	√	√	√	√
1998	F-250 Light Duty	5.4L	Other	RAP	√	√	√	√
1999	F-250 Light Duty	4.2L	Other	ABS/TCS	√	√	√	√
1999	F-250 Light Duty	4.2L	Other	GEM	√	√	√	√
1999	F-250 Light Duty	4.2L	Other	IC	√	√	√	√
1999	F-250 Light Duty	4.2L	Other	PCM	√	√	√	√
1999	F-250 Light Duty	4.2L	Other	RAP	√	√	√	√
1999	F-250 Light Duty	4.2L	Other	RCM	√	√	√	
1999	F-250 Light Duty	4.6L	Other	ABS/TCS	√	√	√	√
1999	F-250 Light Duty	4.6L	Other	GEM	√	√	√	√
1999	F-250 Light Duty	4.6L	Other	IC	√	√	√	√
1999	F-250 Light Duty	4.6L	Other	PCM	√	√	√	√
1999	F-250 Light Duty	4.6L	Other	RAP	√	√	√	√
1999	F-250 Light Duty	4.6L	Other	RCM	√	√	√	√
1999	F-250 Light Duty	5.4L	BIF	ABS/TCS	√	√	√	√
1999	F-250 Light Duty	5.4L	BIF	AFCM	√	√	√	√
1999	F-250 Light Duty	5.4L	BIF	GEM	√	√	√	√
1999	F-250 Light Duty	5.4L	BIF	IC	√	√	√	√
1999	F-250 Light Duty	5.4L	BIF	PCM	√	√	√	√
1999	F-250 Light Duty	5.4L	BIF	RAP	√	√	√	√
1999	F-250 Light Duty	5.4L	BIF	RCM	√	√	√	√
1999	F-250 Light Duty	5.4L	NGV	ABS/TCS	√	√	√	√
1999	F-250 Light Duty	5.4L	NGV	FIM	√	√	√	√
1999	F-250 Light Duty	5.4L	NGV	GEM	√	√	√	√
1999	F-250 Light Duty	5.4L	NGV	IC	√	√	√	√
1999	F-250 Light Duty	5.4L	NGV	PCM	√	√	√	√
1999	F-250 Light Duty	5.4L	NGV	RAP	√	√	√	√
1999	F-250 Light Duty	5.4L	NGV	RCM	√	√	√	√
1999	F-250 Light Duty	5.4L	Other	ABS/TCS	√	√	√	√
1999	F-250 Light Duty	5.4L	Other	GEM	√	√	√	√
1999	F-250 Light Duty	5.4L	Other	IC	√	√	√	√
1999	F-250 Light Duty	5.4L	Other	PCM	√	√	√	√
1999	F-250 Light Duty	5.4L	Other	RCM	√	√	√	√
2000	F-250 Light Duty	4.6L	Other	ABS/TCS	√	√	√	√
2000	F-250 Light Duty	4.6L	Other	GEM	√	√	√	√
2000	F-250 Light Duty	4.6L	Other	IC	√	√	√	√
2000	F-250 Light Duty	4.6L	Other	PCM	√	√	√	√
2000	F-250 Light Duty	4.6L	Other	RAP	√	√	√	√
2000	F-250 Light Duty	4.6L	Other	RCM	√	√	√	√
2000	F-250 Light Duty	5.4L	NGV	ABS/TCS	√	√	√	√
2000	F-250 Light Duty	5.4L	NGV	FIM	√	√	√	√
2000	F-250 Light Duty	5.4L	NGV	GEM	√	√	√	√
2000	F-250 Light Duty	5.4L	NGV	IC	√	√	√	√
2000	F-250 Light Duty	5.4L	NGV	PCM	√	√	√	√

2000	F-250 Light Duty	5.4L	NGV	RAP	✓	✓	✓	✓
2000	F-250 Light Duty	5.4L	NGV	RCM	✓	✓	✓	✓
2000	F-250 Light Duty	5.4L	Other	ABS/TCS	✓	✓	✓	✓
2000	F-250 Light Duty	5.4L	Other	GEM	✓	✓	✓	✓
2000	F-250 Light Duty	5.4L	Other	IC	✓	✓	✓	✓
2000	F-250 Light Duty	5.4L	Other	PCM	✓	✓	✓	✓
2000	F-250 Light Duty	5.4L	Other	RAP	✓	✓	✓	✓
2000	F-250 Light Duty	5.4L	Other	RCM	✓	✓	✓	✓
2000	F-650 / F-750	5.9L	Cummins Diesel	ABS/TCS	✓	✓	✓	✓
2000	F-650 / F-750	5.9L	Cummins Diesel	GEM	✓	✓	✓	✓
2000	F-650 / F-750	7.2L	Caterpillar Diesel	ABS/TCS	✓	✓	✓	✓
2000	F-650 / F-750	7.2L	Caterpillar Diesel	GEM	✓	✓	✓	✓
2000	F-650 / F-750	7.3L	Direct Injection -	ABS/TCS	✓	✓	✓	✓
2000	F-650 / F-750	7.3L	Direct Injection -	GEM	✓	✓	✓	✓
2000	F-650 / F-750	7.3L	Direct Injection -	PCM	✓	✓	✓	✓
2002	F-650 / F-750	5.9L	Cummins Diesel	ABS/TCS	✓	✓	✓	✓
2002	F-650 / F-750	5.9L	Cummins Diesel	GEM	✓	✓	✓	✓
2002	F-650 / F-750	7.2L	Caterpillar Diesel	ABS/TCS	✓	✓	✓	✓
2002	F-650 / F-750	7.2L	Caterpillar Diesel	GEM	✓	✓	✓	✓
2002	F-650 / F-750	7.3L	Direct Injection -	ABS/TCS	✓	✓	✓	✓
2002	F-650 / F-750	7.3L	Direct Injection -	GEM	✓	✓	✓	✓
2002	F-650 / F-750	7.3L	Direct Injection -	PCM	✓	✓	✓	✓
2003	F-650 / F-750	5.9L	Cummins Diesel	ABS/TCS	✓	✓	✓	✓
2003	F-650 / F-750	5.9L	Cummins Diesel	GEM	✓	✓	✓	✓
2003	F-650 / F-750	7.2L	Caterpillar Diesel	ABS/TCS	✓	✓	✓	✓
2003	F-650 / F-750	7.2L	Caterpillar Diesel	GEM	✓	✓	✓	✓
2003	F-650 / F-750	7.3L	Direct Injection -	ABS/TCS	✓	✓	✓	✓
2003	F-650 / F-750	7.3L	Direct Injection -	GEM	✓	✓	✓	✓
2003	F-650 / F-750	7.3L	Direct Injection -	PCM	✓	✓	✓	✓
2004	F-650 / F-750	5.9L	Cummins Diesel	GEM	✓	✓	✓	✓
2004	F-650 / F-750	6.0L	Direct Injection -	GEM	✓	✓	✓	✓
2004	F-650 / F-750	7.2L	Caterpillar Diesel	GEM	✓	✓	✓	✓
2005	F-650 / F-750	5.9L	Cummins Diesel	ABS/TCS	✓	✓	✓	✓
2005	F-650 / F-750	5.9L	Cummins Diesel	GEM	✓	✓	✓	✓
2005	F-650 / F-750	6.0L	Direct Injection -	ABS/TCS	✓	✓	✓	✓
2005	F-650 / F-750	6.0L	Direct Injection -	GEM	✓	✓	✓	✓
2005	F-650 / F-750	7.2L	Caterpillar Diesel	ABS/TCS	✓	✓	✓	✓
2005	F-650 / F-750	7.2L	Caterpillar Diesel	GEM	✓	✓	✓	✓
2005	F-650 / F-750	Other	Other	ABS/TCS	✓	✓	✓	✓
2005	F-650 / F-750	Other	Other	GEM	✓	✓	✓	✓
2006	F-650 / F-750	5.9L	Cummins Diesel	ABS/TCS	✓	✓	✓	✓
2006	F-650 / F-750	5.9L	Cummins Diesel	GEM	✓	✓	✓	✓
2006	F-650 / F-750	6.0L	Direct Injection -	ABS/TCS	✓	✓	✓	✓
2006	F-650 / F-750	6.0L	Direct Injection -	GEM	✓	✓	✓	✓
2006	F-650 / F-750	7.2L	Caterpillar Diesel	ABS/TCS	✓	✓	✓	✓

2006	F-650 / F-750	7.2L	Caterpillar Diesel	GEM	✓	✓	✓	✓
2006	F-650 / F-750	Other	Other	ABS/TCS	✓	✓	✓	✓
2006	F-650 / F-750	Other	Other	GEM	✓	✓	✓	✓
2007	F-650 / F-750	5.9L	Cummins Diesel	ABS/TCS	✓	✓	✓	✓
2007	F-650 / F-750	5.9L	Cummins Diesel	GEM	✓	✓	✓	✓
2007	F-650 / F-750	6.0L	Direct Injection -	ABS/TCS	✓	✓	✓	✓
2007	F-650 / F-750	6.0L	Direct Injection -	GEM	✓	✓	✓	✓
2007	F-650 / F-750	7.2L	Caterpillar Diesel	ABS/TCS	✓	✓	✓	✓
2007	F-650 / F-750	7.2L	Caterpillar Diesel	GEM	✓	✓	✓	✓
2008	F-650 / F-750	6.7L	Cummins Diesel	GEM / SJB	✓	✓	✓	✓
2008	F-650 / F-750	7.2L	Caterpillar Diesel	GEM / SJB	✓	✓	✓	✓
2009	F-650 / F-750	6.7L	Cummins Diesel	GEM / SJB	✓	✓	✓	✓
2009	F-650 / F-750	7.2L	Caterpillar Diesel	GEM / SJB	✓	✓	✓	✓
2010	F-650 / F-750	6.7L	Cummins Diesel	GEM / SJB	✓	✓	✓	✓
2010	F-650 / F-750	7.2L	Caterpillar Diesel	GEM / SJB	✓	✓	✓	✓
2011	F-650 / F-750	6.7L	Cummins Diesel	ACM	✓	✓	✓	✓
2011	F-650 / F-750	6.7L	Cummins Diesel	GEM / SJB	✓	✓	✓	✓
2011	F-650 / F-750	6.7L	Cummins Diesel	HVAC	✓	✓	✓	✓
2011	F-650 / F-750	6.7L	Cummins Diesel	IPC	✓	✓	✓	✓
2012	F-650 / F-750	6.7L	Cummins Diesel	ACM	✓	✓	✓	✓
2012	F-650 / F-750	6.7L	Cummins Diesel	APIM	✓	✓	✓	✓
2012	F-650 / F-750	6.7L	Cummins Diesel	GEM / SJB	✓	✓	✓	✓
2012	F-650 / F-750	6.7L	Cummins Diesel	HVAC	✓	✓	✓	✓
2012	F-650 / F-750	6.7L	Cummins Diesel	IPC	✓	✓	✓	✓
2012	F-650 / F-750	6.8L	3V	ACM	✓	✓	✓	✓
2012	F-650 / F-750	6.8L	3V	APIM	✓	✓	✓	✓
2012	F-650 / F-750	6.8L	3V	GEM / SJB	✓	✓	✓	✓
2012	F-650 / F-750	6.8L	3V	HVAC	✓	✓	✓	✓
2012	F-650 / F-750	6.8L	3V	IPC	✓	✓	✓	✓
2012	F-650 / F-750	6.8L	3V	PCM	✓	✓	✓	✓
2013	F-650 / F-750	6.7L	Cummins Diesel	ACM	✓	✓	✓	✓
2013	F-650 / F-750	6.7L	Cummins Diesel	GEM / SJB	✓	✓	✓	✓
2013	F-650 / F-750	6.7L	Cummins Diesel	HVAC	✓	✓	✓	✓
2013	F-650 / F-750	6.7L	Cummins Diesel	IPC	✓	✓	✓	✓
2013	F-650 / F-750	6.8L	3V	ACM	✓	✓	✓	✓
2013	F-650 / F-750	6.8L	3V	APIM	✓	✓	✓	✓
2013	F-650 / F-750	6.8L	3V	GEM / SJB	✓	✓	✓	✓
2013	F-650 / F-750	6.8L	3V	HVAC	✓	✓	✓	✓
2013	F-650 / F-750	6.8L	3V	IPC	✓	✓	✓	✓
2013	F-650 / F-750	6.8L	3V	PCM	✓	✓	✓	✓
2013	F-650 / F-750	Other	Other	ACM	✓	✓	✓	✓
2013	F-650 / F-750	Other	Other	APIM	✓	✓	✓	✓
2013	F-650 / F-750	Other	Other	HVAC	✓	✓	✓	✓
2013	F-650 / F-750	Other	Other	IPC	✓	✓	✓	✓
2014	F-650 / F-750	6.8L	3V	ACM	✓	✓	✓	✓



2014	F-650 / F-750	6.8L	3V	APIM	✓	✓	✓	✓
2014	F-650 / F-750	6.8L	3V	HVAC	✓	✓	✓	
2014	F-650 / F-750	6.8L	3V	IPC	✓	✓	✓	
1994	F-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓
1994	F-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓
1995	F-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓
1995	F-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓
1996	F-Series	4.9L	GFP	PCM	✓	✓	✓	✓
1996	F-Series	4.9L	Other	PCM	✓	✓	✓	✓
1996	F-Series	5.0L	Other	PCM	✓	✓	✓	✓
1996	F-Series	5.8L	Other	PCM	✓	✓	✓	✓
1996	F-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓
1996	F-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓
1996	F-Series	7.5L	Other	PCM	✓	✓	✓	✓
1997	F-Series	5.8L	Other	PCM	✓	✓	✓	✓
1997	F-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓
1997	F-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓
1997	F-Series	7.5L	Other	PCM	✓	✓	✓	✓
1999	F-Series Super Duty	5.4L	BIF	ABS/TCS	✓	✓	✓	✓
1999	F-Series Super Duty	5.4L	BIF	AFCM	✓	✓	✓	✓
1999	F-Series Super Duty	5.4L	BIF	ECS	✓	✓	✓	✓
1999	F-Series Super Duty	5.4L	BIF	GEM	✓	✓	✓	✓
1999	F-Series Super Duty	5.4L	BIF	OTC	✓	✓	✓	✓
1999	F-Series Super Duty	5.4L	BIF	PCM	✓	✓	✓	✓
1999	F-Series Super Duty	5.4L	Other	ABS/TCS	✓	✓	✓	✓
1999	F-Series Super Duty	5.4L	Other	ECS	✓	✓	✓	✓
1999	F-Series Super Duty	5.4L	Other	GEM	✓	✓	✓	✓
1999	F-Series Super Duty	5.4L	Other	OTC	✓	✓	✓	✓
1999	F-Series Super Duty	5.4L	Other	PCM	✓	✓	✓	✓
1999	F-Series Super Duty	6.8L	Other	ABS/TCS	✓	✓	✓	✓
1999	F-Series Super Duty	6.8L	Other	ECS	✓	✓	✓	✓
1999	F-Series Super Duty	6.8L	Other	GEM	✓	✓	✓	✓
1999	F-Series Super Duty	6.8L	Other	OTC	✓	✓	✓	✓
1999	F-Series Super Duty	6.8L	Other	PCM	✓	✓	✓	✓
1999	F-Series Super Duty	7.3L	Direct Injection -	ABS/TCS	✓	✓	✓	✓
1999	F-Series Super Duty	7.3L	Direct Injection -	ECS	✓	✓	✓	✓
1999	F-Series Super Duty	7.3L	Direct Injection -	GEM	✓	✓	✓	✓
1999	F-Series Super Duty	7.3L	Direct Injection -	OTC	✓	✓	✓	✓
1999	F-Series Super Duty	7.3L	Direct Injection - Turbo	PCM	✓	✓	✓	✓
1999	F-Series Super Duty	7.3L	Direct Injection -	PCM	✓	✓	✓	✓
1999	F-Series Super Duty	7.3L	Direct Injection -	PCM	✓	✓	✓	✓
2000	F-Series Super Duty	5.4L	Other	ABS/TCS	✓	✓	✓	✓
2000	F-Series Super Duty	5.4L	Other	ECS	✓	✓	✓	✓
2000	F-Series Super Duty	5.4L	Other	GEM	✓	✓	✓	✓
2000	F-Series Super Duty	5.4L	Other	OTC	✓	✓	✓	✓

2000	F-Series Super Duty	5.4L	Other	PATS	✓	✓	✓	✓
2000	F-Series Super Duty	5.4L	Other	PCM	✓	✓	✓	✓
2000	F-Series Super Duty	6.8L	Other	ABS/TCS	✓	✓	✓	✓
2000	F-Series Super Duty	6.8L	Other	AFCM	✓	✓	✓	✓
2000	F-Series Super Duty	6.8L	Other	ECS	✓	✓	✓	✓
2000	F-Series Super Duty	6.8L	Other	GEM	✓	✓	✓	✓
2000	F-Series Super Duty	6.8L	Other	OTC	✓	✓	✓	✓
2000	F-Series Super Duty	6.8L	Other	PATS	✓	✓	✓	✓
2000	F-Series Super Duty	6.8L	Other	PCM	✓	✓	✓	✓
2000	F-Series Super Duty	7.3L	Direct Injection -	ABS/TCS	✓	✓	✓	✓
2000	F-Series Super Duty	7.3L	Direct Injection -	ECS	✓	✓	✓	✓
2000	F-Series Super Duty	7.3L	Direct Injection -	GEM	✓	✓	✓	✓
2000	F-Series Super Duty	7.3L	Direct Injection -	OTC	✓	✓	✓	✓
2000	F-Series Super Duty	7.3L	Direct Injection -	PATS	✓	✓	✓	✓
2000	F-Series Super Duty	7.3L	Direct Injection - Turbo	PCM	✓	✓	✓	✓
2001	F-Series Super Duty	4.2L	Other	ABS/TCS	✓	✓	✓	✓
2001	F-Series Super Duty	4.2L	Other	ECS	✓	✓	✓	✓
2001	F-Series Super Duty	4.2L	Other	GEM	✓	✓	✓	✓
2001	F-Series Super Duty	4.2L	Other	OTC	✓	✓	✓	✓
2001	F-Series Super Duty	4.2L	Other	PAM	✓	✓	✓	✓
2001	F-Series Super Duty	4.2L	Other	PCM	✓	✓	✓	✓
2001	F-Series Super Duty	4.2L	Other	RCM	✓	✓	✓	✓
2001	F-Series Super Duty	5.4L	Other	ABS/TCS	✓	✓	✓	✓
2001	F-Series Super Duty	5.4L	Other	ECS	✓	✓	✓	✓
2001	F-Series Super Duty	5.4L	Other	GEM	✓	✓	✓	✓
2001	F-Series Super Duty	5.4L	Other	PAM	✓	✓	✓	✓
2001	F-Series Super Duty	5.4L	Other	PCM	✓	✓	✓	✓
2001	F-Series Super Duty	5.4L	Other	PCM	✓	✓	✓	✓
2001	F-Series Super Duty	5.4L	Other	PCM	✓	✓	✓	✓
2001	F-Series Super Duty	5.4L	Other	RCM	✓	✓	✓	✓
2001	F-Series Super Duty	6.8L	Other	ABS/TCS	✓	✓	✓	✓
2001	F-Series Super Duty	6.8L	Other	AFCM	✓	✓	✓	✓
2001	F-Series Super Duty	6.8L	Other	ECS	✓	✓	✓	✓
2001	F-Series Super Duty	6.8L	Other	GEM	✓	✓	✓	✓
2001	F-Series Super Duty	6.8L	Other	OTC	✓	✓	✓	✓
2001	F-Series Super Duty	6.8L	Other	PAM	✓	✓	✓	✓
2001	F-Series Super Duty	6.8L	Other	PCM	✓	✓	✓	✓
2001	F-Series Super Duty	6.8L	Other	PCM	✓	✓	✓	✓
2001	F-Series Super Duty	6.8L	Other	PCM	✓	✓	✓	✓
2001	F-Series Super Duty	6.8L	Other	RCM	✓	✓	✓	✓
2001	F-Series Super Duty	7.3L	Direct Injection -	ABS/TCS	✓	✓	✓	✓
2001	F-Series Super Duty	7.3L	Direct Injection -	ECS	✓	✓	✓	✓
2001	F-Series Super Duty	7.3L	Direct Injection -	GEM	✓	✓	✓	✓
2001	F-Series Super Duty	7.3L	Direct Injection -	OTC	✓	✓	✓	✓
2001	F-Series Super Duty	7.3L	Direct Injection -	PAM	✓	✓	✓	✓

2001	F-Series Super Duty	7.3L	Direct Injection -	PCM	✓	✓	✓	✓
2001	F-Series Super Duty	7.3L	Direct Injection -	PCM	✓	✓	✓	✓
2001	F-Series Super Duty	7.3L	Direct Injection -	RCM	✓	✓	✓	✓
2002	F-Series Super Duty	5.4L	Other	ABS/TCS	✓	✓	✓	✓
2002	F-Series Super Duty	5.4L	Other	CSM	✓	✓	✓	✓
2002	F-Series Super Duty	5.4L	Other	GEM	✓	✓	✓	✓
2002	F-Series Super Duty	5.4L	Other	HEC	✓	✓	✓	✓
2002	F-Series Super Duty	5.4L	Other	OTC	✓	✓	✓	✓
2002	F-Series Super Duty	5.4L	Other	PAM	✓	✓	✓	✓
2002	F-Series Super Duty	5.4L	Other	PATS	✓	✓	✓	✓
2002	F-Series Super Duty	5.4L	Other	PCM	✓	✓	✓	✓
2002	F-Series Super Duty	5.4L	Other	PCM	✓	✓	✓	✓
2002	F-Series Super Duty	5.4L	Other	PCM	✓	✓	✓	✓
2002	F-Series Super Duty	5.4L	Other	RCM	✓	✓	✓	✓
2002	F-Series Super Duty	6.8L	Other	ABS/TCS	✓	✓	✓	✓
2002	F-Series Super Duty	6.8L	Other	CSM	✓	✓	✓	✓
2002	F-Series Super Duty	6.8L	Other	GEM	✓	✓	✓	✓
2002	F-Series Super Duty	6.8L	Other	HEC	✓	✓	✓	✓
2002	F-Series Super Duty	6.8L	Other	OTC	✓	✓	✓	✓
2002	F-Series Super Duty	6.8L	Other	PAM	✓	✓	✓	✓
2002	F-Series Super Duty	6.8L	Other	PATS	✓	✓	✓	✓
2002	F-Series Super Duty	6.8L	Other	PCM	✓	✓	✓	✓
2002	F-Series Super Duty	6.8L	Other	PCM	✓	✓	✓	✓
2002	F-Series Super Duty	6.8L	Other	PCM	✓	✓	✓	✓
2002	F-Series Super Duty	6.8L	Other	PCM	✓	✓	✓	✓
2002	F-Series Super Duty	6.8L	Other	RCM	✓	✓	✓	✓
2002	F-Series Super Duty	7.3L	Direct Injection -	ABS/TCS	✓	✓	✓	✓
2002	F-Series Super Duty	7.3L	Direct Injection -	CSM	✓	✓	✓	✓
2002	F-Series Super Duty	7.3L	Direct Injection -	GEM	✓	✓	✓	✓
2002	F-Series Super Duty	7.3L	Direct Injection -	HEC	✓	✓	✓	✓
2002	F-Series Super Duty	7.3L	Direct Injection -	OTC	✓	✓	✓	✓
2002	F-Series Super Duty	7.3L	Direct Injection -	PAM	✓	✓	✓	✓
2002	F-Series Super Duty	7.3L	Direct Injection -	PATS	✓	✓	✓	✓
2002	F-Series Super Duty	7.3L	Direct Injection -	PCM	✓	✓	✓	✓
2002	F-Series Super Duty	7.3L	Direct Injection - Turbo	PCM	✓	✓	✓	✓
2002	F-Series Super Duty	7.3L	Direct Injection - Turbo	PCM	✓	✓	✓	✓
2002	F-Series Super Duty	7.3L	Direct Injection -	PCM	✓	✓	✓	✓
2002	F-Series Super Duty	7.3L	Direct Injection -	RCM	✓	✓	✓	✓
2003	F-Series Super Duty	4.2L	Direct Injection -	ABS/TCS	✓	✓	✓	✓
2003	F-Series Super Duty	4.2L	Direct Injection -	FOH	✓	✓	✓	✓
2003	F-Series Super Duty	4.2L	Direct Injection -	GEM	✓	✓	✓	✓
2003	F-Series Super Duty	4.2L	Direct Injection -	HEC	✓	✓	✓	✓
2003	F-Series Super Duty	4.2L	Direct Injection -	OTC	✓	✓	✓	✓
2003	F-Series Super Duty	4.2L	Direct Injection -	PAM	✓	✓	✓	✓
2003	F-Series Super Duty	4.2L	Direct Injection -	PATS	✓	✓	✓	✓

2003	F-Series Super Duty	4.2L	Direct Injection -	PCM	√	√	√	√
2003	F-Series Super Duty	4.2L	Direct Injection -	PCM	√	√	√	√
2003	F-Series Super Duty	4.2L	Direct Injection -	RCM	√	√	√	√
2003	F-Series Super Duty	4.2L	Direct Injection -	VSM	√	√	√	√
2003	F-Series Super Duty	5.4L	Other	ABS/TCS	√	√	√	√
2003	F-Series Super Duty	5.4L	Other	ABS/TCS	√	√	√	√
2003	F-Series Super Duty	5.4L	Other	FOH	√	√	√	√
2003	F-Series Super Duty	5.4L	Other	GEM	√	√	√	√
2003	F-Series Super Duty	5.4L	Other	HEC	√	√	√	√
2003	F-Series Super Duty	5.4L	Other	OTC	√	√	√	√
2003	F-Series Super Duty	5.4L	Other	PAM	√	√	√	√
2003	F-Series Super Duty	5.4L	Other	PATS	√	√	√	√
2003	F-Series Super Duty	5.4L	Other	PCM	√	√	√	√
2003	F-Series Super Duty	5.4L	Other	PCM	√	√	√	√
2003	F-Series Super Duty	5.4L	Other	PCM	√	√	√	√
2003	F-Series Super Duty	5.4L	Other	RCM	√	√	√	√
2003	F-Series Super Duty	5.4L	Other	VSM	√	√	√	√
2003	F-Series Super Duty	6.0L	Direct Injection -	ABS/TCS	√	√	√	√
2003	F-Series Super Duty	6.0L	Direct Injection -	FOH	√	√	√	√
2003	F-Series Super Duty	6.0L	Direct Injection -	GEM	√	√	√	√
2003	F-Series Super Duty	6.0L	Direct Injection -	HEC	√	√	√	√
2003	F-Series Super Duty	6.0L	Direct Injection -	OTC	√	√	√	√
2003	F-Series Super Duty	6.0L	Direct Injection -	PAM	√	√	√	√
2003	F-Series Super Duty	6.0L	Direct Injection -	PATS	√	√	√	√
2003	F-Series Super Duty	6.0L	Direct Injection -	PCM	√	√	√	√
2003	F-Series Super Duty	6.0L	Direct Injection -	PCM	√	√	√	√
2003	F-Series Super Duty	6.0L	Direct Injection -	PCM	√	√	√	√
2003	F-Series Super Duty	6.0L	Direct Injection -	PCM	√	√	√	√
2003	F-Series Super Duty	6.0L	Direct Injection - Turbo	PCM	√	√	√	√
2003	F-Series Super Duty	6.0L	Direct Injection -	RCM	√	√	√	√
2003	F-Series Super Duty	6.0L	Direct Injection -	TCM	√	√	√	√
2003	F-Series Super Duty	6.0L	Direct Injection -	TCM	√	√	√	√
2003	F-Series Super Duty	6.0L	Direct Injection -	TCM	√	√	√	√
2003	F-Series Super Duty	6.0L	Direct Injection -	VSM	√	√	√	√
2003	F-Series Super Duty	6.8L	Other	ABS/TCS	√	√	√	√
2003	F-Series Super Duty	6.8L	Other	ABS/TCS	√	√	√	√
2003	F-Series Super Duty	6.8L	Other	FOH	√	√	√	√
2003	F-Series Super Duty	6.8L	Other	GEM	√	√	√	√
2003	F-Series Super Duty	6.8L	Other	HEC	√	√	√	√
2003	F-Series Super Duty	6.8L	Other	OTC	√	√	√	√
2003	F-Series Super Duty	6.8L	Other	PAM	√	√	√	√
2003	F-Series Super Duty	6.8L	Other	PATS	√	√	√	√
2003	F-Series Super Duty	6.8L	Other	PCM	√	√	√	√
2003	F-Series Super Duty	6.8L	Other	PCM	√	√	√	√
2003	F-Series Super Duty	6.8L	Other	PCM	√	√	√	√
2003	F-Series Super Duty	6.8L	Other	RCM	√	√	√	√

2003	F-Series Super Duty	6.8L	Other	VSM	√	√	√	√
2003	F-Series Super Duty	7.3L	Direct Injection -	ABS/TCS	√	√	√	√
2003	F-Series Super Duty	7.3L	Direct Injection -	FOH	√	√	√	√
2003	F-Series Super Duty	7.3L	Direct Injection -	GEM	√	√	√	√
2003	F-Series Super Duty	7.3L	Direct Injection -	HEC	√	√	√	√
2003	F-Series Super Duty	7.3L	Direct Injection -	OTC	√	√	√	√
2003	F-Series Super Duty	7.3L	Direct Injection -	PAM	√	√	√	√
2003	F-Series Super Duty	7.3L	Direct Injection -	PATS	√	√	√	√
2003	F-Series Super Duty	7.3L	Direct Injection -	PCM	√	√	√	√
2003	F-Series Super Duty	7.3L	Direct Injection - Turbo	PCM	√	√	√	√
2003	F-Series Super Duty	7.3L	Direct Injection - Turbo	PCM	√	√	√	√
2003	F-Series Super Duty	7.3L	Direct Injection -	RCM	√	√	√	√
2003	F-Series Super Duty	7.3L	Direct Injection -	VSM	√	√	√	√
2004	F-Series Super Duty	5.4L	2V	ABS/TCS	√	√	√	√
2004	F-Series Super Duty	5.4L	2V	GEM	√	√	√	√
2004	F-Series Super Duty	5.4L	2V	HEC	√	√	√	√
2004	F-Series Super Duty	5.4L	2V	OTC	√	√	√	√
2004	F-Series Super Duty	5.4L	2V	PAM	√	√	√	√
2004	F-Series Super Duty	5.4L	2V	PATS	√	√	√	√
2004	F-Series Super Duty	5.4L	2V	PCM	√	√	√	√
2004	F-Series Super Duty	5.4L	2V	PCM	√	√	√	√
2004	F-Series Super Duty	5.4L	2V	RCM	√	√	√	√
2004	F-Series Super Duty	5.4L	2V	VSM	√	√	√	√
2004	F-Series Super Duty	6.0L	Direct Injection -	ABS/TCS	√	√	√	√
2004	F-Series Super Duty	6.0L	Direct Injection -	ABS/TCS	√	√	√	√
2004	F-Series Super Duty	6.0L	Direct Injection -	FOH	√	√	√	√
2004	F-Series Super Duty	6.0L	Direct Injection -	GEM	√	√	√	√
2004	F-Series Super Duty	6.0L	Direct Injection -	HEC	√	√	√	√
2004	F-Series Super Duty	6.0L	Direct Injection -	OTC	√	√	√	√
2004	F-Series Super Duty	6.0L	Direct Injection -	PAM	√	√	√	√
2004	F-Series Super Duty	6.0L	Direct Injection -	PATS	√	√	√	√
2004	F-Series Super Duty	6.0L	Direct Injection -	PCM	√	√	√	√
2004	F-Series Super Duty	6.0L	Direct Injection -	PCM	√	√	√	√
2004	F-Series Super Duty	6.0L	Direct Injection -	PCM	√	√	√	√
2004	F-Series Super Duty	6.0L	Direct Injection - Turbo	PCM	√	√	√	√
2004	F-Series Super Duty	6.0L	Direct Injection -	RCM	√	√	√	√
2004	F-Series Super Duty	6.0L	Direct Injection -	TCM	√	√	√	√
2004	F-Series Super Duty	6.0L	Direct Injection -	VSM	√	√	√	√
2004	F-Series Super Duty	6.8L	2V	ABS/TCS	√	√	√	√
2004	F-Series Super Duty	6.8L	2V	GEM	√	√	√	√
2004	F-Series Super Duty	6.8L	2V	HEC	√	√	√	√
2004	F-Series Super Duty	6.8L	2V	OTC	√	√	√	√
2004	F-Series Super Duty	6.8L	2V	PAM	√	√	√	√
2004	F-Series Super Duty	6.8L	2V	PATS	√	√	√	√
2004	F-Series Super Duty	6.8L	2V	PCM	√	√	√	√

2004	F-Series Super Duty	6.8L	2V	PCM	✓	✓	✓	✓
2004	F-Series Super Duty	6.8L	2V	RCM	✓	✓	✓	✓
2004	F-Series Super Duty	6.8L	2V	VSM	✓	✓	✓	✓
2005	F-Series Super Duty	5.4L	2V	ABS	✓	✓	✓	✓
2005	F-Series Super Duty	5.4L	2V	EATC	✓	✓	✓	✓
2005	F-Series Super Duty	5.4L	2V	GEM	✓	✓	✓	✓
2005	F-Series Super Duty	5.4L	2V	IC	✓	✓	✓	✓
2005	F-Series Super Duty	5.4L	2V	PAM	✓	✓	✓	✓
2005	F-Series Super Duty	5.4L	2V	PCM	✓	✓	✓	✓
2005	F-Series Super Duty	5.4L	2V	TBC	✓	✓	✓	✓
2005	F-Series Super Duty	5.4L	2V	VSM	✓	✓	✓	✓
2005	F-Series Super Duty	5.4L	3V	ABS	✓	✓	✓	✓
2005	F-Series Super Duty	5.4L	3V	EATC	✓	✓	✓	✓
2005	F-Series Super Duty	5.4L	3V	GEM	✓	✓	✓	✓
2005	F-Series Super Duty	5.4L	3V	IC	✓	✓	✓	✓
2005	F-Series Super Duty	5.4L	3V	PAM	✓	✓	✓	✓
2005	F-Series Super Duty	5.4L	3V	PCM	✓	✓	✓	✓
2005	F-Series Super Duty	5.4L	3V	PCM	✓	✓	✓	✓
2005	F-Series Super Duty	5.4L	3V	PCM	✓	✓	✓	✓
2005	F-Series Super Duty	5.4L	3V	RCM	✓	✓	✓	✓
2005	F-Series Super Duty	5.4L	3V	TBC	✓	✓	✓	✓
2005	F-Series Super Duty	5.4L	3V	VSM	✓	✓	✓	✓
2005	F-Series Super Duty	6.0L	Direct Injection -	ABS	✓	✓	✓	✓
2005	F-Series Super Duty	6.0L	Direct Injection -	ABS	✓	✓	✓	✓
2005	F-Series Super Duty	6.0L	Direct Injection -	EATC	✓	✓	✓	✓
2005	F-Series Super Duty	6.0L	Direct Injection -	GEM	✓	✓	✓	✓
2005	F-Series Super Duty	6.0L	Direct Injection -	IC	✓	✓	✓	✓
2005	F-Series Super Duty	6.0L	Direct Injection -	PAM	✓	✓	✓	✓
2005	F-Series Super Duty	6.0L	Direct Injection -	PCM	✓	✓	✓	✓
2005	F-Series Super Duty	6.0L	Direct Injection -	PCM	✓	✓	✓	✓
2005	F-Series Super Duty	6.0L	Direct Injection -	PCM	✓	✓	✓	✓
2005	F-Series Super Duty	6.0L	Direct Injection - Turbo	PCM	✓	✓	✓	✓
2005	F-Series Super Duty	6.0L	Direct Injection -	RCM	✓	✓	✓	✓
2005	F-Series Super Duty	6.0L	Direct Injection -	TBC	✓	✓	✓	✓
2005	F-Series Super Duty	6.0L	Direct Injection -	TCM	✓	✓	✓	✓
2005	F-Series Super Duty	6.0L	Direct Injection -	VSM	✓	✓	✓	✓
2005	F-Series Super Duty	6.8L	2V	ABS	✓	✓	✓	✓
2005	F-Series Super Duty	6.8L	2V	EATC	✓	✓	✓	✓
2005	F-Series Super Duty	6.8L	2V	GEM	✓	✓	✓	✓
2005	F-Series Super Duty	6.8L	2V	IC	✓	✓	✓	✓
2005	F-Series Super Duty	6.8L	2V	PAM	✓	✓	✓	✓
2005	F-Series Super Duty	6.8L	2V	PCM	✓	✓	✓	✓
2005	F-Series Super Duty	6.8L	2V	RCM	✓	✓	✓	✓
2005	F-Series Super Duty	6.8L	2V	TBC	✓	✓	✓	✓
2005	F-Series Super Duty	6.8L	2V	VSM	✓	✓	✓	✓



2006	F-Series Super Duty	6.8L	2V	EATC	✓	✓	✓	✓
2006	F-Series Super Duty	6.8L	2V	GEM	✓	✓	✓	✓
2006	F-Series Super Duty	6.8L	2V	IC	✓	✓	✓	✓
2006	F-Series Super Duty	6.8L	2V	PAM	✓	✓	✓	✓
2006	F-Series Super Duty	6.8L	2V	PCM	✓	✓	✓	✓
2006	F-Series Super Duty	6.8L	2V	PCM	✓	✓	✓	✓
2006	F-Series Super Duty	6.8L	2V	RCM	✓	✓	✓	✓
2006	F-Series Super Duty	6.8L	2V	TBC	✓	✓	✓	✓
2006	F-Series Super Duty	6.8L	2V	VSM	✓	✓	✓	✓
2006	F-Series Super Duty	6.8L	3V	ABS	✓	✓	✓	✓
2006	F-Series Super Duty	6.8L	3V	EATC	✓	✓	✓	✓
2006	F-Series Super Duty	6.8L	3V	GEM	✓	✓	✓	✓
2006	F-Series Super Duty	6.8L	3V	IC	✓	✓	✓	✓
2006	F-Series Super Duty	6.8L	3V	PAM	✓	✓	✓	✓
2006	F-Series Super Duty	6.8L	3V	PCM	✓	✓	✓	✓
2006	F-Series Super Duty	6.8L	3V	PCM	✓	✓	✓	✓
2006	F-Series Super Duty	6.8L	3V	RCM	✓	✓	✓	✓
2006	F-Series Super Duty	6.8L	3V	TBC	✓	✓	✓	✓
2006	F-Series Super Duty	6.8L	3V	VSM	✓	✓	✓	✓
2007	F-Series Super Duty	5.4L	3V	ABS	✓	✓	✓	✓
2007	F-Series Super Duty	5.4L	3V	EATC	✓	✓	✓	✓
2007	F-Series Super Duty	5.4L	3V	GEM	✓	✓	✓	✓
2007	F-Series Super Duty	5.4L	3V	IC	✓	✓	✓	✓
2007	F-Series Super Duty	5.4L	3V	PAM	✓	✓	✓	✓
2007	F-Series Super Duty	5.4L	3V	PCM	✓	✓	✓	✓
2007	F-Series Super Duty	5.4L	3V	PCM	✓	✓	✓	✓
2007	F-Series Super Duty	5.4L	3V	PCM	✓	✓	✓	✓
2007	F-Series Super Duty	5.4L	3V	RCM	✓	✓	✓	✓
2007	F-Series Super Duty	5.4L	3V	TBC	✓	✓	✓	✓
2007	F-Series Super Duty	5.4L	3V	VSM	✓	✓	✓	✓
2007	F-Series Super Duty	6.0L	Direct Injection -	ABS	✓	✓	✓	✓
2007	F-Series Super Duty	6.0L	Direct Injection -	ABS	✓	✓	✓	✓
2007	F-Series Super Duty	6.0L	Direct Injection -	EATC	✓	✓	✓	✓
2007	F-Series Super Duty	6.0L	Direct Injection -	GEM	✓	✓	✓	✓
2007	F-Series Super Duty	6.0L	Direct Injection -	IC	✓	✓	✓	✓
2007	F-Series Super Duty	6.0L	Direct Injection -	PAM	✓	✓	✓	✓
2007	F-Series Super Duty	6.0L	Direct Injection -	PCM	✓	✓	✓	✓
2007	F-Series Super Duty	6.0L	Direct Injection -	PCM	✓	✓	✓	✓
2007	F-Series Super Duty	6.0L	Direct Injection - Turbo	PCM	✓	✓	✓	✓
2007	F-Series Super Duty	6.0L	Direct Injection -	RCM	✓	✓	✓	✓
2007	F-Series Super Duty	6.0L	Direct Injection -	TBC	✓	✓	✓	✓
2007	F-Series Super Duty	6.0L	Direct Injection -	TCM	✓	✓	✓	✓
2007	F-Series Super Duty	6.0L	Direct Injection -	VSM	✓	✓	✓	✓
2007	F-Series Super Duty	6.8L	2V	ABS	✓	✓	✓	✓
2007	F-Series Super Duty	6.8L	2V	EATC	✓	✓	✓	✓



2007	F-Series Super Duty	6.8L	2V	GEM	✓	✓	✓	✓
2007	F-Series Super Duty	6.8L	2V	IC	✓	✓	✓	✓
2007	F-Series Super Duty	6.8L	2V	PAM	✓	✓	✓	✓
2007	F-Series Super Duty	6.8L	2V	PCM	✓	✓	✓	✓
2007	F-Series Super Duty	6.8L	2V	PCM	✓	✓	✓	✓
2007	F-Series Super Duty	6.8L	2V	RCM	✓	✓	✓	✓
2007	F-Series Super Duty	6.8L	2V	TBC	✓	✓	✓	✓
2007	F-Series Super Duty	6.8L	2V	VSM	✓	✓	✓	✓
2007	F-Series Super Duty	6.8L	3V	ABS	✓	✓	✓	✓
2007	F-Series Super Duty	6.8L	3V	EATC	✓	✓	✓	✓
2007	F-Series Super Duty	6.8L	3V	GEM	✓	✓	✓	✓
2007	F-Series Super Duty	6.8L	3V	IC	✓	✓	✓	✓
2007	F-Series Super Duty	6.8L	3V	PAM	✓	✓	✓	✓
2007	F-Series Super Duty	6.8L	3V	PCM	✓	✓	✓	✓
2007	F-Series Super Duty	6.8L	3V	PCM	✓	✓	✓	✓
2007	F-Series Super Duty	6.8L	3V	PCM	✓	✓	✓	✓
2007	F-Series Super Duty	6.8L	3V	RCM	✓	✓	✓	✓
2007	F-Series Super Duty	6.8L	3V	TBC	✓	✓	✓	✓
2007	F-Series Super Duty	6.8L	3V	VSM	✓	✓	✓	✓
2008	F-Series Super Duty	5.4L	2V	4X4	✓	✓	✓	✓
2008	F-Series Super Duty	5.4L	2V	ABS	✓	✓	✓	✓
2008	F-Series Super Duty	5.4L	2V	ACM	✓	✓	✓	✓
2008	F-Series Super Duty	5.4L	2V	DSM	✓	✓	✓	✓
2008	F-Series Super Duty	5.4L	2V	GEM / SJB	✓	✓	✓	✓
2008	F-Series Super Duty	5.4L	2V	HVAC	✓	✓	✓	✓
2008	F-Series Super Duty	5.4L	2V	IC	✓	✓	✓	✓
2008	F-Series Super Duty	5.4L	2V	PAM	✓	✓	✓	✓
2008	F-Series Super Duty	5.4L	2V	PCM	✓	✓	✓	✓
2008	F-Series Super Duty	5.4L	2V	RCM	✓	✓	✓	✓
2008	F-Series Super Duty	5.4L	2V	RETM	✓	✓	✓	
2008	F-Series Super Duty	5.4L	2V	SDARS	✓	✓	✓	✓
2008	F-Series Super Duty	5.4L	2V	TBC	✓	✓	✓	✓
2008	F-Series Super Duty	5.4L	3V	4X4	✓	✓	✓	✓
2008	F-Series Super Duty	5.4L	3V	ABS	✓	✓	✓	✓
2008	F-Series Super Duty	5.4L	3V	ACM	✓	✓	✓	✓
2008	F-Series Super Duty	5.4L	3V	DSM	✓	✓	✓	✓
2008	F-Series Super Duty	5.4L	3V	GEM / SJB	✓	✓	✓	✓
2008	F-Series Super Duty	5.4L	3V	HVAC	✓	✓	✓	✓
2008	F-Series Super Duty	5.4L	3V	IC	✓	✓	✓	✓
2008	F-Series Super Duty	5.4L	3V	PCM	✓	✓	✓	✓
2008	F-Series Super Duty	5.4L	3V	PCM	✓	✓	✓	✓
2008	F-Series Super Duty	5.4L	3V	RCM	✓	✓	✓	✓
2008	F-Series Super Duty	5.4L	3V	RETM	✓	✓	✓	
2008	F-Series Super Duty	5.4L	3V	SDARS	✓	✓	✓	✓
2008	F-Series Super Duty	5.4L	3V	TBC	✓	✓	✓	✓



2008	F-Series Super Duty	6.8L	3V	ABS	✓	✓	✓	✓
2008	F-Series Super Duty	6.8L	3V	ACM	✓	✓	✓	✓
2008	F-Series Super Duty	6.8L	3V	DSM	✓	✓	✓	✓
2008	F-Series Super Duty	6.8L	3V	HVAC	✓	✓	✓	✓
2008	F-Series Super Duty	6.8L	3V	IC	✓	✓	✓	✓
2008	F-Series Super Duty	6.8L	3V	PAM	✓	✓	✓	✓
2008	F-Series Super Duty	6.8L	3V	PCM	✓	✓	✓	✓
2008	F-Series Super Duty	6.8L	3V	PCM	✓	✓	✓	✓
2008	F-Series Super Duty	6.8L	3V	RCM	✓	✓	✓	✓
2008	F-Series Super Duty	6.8L	3V	RETM	✓	✓	✓	
2008	F-Series Super Duty	6.8L	3V	SDARS	✓	✓	✓	✓
2008	F-Series Super Duty	6.8L	3V	TBC	✓	✓	✓	✓
2009	F-Series Super Duty	5.4L	3V	4X4	✓	✓	✓	✓
2009	F-Series Super Duty	5.4L	3V	ABS	✓	✓	✓	✓
2009	F-Series Super Duty	5.4L	3V	ACM	✓	✓	✓	✓
2009	F-Series Super Duty	5.4L	3V	ACM	✓	✓	✓	✓
2009	F-Series Super Duty	5.4L	3V	APIM	✓	✓	✓	✓
2009	F-Series Super Duty	5.4L	3V	APIM	✓	✓	✓	✓
2009	F-Series Super Duty	5.4L	3V	DSM	✓	✓	✓	✓
2009	F-Series Super Duty	5.4L	3V	DSM	✓	✓	✓	✓
2009	F-Series Super Duty	5.4L	3V	GEM / SJB	✓	✓	✓	✓
2009	F-Series Super Duty	5.4L	3V	GEM / SJB	✓	✓	✓	✓
2009	F-Series Super Duty	5.4L	3V	HVAC	✓	✓	✓	✓
2009	F-Series Super Duty	5.4L	3V	IC	✓	✓	✓	✓
2009	F-Series Super Duty	5.4L	3V	PAM	✓	✓	✓	✓
2009	F-Series Super Duty	5.4L	3V	PCM	✓	✓	✓	✓
2009	F-Series Super Duty	5.4L	3V	PCM	✓	✓	✓	✓
2009	F-Series Super Duty	5.4L	3V	RCM	✓	✓	✓	✓
2009	F-Series Super Duty	5.4L	3V	RCM	✓	✓	✓	✓
2009	F-Series Super Duty	5.4L	3V	RETM	✓	✓	✓	
2009	F-Series Super Duty	5.4L	3V	RETM	✓	✓	✓	
2009	F-Series Super Duty	5.4L	3V	SDARS	✓	✓	✓	✓
2009	F-Series Super Duty	5.4L	3V	SDARS	✓	✓	✓	✓
2009	F-Series Super Duty	5.4L	3V	TBC	✓	✓	✓	✓
2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo	4X4	✓	✓	✓	✓
2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo	ABS	✓	✓	✓	✓
2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo	ABS	✓	✓	✓	✓
2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo	ABS	✓	✓	✓	✓
2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo	ACM	✓	✓	✓	✓
2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo	ACM	✓	✓	✓	✓
2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo	ACM	✓	✓	✓	✓
2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo	ACM	✓	✓	✓	✓
2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo	ACM	✓	✓	✓	✓
2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo	AHCM	✓	✓	✓	✓
2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo	APIM	✓	✓	✓	✓





2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo	SDARS	✓	✓	✓	✓
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo	TBC	✓	✓	✓	✓
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo	TCM	✓	✓	✓	✓
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo	TCM	✓	✓	✓	✓
2010	F-Series Super Duty	6.8L	3V	4X4	✓	✓	✓	✓
2010	F-Series Super Duty	6.8L	3V	ABS	✓	✓	✓	✓
2010	F-Series Super Duty	6.8L	3V	ABS	✓	✓	✓	✓
2010	F-Series Super Duty	6.8L	3V	ACM	✓	✓	✓	✓
2010	F-Series Super Duty	6.8L	3V	ACM	✓	✓	✓	✓
2010	F-Series Super Duty	6.8L	3V	APIM	✓	✓	✓	✓
2010	F-Series Super Duty	6.8L	3V	DSM	✓	✓	✓	✓
2010	F-Series Super Duty	6.8L	3V	GEM / SJB	✓	✓	✓	✓
2010	F-Series Super Duty	6.8L	3V	GPSM	✓	✓	✓	✓
2010	F-Series Super Duty	6.8L	3V	HVAC	✓	✓	✓	✓
2010	F-Series Super Duty	6.8L	3V	IC	✓	✓	✓	✓
2010	F-Series Super Duty	6.8L	3V	PAM	✓	✓	✓	✓
2010	F-Series Super Duty	6.8L	3V	PCM	✓	✓	✓	✓
2010	F-Series Super Duty	6.8L	3V	PCM	✓	✓	✓	✓
2010	F-Series Super Duty	6.8L	3V	RCM	✓	✓	✓	✓
2010	F-Series Super Duty	6.8L	3V	RETM	✓	✓	✓	
2010	F-Series Super Duty	6.8L	3V	SDARS	✓	✓	✓	✓
2010	F-Series Super Duty	6.8L	3V	TBC	✓	✓	✓	✓
2011	F-Series Super Duty	6.2L	2V	ABS	✓	✓	✓	✓
2011	F-Series Super Duty	6.2L	2V	ACM	✓	✓	✓	✓
2011	F-Series Super Duty	6.2L	2V	APIM	✓	✓	✓	✓
2011	F-Series Super Duty	6.2L	2V	BCM#1	✓	✓	✓	✓
2011	F-Series Super Duty	6.2L	2V	DCSM	✓	✓	✓	✓
2011	F-Series Super Duty	6.2L	2V	DSM	✓	✓	✓	✓
2011	F-Series Super Duty	6.2L	2V	GPSM	✓	✓	✓	✓
2011	F-Series Super Duty	6.2L	2V	HVAC	✓	✓	✓	✓
2011	F-Series Super Duty	6.2L	2V	IPC	✓	✓	✓	✓
2011	F-Series Super Duty	6.2L	2V	PAM	✓	✓	✓	
2011	F-Series Super Duty	6.2L	2V	PCM	✓	✓	✓	
2011	F-Series Super Duty	6.2L	2V	RCM	✓	✓	✓	
2011	F-Series Super Duty	6.2L	2V	SCCM	✓	✓	✓	✓
2011	F-Series Super Duty	6.2L	2V	SDARS	✓	✓	✓	✓
2011	F-Series Super Duty	6.2L	2V	TBC	✓	✓	✓	✓
2011	F-Series Super Duty	6.2L	2V	TCCM	✓	✓	✓	✓
2011	F-Series Super Duty	6.2L	2V	TPM	✓	✓	✓	✓
2011	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	ABS	✓	✓	✓	
2011	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	ABS	✓	✓	✓	✓
2011	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	ABS	✓	✓	✓	✓
2011	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	ABS	✓	✓	✓	✓
2011	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	ACM	✓	✓	✓	
2011	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	ACM	✓	✓	✓	✓



2011	F-Series Super Duty	6.8L	3V	PCM	✓	✓	✓	✓
2011	F-Series Super Duty	6.8L	3V	PCM	✓	✓	✓	✓
2011	F-Series Super Duty	6.8L	3V	PCM	✓	✓	✓	✓
2011	F-Series Super Duty	6.8L	3V	RCM	✓	✓	✓	✓
2011	F-Series Super Duty	6.8L	3V	SDARS	✓	✓	✓	✓
2011	F-Series Super Duty	6.8L	3V	TBC	✓	✓	✓	✓
2011	F-Series Super Duty	6.8L	3V	TCCM	✓	✓	✓	✓
2011	F-Series Super Duty	6.8L	3V	TPM	✓	✓	✓	✓
2012	F-Series Super Duty	6.2L	2V	ABS	✓	✓	✓	✓
2012	F-Series Super Duty	6.2L	2V	ABS	✓	✓	✓	✓
2012	F-Series Super Duty	6.2L	2V	ACM	✓	✓	✓	✓
2012	F-Series Super Duty	6.2L	2V	ACM	✓	✓	✓	✓
2012	F-Series Super Duty	6.2L	2V	APIM	✓	✓	✓	✓
2012	F-Series Super Duty	6.2L	2V	APIM	✓	✓	✓	✓
2012	F-Series Super Duty	6.2L	2V	BCM#1	✓	✓	✓	✓
2012	F-Series Super Duty	6.2L	2V	DCSM	✓	✓	✓	✓
2012	F-Series Super Duty	6.2L	2V	DSM	✓	✓	✓	
2012	F-Series Super Duty	6.2L	2V	DSM	✓	✓	✓	✓
2012	F-Series Super Duty	6.2L	2V	GPSM	✓	✓	✓	
2012	F-Series Super Duty	6.2L	2V	GPSM	✓	✓	✓	✓
2012	F-Series Super Duty	6.2L	2V	HVAC	✓	✓	✓	
2012	F-Series Super Duty	6.2L	2V	HVAC	✓	✓	✓	✓
2012	F-Series Super Duty	6.2L	2V	IPC	✓	✓	✓	✓
2012	F-Series Super Duty	6.2L	2V	PAM	✓	✓	✓	
2012	F-Series Super Duty	6.2L	2V	PCM	✓	✓	✓	
2012	F-Series Super Duty	6.2L	2V	PCM	✓	✓	✓	✓
2012	F-Series Super Duty	6.2L	2V	PCM	✓	✓	✓	✓
2012	F-Series Super Duty	6.2L	2V	RCM	✓	✓	✓	
2012	F-Series Super Duty	6.2L	2V	RCM	✓	✓	✓	✓
2012	F-Series Super Duty	6.2L	2V	SCCM	✓	✓	✓	✓
2012	F-Series Super Duty	6.2L	2V	SDARS	✓	✓	✓	
2012	F-Series Super Duty	6.2L	2V	TBC	✓	✓	✓	
2012	F-Series Super Duty	6.2L	2V	TBC	✓	✓	✓	✓
2012	F-Series Super Duty	6.2L	2V	TCCM	✓	✓	✓	✓
2012	F-Series Super Duty	6.2L	2V	TPM	✓	✓	✓	✓
2012	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	ABS	✓	✓	✓	✓
2012	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	ABS	✓	✓	✓	✓
2012	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	ACM	✓	✓	✓	✓
2012	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	ACM	✓	✓	✓	✓
2012	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	AHCM	✓	✓	✓	✓
2012	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	APIM	✓	✓	✓	✓
2012	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	BCM#1	✓	✓	✓	✓
2012	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	BCM#1	✓	✓	✓	✓
2012	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	CDIM	✓	✓	✓	✓
2012	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	DCSM	✓	✓	✓	✓







2013	F-Series Super Duty	6.8L	3V	BCM#1	✓	✓	✓	✓
2013	F-Series Super Duty	6.8L	3V	BCM#1	✓	✓	✓	✓
2013	F-Series Super Duty	6.8L	3V	DCSM	✓	✓	✓	✓
2013	F-Series Super Duty	6.8L	3V	DSM	✓	✓	✓	✓
2013	F-Series Super Duty	6.8L	3V	DSP	✓	✓	✓	✓
2013	F-Series Super Duty	6.8L	3V	FCDIM	✓	✓	✓	✓
2013	F-Series Super Duty	6.8L	3V	FCIM	✓	✓	✓	✓
2013	F-Series Super Duty	6.8L	3V	GPSM	✓	✓	✓	✓
2013	F-Series Super Duty	6.8L	3V	HSWM	✓	✓	✓	✓
2013	F-Series Super Duty	6.8L	3V	IPC	✓	✓	✓	✓
2013	F-Series Super Duty	6.8L	3V	PAM	✓	✓	✓	✓
2013	F-Series Super Duty	6.8L	3V	PCM	✓	✓	✓	✓
2013	F-Series Super Duty	6.8L	3V	PCM	✓	✓	✓	✓
2013	F-Series Super Duty	6.8L	3V	RCM	✓	✓	✓	✓
2013	F-Series Super Duty	6.8L	3V	RTM	✓	✓	✓	✓
2013	F-Series Super Duty	6.8L	3V	SCCM	✓	✓	✓	✓
2013	F-Series Super Duty	6.8L	3V	TBC	✓	✓	✓	✓
2013	F-Series Super Duty	6.8L	3V	TCCM	✓	✓	✓	✓
2014	F-Series Super Duty	6.2L	2V	ABS	✓	✓	✓	✓
2014	F-Series Super Duty	6.2L	2V	ACM	✓	✓	✓	✓
2014	F-Series Super Duty	6.2L	2V	ACM	✓	✓	✓	✓
2014	F-Series Super Duty	6.2L	2V	APIM	✓	✓	✓	✓
2014	F-Series Super Duty	6.2L	2V	APIM	✓	✓	✓	✓
2014	F-Series Super Duty	6.2L	2V	BCM#1	✓	✓	✓	✓
2014	F-Series Super Duty	6.2L	2V	DCSM	✓	✓	✓	✓
2014	F-Series Super Duty	6.2L	2V	DSM	✓	✓	✓	✓
2014	F-Series Super Duty	6.2L	2V	DSP	✓	✓	✓	✓
2014	F-Series Super Duty	6.2L	2V	FCDIM	✓	✓	✓	✓
2014	F-Series Super Duty	6.2L	2V	FCIM	✓	✓	✓	✓
2014	F-Series Super Duty	6.2L	2V	GPSM	✓	✓	✓	✓
2014	F-Series Super Duty	6.2L	2V	HSWM	✓	✓	✓	✓
2014	F-Series Super Duty	6.2L	2V	IPC	✓	✓	✓	✓
2014	F-Series Super Duty	6.2L	2V	PAM	✓	✓	✓	✓
2014	F-Series Super Duty	6.2L	2V	PCM	✓	✓	✓	✓
2014	F-Series Super Duty	6.2L	2V	PCM	✓	✓	✓	✓
2014	F-Series Super Duty	6.2L	2V	RCM	✓	✓	✓	✓
2014	F-Series Super Duty	6.2L	2V	RTM	✓	✓	✓	✓
2014	F-Series Super Duty	6.2L	2V	SCCM	✓	✓	✓	✓
2014	F-Series Super Duty	6.2L	2V	TBC	✓	✓	✓	✓
2014	F-Series Super Duty	6.2L	2V	TCCM	✓	✓	✓	✓
2014	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	ABS	✓	✓	✓	✓
2014	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	ACM	✓	✓	✓	✓
2014	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	AHCM	✓	✓	✓	✓
2014	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	APIM	✓	✓	✓	✓
2014	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	BCM#1	✓	✓	✓	✓

2014	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	CDIM	✓	✓	✓	✓
2014	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	DCSM	✓	✓	✓	✓
2014	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	DSM	✓	✓	✓	✓
2014	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	DSP	✓	✓	✓	✓
2014	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	FCDIM	✓	✓	✓	✓
2014	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	FCIM	✓	✓	✓	✓
2014	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	GPSM	✓	✓	✓	✓
2014	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	HSWM	✓	✓	✓	✓
2014	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	IPC	✓	✓	✓	✓
2014	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	PAM	✓	✓	✓	✓
2014	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	RCM	✓	✓	✓	✓
2014	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	RTM	✓	✓	✓	✓
2014	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	SCCM	✓	✓	✓	✓
2014	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	TBC	✓	✓	✓	✓
2014	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	TCCM	✓	✓	✓	✓
2014	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo	TCM	✓	✓	✓	✓
2014	F-Series Super Duty	6.8L	3V	ABS	✓	✓	✓	✓
2014	F-Series Super Duty	6.8L	3V	ACM	✓	✓	✓	✓
2014	F-Series Super Duty	6.8L	3V	APIM	✓	✓	✓	✓
2014	F-Series Super Duty	6.8L	3V	BCM#1	✓	✓	✓	✓
2014	F-Series Super Duty	6.8L	3V	DCSM	✓	✓	✓	✓
2014	F-Series Super Duty	6.8L	3V	DSM	✓	✓	✓	✓
2014	F-Series Super Duty	6.8L	3V	DSP	✓	✓	✓	✓
2014	F-Series Super Duty	6.8L	3V	FCDIM	✓	✓	✓	✓
2014	F-Series Super Duty	6.8L	3V	FCIM	✓	✓	✓	✓
2014	F-Series Super Duty	6.8L	3V	GPSM	✓	✓	✓	✓
2014	F-Series Super Duty	6.8L	3V	HSWM	✓	✓	✓	✓
2014	F-Series Super Duty	6.8L	3V	IPC	✓	✓	✓	✓
2014	F-Series Super Duty	6.8L	3V	PAM	✓	✓	✓	✓
2014	F-Series Super Duty	6.8L	3V	PCM	✓	✓	✓	✓
2014	F-Series Super Duty	6.8L	3V	RCM	✓	✓	✓	✓
2014	F-Series Super Duty	6.8L	3V	RTM	✓	✓	✓	✓
2014	F-Series Super Duty	6.8L	3V	SCCM	✓	✓	✓	✓
2014	F-Series Super Duty	6.8L	3V	TBC	✓	✓	✓	✓
2014	F-Series Super Duty	6.8L	3V	TCCM	✓	✓	✓	✓
2009	F350/4000	3.9L	Cummins Diesel	4X4	✓	✓	✓	✓
2009	F350/4000	3.9L	Cummins Diesel	GEM	✓	✓	✓	✓
2009	F350/4000	3.9L	Cummins Diesel	TBM	✓	✓	✓	✓
1998	FAMILIA / LASER	1.3L	B3	ABS	✓	✓	✓	✓
1998	FAMILIA / LASER	1.3L	B3	PCM	✓	✓	✓	✓
1998	FAMILIA / LASER	1.5L	ZL	ABS	✓	✓	✓	✓
1998	FAMILIA / LASER	1.5L	ZL	PCM	✓	✓	✓	✓
1998	FAMILIA / LASER	1.8L	FP	ABS	✓	✓	✓	✓
1998	FAMILIA / LASER	1.8L	FP	PCM	✓	✓	✓	✓
1998	FAMILIA / LASER	2.0L	RF	ABS	✓	✓	✓	✓

1998	FAMILIA / LASER	2.0L	RF	PCM	✓	✓	✓	✓
1999	FAMILIA / LASER	2.0L	FS	ABS	✓	✓	✓	✓
1999	FAMILIA / LASER	2.0L	FS	PCM	✓	✓	✓	✓
2000	FAMILIA / LASER	1.5L	ZL	ABS	✓	✓	✓	✓
2000	FAMILIA / LASER	1.5L	ZL	ABS/TCS	✓	✓	✓	✓
2000	FAMILIA / LASER	1.5L	ZL	PCM	✓	✓	✓	✓
2000	FAMILIA / LASER	2.0L	FS	ABS	✓	✓	✓	✓
2000	FAMILIA / LASER	2.0L	FS	PCM	✓	✓	✓	✓
2002	FAMILIA / LASER	1.5L	ZL	ABS/TCS	✓	✓	✓	✓
2002	FAMILIA / LASER	1.5L	ZL	PCM	✓	✓	✓	✓
2002	FAMILIA / LASER	2.0L	FS	ABS/TCS	✓	✓	✓	✓
2002	FAMILIA / LASER	2.0L	FS	PCM	✓	✓	✓	✓
2010.25	FIGO	1 4 DV4	Duratorq Turbo Diesel Common Rail	ABS/TCS	✓	✓	✓	✓
2010.25	FIGO	1 4 DV4	Duratorq Turbo Diesel Common Rail	IC	✓	✓	✓	✓
2010.25	FIGO	1 4 DV4	Duratorq Turbo Diesel Common Rail	PCM	✓	✓	✓	✓
2010.25	FIGO	1 4 DV4	Duratorq Turbo Diesel Common Rail	RCM	✓	✓	✓	✓
2010.25	FIGO	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓
2010.25	FIGO	1.4L	DURATEC 16V	IC	✓	✓	✓	✓
2010.25	FIGO	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓
2010.25	FIGO	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓
2010.25	FIGO	1_19L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓
2010.25	FIGO	1_19L	DURATEC 16V	IC	✓	✓	✓	✓
2010.25	FIGO	1_19L	DURATEC 16V	PCM	✓	✓	✓	✓
2010.25	FIGO	1_19L	DURATEC 16V	RCM	✓	✓	✓	✓
2011.25	FIGO	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓
2011.25	FIGO	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓
2011.25	FIGO	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓
2011.25	FIGO	1.4L	DURATEC 16V	IC	✓	✓	✓	✓
2011.25	FIGO	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓
2011.25	FIGO	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓
2011.25	FIGO	1.6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓
2011.25	FIGO	1.6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓
2011.25	FIGO	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓
2011.25	FIGO	1.6L	DURATEC 16V	IC	✓	✓	✓	✓
2011.25	FIGO	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓
2011.25	FIGO	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓
2011.25	FIGO	1.6L	DURATEC 16V	TCM	✓	✓	✓	✓
2011.25	FIGO	Other	DURATEC 16V	ABS/TCS	✓	✓	✓	✓
2011.25	FIGO	Other	DURATEC 16V	GEM	✓	✓	✓	✓
2011.25	FIGO	Other	DURATEC 16V	IC	✓	✓	✓	✓
2011.25	FIGO	Other	DURATEC 16V	RCM	✓	✓	✓	✓
2005	FORD GT	5.4L	4V	AFCM	✓	✓	✓	✓
2005	FORD GT	5.4L	4V	GEM	✓	✓	✓	✓
2005	FORD GT	5.4L	4V	IC	✓	✓	✓	✓
2005	FORD GT	5.4L	4V	PATS	✓	✓	✓	✓

2005	FORD GT	5.4L	4V	PCM	√	√	√	√
2005	FORD GT	5.4L	4V	RCM	√	√	√	√
2006	FORD GT	5.4L	4V	ABS/TCS	√	√	√	√
2006	FORD GT	5.4L	4V	AFCM	√	√	√	√
2006	FORD GT	5.4L	4V	GEM	√	√	√	√
2006	FORD GT	5.4L	4V	IC	√	√	√	√
2006	FORD GT	5.4L	4V	PATS	√	√	√	√
2006	FORD GT	5.4L	4V	PCM	√	√	√	√
2006	FORD GT	5.4L	4V	RCM	√	√	√	√
1997	FRIENDEE / FRED A / BONGO FRIENDEE	2.0L	FE	PCM	√	√	√	√
1999	FRIENDEE / FRED A / BONGO FRIENDEE	2.0L	FE	PCM	√	√	√	√
1999	FRIENDEE / FRED A / BONGO FRIENDEE	2.5L	WL_T	PCM	√	√	√	√
2002	FRIENDEE / FRED A / BONGO FRIENDEE	2.0L	FE	PCM	√	√	√	√
2002	FRIENDEE / FRED A / BONGO FRIENDEE	2.0L	FE	TCM	√	√	√	√
2003	Fairlane / LTD	4.0L	DOHC VCT	ABS/TCS	√	√	√	√
2003	Fairlane / LTD	4.0L	DOHC VCT	ACM	√	√	√	√
2003	Fairlane / LTD	4.0L	DOHC VCT	BEM	√	√	√	√
2003	Fairlane / LTD	4.0L	DOHC VCT	HIM	√	√	√	√
2003	Fairlane / LTD	4.0L	DOHC VCT	IC	√	√	√	√
2003	Fairlane / LTD	4.0L	DOHC VCT	PAM	√	√	√	√
2003	Fairlane / LTD	4.0L	DOHC VCT	PCM	√	√	√	√
2003	Fairlane / LTD	4.0L	DOHC VCT	RCM	√	√	√	√
2003	Fairlane / LTD	5.4L	3V	ABS/TCS	√	√	√	√
2003	Fairlane / LTD	5.4L	3V	ACM	√	√	√	√
2003	Fairlane / LTD	5.4L	3V	BEM	√	√	√	√
2003	Fairlane / LTD	5.4L	3V	HIM	√	√	√	√
2003	Fairlane / LTD	5.4L	3V	IC	√	√	√	√
2003	Fairlane / LTD	5.4L	3V	PAM	√	√	√	√
2003	Fairlane / LTD	5.4L	3V	PCM	√	√	√	√
2003	Fairlane / LTD	5.4L	3V	RCM	√	√	√	√
2006	Fairlane / LTD	4.0L	DOHC VCT	ABS	√	√	√	√
2006	Fairlane / LTD	4.0L	DOHC VCT	ABS/TCS	√	√	√	√
2006	Fairlane / LTD	4.0L	DOHC VCT	ACM	√	√	√	√
2006	Fairlane / LTD	4.0L	DOHC VCT	BEM	√	√	√	√
2006	Fairlane / LTD	4.0L	DOHC VCT	HIM	√	√	√	√
2006	Fairlane / LTD	4.0L	DOHC VCT	IC	√	√	√	√
2006	Fairlane / LTD	4.0L	DOHC VCT	PAM	√	√	√	√
2006	Fairlane / LTD	4.0L	DOHC VCT	PCM	√	√	√	√
2006	Fairlane / LTD	4.0L	DOHC VCT	RCM	√	√	√	√
2006	Fairlane / LTD	4.0L	DOHC VCT	TCM	√	√	√	√
2006	Fairlane / LTD	5.4L	3V	ABS	√	√	√	√
2006	Fairlane / LTD	5.4L	3V	ABS/TCS	√	√	√	√
2006	Fairlane / LTD	5.4L	3V	ACM	√	√	√	√
2006	Fairlane / LTD	5.4L	3V	BEM	√	√	√	√
2006	Fairlane / LTD	5.4L	3V	HIM	√	√	√	√

2006	Fairlane / LTD	5.4L	3V	IC	√	√	√	√
2006	Fairlane / LTD	5.4L	3V	PAM	√	√	√	√
2006	Fairlane / LTD	5.4L	3V	PCM	√	√	√	√
2006	Fairlane / LTD	5.4L	3V	RCM	√	√	√	√
2006	Fairlane / LTD	5.4L	3V	TCM	√	√	√	√
Other	Fairlane / LTD	4.0L	Other	ABS	√	√	√	√
Other	Fairlane / LTD	4.0L	Other	ABS/TCS	√	√	√	√
Other	Fairlane / LTD	4.0L	Other	ACM	√	√	√	√
Other	Fairlane / LTD	4.0L	Other	BEM	√	√	√	√
Other	Fairlane / LTD	4.0L	Other	IAB	√	√	√	√
Other	Fairlane / LTD	4.0L	Other	IC	√	√	√	√
Other	Fairlane / LTD	4.0L	Other	PCM	√	√	√	√
Other	Fairlane / LTD	4.0L	Other	PCM	√	√	√	√
Other	Fairlane / LTD	4.0L	Other	RCM	√	√	√	√
Other	Fairlane / LTD	5.0L	Other	ABS	√	√	√	√
Other	Fairlane / LTD	5.0L	Other	ABS/TCS	√	√	√	√
Other	Fairlane / LTD	5.0L	Other	ACM	√	√	√	√
Other	Fairlane / LTD	5.0L	Other	BEM	√	√	√	√
Other	Fairlane / LTD	5.0L	Other	IAB	√	√	√	√
Other	Fairlane / LTD	5.0L	Other	IC	√	√	√	√
Other	Fairlane / LTD	5.0L	Other	PCM	√	√	√	√
Other	Fairlane / LTD	5.0L	Other	RCM	√	√	√	√
2003	Fairmont	4.0L	DOHC VCT	ABS/TCS	√	√	√	√
2003	Fairmont	4.0L	DOHC VCT	BEM	√	√	√	√
2003	Fairmont	4.0L	DOHC VCT	HIM	√	√	√	√
2003	Fairmont	4.0L	DOHC VCT	IC	√	√	√	√
2003	Fairmont	4.0L	DOHC VCT	PAM	√	√	√	√
2003	Fairmont	4.0L	DOHC VCT	PCM	√	√	√	√
2003	Fairmont	4.0L	DOHC VCT	RCM	√	√	√	√
2003	Fairmont	5.4L	3V	ABS/TCS	√	√	√	√
2003	Fairmont	5.4L	3V	ACM	√	√	√	√
2003	Fairmont	5.4L	3V	BEM	√	√	√	√
2003	Fairmont	5.4L	3V	HIM	√	√	√	√
2003	Fairmont	5.4L	3V	IC	√	√	√	√
2003	Fairmont	5.4L	3V	PAM	√	√	√	√
2003	Fairmont	5.4L	3V	PCM	√	√	√	√
2003	Fairmont	5.4L	3V	RCM	√	√	√	√
2006	Fairmont	4.0L	DOHC VCT	ABS	√	√	√	√
2006	Fairmont	4.0L	DOHC VCT	ABS/TCS	√	√	√	√
2006	Fairmont	4.0L	DOHC VCT	ACM	√	√	√	√
2006	Fairmont	4.0L	DOHC VCT	BEM	√	√	√	√
2006	Fairmont	4.0L	DOHC VCT	HIM	√	√	√	√
2006	Fairmont	4.0L	DOHC VCT	IC	√	√	√	√
2006	Fairmont	4.0L	DOHC VCT	PAM	√	√	√	√
2006	Fairmont	4.0L	DOHC VCT	PCM	√	√	√	√

2006	Fairmont	4.0L	DOHC VCT	RCM	√	√	√	√
2006	Fairmont	4.0L	DOHC VCT	TCM	√	√	√	√
2006	Fairmont	5.4L	3V	ABS	√	√	√	√
2006	Fairmont	5.4L	3V	ABS/TCS	√	√	√	
2006	Fairmont	5.4L	3V	ACM	√	√	√	√
2006	Fairmont	5.4L	3V	BEM	√	√	√	√
2006	Fairmont	5.4L	3V	HIM	√	√	√	√
2006	Fairmont	5.4L	3V	IC	√	√	√	√
2006	Fairmont	5.4L	3V	PAM	√	√	√	√
2006	Fairmont	5.4L	3V	PCM	√	√	√	√
2006	Fairmont	5.4L	3V	RCM	√	√	√	√
2006	Fairmont	5.4L	3V	TCM	√	√	√	√
Other	Fairmont	4.0L	Other	ABS	√	√	√	√
Other	Fairmont	4.0L	Other	ABS/TCS	√	√	√	√
Other	Fairmont	4.0L	Other	ACM	√	√	√	√
Other	Fairmont	4.0L	Other	BEM	√	√	√	√
Other	Fairmont	4.0L	Other	IAB	√	√	√	√
Other	Fairmont	4.0L	Other	IC	√	√	√	√
Other	Fairmont	4.0L	Other	PCM	√	√	√	√
Other	Fairmont	4.0L	Other	PCM	√	√	√	√
Other	Fairmont	4.0L	Other	RCM	√	√	√	√
Other	Fairmont	5.0L	Other	ABS	√	√	√	√
Other	Fairmont	5.0L	Other	ABS/TCS	√	√	√	√
Other	Fairmont	5.0L	Other	ACM	√	√	√	√
Other	Fairmont	5.0L	Other	BEM	√	√	√	√
Other	Fairmont	5.0L	Other	IAB	√	√	√	√
Other	Fairmont	5.0L	Other	IC	√	√	√	√
Other	Fairmont	5.0L	Other	PCM	√	√	√	√
Other	Fairmont	5.0L	Other	RCM	√	√	√	√
2011	Falcon	2.0L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2011	Falcon	2.0L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2011	Falcon	2.0L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2011	Falcon	2.0L	EcoBoost - Gas Turbocharged Direct	BEM	√	√	√	√
2011	Falcon	2.0L	EcoBoost - Gas Turbocharged Direct	BEM	√	√	√	√
2011	Falcon	2.0L	EcoBoost - Gas Turbocharged Direct	FDIM	√	√	√	√
2011	Falcon	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FDIM	√	√	√	√
2011	Falcon	2.0L	EcoBoost - Gas Turbocharged Direct	HIM	√	√	√	√
2011	Falcon	2.0L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2011	Falcon	2.0L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2011	Falcon	2.0L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2011	Falcon	2.0L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2011	Falcon	2.0L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2011	Falcon	2.0L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2011	Falcon	2.0L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√



2011	Falcon	2.0L	EcoBoost - Gas Turbocharged Direct	TCM	√	√	√	√
2011	Falcon	4.0L	DOHC VCT	ABS	√	√	√	√
2011	Falcon	4.0L	DOHC VCT	ABS	√	√	√	√
2011	Falcon	4.0L	DOHC VCT	ACM	√	√	√	√
2011	Falcon	4.0L	DOHC VCT	ACM	√	√	√	√
2011	Falcon	4.0L	DOHC VCT	BEM	√	√	√	√
2011	Falcon	4.0L	DOHC VCT	BEM	√	√	√	√
2011	Falcon	4.0L	DOHC VCT	FDIM	√	√	√	√
2011	Falcon	4.0L	DOHC VCT	FDIM	√	√	√	√
2011	Falcon	4.0L	DOHC VCT	HIM	√	√	√	√
2011	Falcon	4.0L	DOHC VCT	HIM	√	√	√	√
2011	Falcon	4.0L	DOHC VCT	IPC	√	√	√	√
2011	Falcon	4.0L	DOHC VCT	IPC	√	√	√	√
2011	Falcon	4.0L	DOHC VCT	PAM	√	√	√	√
2011	Falcon	4.0L	DOHC VCT	PAM	√	√	√	√
2011	Falcon	4.0L	DOHC VCT	PCM	√	√	√	√
2011	Falcon	4.0L	DOHC VCT	PCM	√	√	√	√
2011	Falcon	4.0L	DOHC VCT	RCM	√	√	√	√
2011	Falcon	4.0L	DOHC VCT	TCM	√	√	√	√
2011	Falcon	4.0L	DOHC_VCT_LPG	ABS	√	√	√	√
2011	Falcon	4.0L	DOHC_VCT_LPG	ACM	√	√	√	√
2011	Falcon	4.0L	DOHC_VCT_LPG	ACM	√	√	√	√
2011	Falcon	4.0L	DOHC_VCT_LPG	BEM	√	√	√	√
2011	Falcon	4.0L	DOHC_VCT_LPG	BEM	√	√	√	√
2011	Falcon	4.0L	DOHC_VCT_LPG	FDIM	√	√	√	√
2011	Falcon	4.0L	DOHC_VCT_LPG	FDIM	√	√	√	√
2011	Falcon	4.0L	DOHC_VCT_LPG	HIM	√	√	√	√
2011	Falcon	4.0L	DOHC_VCT_LPG	HIM	√	√	√	√
2011	Falcon	4.0L	DOHC_VCT_LPG	IPC	√	√	√	√
2011	Falcon	4.0L	DOHC_VCT_LPG	IPC	√	√	√	√
2011	Falcon	4.0L	DOHC_VCT_LPG	PAM	√	√	√	√
2011	Falcon	4.0L	DOHC_VCT_LPG	PAM	√	√	√	√
2011	Falcon	4.0L	DOHC_VCT_LPG	PCM	√	√	√	√
2011	Falcon	4.0L	DOHC_VCT_LPG	PCM	√	√	√	√
2011	Falcon	4.0L	DOHC_VCT_LPG	RCM	√	√	√	
2011	Falcon	4.0L	DOHC_VCT_LPG	RCM	√	√	√	√
2011	Falcon	4.0L	DOHC_VCT_LPG	TCM	√	√	√	
2011	Falcon	4.0L	DOHC_VCT_LPG	TCM	√	√	√	√
2011	Falcon	5.0L	4V	ABS	√	√	√	√
2011	Falcon	5.0L	4V	ACM	√	√	√	√
2011	Falcon	5.0L	4V	BEM	√	√	√	√
2011	Falcon	5.0L	4V	FDIM	√	√	√	√
2011	Falcon	5.0L	4V	HIM	√	√	√	√
2011	Falcon	5.0L	4V	IPC	√	√	√	√
2011	Falcon	5.0L	4V	PAM	√	√	√	√







2010	Falcon Forte S / Futura / XR / XT	5.0L	4V	IC	✓	✓	✓	✓
2010	Falcon Forte S / Futura / XR / XT	5.0L	4V	PAM	✓	✓	✓	✓
2010	Falcon Forte S / Futura / XR / XT	5.0L	4V	PCM	✓	✓	✓	✓
2010	Falcon Forte S / Futura / XR / XT	5.0L	4V	PCM	✓	✓	✓	✓
2010	Falcon Forte S / Futura / XR / XT	5.0L	4V	RCM	✓	✓	✓	✓
2010	Falcon Forte S / Futura / XR / XT	5.0L	4V	RCM	✓	✓	✓	✓
2010	Falcon Forte S / Futura / XR / XT	5.0L	4V	TCM	✓	✓	✓	✓
Other	Falcon Forte S / Futura / XR / XT	4.0L	Other	ABS	✓	✓	✓	✓
Other	Falcon Forte S / Futura / XR / XT	4.0L	Other	ABS/TCS	✓	✓	✓	✓
Other	Falcon Forte S / Futura / XR / XT	4.0L	Other	ACM	✓	✓	✓	✓
Other	Falcon Forte S / Futura / XR / XT	4.0L	Other	BEM	✓	✓	✓	✓
Other	Falcon Forte S / Futura / XR / XT	4.0L	Other	IAB	✓	✓	✓	✓
Other	Falcon Forte S / Futura / XR / XT	4.0L	Other	PCM	✓	✓	✓	✓
Other	Falcon Forte S / Futura / XR / XT	4.0L	Other	PCM	✓	✓	✓	✓
Other	Falcon Forte S / Futura / XR / XT	4.0L	Other	RCM	✓	✓	✓	✓
Other	Falcon Forte S / Futura / XR / XT	5.0L	Other	ABS	✓	✓	✓	✓
Other	Falcon Forte S / Futura / XR / XT	5.0L	Other	ABS/TCS	✓	✓	✓	✓
Other	Falcon Forte S / Futura / XR / XT	5.0L	Other	ACM	✓	✓	✓	✓
Other	Falcon Forte S / Futura / XR / XT	5.0L	Other	BEM	✓	✓	✓	✓
Other	Falcon Forte S / Futura / XR / XT	5.0L	Other	IAB	✓	✓	✓	✓
Other	Falcon Forte S / Futura / XR / XT	5.0L	Other	IC	✓	✓	✓	✓
Other	Falcon Forte S / Futura / XR / XT	5.0L	Other	PCM	✓	✓	✓	✓
Other	Falcon Forte S / Futura / XR / XT	5.0L	Other	RCM	✓	✓	✓	✓
Other	Festiva	1.5L	Other	PCM	✓	✓	✓	✓
Other	Festiva Sedan	1.5L	Other	PCM	✓	✓	✓	✓
2002	Fiesta	1.25L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓
2002	Fiesta	1.25L	DURATEC 16V	GEM	✓	✓	✓	✓
2002	Fiesta	1.25L	DURATEC 16V	IC	✓	✓	✓	✓
2002	Fiesta	1.25L	DURATEC 16V	PCM	✓	✓	✓	✓
2002	Fiesta	1.25L	DURATEC 16V	RCM	✓	✓	✓	✓
2002	Fiesta	1.3L	DURATEC 8V	ABS/TCS	✓	✓	✓	✓
2002	Fiesta	1.3L	DURATEC 8V	GEM	✓	✓	✓	✓
2002	Fiesta	1.3L	DURATEC 8V	IC	✓	✓	✓	✓
2002	Fiesta	1.3L	DURATEC 8V	PCM	✓	✓	✓	✓
2002	Fiesta	1.3L	DURATEC 8V	RCM	✓	✓	✓	✓
2002	Fiesta	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓
2002	Fiesta	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓
2002	Fiesta	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓
2002	Fiesta	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓
2002	Fiesta	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓
2002	Fiesta	1.4L	DURATEC 16V	IC	✓	✓	✓	✓
2002	Fiesta	1.4L	DURATEC 16V	IC	✓	✓	✓	✓
2002	Fiesta	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓
2002	Fiesta	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓
2002	Fiesta	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓

2002	Fiesta	1.4L	DURATEC 16V	TCM	√	√	√	√
2002	Fiesta	1.4L	DURATEC 16V	TCM	√	√	√	√
2002	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	ABS/TCS	√	√	√	√
2002	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	ABS/TCS	√	√	√	√
2002	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	GEM	√	√	√	√
2002	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	IC	√	√	√	√
2002	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2002	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2002	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	TCM	√	√	√	√
2002	Fiesta	1.6L	DURATEC 16V	ABS/TCS	√	√	√	√
2002	Fiesta	1.6L	DURATEC 16V	ABS/TCS	√	√	√	√
2002	Fiesta	1.6L	DURATEC 16V	GEM	√	√	√	√
2002	Fiesta	1.6L	DURATEC 16V	IC	√	√	√	√
2002	Fiesta	1.6L	DURATEC 16V	PCM	√	√	√	√
2002	Fiesta	1.6L	DURATEC 16V	PCM	√	√	√	√
2002	Fiesta	1.6L	DURATEC 16V	RCM	√	√	√	√
2002	Fiesta	1.6L	DURATEC 16V	TCM	√	√	√	√
2002	Fiesta	1.6L	DURATEC 16V	TCM	√	√	√	√
2002	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	ABS/TCS	√	√	√	√
2002	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	EPS	√	√	√	√
2002	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	GEM	√	√	√	√
2002	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	IC	√	√	√	√
2002	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2002	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2006	Fiesta	1.25L	DURATEC 16V	ABS/TCS	√	√	√	√
2006	Fiesta	1.25L	DURATEC 16V	ACM	√	√	√	√
2006	Fiesta	1.25L	DURATEC 16V	EATC	√	√	√	√
2006	Fiesta	1.25L	DURATEC 16V	GEM	√	√	√	√
2006	Fiesta	1.25L	DURATEC 16V	IC	√	√	√	√
2006	Fiesta	1.25L	DURATEC 16V	PCM	√	√	√	√
2006	Fiesta	1.25L	DURATEC 16V	RCM	√	√	√	√
2006	Fiesta	1.25L	DURATEC 16V	SRM	√	√	√	√
2006	Fiesta	1.3L	DURATEC 8V	ABS/TCS	√	√	√	√
2006	Fiesta	1.3L	DURATEC 8V	ACM	√	√	√	√
2006	Fiesta	1.3L	DURATEC 8V	EATC	√	√	√	√
2006	Fiesta	1.3L	DURATEC 8V	GEM	√	√	√	√
2006	Fiesta	1.3L	DURATEC 8V	IC	√	√	√	√
2006	Fiesta	1.3L	DURATEC 8V	PCM	√	√	√	√
2006	Fiesta	1.3L	DURATEC 8V	RCM	√	√	√	√
2006	Fiesta	1.3L	DURATEC 8V	SRM	√	√	√	√
2006	Fiesta	1.4L	DURATEC 16V	ACM	√	√	√	√
2006	Fiesta	1.4L	DURATEC 16V	EATC	√	√	√	√
2006	Fiesta	1.4L	DURATEC 16V	GEM	√	√	√	√
2006	Fiesta	1.4L	DURATEC 16V	IC	√	√	√	√
2006	Fiesta	1.4L	DURATEC 16V	PCM	√	√	√	√

2006	Fiesta	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓
2006	Fiesta	1.4L	DURATEC 16V	SRM	✓	✓	✓	✓
2006	Fiesta	1.4L	DURATEC 16V	TCM	✓	✓	✓	✓
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	ABS/TCS	✓	✓	✓	✓
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	ACM	✓	✓	✓	✓
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	EATC	✓	✓	✓	✓
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	GEM	✓	✓	✓	✓
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	GEM	✓	✓	✓	✓
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	IC	✓	✓	✓	✓
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	IC	✓	✓	✓	✓
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	PCM	✓	✓	✓	✓
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	RCM	✓	✓	✓	✓
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	SRM	✓	✓	✓	✓
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	TCM	✓	✓	✓	✓
2006	Fiesta	1.6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓
2006	Fiesta	1.6L	DURATEC 16V	ACM	✓	✓	✓	✓
2006	Fiesta	1.6L	DURATEC 16V	EATC	✓	✓	✓	✓
2006	Fiesta	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓
2006	Fiesta	1.6L	DURATEC 16V	IC	✓	✓	✓	✓
2006	Fiesta	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓
2006	Fiesta	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓
2006	Fiesta	1.6L	DURATEC 16V	SRM	✓	✓	✓	✓
2006	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	ABS/TCS	✓	✓	✓	✓
2006	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	ACM	✓	✓	✓	✓
2006	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	EATC	✓	✓	✓	✓
2006	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	EPS	✓	✓	✓	✓
2006	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	GEM	✓	✓	✓	✓
2006	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	IC	✓	✓	✓	✓
2006	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	PCM	✓	✓	✓	✓
2006	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	RCM	✓	✓	✓	✓
2006	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	SRM	✓	✓	✓	✓
2008.75	Fiesta	1.25L	DURATEC 16V	ABS	✓	✓	✓	✓
2008.75	Fiesta	1.25L	DURATEC 16V	ACM	✓	✓	✓	✓
2008.75	Fiesta	1.25L	DURATEC 16V	BCMii	✓	✓	✓	✓
2008.75	Fiesta	1.25L	DURATEC 16V	FCDIM	✓	✓	✓	✓
2008.75	Fiesta	1.25L	DURATEC 16V	HVAC	✓	✓	✓	✓
2008.75	Fiesta	1.25L	DURATEC 16V	IPC	✓	✓	✓	✓
2008.75	Fiesta	1.25L	DURATEC 16V	PCM	✓	✓	✓	✓
2008.75	Fiesta	1.25L	DURATEC 16V	PSCM	✓	✓	✓	✓
2008.75	Fiesta	1.25L	DURATEC 16V	RCM	✓	✓	✓	✓
2008.75	Fiesta	1.25L	DURATEC 16V	RFA	✓	✓	✓	✓
2008.75	Fiesta	1.25L	DURATEC 16V	SRM	✓	✓	✓	✓
2008.75	Fiesta	1.3L	BZ	ABS	✓	✓	✓	✓
2008.75	Fiesta	1.3L	BZ	ACM	✓	✓	✓	✓
2008.75	Fiesta	1.3L	BZ	BCMii	✓	✓	✓	✓

2008.75	Fiesta	1.3L	BZ	FCDIM	√	√	√	√
2008.75	Fiesta	1.3L	BZ	HVAC	√	√	√	√
2008.75	Fiesta	1.3L	BZ	IPC	√	√	√	√
2008.75	Fiesta	1.3L	BZ	PCM	√	√	√	√
2008.75	Fiesta	1.3L	BZ	PSCM	√	√	√	√
2008.75	Fiesta	1.3L	BZ	RCM	√	√	√	√
2008.75	Fiesta	1.3L	BZ	RFA	√	√	√	√
2008.75	Fiesta	1.3L	BZ	SRM	√	√	√	√
2008.75	Fiesta	1.4L	DURATEC 16V	ABS	√	√	√	√
2008.75	Fiesta	1.4L	DURATEC 16V	ACM	√	√	√	√
2008.75	Fiesta	1.4L	DURATEC 16V	BCMii	√	√	√	√
2008.75	Fiesta	1.4L	DURATEC 16V	FCDIM	√	√	√	√
2008.75	Fiesta	1.4L	DURATEC 16V	HVAC	√	√	√	√
2008.75	Fiesta	1.4L	DURATEC 16V	IPC	√	√	√	√
2008.75	Fiesta	1.4L	DURATEC 16V	PCM	√	√	√	√
2008.75	Fiesta	1.4L	DURATEC 16V	PSCM	√	√	√	√
2008.75	Fiesta	1.4L	DURATEC 16V	RCM	√	√	√	√
2008.75	Fiesta	1.4L	DURATEC 16V	RFA	√	√	√	√
2008.75	Fiesta	1.4L	DURATEC 16V	SRM	√	√	√	√
2008.75	Fiesta	1.4L	DURATEC 16V	TCM	√	√	√	√
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	BCMii	√	√	√	√
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	FCDIM	√	√	√	√
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	HVAC	√	√	√	√
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	IPC	√	√	√	√
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	PSCM	√	√	√	√
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	RFA	√	√	√	√
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	√
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	BCMii	√	√	√	√
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	FCDIM	√	√	√	√
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	HVAC	√	√	√	√
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	IPC	√	√	√	√
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	IPC	√	√	√	√
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	PSCM	√	√	√	√
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	PSCM	√	√	√	√
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√



2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	RFA	√	√	√	√
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	√
2008.75	Fiesta	1.5L	BZ	ABS	√	√	√	√
2008.75	Fiesta	1.5L	BZ	ACM	√	√	√	√
2008.75	Fiesta	1.5L	BZ	BCMii	√	√	√	√
2008.75	Fiesta	1.5L	BZ	FCDIM	√	√	√	√
2008.75	Fiesta	1.5L	BZ	HVAC	√	√	√	
2008.75	Fiesta	1.5L	BZ	HVAC	√	√	√	√
2008.75	Fiesta	1.5L	BZ	IPC	√	√	√	√
2008.75	Fiesta	1.5L	BZ	PCM	√	√	√	√
2008.75	Fiesta	1.5L	BZ	PSCM	√	√	√	√
2008.75	Fiesta	1.5L	BZ	RCM	√	√	√	√
2008.75	Fiesta	1.5L	BZ	RFA	√	√	√	√
2008.75	Fiesta	1.5L	BZ	SRM	√	√	√	√
2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail	BCMii	√	√	√	√
2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail	FCDIM	√	√	√	√
2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail	HVAC	√	√	√	√
2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail	IPC	√	√	√	√
2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail	PSCM	√	√	√	√
2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail	RFA	√	√	√	√
2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	√
2008.75	Fiesta	1.5L	TiVCT	ABS	√	√	√	√
2008.75	Fiesta	1.5L	TiVCT	ABS	√	√	√	√
2008.75	Fiesta	1.5L	TiVCT	ACM	√	√	√	√
2008.75	Fiesta	1.5L	TiVCT	BCMii	√	√	√	√
2008.75	Fiesta	1.5L	TiVCT	FCDIM	√	√	√	√
2008.75	Fiesta	1.5L	TiVCT	FCDIM	√	√	√	√
2008.75	Fiesta	1.5L	TiVCT	HVAC	√	√	√	
2008.75	Fiesta	1.5L	TiVCT	HVAC	√	√	√	√
2008.75	Fiesta	1.5L	TiVCT	IPC	√	√	√	√
2008.75	Fiesta	1.5L	TiVCT	PCM	√	√	√	√
2008.75	Fiesta	1.5L	TiVCT	PSCM	√	√	√	√
2008.75	Fiesta	1.5L	TiVCT	PSCM	√	√	√	√
2008.75	Fiesta	1.5L	TiVCT	RCM	√	√	√	√
2008.75	Fiesta	1.5L	TiVCT	RCM	√	√	√	√
2008.75	Fiesta	1.5L	TiVCT	RFA	√	√	√	√
2008.75	Fiesta	1.5L	TiVCT	SRM	√	√	√	√
2008.75	Fiesta	1.5L	TiVCT	TCM	√	√	√	√
2008.75	Fiesta	1.5L	TiVCT	TCM	√	√	√	√
2008.75	Fiesta	1.5L	TiVCT	TCM	√	√	√	√
2008.75	Fiesta	1.6L	DURATEC VCT	ABS	√	√	√	√
2008.75	Fiesta	1.6L	DURATEC VCT	ACM	√	√	√	√

2008.75	Fiesta	1.6L	DURATEC VCT	BCMii	√	√	√	√
2008.75	Fiesta	1.6L	DURATEC VCT	FCDIM	√	√	√	√
2008.75	Fiesta	1.6L	DURATEC VCT	HVAC	√	√	√	√
2008.75	Fiesta	1.6L	DURATEC VCT	IPC	√	√	√	√
2008.75	Fiesta	1.6L	DURATEC VCT	PCM	√	√	√	√
2008.75	Fiesta	1.6L	DURATEC VCT	PSCM	√	√	√	√
2008.75	Fiesta	1.6L	DURATEC VCT	RCM	√	√	√	√
2008.75	Fiesta	1.6L	DURATEC VCT	RFA	√	√	√	√
2008.75	Fiesta	1.6L	DURATEC VCT	SRM	√	√	√	√
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	BCMii	√	√	√	√
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	FCDIM	√	√	√	√
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	HVAC	√	√	√	√
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	IPC	√	√	√	√
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	PSCM	√	√	√	√
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	RFA	√	√	√	√
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	√
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	BCMii	√	√	√	√
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	FCDIM	√	√	√	√
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	IPC	√	√	√	√
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	PSCM	√	√	√	√
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	RFA	√	√	√	√
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	√
2008.75	Fiesta	1.6L	TDCi ECO II	ABS	√	√	√	√
2008.75	Fiesta	1.6L	TDCi ECO II	ACM	√	√	√	√
2008.75	Fiesta	1.6L	TDCi ECO II	BCMii	√	√	√	√
2008.75	Fiesta	1.6L	TDCi ECO II	FCDIM	√	√	√	√
2008.75	Fiesta	1.6L	TDCi ECO II	HVAC	√	√	√	√
2008.75	Fiesta	1.6L	TDCi ECO II	IPC	√	√	√	√
2008.75	Fiesta	1.6L	TDCi ECO II	PCM	√	√	√	√
2008.75	Fiesta	1.6L	TDCi ECO II	PSCM	√	√	√	√
2008.75	Fiesta	1.6L	TDCi ECO II	RCM	√	√	√	√
2008.75	Fiesta	1.6L	TDCi ECO II	RFA	√	√	√	√
2008.75	Fiesta	1.6L	TDCi ECO II	SRM	√	√	√	√
2008.75	Fiesta	1.6L	TiVCT	ABS	√	√	√	√
2008.75	Fiesta	1.6L	TiVCT	ABS	√	√	√	√
2008.75	Fiesta	1.6L	TiVCT	ACM	√	√	√	√

2008.75	Fiesta	1.6L	TiVCT	BCMii	√	√	√	√
2008.75	Fiesta	1.6L	TiVCT	FCDIM	√	√	√	√
2008.75	Fiesta	1.6L	TiVCT	FCDIM	√	√	√	√
2008.75	Fiesta	1.6L	TiVCT	HVAC	√	√	√	√
2008.75	Fiesta	1.6L	TiVCT	IPC	√	√	√	√
2008.75	Fiesta	1.6L	TiVCT	PCM	√	√	√	√
2008.75	Fiesta	1.6L	TiVCT	PSCM	√	√	√	√
2008.75	Fiesta	1.6L	TiVCT	PSCM	√	√	√	√
2008.75	Fiesta	1.6L	TiVCT	RCM	√	√	√	√
2008.75	Fiesta	1.6L	TiVCT	RCM	√	√	√	√
2008.75	Fiesta	1.6L	TiVCT	RFA	√	√	√	√
2008.75	Fiesta	1.6L	TiVCT	SRM	√	√	√	√
2008.75	Fiesta	1.6L	TiVCT	TCM	√	√	√	√
2008.75	Fiesta	1.6L	TiVCT	TCM	√	√	√	√
2011	Fiesta	1.6L	Sigma	ABS	√	√	√	√
2011	Fiesta	1.6L	Sigma	ACM	√	√	√	√
2011	Fiesta	1.6L	Sigma	APIM	√	√	√	√
2011	Fiesta	1.6L	Sigma	BCM#1	√	√	√	√
2011	Fiesta	1.6L	Sigma	FCDIM	√	√	√	√
2011	Fiesta	1.6L	Sigma	GPSM	√	√	√	√
2011	Fiesta	1.6L	Sigma	IPC	√	√	√	√
2011	Fiesta	1.6L	Sigma	OCSM	√	√	√	√
2011	Fiesta	1.6L	Sigma	PCM	√	√	√	√
2011	Fiesta	1.6L	Sigma	PSCM	√	√	√	√
2011	Fiesta	1.6L	Sigma	RCM	√	√	√	√
2011	Fiesta	1.6L	Sigma	RCM	√	√	√	√
2011	Fiesta	1.6L	Sigma	RFA	√	√	√	√
2011	Fiesta	1.6L	Sigma	TBM	√	√	√	√
2011	Fiesta	1.6L	Sigma	TCM	√	√	√	√
2011	Fiesta	1.6L	Sigma	VSM	√	√	√	√
2011	Fiesta	1.6L	TiVCT	ABS	√	√	√	√
2011	Fiesta	1.6L	TiVCT	ABS	√	√	√	√
2011	Fiesta	1.6L	TiVCT	ACM	√	√	√	√
2011	Fiesta	1.6L	TiVCT	APIM	√	√	√	√
2011	Fiesta	1.6L	TiVCT	BCM#1	√	√	√	√
2011	Fiesta	1.6L	TiVCT	FCDIM	√	√	√	√
2011	Fiesta	1.6L	TiVCT	GPSM	√	√	√	√
2011	Fiesta	1.6L	TiVCT	IPC	√	√	√	√
2011	Fiesta	1.6L	TiVCT	OCSM	√	√	√	√
2011	Fiesta	1.6L	TiVCT	OCSM	√	√	√	√
2011	Fiesta	1.6L	TiVCT	PCM	√	√	√	√
2011	Fiesta	1.6L	TiVCT	PSCM	√	√	√	√
2011	Fiesta	1.6L	TiVCT	PSCM	√	√	√	√
2011	Fiesta	1.6L	TiVCT	RCM	√	√	√	√
2011	Fiesta	1.6L	TiVCT	RCM	√	√	√	√

2011	Fiesta	1.6L	TiVCT	RFA	√	√	√	√
2011	Fiesta	1.6L	TiVCT	TCM	√	√	√	√
2011	Fiesta	1.6L	TiVCT	TCM	√	√	√	√
2011	Fiesta	1.6L	TiVCT	VSM	√	√	√	√
2011	Fiesta	1.6L	TiVCT	VSM	√	√	√	√
2012	Fiesta	1.6L	Sigma	ABS	√	√	√	√
2012	Fiesta	1.6L	Sigma	ACM	√	√	√	√
2012	Fiesta	1.6L	Sigma	APIM	√	√	√	√
2012	Fiesta	1.6L	Sigma	BCM#1	√	√	√	√
2012	Fiesta	1.6L	Sigma	FCDIM	√	√	√	√
2012	Fiesta	1.6L	Sigma	GPSM	√	√	√	√
2012	Fiesta	1.6L	Sigma	IPC	√	√	√	√
2012	Fiesta	1.6L	Sigma	OCSM	√	√	√	√
2012	Fiesta	1.6L	Sigma	PCM	√	√	√	√
2012	Fiesta	1.6L	Sigma	PSCM	√	√	√	√
2012	Fiesta	1.6L	Sigma	RCM	√	√	√	√
2012	Fiesta	1.6L	Sigma	RFA	√	√	√	√
2012	Fiesta	1.6L	Sigma	TBM	√	√	√	√
2012	Fiesta	1.6L	Sigma	TCM	√	√	√	√
2012	Fiesta	1.6L	Sigma	VSM	√	√	√	√
2012	Fiesta	1.6L	TiVCT	ABS	√	√	√	√
2012	Fiesta	1.6L	TiVCT	ABS	√	√	√	√
2012	Fiesta	1.6L	TiVCT	ACM	√	√	√	√
2012	Fiesta	1.6L	TiVCT	APIM	√	√	√	√
2012	Fiesta	1.6L	TiVCT	BCM#1	√	√	√	√
2012	Fiesta	1.6L	TiVCT	FCDIM	√	√	√	√
2012	Fiesta	1.6L	TiVCT	GPSM	√	√	√	√
2012	Fiesta	1.6L	TiVCT	IPC	√	√	√	√
2012	Fiesta	1.6L	TiVCT	OCSM	√	√	√	√
2012	Fiesta	1.6L	TiVCT	OCSM	√	√	√	√
2012	Fiesta	1.6L	TiVCT	PCM	√	√	√	√
2012	Fiesta	1.6L	TiVCT	PCM	√	√	√	√
2012	Fiesta	1.6L	TiVCT	PSCM	√	√	√	√
2012	Fiesta	1.6L	TiVCT	PSCM	√	√	√	√
2012	Fiesta	1.6L	TiVCT	RCM	√	√	√	√
2012	Fiesta	1.6L	TiVCT	RCM	√	√	√	√
2012	Fiesta	1.6L	TiVCT	RFA	√	√	√	√
2012	Fiesta	1.6L	TiVCT	TCM	√	√	√	√
2012	Fiesta	1.6L	TiVCT	TCM	√	√	√	√
2012	Fiesta	1.6L	TiVCT	VSM	√	√	√	√
2013	Fiesta	1.6L	TiVCT	ABS	√	√	√	√
2013	Fiesta	1.6L	TiVCT	ABS	√	√	√	√
2013	Fiesta	1.6L	TiVCT	ABS	√	√	√	√
2013	Fiesta	1.6L	TiVCT	ACM	√	√	√	√
2013	Fiesta	1.6L	TiVCT	APIM	√	√	√	√

2013	Fiesta	1.6L	TiVCT	BCM#1	✓	✓	✓	✓
2013	Fiesta	1.6L	TiVCT	FCDIM	✓	✓	✓	✓
2013	Fiesta	1.6L	TiVCT	GPSM	✓	✓	✓	✓
2013	Fiesta	1.6L	TiVCT	IPC	✓	✓	✓	✓
2013	Fiesta	1.6L	TiVCT	OCSM	✓	✓	✓	✓
2013	Fiesta	1.6L	TiVCT	OCSM	✓	✓	✓	✓
2013	Fiesta	1.6L	TiVCT	PCM	✓	✓	✓	✓
2013	Fiesta	1.6L	TiVCT	PCM	✓	✓	✓	✓
2013	Fiesta	1.6L	TiVCT	PSCM	✓	✓	✓	✓
2013	Fiesta	1.6L	TiVCT	PSCM	✓	✓	✓	✓
2013	Fiesta	1.6L	TiVCT	RCM	✓	✓	✓	✓
2013	Fiesta	1.6L	TiVCT	RFA	✓	✓	✓	✓
2013	Fiesta	1.6L	TiVCT	TCM	✓	✓	✓	✓
2013	Fiesta	1.6L	TiVCT	TCM	✓	✓	✓	✓
2013	Fiesta	1.6L	TiVCT	VSM	✓	✓	✓	✓
2013	Fiesta	1.6L	TiVCT	VSM	✓	✓	✓	✓
2013.25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓
2013.25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct	ACM	✓	✓	✓	✓
2013.25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct	APIM	✓	✓	✓	✓
2013.25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct	BCMii	✓	✓	✓	✓
2013.25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct	DDM	✓	✓	✓	✓
2013.25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct	FCDIM	✓	✓	✓	✓
2013.25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct	FDSM	✓	✓	✓	✓
2013.25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct	GPSM	✓	✓	✓	✓
2013.25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓
2013.25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2013.25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct	PDM	✓	✓	✓	✓
2013.25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct	PSCM	✓	✓	✓	✓
2013.25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct	RCM	✓	✓	✓	✓
2013.25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct	RFA	✓	✓	✓	✓
2013.25	Fiesta	1.0L	GTDI FGEC	ABS	✓	✓	✓	
2013.25	Fiesta	1.0L	GTDI FGEC	ACM	✓	✓	✓	
2013.25	Fiesta	1.0L	GTDI FGEC	APIM	✓	✓	✓	
2013.25	Fiesta	1.0L	GTDI FGEC	BCMii	✓	✓	✓	✓
2013.25	Fiesta	1.0L	GTDI FGEC	DDM	✓	✓	✓	✓
2013.25	Fiesta	1.0L	GTDI FGEC	FCDIM	✓	✓	✓	✓
2013.25	Fiesta	1.0L	GTDI FGEC	FDSM	✓	✓	✓	✓
2013.25	Fiesta	1.0L	GTDI FGEC	GPSM	✓	✓	✓	✓
2013.25	Fiesta	1.0L	GTDI FGEC	HVAC	✓	✓	✓	✓
2013.25	Fiesta	1.0L	GTDI FGEC	IPC	✓	✓	✓	✓
2013.25	Fiesta	1.0L	GTDI FGEC	PCM	✓	✓	✓	✓
2013.25	Fiesta	1.0L	GTDI FGEC	PDM	✓	✓	✓	✓
2013.25	Fiesta	1.0L	GTDI FGEC	PSCM	✓	✓	✓	✓

2013.25	Fiesta	1.0L	GTDI FGEC	RCM	√	√	√	√
2013.25	Fiesta	1.0L	GTDI FGEC	RFA	√	√	√	√
2013.25	Fiesta	1.0L	GTDI FGEC	TCM	√	√	√	√
2013.25	Fiesta	1.0L	Gasoline_Direct_injecti on	ABS	√	√	√	√
2013.25	Fiesta	1.0L	Gasoline_Direct_injecti on	ACM	√	√	√	√
2013.25	Fiesta	1.0L	Gasoline_Direct_injecti on	APIM	√	√	√	√
2013.25	Fiesta	1.0L	Gasoline_Direct_injecti on	BCMii	√	√	√	√
2013.25	Fiesta	1.0L	Gasoline_Direct_injecti on	DDM	√	√	√	√
2013.25	Fiesta	1.0L	Gasoline_Direct_injecti on	FCDIM	√	√	√	√
2013.25	Fiesta	1.0L	Gasoline_Direct_injecti on	FDSM	√	√	√	√
2013.25	Fiesta	1.0L	Gasoline_Direct_injecti on	GPSM	√	√	√	√
2013.25	Fiesta	1.0L	Gasoline_Direct_injecti on	HVAC	√	√	√	√
2013.25	Fiesta	1.0L	Gasoline_Direct_injecti on	IPC	√	√	√	√
2013.25	Fiesta	1.0L	Gasoline_Direct_injecti on	PCM	√	√	√	√
2013.25	Fiesta	1.0L	Gasoline_Direct_injecti on	PDM	√	√	√	√
2013.25	Fiesta	1.0L	Gasoline_Direct_injecti on	PSCM	√	√	√	√
2013.25	Fiesta	1.0L	Gasoline_Direct_injecti on	RCM	√	√	√	√
2013.25	Fiesta	1.0L	Gasoline_Direct_injecti on	RFA	√	√	√	√
2013.25	Fiesta	1.25L	DURATEC 16V	ABS	√	√	√	√
2013.25	Fiesta	1.25L	DURATEC 16V	ACM	√	√	√	√
2013.25	Fiesta	1.25L	DURATEC 16V	APIM	√	√	√	√
2013.25	Fiesta	1.25L	DURATEC 16V	BCMii	√	√	√	√
2013.25	Fiesta	1.25L	DURATEC 16V	DDM	√	√	√	√
2013.25	Fiesta	1.25L	DURATEC 16V	FCDIM	√	√	√	√
2013.25	Fiesta	1.25L	DURATEC 16V	FDSM	√	√	√	√
2013.25	Fiesta	1.25L	DURATEC 16V	GPSM	√	√	√	√
2013.25	Fiesta	1.25L	DURATEC 16V	HVAC	√	√	√	√
2013.25	Fiesta	1.25L	DURATEC 16V	IPC	√	√	√	√
2013.25	Fiesta	1.25L	DURATEC 16V	PCM	√	√	√	√
2013.25	Fiesta	1.25L	DURATEC 16V	PDM	√	√	√	√
2013.25	Fiesta	1.25L	DURATEC 16V	PSCM	√	√	√	√
2013.25	Fiesta	1.25L	DURATEC 16V	RCM	√	√	√	√
2013.25	Fiesta	1.25L	DURATEC 16V	RFA	√	√	√	√
2013.25	Fiesta	1.4L	DURATEC 16V	ABS	√	√	√	√
2013.25	Fiesta	1.4L	DURATEC 16V	ACM	√	√	√	√
2013.25	Fiesta	1.4L	DURATEC 16V	APIM	√	√	√	√
2013.25	Fiesta	1.4L	DURATEC 16V	BCMii	√	√	√	√
2013.25	Fiesta	1.4L	DURATEC 16V	DDM	√	√	√	√
2013.25	Fiesta	1.4L	DURATEC 16V	FCDIM	√	√	√	√
2013.25	Fiesta	1.4L	DURATEC 16V	FDSM	√	√	√	√
2013.25	Fiesta	1.4L	DURATEC 16V	HVAC	√	√	√	√
2013.25	Fiesta	1.4L	DURATEC 16V	IPC	√	√	√	√
2013.25	Fiesta	1.4L	DURATEC 16V	PCM	√	√	√	√
2013.25	Fiesta	1.4L	DURATEC 16V	PDM	√	√	√	√
2013.25	Fiesta	1.4L	DURATEC 16V	PSCM	√	√	√	√

2013.25	Fiesta	1.4L	DURATEC 16V	RCM	√	√	√	√
2013.25	Fiesta	1.4L	DURATEC 16V	RFA	√	√	√	√
2013.25	Fiesta	1.5L	DURATEC 16V	ABS	√	√	√	√
2013.25	Fiesta	1.5L	DURATEC 16V	ACM	√	√	√	√
2013.25	Fiesta	1.5L	DURATEC 16V	APIM	√	√	√	√
2013.25	Fiesta	1.5L	DURATEC 16V	BCMii	√	√	√	√
2013.25	Fiesta	1.5L	DURATEC 16V	DDM	√	√	√	√
2013.25	Fiesta	1.5L	DURATEC 16V	FCDIM	√	√	√	√
2013.25	Fiesta	1.5L	DURATEC 16V	FDSM	√	√	√	√
2013.25	Fiesta	1.5L	DURATEC 16V	GPSM	√	√	√	√
2013.25	Fiesta	1.5L	DURATEC 16V	HVAC	√	√	√	√
2013.25	Fiesta	1.5L	DURATEC 16V	IPC	√	√	√	√
2013.25	Fiesta	1.5L	DURATEC 16V	PCM	√	√	√	√
2013.25	Fiesta	1.5L	DURATEC 16V	PDM	√	√	√	√
2013.25	Fiesta	1.5L	DURATEC 16V	PSCM	√	√	√	√
2013.25	Fiesta	1.5L	DURATEC 16V	RCM	√	√	√	√
2013.25	Fiesta	1.5L	DURATEC 16V	RFA	√	√	√	√
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail	APIM	√	√	√	√
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail	BCMii	√	√	√	√
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail	DDM	√	√	√	√
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	FCDIM	√	√	√	√
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail	FCDIM	√	√	√	√
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail	FDSM	√	√	√	√
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail	GPSM	√	√	√	√
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail	HVAC	√	√	√	√
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail	IPC	√	√	√	√
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	PDM	√	√	√	√
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail	PSCM	√	√	√	√
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail	RFA	√	√	√	√
2013.25	Fiesta	1.5L	TiVCT	ABS	√	√	√	√
2013.25	Fiesta	1.5L	TiVCT	ACM	√	√	√	√
2013.25	Fiesta	1.5L	TiVCT	APIM	√	√	√	√
2013.25	Fiesta	1.5L	TiVCT	BCMii	√	√	√	√
2013.25	Fiesta	1.5L	TiVCT	DDM	√	√	√	√
2013.25	Fiesta	1.5L	TiVCT	FCDIM	√	√	√	√
2013.25	Fiesta	1.5L	TiVCT	FDSM	√	√	√	√
2013.25	Fiesta	1.5L	TiVCT	GPSM	√	√	√	√
2013.25	Fiesta	1.5L	TiVCT	HVAC	√	√	√	√

2013.25	Fiesta	1.5L	TiVCT	IPC	√	√	√	√
2013.25	Fiesta	1.5L	TiVCT	PCM	√	√	√	√
2013.25	Fiesta	1.5L	TiVCT	PDM	√	√	√	√
2013.25	Fiesta	1.5L	TiVCT	PSCM	√	√	√	√
2013.25	Fiesta	1.5L	TiVCT	RCM	√	√	√	√
2013.25	Fiesta	1.5L	TiVCT	TCM	√	√	√	√
2013.25	Fiesta	1.5L	Zetec-SE	ABS	√	√	√	√
2013.25	Fiesta	1.5L	Zetec-SE	ACM	√	√	√	√
2013.25	Fiesta	1.5L	Zetec-SE	APIM	√	√	√	√
2013.25	Fiesta	1.5L	Zetec-SE	BCMii	√	√	√	√
2013.25	Fiesta	1.5L	Zetec-SE	DDM	√	√	√	√
2013.25	Fiesta	1.5L	Zetec-SE	FCDIM	√	√	√	√
2013.25	Fiesta	1.5L	Zetec-SE	FDSM	√	√	√	√
2013.25	Fiesta	1.5L	Zetec-SE	GPSM	√	√	√	√
2013.25	Fiesta	1.5L	Zetec-SE	HVAC	√	√	√	√
2013.25	Fiesta	1.5L	Zetec-SE	IPC	√	√	√	√
2013.25	Fiesta	1.5L	Zetec-SE	PCM	√	√	√	√
2013.25	Fiesta	1.5L	Zetec-SE	PDM	√	√	√	√
2013.25	Fiesta	1.5L	Zetec-SE	PSCM	√	√	√	√
2013.25	Fiesta	1.5L	Zetec-SE	RCM	√	√	√	√
2013.25	Fiesta	1.5L	Zetec-SE	RFA	√	√	√	√
2013.25	Fiesta	1.6L	DURATEC VCT	ABS	√	√	√	√
2013.25	Fiesta	1.6L	DURATEC VCT	ACM	√	√	√	√
2013.25	Fiesta	1.6L	DURATEC VCT	APIM	√	√	√	√
2013.25	Fiesta	1.6L	DURATEC VCT	BCMii	√	√	√	√
2013.25	Fiesta	1.6L	DURATEC VCT	DDM	√	√	√	√
2013.25	Fiesta	1.6L	DURATEC VCT	FCDIM	√	√	√	√
2013.25	Fiesta	1.6L	DURATEC VCT	FDSM	√	√	√	√
2013.25	Fiesta	1.6L	DURATEC VCT	GPSM	√	√	√	√
2013.25	Fiesta	1.6L	DURATEC VCT	HVAC	√	√	√	√
2013.25	Fiesta	1.6L	DURATEC VCT	IPC	√	√	√	√
2013.25	Fiesta	1.6L	DURATEC VCT	PCM	√	√	√	√
2013.25	Fiesta	1.6L	DURATEC VCT	PDM	√	√	√	√
2013.25	Fiesta	1.6L	DURATEC VCT	PSCM	√	√	√	√
2013.25	Fiesta	1.6L	DURATEC VCT	RCM	√	√	√	√
2013.25	Fiesta	1.6L	DURATEC VCT	RFA	√	√	√	√
2013.25	Fiesta	1.6L	DURATEC VCT	TCM	√	√	√	√
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	APIM	√	√	√	√
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	BCMii	√	√	√	√
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	DDM	√	√	√	√
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	FCDIM	√	√	√	√
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	FCDIM	√	√	√	√
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	FDSM	√	√	√	√



2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	GPSM	√	√	√	√
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	HVAC	√	√	√	√
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	IPC	√	√	√	√
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	PDM	√	√	√	√
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	PSCM	√	√	√	√
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail	RFA	√	√	√	√
2013.25	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS	√	√	√	√
2013.25	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2013.25	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct	BCMii	√	√	√	√
2013.25	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	√
2013.25	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct	FCDIM	√	√	√	√
2013.25	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct	FDSM	√	√	√	√
2013.25	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	√
2013.25	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	√
2013.25	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2013.25	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2013.25	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct	PDM	√	√	√	√
2013.25	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2013.25	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2013.25	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	√
2013.25	Fiesta	1.6L	TDCi ECO II	ABS	√	√	√	√
2013.25	Fiesta	1.6L	TDCi ECO II	ACM	√	√	√	√
2013.25	Fiesta	1.6L	TDCi ECO II	APIM	√	√	√	√
2013.25	Fiesta	1.6L	TDCi ECO II	BCMii	√	√	√	√
2013.25	Fiesta	1.6L	TDCi ECO II	DDM	√	√	√	√
2013.25	Fiesta	1.6L	TDCi ECO II	FCDIM	√	√	√	√
2013.25	Fiesta	1.6L	TDCi ECO II	FCDIM	√	√	√	√
2013.25	Fiesta	1.6L	TDCi ECO II	FDSM	√	√	√	√
2013.25	Fiesta	1.6L	TDCi ECO II	GPSM	√	√	√	√
2013.25	Fiesta	1.6L	TDCi ECO II	HVAC	√	√	√	√
2013.25	Fiesta	1.6L	TDCi ECO II	IPC	√	√	√	√
2013.25	Fiesta	1.6L	TDCi ECO II	PCM	√	√	√	√
2013.25	Fiesta	1.6L	TDCi ECO II	PCM	√	√	√	√
2013.25	Fiesta	1.6L	TDCi ECO II	PDM	√	√	√	√
2013.25	Fiesta	1.6L	TDCi ECO II	PSCM	√	√	√	√
2013.25	Fiesta	1.6L	TDCi ECO II	RCM	√	√	√	√
2013.25	Fiesta	1.6L	TDCi ECO II	RFA	√	√	√	√
2013.25	Fiesta	1.6L	TiVCT	ABS	√	√	√	√
2013.25	Fiesta	1.6L	TiVCT	ACM	√	√	√	√
2013.25	Fiesta	1.6L	TiVCT	APIM	√	√	√	√
2013.25	Fiesta	1.6L	TiVCT	BCMii	√	√	√	√

2013.25	Fiesta	1.6L	TiVCT	DDM	√	√	√	√
2013.25	Fiesta	1.6L	TiVCT	FCDIM	√	√	√	√
2013.25	Fiesta	1.6L	TiVCT	FDSM	√	√	√	√
2013.25	Fiesta	1.6L	TiVCT	GPSM	√	√	√	√
2013.25	Fiesta	1.6L	TiVCT	HVAC	√	√	√	√
2013.25	Fiesta	1.6L	TiVCT	IPC	√	√	√	√
2013.25	Fiesta	1.6L	TiVCT	PCM	√	√	√	√
2013.25	Fiesta	1.6L	TiVCT	PDM	√	√	√	√
2013.25	Fiesta	1.6L	TiVCT	PSCM	√	√	√	√
2013.25	Fiesta	1.6L	TiVCT	RCM	√	√	√	√
2013.25	Fiesta	1.6L	TiVCT	RFA	√	√	√	√
2013.25	Fiesta	1.6L	TiVCT	TCM	√	√	√	√
2014	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2014	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2014	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2014	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	
2014	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct	FCDIM	√	√	√	√
2014	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	√
2014	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	√
2014	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	√
2014	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2014	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct	OCSM	√	√	√	√
2014	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2014	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2014	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2014	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	√
2014	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2014	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2014	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2014	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct	BCM#1	√	√	√	√
2014	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	
2014	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct	FCDIM	√	√	√	√
2014	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	√
2014	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	√
2014	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	√
2014	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC	√	√	√	√
2014	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct	OCSM	√	√	√	√
2014	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2014	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2014	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2014	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2014	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2014	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	√
2014	Fiesta	1.6L	TiVCT	ABS	√	√	√	√

2014	Fiesta	1.6L	TiVCT	ACM	✓	✓	✓	✓
2014	Fiesta	1.6L	TiVCT	APIM	✓	✓	✓	✓
2014	Fiesta	1.6L	TiVCT	DDM	✓	✓	✓	
2014	Fiesta	1.6L	TiVCT	FCDIM	✓	✓	✓	✓
2014	Fiesta	1.6L	TiVCT	FCIM	✓	✓	✓	✓
2014	Fiesta	1.6L	TiVCT	GPSM	✓	✓	✓	✓
2014	Fiesta	1.6L	TiVCT	HVAC	✓	✓	✓	✓
2014	Fiesta	1.6L	TiVCT	IPC	✓	✓	✓	✓
2014	Fiesta	1.6L	TiVCT	OCSM	✓	✓	✓	✓
2014	Fiesta	1.6L	TiVCT	PCM	✓	✓	✓	✓
2014	Fiesta	1.6L	TiVCT	PSCM	✓	✓	✓	✓
2014	Fiesta	1.6L	TiVCT	RCM	✓	✓	✓	✓
2014	Fiesta	1.6L	TiVCT	RFA	✓	✓	✓	✓
2014	Fiesta	1.6L	TiVCT	TCM	✓	✓	✓	✓
2014	Fiesta	1.6L	TiVCT	TCM	✓	✓	✓	✓
2014	Fiesta	1.6L	TiVCT	TCM	✓	✓	✓	✓
2006.25	Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail	ABS/TCS	✓	✓	✓	✓
2006.25	Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail	GEM	✓	✓	✓	✓
2006.25	Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail	IC	✓	✓	✓	✓
2006.25	Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail	PCM	✓	✓	✓	✓
2006.25	Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail	PCM	✓	✓	✓	✓
2006.25	Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail	RCM	✓	✓	✓	✓
2006.25	Fiesta / Ikon	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓
2006.25	Fiesta / Ikon	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓
2006.25	Fiesta / Ikon	1.4L	DURATEC 16V	IC	✓	✓	✓	✓
2006.25	Fiesta / Ikon	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓
2006.25	Fiesta / Ikon	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓
2006.25	Fiesta / Ikon	1.6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓
2006.25	Fiesta / Ikon	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓
2006.25	Fiesta / Ikon	1.6L	DURATEC 16V	IC	✓	✓	✓	✓
2006.25	Fiesta / Ikon	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓
2006.25	Fiesta / Ikon	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓
2006.25	Fiesta / Ikon	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓
1992	Fiesta / Mazda 121 / Bantam	1.8L	Zetec	ABS/TCS	✓	✓	✓	
1992	Fiesta / Mazda 121 / Bantam	1.8L	Zetec	CSM	✓	✓	✓	
1992	Fiesta / Mazda 121 / Bantam	1.8L	Zetec	HEC	✓	✓	✓	✓
1994	Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	ABS/TCS	✓	✓	✓	
1994	Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	CSM	✓	✓	✓	
1994	Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	HEC	✓	✓	✓	✓
1994.5	Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	ABS/TCS	✓	✓	✓	
1994.5	Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	CSM	✓	✓	✓	
1994.5	Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	HEC	✓	✓	✓	✓
1994.5	Fiesta / Mazda 121 / Bantam	1.8L	Zetec	ABS/TCS	✓	✓	✓	
1994.5	Fiesta / Mazda 121 / Bantam	1.8L	Zetec	CSM	✓	✓	✓	
1994.5	Fiesta / Mazda 121 / Bantam	1.8L	Zetec	HEC	✓	✓	✓	✓

1996	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	ABS/TCS	✓	✓	✓	
1996	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	CSM	✓	✓	✓	
1996	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	HEC	✓	✓	✓	✓
1996	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	PCM	✓	✓	✓	✓
1996	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	ABS/TCS	✓	✓	✓	
1996	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	CSM	✓	✓	✓	
1996	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	HEC	✓	✓	✓	✓
1996	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	PCM	✓	✓	✓	✓
1996	Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	ABS/TCS	✓	✓	✓	
1996	Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	CSM	✓	✓	✓	
1996	Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	HEC	✓	✓	✓	✓
1996.25	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	ABS/TCS	✓	✓	✓	
1996.25	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	CSM	✓	✓	✓	
1996.25	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	ECS	✓	✓	✓	
1996.25	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	HEC	✓	✓	✓	✓
1996.25	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	PATS	✓	✓	✓	✓
1996.25	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	PCM			✓	✓
1996.5	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	ABS/TCS	✓	✓	✓	
1996.5	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	CSM	✓	✓	✓	
1996.5	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	HEC	✓	✓	✓	✓
1996.5	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	PCM	✓	✓	✓	✓
1996.75	Fiesta / Mazda 121 / Bantam	1.0L	HCS	ABS/TCS	✓	✓	✓	
1996.75	Fiesta / Mazda 121 / Bantam	1.0L	HCS	CSM	✓	✓	✓	
1996.75	Fiesta / Mazda 121 / Bantam	1.0L	HCS	HEC	✓	✓	✓	✓
1996.75	Fiesta / Mazda 121 / Bantam	1.0L	HCS	PCM	✓	✓	✓	✓
1996.75	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	ABS/TCS	✓	✓	✓	
1996.75	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	CSM	✓	✓	✓	
1996.75	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	HEC	✓	✓	✓	✓
1996.75	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	PCM	✓	✓	✓	✓
1996.75	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	ABS/TCS	✓	✓	✓	
1996.75	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	CSM	✓	✓	✓	
1996.75	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	HEC	✓	✓	✓	✓
1996.75	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	PCM	✓	✓	✓	✓
1997	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	ABS/TCS	✓	✓	✓	
1997	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	CSM	✓	✓	✓	
1997	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	HEC	✓	✓	✓	✓
1997	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	PCM	✓	✓	✓	✓
1997.5	Fiesta / Mazda 121 / Bantam	1.0L	HCS	ABS/TCS	✓	✓	✓	
1997.5	Fiesta / Mazda 121 / Bantam	1.0L	HCS	CSM	✓	✓	✓	
1997.5	Fiesta / Mazda 121 / Bantam	1.0L	HCS	PCM	✓	✓	✓	✓
1997.5	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	ABS/TCS	✓	✓	✓	
1997.5	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	CSM	✓	✓	✓	
1997.5	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	HEC	✓	✓	✓	✓
1997.5	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	PCM	✓	✓	✓	✓
1997.5	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	ABS/TCS	✓	✓	✓	

1997.5	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	CSM	√	√	√	
1997.5	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	HEC	√	√	√	√
1997.5	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	PCM	√	√	√	√
1997.5	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	ABS/TCS	√	√	√	
1997.5	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	CSM	√	√	√	
1997.5	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	HEC	√	√	√	√
1997.5	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	PCM	√	√	√	√
1998.5	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	ABS/TCS	√	√	√	
1998.5	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	CSM	√	√	√	
1998.5	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	HEC	√	√	√	√
1998.5	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	PCM	√	√	√	√
1998.5	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	ABS/TCS	√	√	√	
1998.5	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	CSM	√	√	√	
1998.5	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	HEC	√	√	√	√
1998.5	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	PCM	√	√	√	√
1998.5	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	ABS/TCS	√	√	√	
1998.5	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	CSM	√	√	√	
1998.5	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	HEC	√	√	√	√
1998.5	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	PCM	√	√	√	√
1999	Fiesta / Mazda 121 / Bantam	1.0L	HCS	ABS/TCS	√	√	√	
1999	Fiesta / Mazda 121 / Bantam	1.0L	HCS	CSM	√	√	√	
1999	Fiesta / Mazda 121 / Bantam	1.0L	HCS	ECS	√	√	√	
1999	Fiesta / Mazda 121 / Bantam	1.0L	HCS	HEC	√	√	√	√
1999	Fiesta / Mazda 121 / Bantam	1.0L	HCS	PCM	√	√	√	√
1999	Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	ABS/TCS	√	√	√	
1999	Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	CSM	√	√	√	
1999	Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	ECS	√	√	√	
1999	Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	HEC	√	√	√	√
1999	Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	PCM	√	√	√	√
1999	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	ABS/TCS	√	√	√	
1999	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	CSM	√	√	√	
1999	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	ECS	√	√	√	
1999	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	HEC	√	√	√	√
1999	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	PCM	√	√	√	√
1999	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	ABS/TCS	√	√	√	
1999	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	CSM	√	√	√	
1999	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	ECS	√	√	√	
1999	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	HEC	√	√	√	√
1999	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	PCM	√	√	√	√
1999	Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	ABS/TCS	√	√	√	
1999	Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	CSM	√	√	√	
1999	Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	ECS	√	√	√	
1999	Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	HEC	√	√	√	√
1999	Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	PCM	√	√	√	√
1999.5	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	ABS/TCS	√	√	√	

1999.5	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	CSM	√	√	√	
1999.5	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	ECS	√	√	√	
1999.5	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	GEM	√	√	√	√
1999.5	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	HEC	√	√	√	√
1999.5	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	PCM	√	√	√	√
1999.5	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	ABS/TCS	√	√	√	
1999.5	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	CSM	√	√	√	
1999.5	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	ECS	√	√	√	
1999.5	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	GEM	√	√	√	√
1999.5	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	HEC	√	√	√	√
1999.5	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	PCM	√	√	√	√
1999.5	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	PCM	√	√	√	√
1999.5	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	ABS/TCS	√	√	√	
1999.5	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	CSM	√	√	√	
1999.5	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	ECS	√	√	√	
1999.5	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	GEM	√	√	√	√
1999.5	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	HEC	√	√	√	√
1999.5	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	PCM	√	√	√	√
1999.75	Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	ABS/TCS	√	√	√	
1999.75	Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	CSM	√	√	√	
1999.75	Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	ECS	√	√	√	
1999.75	Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	GEM	√	√	√	√
1999.75	Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	HEC	√	√	√	√
1999.75	Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	PCM	√	√	√	√
1999.75	Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	ABS/TCS	√	√	√	
1999.75	Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	CSM	√	√	√	
1999.75	Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	ECS	√	√	√	
1999.75	Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	GEM	√	√	√	√
1999.75	Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	HEC	√	√	√	√
1999.75	Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	PCM	√	√	√	√
2000	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	ABS/TCS	√	√	√	
2000	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	CSM	√	√	√	
2000	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	ECS	√	√	√	
2000	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	GEM	√	√	√	√
2000	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	HEC	√	√	√	√
2000	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	PATS	√	√	√	√
2000	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	PCM	√	√	√	√
2000	Fiesta / Mazda 121 / Bantam	1.4L	PT-E	CSM	√	√	√	
2000	Fiesta / Mazda 121 / Bantam	1.4L	PT-E	ECS	√	√	√	
2000	Fiesta / Mazda 121 / Bantam	1.4L	PT-E	HEC	√	√	√	√
2000	Fiesta / Mazda 121 / Bantam	1.4L	PT-E	PCM	√	√	√	√
2000	Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	ABS/TCS	√	√	√	
2000	Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	CSM	√	√	√	
2000	Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	ECS	√	√	√	
2000	Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	GEM	√	√	√	√

2000	Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	HEC	√	√	√	√
2000	Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	PCM	√	√	√	√
2000	Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	ABS/TCS	√	√	√	
2000	Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	CSM	√	√	√	
2000	Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	ECS	√	√	√	
2000	Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	FIP	√	√	√	
2000	Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	GEM	√	√	√	√
2000	Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	HEC	√	√	√	√
2000	Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	PATS	√	√	√	√
2000	Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	PCM	√	√	√	√
2001	Fiesta / Mazda 121 / Bantam	1.6L	Other	ABS/TCS	√	√	√	
2001	Fiesta / Mazda 121 / Bantam	1.6L	Other	CSM	√	√	√	
2001	Fiesta / Mazda 121 / Bantam	1.6L	Other	GEM	√	√	√	√
2001	Fiesta / Mazda 121 / Bantam	1.6L	Other	HEC	√	√	√	√
2001	Fiesta / Mazda 121 / Bantam	1.6L	Other	PATS	√	√	√	√
2001	Fiesta / Mazda 121 / Bantam	1.6L	Other	PCM	√	√	√	√
Other	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	ABS/TCS	√	√	√	
Other	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	CSM	√	√	√	
Other	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	ECS	√	√	√	
Other	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	HEC	√	√	√	√
Other	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	PATS	√	√	√	√
Other	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	PCM			√	√
2002	Fiesta 3-Door	1.25L	DURATEC 16V	ABS/TCS	√	√	√	√
2002	Fiesta 3-Door	1.25L	DURATEC 16V	GEM	√	√	√	√
2002	Fiesta 3-Door	1.25L	DURATEC 16V	IC	√	√	√	√
2002	Fiesta 3-Door	1.25L	DURATEC 16V	PCM	√	√	√	√
2002	Fiesta 3-Door	1.25L	DURATEC 16V	RCM	√	√	√	√
2002	Fiesta 3-Door	1.3L	DURATEC 8V	ABS/TCS	√	√	√	√
2002	Fiesta 3-Door	1.3L	DURATEC 8V	GEM	√	√	√	√
2002	Fiesta 3-Door	1.3L	DURATEC 8V	IC	√	√	√	√
2002	Fiesta 3-Door	1.3L	DURATEC 8V	PCM	√	√	√	√
2002	Fiesta 3-Door	1.3L	DURATEC 8V	RCM	√	√	√	√
2002	Fiesta 3-Door	1.4L	DURATEC 16V	ABS/TCS	√	√	√	√
2002	Fiesta 3-Door	1.4L	DURATEC 16V	ABS/TCS	√	√	√	√
2002	Fiesta 3-Door	1.4L	DURATEC 16V	ABS/TCS	√	√	√	√
2002	Fiesta 3-Door	1.4L	DURATEC 16V	GEM	√	√	√	√
2002	Fiesta 3-Door	1.4L	DURATEC 16V	GEM	√	√	√	√
2002	Fiesta 3-Door	1.4L	DURATEC 16V	IC	√	√	√	√
2002	Fiesta 3-Door	1.4L	DURATEC 16V	IC	√	√	√	√
2002	Fiesta 3-Door	1.4L	DURATEC 16V	PCM	√	√	√	√
2002	Fiesta 3-Door	1.4L	DURATEC 16V	PCM	√	√	√	√
2002	Fiesta 3-Door	1.4L	DURATEC 16V	RCM	√	√	√	√
2002	Fiesta 3-Door	1.4L	DURATEC 16V	TCM	√	√	√	√
2002	Fiesta 3-Door	1.4L	DURATEC 16V	TCM	√	√	√	√
2002	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail	ABS/TCS	√	√	√	√

2002	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail	ABS/TCS	√	√	√	√
2002	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail	GEM	√	√	√	√
2002	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail	IC	√	√	√	√
2002	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2002	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2002	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail	TCM	√	√	√	√
2002	Fiesta 3-Door	1.6L	DURATEC 16V	ABS/TCS	√	√	√	√
2002	Fiesta 3-Door	1.6L	DURATEC 16V	ABS/TCS	√	√	√	√
2002	Fiesta 3-Door	1.6L	DURATEC 16V	GEM	√	√	√	√
2002	Fiesta 3-Door	1.6L	DURATEC 16V	IC	√	√	√	√
2002	Fiesta 3-Door	1.6L	DURATEC 16V	PCM	√	√	√	√
2002	Fiesta 3-Door	1.6L	DURATEC 16V	PCM	√	√	√	√
2002	Fiesta 3-Door	1.6L	DURATEC 16V	RCM	√	√	√	√
2002	Fiesta 3-Door	1.6L	DURATEC 16V	TCM	√	√	√	√
2002	Fiesta 3-Door	1.6L	DURATEC 16V	TCM	√	√	√	√
2002	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail	ABS/TCS	√	√	√	√
2002	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail	EPS	√	√	√	√
2002	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail	GEM	√	√	√	√
2002	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail	IC	√	√	√	√
2002	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2002	Fiesta 3-Door	2.0L	DURATEC-HE / I4	ABS/TCS	√	√	√	√
2002	Fiesta 3-Door	2.0L	DURATEC-HE / I4	GEM	√	√	√	√
2002	Fiesta 3-Door	2.0L	DURATEC-HE / I4	IC	√	√	√	√
2002	Fiesta 3-Door	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2002	Fiesta 3-Door	2.0L	DURATEC-HE / I4	RCM	√	√	√	√
2006	Fiesta 3-Door	1.25L	DURATEC 16V	ABS/TCS	√	√	√	√
2006	Fiesta 3-Door	1.25L	DURATEC 16V	ACM	√	√	√	√
2006	Fiesta 3-Door	1.25L	DURATEC 16V	EATC	√	√	√	√
2006	Fiesta 3-Door	1.25L	DURATEC 16V	GEM	√	√	√	√
2006	Fiesta 3-Door	1.25L	DURATEC 16V	IC	√	√	√	√
2006	Fiesta 3-Door	1.25L	DURATEC 16V	PCM	√	√	√	√
2006	Fiesta 3-Door	1.25L	DURATEC 16V	RCM	√	√	√	√
2006	Fiesta 3-Door	1.25L	DURATEC 16V	SRM	√	√	√	√
2006	Fiesta 3-Door	1.3L	DURATEC 8V	ABS/TCS	√	√	√	√
2006	Fiesta 3-Door	1.3L	DURATEC 8V	ACM	√	√	√	√
2006	Fiesta 3-Door	1.3L	DURATEC 8V	EATC	√	√	√	√
2006	Fiesta 3-Door	1.3L	DURATEC 8V	GEM	√	√	√	√
2006	Fiesta 3-Door	1.3L	DURATEC 8V	IC	√	√	√	√
2006	Fiesta 3-Door	1.3L	DURATEC 8V	PCM	√	√	√	√
2006	Fiesta 3-Door	1.3L	DURATEC 8V	RCM	√	√	√	√
2006	Fiesta 3-Door	1.3L	DURATEC 8V	SRM	√	√	√	√
2006	Fiesta 3-Door	1.4L	DURATEC 16V	ABS/TCS	√	√	√	√
2006	Fiesta 3-Door	1.4L	DURATEC 16V	ACM	√	√	√	√
2006	Fiesta 3-Door	1.4L	DURATEC 16V	EATC	√	√	√	√
2006	Fiesta 3-Door	1.4L	DURATEC 16V	GEM	√	√	√	√



2006	Fiesta 3-Door	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓
2006	Fiesta 3-Door	1.4L	DURATEC 16V	IC	✓	✓	✓	✓
2006	Fiesta 3-Door	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓
2006	Fiesta 3-Door	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓
2006	Fiesta 3-Door	1.4L	DURATEC 16V	SRM	✓	✓	✓	✓
2006	Fiesta 3-Door	1.4L	DURATEC 16V	SRM	✓	✓	✓	✓
2006	Fiesta 3-Door	1.4L	DURATEC 16V	TCM	✓	✓	✓	✓
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail	ABS/TCS	✓	✓	✓	✓
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail	ACM	✓	✓	✓	✓
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail	EATC	✓	✓	✓	✓
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail	GEM	✓	✓	✓	✓
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail	GEM	✓	✓	✓	✓
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail	GEM	✓	✓	✓	✓
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail	IC	✓	✓	✓	✓
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail	IC	✓	✓	✓	✓
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail	PCM	✓	✓	✓	✓
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail	RCM	✓	✓	✓	✓
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail	SRM	✓	✓	✓	✓
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail	SRM	✓	✓	✓	✓
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail	TCM	✓	✓	✓	✓
2006	Fiesta 3-Door	1.6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓
2006	Fiesta 3-Door	1.6L	DURATEC 16V	ACM	✓	✓	✓	✓
2006	Fiesta 3-Door	1.6L	DURATEC 16V	EATC	✓	✓	✓	✓
2006	Fiesta 3-Door	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓
2006	Fiesta 3-Door	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓
2006	Fiesta 3-Door	1.6L	DURATEC 16V	IC	✓	✓	✓	✓
2006	Fiesta 3-Door	1.6L	DURATEC 16V	IC	✓	✓	✓	✓
2006	Fiesta 3-Door	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓
2006	Fiesta 3-Door	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓
2006	Fiesta 3-Door	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓
2006	Fiesta 3-Door	1.6L	DURATEC 16V	SRM	✓	✓	✓	✓
2006	Fiesta 3-Door	1.6L	DURATEC 16V	SRM	✓	✓	✓	✓
2006	Fiesta 3-Door	1.6L	DURATEC 16V	TCM	✓	✓	✓	✓
2006	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail	ABS/TCS	✓	✓	✓	✓
2006	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail	ACM	✓	✓	✓	✓
2006	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail	EATC	✓	✓	✓	✓
2006	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail	EPS	✓	✓	✓	✓
2006	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail	GEM	✓	✓	✓	✓
2006	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail	IC	✓	✓	✓	✓
2006	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail	PCM	✓	✓	✓	✓
2006	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail	SRM	✓	✓	✓	✓
2006	Fiesta 3-Door	2.0L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓
2006	Fiesta 3-Door	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓
2006	Fiesta 3-Door	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓
2006	Fiesta 3-Door	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓

2006	Fiesta 3-Door	2.0L	DURATEC-HE / I4	IC	√	√	√	√
2006	Fiesta 3-Door	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2006	Fiesta 3-Door	2.0L	DURATEC-HE / I4	RCM	√	√	√	√
2006	Fiesta 3-Door	2.0L	DURATEC-HE / I4	SRM	√	√	√	√
2006	Five Hundred	3.0L	4V	4X4	√	√	√	√
2006	Five Hundred	3.0L	4V	ABS	√	√	√	√
2006	Five Hundred	3.0L	4V	ABS	√	√	√	√
2006	Five Hundred	3.0L	4V	ACM	√	√	√	√
2006	Five Hundred	3.0L	4V	ACM	√	√	√	√
2006	Five Hundred	3.0L	4V	ACM	√	√	√	√
2006	Five Hundred	3.0L	4V	DSM	√	√	√	√
2006	Five Hundred	3.0L	4V	DSM	√	√	√	√
2006	Five Hundred	3.0L	4V	EATC	√	√	√	√
2006	Five Hundred	3.0L	4V	GEM	√	√	√	√
2006	Five Hundred	3.0L	4V	GEM	√	√	√	√
2006	Five Hundred	3.0L	4V	IC	√	√	√	√
2006	Five Hundred	3.0L	4V	IC	√	√	√	√
2006	Five Hundred	3.0L	4V	PAM	√	√	√	√
2006	Five Hundred	3.0L	4V	PAM	√	√	√	√
2006	Five Hundred	3.0L	4V	PCM	√	√	√	√
2006	Five Hundred	3.0L	4V	PCM	√	√	√	√
2006	Five Hundred	3.0L	4V	RCM	√	√	√	√
2006	Five Hundred	3.0L	4V	RCM	√	√	√	√
2006	Five Hundred	3.0L	4V	RETM	√	√	√	√
2006	Five Hundred	3.0L	4V	TCM	√	√	√	√
2007	Five Hundred	3.0L	4V	4X4	√	√	√	√
2007	Five Hundred	3.0L	4V	ABS	√	√	√	√
2007	Five Hundred	3.0L	4V	ABS	√	√	√	√
2007	Five Hundred	3.0L	4V	ACM	√	√	√	√
2007	Five Hundred	3.0L	4V	ACM	√	√	√	√
2007	Five Hundred	3.0L	4V	DSM	√	√	√	√
2007	Five Hundred	3.0L	4V	EATC	√	√	√	√
2007	Five Hundred	3.0L	4V	GEM	√	√	√	√
2007	Five Hundred	3.0L	4V	IC	√	√	√	√
2007	Five Hundred	3.0L	4V	PAM	√	√	√	√
2007	Five Hundred	3.0L	4V	PAM	√	√	√	√
2007	Five Hundred	3.0L	4V	PCM	√	√	√	√
2007	Five Hundred	3.0L	4V	PCM	√	√	√	√
2007	Five Hundred	3.0L	4V	PCM	√	√	√	√
2007	Five Hundred	3.0L	4V	PCM	√	√	√	√
2007	Five Hundred	3.0L	4V	RCM	√	√	√	√
2007	Five Hundred	3.0L	4V	RCM	√	√	√	√
2007	Five Hundred	3.0L	4V	RETM	√	√	√	√
2007	Five Hundred	3.0L	4V	SDARS	√	√	√	√
2007	Five Hundred	3.0L	4V	SDARS	√	√	√	√

2007	Five Hundred	3.0L	4V	TCM	√	√	√	√
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	4X4	√	√	√	√
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	ABS	√	√	√	√
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	ACM	√	√	√	√
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	ACM	√	√	√	√
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	DSM	√	√	√	√
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	EATC	√	√	√	√
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	GEM	√	√	√	√
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	IC	√	√	√	√
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	PAM	√	√	√	√
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	PCM	√	√	√	√
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	RCM	√	√	√	√
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	RETM	√	√	√	√
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	TCM	√	√	√	√
2009	Flex	3.5L	4V	4X4	√	√	√	√
2009	Flex	3.5L	4V	ABS	√	√	√	√
2009	Flex	3.5L	4V	ACM	√	√	√	√
2009	Flex	3.5L	4V	APIM	√	√	√	√
2009	Flex	3.5L	4V	DCSM	√	√	√	√
2009	Flex	3.5L	4V	DSM	√	√	√	√
2009	Flex	3.5L	4V	DSP	√	√	√	
2009	Flex	3.5L	4V	FCIM	√	√	√	√
2009	Flex	3.5L	4V	FDIM	√	√	√	√
2009	Flex	3.5L	4V	GEM / SJB	√	√	√	√
2009	Flex	3.5L	4V	HVAC	√	√	√	√
2009	Flex	3.5L	4V	IC	√	√	√	√
2009	Flex	3.5L	4V	LTM	√	√	√	√
2009	Flex	3.5L	4V	OCSM	√	√	√	√
2009	Flex	3.5L	4V	PAM	√	√	√	√
2009	Flex	3.5L	4V	PCM	√	√	√	√
2009	Flex	3.5L	4V	RCM	√	√	√	√
2009	Flex	3.5L	4V	RETM	√	√	√	√
2009	Flex	3.5L	4V	SECM	√	√	√	√
2010	Flex	3.5L	4V	4X4	√	√	√	√
2010	Flex	3.5L	4V	ABS	√	√	√	√
2010	Flex	3.5L	4V	ACM	√	√	√	√
2010	Flex	3.5L	4V	C-CM	√	√	√	√
2010	Flex	3.5L	4V	DCSM	√	√	√	√
2010	Flex	3.5L	4V	DDM	√	√	√	√
2010	Flex	3.5L	4V	DSM	√	√	√	√
2010	Flex	3.5L	4V	DSP	√	√	√	
2010	Flex	3.5L	4V	FCIM	√	√	√	√
2010	Flex	3.5L	4V	FDIM	√	√	√	√
2010	Flex	3.5L	4V	GEM / SJB	√	√	√	√
2010	Flex	3.5L	4V	GPSM	√	√	√	√

2010	Flex	3.5L	4V	HCM	✓	✓	✓	✓
2010	Flex	3.5L	4V	HCM-2	✓	✓	✓	✓
2010	Flex	3.5L	4V	HUD	✓	✓	✓	✓
2010	Flex	3.5L	4V	HVAC	✓	✓	✓	✓
2010	Flex	3.5L	4V	IC	✓	✓	✓	✓
2010	Flex	3.5L	4V	ILCM	✓	✓	✓	✓
2010	Flex	3.5L	4V	LTM	✓	✓	✓	✓
2010	Flex	3.5L	4V	OCSM	✓	✓	✓	✓
2010	Flex	3.5L	4V	PAM	✓	✓	✓	✓
2010	Flex	3.5L	4V	PCM	✓	✓	✓	✓
2010	Flex	3.5L	4V	PSCM	✓	✓	✓	✓
2010	Flex	3.5L	4V	RCM	✓	✓	✓	✓
2010	Flex	3.5L	4V	RETM	✓	✓	✓	✓
2010	Flex	3.5L	4V	SASM	✓	✓	✓	✓
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	4X4	✓	✓	✓	✓
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	ABS	✓	✓	✓	✓
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	ACM	✓	✓	✓	✓
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	ACM	✓	✓	✓	✓
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	APIM	✓	✓	✓	✓
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	DCSM	✓	✓	✓	✓
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	DDM	✓	✓	✓	✓
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	DSM	✓	✓	✓	✓
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	DSP	✓	✓	✓	
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	FCIM	✓	✓	✓	✓
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	FDIM	✓	✓	✓	✓
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	GEM / SJB	✓	✓	✓	✓
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	HCM	✓	✓	✓	✓
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	HCM-2	✓	✓	✓	✓
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	HUD	✓	✓	✓	✓
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	HVAC	✓	✓	✓	✓
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	IC	✓	✓	✓	✓
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	ILCM	✓	✓	✓	✓
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	LTM	✓	✓	✓	✓
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	PSCM	✓	✓	✓	✓
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	RCM	✓	✓	✓	✓
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	RETM	✓	✓	✓	✓
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	SASM	✓	✓	✓	✓
2011	Flex	3.5L	4V	4X4	✓	✓	✓	✓

2011	Flex	3.5L	4V	ABS	√	√	√	√
2011	Flex	3.5L	4V	ACM	√	√	√	√
2011	Flex	3.5L	4V	ACM	√	√	√	√
2011	Flex	3.5L	4V	APIM	√	√	√	√
2011	Flex	3.5L	4V	C-CM	√	√	√	√
2011	Flex	3.5L	4V	DCSM	√	√	√	√
2011	Flex	3.5L	4V	DDM	√	√	√	√
2011	Flex	3.5L	4V	DSM	√	√	√	√
2011	Flex	3.5L	4V	DSP	√	√	√	
2011	Flex	3.5L	4V	FCIM	√	√	√	√
2011	Flex	3.5L	4V	FDIM	√	√	√	√
2011	Flex	3.5L	4V	GEM / SJB	√	√	√	√
2011	Flex	3.5L	4V	GPSM	√	√	√	√
2011	Flex	3.5L	4V	HCM	√	√	√	√
2011	Flex	3.5L	4V	HCM-2	√	√	√	√
2011	Flex	3.5L	4V	HUD	√	√	√	√
2011	Flex	3.5L	4V	HVAC	√	√	√	√
2011	Flex	3.5L	4V	IC	√	√	√	√
2011	Flex	3.5L	4V	ILCM	√	√	√	√
2011	Flex	3.5L	4V	LTM	√	√	√	√
2011	Flex	3.5L	4V	OCSM	√	√	√	√
2011	Flex	3.5L	4V	PAM	√	√	√	√
2011	Flex	3.5L	4V	PCM	√	√	√	√
2011	Flex	3.5L	4V	PSCM	√	√	√	√
2011	Flex	3.5L	4V	RCM	√	√	√	√
2011	Flex	3.5L	4V	RETM	√	√	√	√
2011	Flex	3.5L	4V	SASM	√	√	√	√
2011	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	4X4	√	√	√	√
2011	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2011	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2011	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2011	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	C-CM	√	√	√	√
2011	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	DCSM	√	√	√	√
2011	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM	√	√	√	√
2011	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	DSM	√	√	√	√
2011	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	DSP	√	√	√	
2011	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	√
2011	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	FDIM	√	√	√	√
2011	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	GEM / SJB	√	√	√	√
2011	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	√
2011	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	HCM	√	√	√	√
2011	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	HUD	√	√	√	√
2011	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	√
2011	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	IC	√	√	√	√

2011	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	ILCM	√	√	√	√
2011	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	LTM	√	√	√	√
2011	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	OCSM	√	√	√	√
2011	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2011	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2011	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2011	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2011	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	RETM	√	√	√	√
2011	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	SASM	√	√	√	√
2012	Flex	3.5L	4V	4X4	√	√	√	√
2012	Flex	3.5L	4V	ABS	√	√	√	√
2012	Flex	3.5L	4V	ACM	√	√	√	√
2012	Flex	3.5L	4V	APIM	√	√	√	√
2012	Flex	3.5L	4V	DCSM	√	√	√	√
2012	Flex	3.5L	4V	DDM	√	√	√	√
2012	Flex	3.5L	4V	DSM	√	√	√	√
2012	Flex	3.5L	4V	DSP	√	√	√	√
2012	Flex	3.5L	4V	FCIM	√	√	√	√
2012	Flex	3.5L	4V	FDIM	√	√	√	√
2012	Flex	3.5L	4V	GEM / SJB	√	√	√	√
2012	Flex	3.5L	4V	GPSM	√	√	√	√
2012	Flex	3.5L	4V	HCM	√	√	√	√
2012	Flex	3.5L	4V	HCM-2	√	√	√	√
2012	Flex	3.5L	4V	HVAC	√	√	√	√
2012	Flex	3.5L	4V	IC	√	√	√	√
2012	Flex	3.5L	4V	ILCM	√	√	√	√
2012	Flex	3.5L	4V	LTM	√	√	√	√
2012	Flex	3.5L	4V	OCSM	√	√	√	√
2012	Flex	3.5L	4V	PAM	√	√	√	√
2012	Flex	3.5L	4V	PCM	√	√	√	√
2012	Flex	3.5L	4V	PSCM	√	√	√	√
2012	Flex	3.5L	4V	RCM	√	√	√	√
2012	Flex	3.5L	4V	RETM	√	√	√	√
2012	Flex	3.5L	4V	SASM	√	√	√	√
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	4X4	√	√	√	√
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	DCSM	√	√	√	√
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	√
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	DSM	√	√	√	√
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	DSP	√	√	√	√
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	FDIM	√	√	√	√
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	GEM / SJB	√	√	√	√

2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	√
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	HCM	√	√	√	√
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	HCM-2	√	√	√	√
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	√
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	IC	√	√	√	√
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	ILCM	√	√	√	√
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	LTM	√	√	√	√
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	OCSM	√	√	√	√
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	RETM	√	√	√	√
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	SASM	√	√	√	√
2012	Flex	Other	Other	4X4	√	√	√	√
2012	Flex	Other	Other	ABS	√	√	√	√
2012	Flex	Other	Other	ACM	√	√	√	√
2012	Flex	Other	Other	APIM	√	√	√	√
2012	Flex	Other	Other	DCSM	√	√	√	√
2012	Flex	Other	Other	DDM	√	√	√	√
2012	Flex	Other	Other	DSM	√	√	√	√
2012	Flex	Other	Other	DSP	√	√	√	
2012	Flex	Other	Other	FCIM	√	√	√	√
2012	Flex	Other	Other	FDIM	√	√	√	√
2012	Flex	Other	Other	GEM / SJB	√	√	√	√
2012	Flex	Other	Other	GPSM	√	√	√	√
2012	Flex	Other	Other	HCM	√	√	√	√
2012	Flex	Other	Other	HCM-2	√	√	√	√
2012	Flex	Other	Other	HVAC	√	√	√	√
2012	Flex	Other	Other	IC	√	√	√	√
2012	Flex	Other	Other	ILCM	√	√	√	√
2012	Flex	Other	Other	LTM	√	√	√	√
2012	Flex	Other	Other	OCSM	√	√	√	√
2012	Flex	Other	Other	PAM	√	√	√	√
2012	Flex	Other	Other	PSCM	√	√	√	√
2012	Flex	Other	Other	RCM	√	√	√	√
2012	Flex	Other	Other	RETM	√	√	√	√
2012	Flex	Other	Other	SASM	√	√	√	√
2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	BCM#1	√	√	√	√
2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	√	√	√	√
2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	√

2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	DSM	✓	✓	✓	✓
2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	DSP	✓	✓	✓	✓
2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	FCDIM	✓	✓	✓	✓
2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	FCIM	✓	✓	✓	✓
2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	GPSM	✓	✓	✓	✓
2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	HCM	✓	✓	✓	✓
2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	HUD	✓	✓	✓	✓
2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	HVAC	✓	✓	✓	✓
2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	IPC	✓	✓	✓	✓
2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	LTM	✓	✓	✓	✓
2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	OCSM	✓	✓	✓	✓
2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	PAM	✓	✓	✓	✓
2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	PSCM	✓	✓	✓	✓
2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	RACM	✓	✓	✓	✓
2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	RCM	✓	✓	✓	✓
2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	RFA	✓	✓	✓	✓
2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	RTM	✓	✓	✓	✓
2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	SCCM	✓	✓	✓	✓
2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓
2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-R	✓	✓	✓	✓
2013	Flex	3.5L	TiVCT	ABS	✓	✓	✓	✓
2013	Flex	3.5L	TiVCT	ACM	✓	✓	✓	✓
2013	Flex	3.5L	TiVCT	APIM	✓	✓	✓	✓
2013	Flex	3.5L	TiVCT	BCM#1	✓	✓	✓	✓
2013	Flex	3.5L	TiVCT	C-CM	✓	✓	✓	✓
2013	Flex	3.5L	TiVCT	DCSM	✓	✓	✓	✓
2013	Flex	3.5L	TiVCT	DDM	✓	✓	✓	✓
2013	Flex	3.5L	TiVCT	DSM	✓	✓	✓	✓
2013	Flex	3.5L	TiVCT	DSP	✓	✓	✓	✓
2013	Flex	3.5L	TiVCT	FCDIM	✓	✓	✓	✓
2013	Flex	3.5L	TiVCT	FCIM	✓	✓	✓	✓
2013	Flex	3.5L	TiVCT	GPSM	✓	✓	✓	✓
2013	Flex	3.5L	TiVCT	HCM	✓	✓	✓	✓
2013	Flex	3.5L	TiVCT	HUD	✓	✓	✓	✓
2013	Flex	3.5L	TiVCT	HVAC	✓	✓	✓	✓
2013	Flex	3.5L	TiVCT	IPC	✓	✓	✓	✓
2013	Flex	3.5L	TiVCT	LTM	✓	✓	✓	✓
2013	Flex	3.5L	TiVCT	OCSM	✓	✓	✓	✓
2013	Flex	3.5L	TiVCT	PAM	✓	✓	✓	✓
2013	Flex	3.5L	TiVCT	PCM	✓	✓	✓	✓
2013	Flex	3.5L	TiVCT	PSCM	✓	✓	✓	✓
2013	Flex	3.5L	TiVCT	RACM	✓	✓	✓	✓
2013	Flex	3.5L	TiVCT	RCM	✓	✓	✓	✓



2013	Flex	3.5L	TiVCT	RFA	✓	✓	✓	✓
2013	Flex	3.5L	TiVCT	RTM	✓	✓	✓	✓
2013	Flex	3.5L	TiVCT	SCCM	✓	✓	✓	✓
2013	Flex	3.5L	TiVCT	SOD-L	✓	✓	✓	✓
2013	Flex	3.5L	TiVCT	SOD-R	✓	✓	✓	✓
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	ABS	✓	✓	✓	✓
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	ACM	✓	✓	✓	✓
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	BCM#1	✓	✓	✓	✓
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	C-CM	✓	✓	✓	✓
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	DCSM	✓	✓	✓	✓
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	DDM	✓	✓	✓	✓
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	DSM	✓	✓	✓	✓
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	DSP	✓	✓	✓	✓
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	FCDIM	✓	✓	✓	✓
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	GPSM	✓	✓	✓	✓
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	HCM	✓	✓	✓	✓
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	HUD	✓	✓	✓	✓
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	HVAC	✓	✓	✓	✓
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	IPC	✓	✓	✓	✓
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	LTM	✓	✓	✓	✓
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	OCSM	✓	✓	✓	✓
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	PSCM	✓	✓	✓	✓
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	RACM	✓	✓	✓	✓
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	RCM	✓	✓	✓	✓
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	RFA	✓	✓	✓	✓
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	RTM	✓	✓	✓	✓
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	SCCM	✓	✓	✓	✓
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-R	✓	✓	✓	✓
2014	Flex	3.5L	TiVCT	ABS	✓	✓	✓	✓
2014	Flex	3.5L	TiVCT	ACM	✓	✓	✓	✓
2014	Flex	3.5L	TiVCT	APIM	✓	✓	✓	✓
2014	Flex	3.5L	TiVCT	BCM#1	✓	✓	✓	✓
2014	Flex	3.5L	TiVCT	C-CM	✓	✓	✓	✓
2014	Flex	3.5L	TiVCT	DCSM	✓	✓	✓	✓
2014	Flex	3.5L	TiVCT	DDM	✓	✓	✓	✓
2014	Flex	3.5L	TiVCT	DSM	✓	✓	✓	✓
2014	Flex	3.5L	TiVCT	DSP	✓	✓	✓	✓
2014	Flex	3.5L	TiVCT	FCDIM	✓	✓	✓	✓

2014	Flex	3.5L	TiVCT	FCIM	√	√	√	√
2014	Flex	3.5L	TiVCT	GPSM	√	√	√	√
2014	Flex	3.5L	TiVCT	HCM	√	√	√	√
2014	Flex	3.5L	TiVCT	HUD	√	√	√	√
2014	Flex	3.5L	TiVCT	HVAC	√	√	√	√
2014	Flex	3.5L	TiVCT	IPC	√	√	√	√
2014	Flex	3.5L	TiVCT	LTM	√	√	√	√
2014	Flex	3.5L	TiVCT	OCSM	√	√	√	√
2014	Flex	3.5L	TiVCT	PAM	√	√	√	√
2014	Flex	3.5L	TiVCT	PCM	√	√	√	√
2014	Flex	3.5L	TiVCT	PSCM	√	√	√	√
2014	Flex	3.5L	TiVCT	RACM	√	√	√	√
2014	Flex	3.5L	TiVCT	RCM	√	√	√	√
2014	Flex	3.5L	TiVCT	RFA	√	√	√	√
2014	Flex	3.5L	TiVCT	RTM	√	√	√	√
2014	Flex	3.5L	TiVCT	SCCM	√	√	√	√
2014	Flex	3.5L	TiVCT	SOD-L	√	√	√	√
2014	Flex	3.5L	TiVCT	SOD-R	√	√	√	√
2014	Flex	Other	Other	ABS	√	√	√	√
2014	Flex	Other	Other	ACM	√	√	√	√
2014	Flex	Other	Other	APIM	√	√	√	√
2014	Flex	Other	Other	BCM#1	√	√	√	√
2014	Flex	Other	Other	C-CM	√	√	√	√
2014	Flex	Other	Other	DCSM	√	√	√	√
2014	Flex	Other	Other	DDM	√	√	√	√
2014	Flex	Other	Other	DSM	√	√	√	√
2014	Flex	Other	Other	DSP	√	√	√	√
2014	Flex	Other	Other	FCDIM	√	√	√	√
2014	Flex	Other	Other	FCIM	√	√	√	√
2014	Flex	Other	Other	GPSM	√	√	√	√
2014	Flex	Other	Other	HCM	√	√	√	√
2014	Flex	Other	Other	HUD	√	√	√	√
2014	Flex	Other	Other	HVAC	√	√	√	√
2014	Flex	Other	Other	IPC	√	√	√	√
2014	Flex	Other	Other	LTM	√	√	√	√
2014	Flex	Other	Other	OCSM	√	√	√	√
2014	Flex	Other	Other	PAM	√	√	√	√
2014	Flex	Other	Other	PSCM	√	√	√	√
2014	Flex	Other	Other	RACM	√	√	√	√
2014	Flex	Other	Other	RCM	√	√	√	√
2014	Flex	Other	Other	RFA	√	√	√	√
2014	Flex	Other	Other	RTM	√	√	√	√
2014	Flex	Other	Other	SCCM	√	√	√	√
2014	Flex	Other	Other	SOD-L	√	√	√	√
2014	Flex	Other	Other	SOD-R	√	√	√	√

1999	Focus	1.4L	Zetec-SE	ABS/TCS	√	√	√	√
1999	Focus	1.4L	Zetec-SE	CSM	√	√	√	√
1999	Focus	1.4L	Zetec-SE	CSM	√	√	√	√
1999	Focus	1.4L	Zetec-SE	CTM	√	√	√	√
1999	Focus	1.4L	Zetec-SE	ECS	√	√	√	√
1999	Focus	1.4L	Zetec-SE	HEC	√	√	√	√
1999	Focus	1.4L	Zetec-SE	MC	√	√	√	√
1999	Focus	1.4L	Zetec-SE	PATS	√	√	√	√
1999	Focus	1.4L	Zetec-SE	PCM	√	√	√	√
1999	Focus	1.6L	Zetec	ABS/TCS	√	√	√	√
1999	Focus	1.6L	Zetec	CSM	√	√	√	√
1999	Focus	1.6L	Zetec	CTM	√	√	√	√
1999	Focus	1.6L	Zetec	ECS	√	√	√	√
1999	Focus	1.6L	Zetec	HEC	√	√	√	√
1999	Focus	1.6L	Zetec	PATS	√	√	√	√
1999	Focus	1.6L	Zetec	PCM	√	√	√	√
1999	Focus	1.6L	Zetec-SE	ABS/TCS	√	√	√	√
1999	Focus	1.6L	Zetec-SE	CSM	√	√	√	√
1999	Focus	1.6L	Zetec-SE	CSM	√	√	√	√
1999	Focus	1.6L	Zetec-SE	CTM	√	√	√	√
1999	Focus	1.6L	Zetec-SE	ECS	√	√	√	√
1999	Focus	1.6L	Zetec-SE	HEC	√	√	√	√
1999	Focus	1.6L	Zetec-SE	MC	√	√	√	√
1999	Focus	1.6L	Zetec-SE	PATS	√	√	√	√
1999	Focus	1.6L	Zetec-SE	PCM	√	√	√	√
1999	Focus	1.8L	Endura DI	ABS/TCS	√	√	√	√
1999	Focus	1.8L	Endura DI	CSM	√	√	√	√
1999	Focus	1.8L	Endura DI	CTM	√	√	√	√
1999	Focus	1.8L	Endura DI	ECS	√	√	√	√
1999	Focus	1.8L	Endura DI	FFH	√	√	√	√
1999	Focus	1.8L	Endura DI	FIP	√	√	√	√
1999	Focus	1.8L	Endura DI	HEC	√	√	√	√
1999	Focus	1.8L	Endura DI	MC	√	√	√	√
1999	Focus	1.8L	Endura DI	PATS	√	√	√	√
1999	Focus	1.8L	Endura DI	PCM	√	√	√	√
1999	Focus	1.8L	Endura DI	PCM	√	√	√	√
1999	Focus	1.8L	Zetec	ABS/TCS	√	√	√	√
1999	Focus	1.8L	Zetec	AFCM	√	√	√	√
1999	Focus	1.8L	Zetec	CSM	√	√	√	√
1999	Focus	1.8L	Zetec	CSM	√	√	√	√
1999	Focus	1.8L	Zetec	CTM	√	√	√	√
1999	Focus	1.8L	Zetec	CTM	√	√	√	√
1999	Focus	1.8L	Zetec	ECS	√	√	√	√
1999	Focus	1.8L	Zetec	HEC	√	√	√	√
1999	Focus	1.8L	Zetec	MC	√	√	√	√

1999	Focus	1.8L	Zetec	PATS	√	√	√	√
1999	Focus	1.8L	Zetec	PCM	√	√	√	√
1999	Focus	2.0L	Zetec	ABS/TCS	√	√	√	√
1999	Focus	2.0L	Zetec	CSM	√	√	√	√
1999	Focus	2.0L	Zetec	CSM	√	√	√	√
1999	Focus	2.0L	Zetec	CTM	√	√	√	√
1999	Focus	2.0L	Zetec	CTM	√	√	√	√
1999	Focus	2.0L	Zetec	ECS	√	√	√	√
1999	Focus	2.0L	Zetec	HEC	√	√	√	√
1999	Focus	2.0L	Zetec	HEC	√	√	√	√
1999	Focus	2.0L	Zetec	MC	√	√	√	√
1999	Focus	2.0L	Zetec	PATS	√	√	√	√
1999	Focus	2.0L	Zetec	PCM	√	√	√	√
2000	Focus	2.0L	SPI	ABS/TCS	√	√	√	√
2000	Focus	2.0L	SPI	CSM	√	√	√	√
2000	Focus	2.0L	SPI	CSM	√	√	√	√
2000	Focus	2.0L	SPI	CTM	√	√	√	√
2000	Focus	2.0L	SPI	ECS	√	√	√	√
2000	Focus	2.0L	SPI	HEC	√	√	√	√
2000	Focus	2.0L	SPI	PCM	√	√	√	√
2000	Focus	2.0L	Zetec	ABS/TCS	√	√	√	√
2000	Focus	2.0L	Zetec	CSM	√	√	√	√
2000	Focus	2.0L	Zetec	CSM	√	√	√	√
2000	Focus	2.0L	Zetec	CTM	√	√	√	√
2000	Focus	2.0L	Zetec	CTM	√	√	√	√
2000	Focus	2.0L	Zetec	ECS	√	√	√	√
2000	Focus	2.0L	Zetec	HEC	√	√	√	√
2000	Focus	2.0L	Zetec	HEC	√	√	√	√
2000	Focus	2.0L	Zetec	PCM	√	√	√	√
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail	ABS/TCS	√	√	√	√
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail	CSM	√	√	√	√
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail	CSM	√	√	√	√
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail	CTM	√	√	√	√
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail	ECS	√	√	√	√
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail	FFH	√	√	√	√
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail	FFH	√	√	√	√
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail	HEC	√	√	√	√
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail	ICU			√	√
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail	MC	√	√	√	√
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2002	Focus	1.4L	Zetec-SE	ABS/TCS	√	√	√	√
2002	Focus	1.4L	Zetec-SE	EATC	√	√	√	√
2002	Focus	1.4L	Zetec-SE	ECS	√	√	√	√
2002	Focus	1.4L	Zetec-SE	GEM	√	√	√	√
2002	Focus	1.4L	Zetec-SE	HCM	√	√	√	√

2002	Focus	1.4L	Zetec-SE	HEC	√	√	√	√
2002	Focus	1.4L	Zetec-SE	MC	√	√	√	√
2002	Focus	1.4L	Zetec-SE	PATS	√	√	√	√
2002	Focus	1.4L	Zetec-SE	PCM	√	√	√	√
2002	Focus	1.4L	Zetec-SE	RCM	√	√	√	√
2002	Focus	1.6L	Zetec	ABS/TCS	√	√	√	√
2002	Focus	1.6L	Zetec	EATC	√	√	√	√
2002	Focus	1.6L	Zetec	ECS	√	√	√	√
2002	Focus	1.6L	Zetec	GEM	√	√	√	√
2002	Focus	1.6L	Zetec	HCM	√	√	√	√
2002	Focus	1.6L	Zetec	HEC	√	√	√	√
2002	Focus	1.6L	Zetec	MC	√	√	√	√
2002	Focus	1.6L	Zetec	PCM	√	√	√	√
2002	Focus	1.6L	Zetec	RCM	√	√	√	√
2002	Focus	1.6L	Zetec Rocam	EATC	√	√	√	√
2002	Focus	1.6L	Zetec Rocam	ECS	√	√	√	√
2002	Focus	1.6L	Zetec Rocam	GEM	√	√	√	√
2002	Focus	1.6L	Zetec Rocam	HCM	√	√	√	√
2002	Focus	1.6L	Zetec Rocam	HEC	√	√	√	√
2002	Focus	1.6L	Zetec Rocam	MC	√	√	√	√
2002	Focus	1.6L	Zetec Rocam	PCM	√	√	√	√
2002	Focus	1.6L	Zetec Rocam	RCM	√	√	√	√
2002	Focus	1.6L	Zetec-SE	ABS/TCS	√	√	√	√
2002	Focus	1.6L	Zetec-SE	EATC	√	√	√	√
2002	Focus	1.6L	Zetec-SE	ECS	√	√	√	√
2002	Focus	1.6L	Zetec-SE	GEM	√	√	√	√
2002	Focus	1.6L	Zetec-SE	HCM	√	√	√	√
2002	Focus	1.6L	Zetec-SE	HEC	√	√	√	√
2002	Focus	1.6L	Zetec-SE	MC	√	√	√	√
2002	Focus	1.6L	Zetec-SE	PATS	√	√	√	√
2002	Focus	1.6L	Zetec-SE	PCM	√	√	√	√
2002	Focus	1.6L	Zetec-SE	RCM	√	√	√	√
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail	ABS/TCS	√	√	√	√
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail	ABS/TCS	√	√	√	√
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail	EATC	√	√	√	√
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail	ECS	√	√	√	√
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail	FFH	√	√	√	√
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail	FFH	√	√	√	√
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail	GEM	√	√	√	√
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail	GEM	√	√	√	√
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	√
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	√
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail	HEC	√	√	√	√
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail	HEC	√	√	√	√
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail	ICU			√	√

2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail	MC	√	√	√	√
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2002	Focus	1.8L	Endura DI	ABS/TCS	√	√	√	√
2002	Focus	1.8L	Endura DI	EATC	√	√	√	√
2002	Focus	1.8L	Endura DI	ECS	√	√	√	√
2002	Focus	1.8L	Endura DI	FFH	√	√	√	√
2002	Focus	1.8L	Endura DI	FIP	√	√	√	√
2002	Focus	1.8L	Endura DI	GEM	√	√	√	√
2002	Focus	1.8L	Endura DI	HCM	√	√	√	√
2002	Focus	1.8L	Endura DI	HEC	√	√	√	√
2002	Focus	1.8L	Endura DI	MC	√	√	√	√
2002	Focus	1.8L	Endura DI	PATS	√	√	√	√
2002	Focus	1.8L	Endura DI	PCM	√	√	√	√
2002	Focus	1.8L	Endura DI	RCM	√	√	√	√
2002	Focus	1.8L	Zetec	ABS/TCS	√	√	√	√
2002	Focus	1.8L	Zetec	ABS/TCS	√	√	√	√
2002	Focus	1.8L	Zetec	AFCM	√	√	√	√
2002	Focus	1.8L	Zetec	EATC	√	√	√	√
2002	Focus	1.8L	Zetec	ECS	√	√	√	√
2002	Focus	1.8L	Zetec	GEM	√	√	√	√
2002	Focus	1.8L	Zetec	HCM	√	√	√	√
2002	Focus	1.8L	Zetec	HCM	√	√	√	√
2002	Focus	1.8L	Zetec	HEC	√	√	√	√
2002	Focus	1.8L	Zetec	MC	√	√	√	√
2002	Focus	1.8L	Zetec	PCM	√	√	√	√
2002	Focus	1.8L	Zetec	PCM	√	√	√	√
2002	Focus	1.8L	Zetec	RCM	√	√	√	√
2002	Focus	2.0L	SPI	ABS/TCS	√	√	√	√
2002	Focus	2.0L	SPI	EATC	√	√	√	√
2002	Focus	2.0L	SPI	ECS	√	√	√	√
2002	Focus	2.0L	SPI	GEM	√	√	√	√
2002	Focus	2.0L	SPI	HCM	√	√	√	√
2002	Focus	2.0L	SPI	HEC	√	√	√	√
2002	Focus	2.0L	SPI	MC	√	√	√	√
2002	Focus	2.0L	SPI	PCM	√	√	√	√
2002	Focus	2.0L	SPI	RCM	√	√	√	√
2002	Focus	2.0L	ZETEC ST	ABS/TCS	√	√	√	√
2002	Focus	2.0L	ZETEC ST	EATC	√	√	√	√
2002	Focus	2.0L	ZETEC ST	GEM	√	√	√	√
2002	Focus	2.0L	ZETEC ST	HCM	√	√	√	√
2002	Focus	2.0L	ZETEC ST	HEC	√	√	√	√
2002	Focus	2.0L	ZETEC ST	MC	√	√	√	√
2002	Focus	2.0L	ZETEC ST	PCM	√	√	√	√

2002	Focus	2.0L	ZETEC ST	RCM	√	√	√	√
2002	Focus	2.0L	Zetec	ABS/TCS	√	√	√	√
2002	Focus	2.0L	Zetec	EATC	√	√	√	√
2002	Focus	2.0L	Zetec	ECS	√	√	√	√
2002	Focus	2.0L	Zetec	GEM	√	√	√	√
2002	Focus	2.0L	Zetec	GEM	√	√	√	√
2002	Focus	2.0L	Zetec	HCM	√	√	√	√
2002	Focus	2.0L	Zetec	HCM	√	√	√	√
2002	Focus	2.0L	Zetec	HEC	√	√	√	√
2002	Focus	2.0L	Zetec	HEC	√	√	√	√
2002	Focus	2.0L	Zetec	MC	√	√	√	√
2002	Focus	2.0L	Zetec	PCM	√	√	√	√
2002	Focus	2.0L	Zetec	PCM	√	√	√	√
2002	Focus	2.0L	Zetec	RCM	√	√	√	√
2002	Focus	2.0L	Zetec	RCM	√	√	√	√
2003	Focus	2.0L	SPI	ABS/TCS	√	√	√	√
2003	Focus	2.0L	SPI	GEM	√	√	√	√
2003	Focus	2.0L	SPI	HEC	√	√	√	√
2003	Focus	2.0L	SPI	PCM	√	√	√	√
2003	Focus	2.0L	SPI	RCM	√	√	√	√
2003	Focus	2.0L	ZETEC ST	ABS/TCS	√	√	√	√
2003	Focus	2.0L	ZETEC ST	GEM	√	√	√	√
2003	Focus	2.0L	ZETEC ST	HEC	√	√	√	√
2003	Focus	2.0L	ZETEC ST	PCM	√	√	√	√
2003	Focus	2.0L	ZETEC ST	RCM	√	√	√	√
2003	Focus	2.0L	Zetec	ABS/TCS	√	√	√	√
2003	Focus	2.0L	Zetec	GEM	√	√	√	√
2003	Focus	2.0L	Zetec	HEC	√	√	√	√
2003	Focus	2.0L	Zetec	PCM	√	√	√	√
2003	Focus	2.0L	Zetec	RCM	√	√	√	√
2003.25	Focus	1.4L	DURATEC 16V	ABS	√	√	√	√
2003.25	Focus	1.4L	DURATEC 16V	ACM	√	√	√	√
2003.25	Focus	1.4L	DURATEC 16V	CDP	√	√	√	√
2003.25	Focus	1.4L	DURATEC 16V	D_DCU	√	√	√	√
2003.25	Focus	1.4L	DURATEC 16V	EATC	√	√	√	√
2003.25	Focus	1.4L	DURATEC 16V	FFH	√	√	√	√
2003.25	Focus	1.4L	DURATEC 16V	GDM	√	√	√	√
2003.25	Focus	1.4L	DURATEC 16V	GEM	√	√	√	√
2003.25	Focus	1.4L	DURATEC 16V	HCM	√	√	√	√
2003.25	Focus	1.4L	DURATEC 16V	IC	√	√	√	√
2003.25	Focus	1.4L	DURATEC 16V	NAV	√	√	√	√
2003.25	Focus	1.4L	DURATEC 16V	PAM	√	√	√	√
2003.25	Focus	1.4L	DURATEC 16V	PCM	√	√	√	√
2003.25	Focus	1.4L	DURATEC 16V	P_DCU	√	√	√	√
2003.25	Focus	1.4L	DURATEC 16V	RCM	√	√	√	√





2003.25	Focus	1.6L	DURATEC 16V	TCM	√	√	√	√
2003.25	Focus	1.6L	DURATEC 16V	TCM	√	√	√	√
2003.25	Focus	1.6L	DURATEC VCT	ABS	√	√	√	√
2003.25	Focus	1.6L	DURATEC VCT	ACM	√	√	√	√
2003.25	Focus	1.6L	DURATEC VCT	CDP	√	√	√	√
2003.25	Focus	1.6L	DURATEC VCT	D_DCU	√	√	√	√
2003.25	Focus	1.6L	DURATEC VCT	EATC	√	√	√	√
2003.25	Focus	1.6L	DURATEC VCT	FFH	√	√	√	√
2003.25	Focus	1.6L	DURATEC VCT	GDM	√	√	√	√
2003.25	Focus	1.6L	DURATEC VCT	GEM	√	√	√	√
2003.25	Focus	1.6L	DURATEC VCT	HCM	√	√	√	√
2003.25	Focus	1.6L	DURATEC VCT	IC	√	√	√	√
2003.25	Focus	1.6L	DURATEC VCT	NAV	√	√	√	√
2003.25	Focus	1.6L	DURATEC VCT	PAM	√	√	√	√
2003.25	Focus	1.6L	DURATEC VCT	PCM	√	√	√	√
2003.25	Focus	1.6L	DURATEC VCT	P_DCU	√	√	√	√
2003.25	Focus	1.6L	DURATEC VCT	RCM	√	√	√	√
2003.25	Focus	1.6L	DURATEC VCT	RETM	√	√	√	√
2003.25	Focus	1.6L	DURATEC VCT	RKE	√	√	√	√
2003.25	Focus	1.6L	DURATEC VCT	RL_DCU	√	√	√	√
2003.25	Focus	1.6L	DURATEC VCT	RR_DCU	√	√	√	√
2003.25	Focus	1.6L	DURATEC VCT	SRM	√	√	√	√
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	CDP	√	√	√	√
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	CDP	√	√	√	√
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	D_DCU	√	√	√	√
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	D_DCU	√	√	√	√
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	EATC	√	√	√	√
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	EATC	√	√	√	√
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	EPS	√	√	√	√
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	EPS	√	√	√	√
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	FACM	√	√	√	√
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	FACM	√	√	√	√
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	FFH	√	√	√	√
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	FFH	√	√	√	√
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	GDM	√	√	√	√
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	GDM	√	√	√	√
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	GEM	√	√	√	√
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	GEM	√	√	√	√
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	√
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	√
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	√



2003.25	Focus	1.8L	DURATEC-HE / I4	RCM	√	√	√	√
2003.25	Focus	1.8L	DURATEC-HE / I4	RETM	√	√	√	√
2003.25	Focus	1.8L	DURATEC-HE / I4	RKE	√	√	√	√
2003.25	Focus	1.8L	DURATEC-HE / I4	RL_DCU	√	√	√	√
2003.25	Focus	1.8L	DURATEC-HE / I4	RL_DCU	√	√	√	√
2003.25	Focus	1.8L	DURATEC-HE / I4	RR_DCU	√	√	√	√
2003.25	Focus	1.8L	DURATEC-HE / I4	RR_DCU	√	√	√	√
2003.25	Focus	1.8L	DURATEC-HE / I4	SRM	√	√	√	√
2003.25	Focus	1.8L	DURATEC-HE / I4	TCM	√	√	√	√
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail	CDP	√	√	√	√
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail	D_DCU	√	√	√	√
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail	EATC	√	√	√	√
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail	FFH	√	√	√	√
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail	GDM	√	√	√	√
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail	GEM	√	√	√	√
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	√
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail	IC	√	√	√	√
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail	NAV	√	√	√	√
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail	PAM	√	√	√	√
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail	P_DCU	√	√	√	√
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail	RETM	√	√	√	√
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail	RKE	√	√	√	√
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail	RL_DCU	√	√	√	√
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail	RR_DCU	√	√	√	√
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	√
2003.25	Focus	2.0L	DURATEC-HE / I4	ABS	√	√	√	√
2003.25	Focus	2.0L	DURATEC-HE / I4	ABS	√	√	√	√
2003.25	Focus	2.0L	DURATEC-HE / I4	ACM	√	√	√	√
2003.25	Focus	2.0L	DURATEC-HE / I4	CDP	√	√	√	√
2003.25	Focus	2.0L	DURATEC-HE / I4	D_DCU	√	√	√	√
2003.25	Focus	2.0L	DURATEC-HE / I4	EATC	√	√	√	√
2003.25	Focus	2.0L	DURATEC-HE / I4	EPS	√	√	√	√
2003.25	Focus	2.0L	DURATEC-HE / I4	FFH	√	√	√	√
2003.25	Focus	2.0L	DURATEC-HE / I4	GDM	√	√	√	√
2003.25	Focus	2.0L	DURATEC-HE / I4	GDM	√	√	√	√
2003.25	Focus	2.0L	DURATEC-HE / I4	GEM	√	√	√	√
2003.25	Focus	2.0L	DURATEC-HE / I4	HCM	√	√	√	√
2003.25	Focus	2.0L	DURATEC-HE / I4	IC	√	√	√	√
2003.25	Focus	2.0L	DURATEC-HE / I4	NAV	√	√	√	√
2003.25	Focus	2.0L	DURATEC-HE / I4	PAM	√	√	√	√
2003.25	Focus	2.0L	DURATEC-HE / I4	PCM	√	√	√	√

2003.25	Focus	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2003.25	Focus	2.0L	DURATEC-HE / I4	P_DCU	√	√	√	√
2003.25	Focus	2.0L	DURATEC-HE / I4	RCM	√	√	√	√
2003.25	Focus	2.0L	DURATEC-HE / I4	RETM	√	√	√	√
2003.25	Focus	2.0L	DURATEC-HE / I4	RKE	√	√	√	√
2003.25	Focus	2.0L	DURATEC-HE / I4	RL_DCU	√	√	√	√
2003.25	Focus	2.0L	DURATEC-HE / I4	RR_DCU	√	√	√	√
2003.25	Focus	2.0L	DURATEC-HE / I4	SRM	√	√	√	√
2003.25	Focus	2.0L	DURATEC-HE / I4	TCM	√	√	√	√
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	CDP	√	√	√	√
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	D_DCU	√	√	√	√
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	EATC	√	√	√	√
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	EATC	√	√	√	√
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	EPS	√	√	√	√
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	FACM	√	√	√	√
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	FFH	√	√	√	√
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	GDM	√	√	√	√
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	√
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	IC	√	√	√	√
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	NAV	√	√	√	√
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	PAM	√	√	√	√
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	P_DCU	√	√	√	√
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	RETM	√	√	√	√
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	RKE	√	√	√	√
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	RL_DCU	√	√	√	√
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	RR_DCU	√	√	√	√
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	√
2003.25	Focus	2.5L	I5	ABS	√	√	√	√
2003.25	Focus	2.5L	I5	ACM	√	√	√	√
2003.25	Focus	2.5L	I5	ACM	√	√	√	√
2003.25	Focus	2.5L	I5	CDP	√	√	√	√
2003.25	Focus	2.5L	I5	D_DCU	√	√	√	√
2003.25	Focus	2.5L	I5	EATC	√	√	√	√
2003.25	Focus	2.5L	I5	EATC	√	√	√	√
2003.25	Focus	2.5L	I5	EPS	√	√	√	√
2003.25	Focus	2.5L	I5	FFH	√	√	√	√
2003.25	Focus	2.5L	I5	GDM	√	√	√	√
2003.25	Focus	2.5L	I5	GEM	√	√	√	√
2003.25	Focus	2.5L	I5	HCM	√	√	√	√
2003.25	Focus	2.5L	I5	IC	√	√	√	√

2003.25	Focus	2.5L	I5	MC	√	√	√	√
2003.25	Focus	2.5L	I5	NAV	√	√	√	√
2003.25	Focus	2.5L	I5	PAM	√	√	√	√
2003.25	Focus	2.5L	I5	PCM	√	√	√	√
2003.25	Focus	2.5L	I5	P_DCU	√	√	√	√
2003.25	Focus	2.5L	I5	RCM	√	√	√	√
2003.25	Focus	2.5L	I5	RETM	√	√	√	√
2003.25	Focus	2.5L	I5	RKE	√	√	√	√
2003.25	Focus	2.5L	I5	RL_DCU	√	√	√	√
2003.25	Focus	2.5L	I5	RR_DCU	√	√	√	√
2003.25	Focus	2.5L	I5	SRM	√	√	√	√
2003.5	Focus	2.3L	DURATEC-HE / I4	ABS/TCS	√	√	√	√
2003.5	Focus	2.3L	DURATEC-HE / I4	GEM	√	√	√	√
2003.5	Focus	2.3L	DURATEC-HE / I4	IC	√	√	√	√
2003.5	Focus	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2003.5	Focus	2.3L	DURATEC-HE / I4	RCM	√	√	√	√
2004	Focus	2.0L	SPI	ABS/TCS	√	√	√	√
2004	Focus	2.0L	SPI	GEM	√	√	√	√
2004	Focus	2.0L	SPI	HEC	√	√	√	√
2004	Focus	2.0L	SPI	PCM	√	√	√	√
2004	Focus	2.0L	SPI	RCM	√	√	√	√
2004	Focus	2.0L	ZETEC ST	ABS/TCS	√	√	√	√
2004	Focus	2.0L	ZETEC ST	GEM	√	√	√	√
2004	Focus	2.0L	ZETEC ST	HEC	√	√	√	√
2004	Focus	2.0L	ZETEC ST	PCM	√	√	√	√
2004	Focus	2.0L	ZETEC ST	RCM	√	√	√	√
2004	Focus	2.0L	Zetec	ABS/TCS	√	√	√	√
2004	Focus	2.0L	Zetec	GEM	√	√	√	√
2004	Focus	2.0L	Zetec	HEC	√	√	√	√
2004	Focus	2.0L	Zetec	PCM	√	√	√	√
2004	Focus	2.0L	Zetec	RCM	√	√	√	√
2004	Focus	2.3L	DURATEC-HE / I4	ABS/TCS	√	√	√	√
2004	Focus	2.3L	DURATEC-HE / I4	GEM	√	√	√	√
2004	Focus	2.3L	DURATEC-HE / I4	HEC	√	√	√	√
2004	Focus	2.3L	DURATEC-HE / I4	IC	√	√	√	√
2004	Focus	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2004	Focus	2.3L	DURATEC-HE / I4	RCM	√	√	√	√
2005	Focus	2.0L	DURATEC-HE / I4	ABS	√	√	√	√
2005	Focus	2.0L	DURATEC-HE / I4	GEM	√	√	√	√
2005	Focus	2.0L	DURATEC-HE / I4	IC	√	√	√	√
2005	Focus	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2005	Focus	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2005	Focus	2.0L	DURATEC-HE / I4	RCM	√	√	√	√
2005	Focus	2.3L	DURATEC-HE / I4	ABS	√	√	√	√
2005	Focus	2.3L	DURATEC-HE / I4	GEM	√	√	√	√

2005	Focus	2.3L	DURATEC-HE / I4	IC	√	√	√	√
2005	Focus	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2005.5	Focus	2.0L	DURATEC 16V	ABS/TCS	√	√	√	√
2005.5	Focus	2.0L	DURATEC 16V	EATC	√	√	√	√
2005.5	Focus	2.0L	DURATEC 16V	GEM	√	√	√	√
2005.5	Focus	2.0L	DURATEC 16V	HCM	√	√	√	√
2005.5	Focus	2.0L	DURATEC 16V	IC	√	√	√	√
2005.5	Focus	2.0L	DURATEC 16V	MC	√	√	√	√
2005.5	Focus	2.0L	DURATEC 16V	PCM	√	√	√	√
2005.5	Focus	2.0L	DURATEC 16V	RCM	√	√	√	√
2006	Focus	2.0L	DURATEC-HE / I4	ABS	√	√	√	√
2006	Focus	2.0L	DURATEC-HE / I4	GEM	√	√	√	√
2006	Focus	2.0L	DURATEC-HE / I4	IC	√	√	√	√
2006	Focus	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2006	Focus	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2006	Focus	2.0L	DURATEC-HE / I4	RCM	√	√	√	√
2006	Focus	2.3L	DURATEC-HE / I4	ABS	√	√	√	√
2006	Focus	2.3L	DURATEC-HE / I4	GEM	√	√	√	√
2006	Focus	2.3L	DURATEC-HE / I4	IC	√	√	√	√
2006	Focus	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2006	Focus	2.3L	DURATEC-HE / I4	RCM	√	√	√	√
2007	Focus	1.6L	FFV	ABS/TCS	√	√	√	√
2007	Focus	1.6L	FFV	GEM	√	√	√	√
2007	Focus	1.6L	FFV	IC	√	√	√	√
2007	Focus	1.6L	FFV	PCM	√	√	√	√
2007	Focus	1.6L	FFV	RCM	√	√	√	√
2007	Focus	2.0L	DURATEC-HE / I4	ABS	√	√	√	√
2007	Focus	2.0L	DURATEC-HE / I4	ABS	√	√	√	√
2007	Focus	2.0L	DURATEC-HE / I4	GEM	√	√	√	√
2007	Focus	2.0L	DURATEC-HE / I4	IC	√	√	√	√
2007	Focus	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2007	Focus	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2007	Focus	2.0L	DURATEC-HE / I4	RCM	√	√	√	√
2007	Focus	2.3L	DURATEC-HE / I4	ABS	√	√	√	√
2007	Focus	2.3L	DURATEC-HE / I4	GEM	√	√	√	√
2007	Focus	2.3L	DURATEC-HE / I4	IC	√	√	√	√
2007	Focus	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2007	Focus	2.3L	DURATEC-HE / I4	RCM	√	√	√	√
2007.5	Focus	1.4L	DURATEC 16V	ABS	√	√	√	√
2007.5	Focus	1.4L	DURATEC 16V	ACM	√	√	√	√
2007.5	Focus	1.4L	DURATEC 16V	CDP	√	√	√	√
2007.5	Focus	1.4L	DURATEC 16V	D_DCU	√	√	√	√
2007.5	Focus	1.4L	DURATEC 16V	EATC	√	√	√	√
2007.5	Focus	1.4L	DURATEC 16V	FFH	√	√	√	√
2007.5	Focus	1.4L	DURATEC 16V	GDM	√	√	√	√

2007.5	Focus	1.4L	DURATEC 16V	GEM	√	√	√	√
2007.5	Focus	1.4L	DURATEC 16V	HCM	√	√	√	√
2007.5	Focus	1.4L	DURATEC 16V	IC	√	√	√	√
2007.5	Focus	1.4L	DURATEC 16V	NAV	√	√	√	√
2007.5	Focus	1.4L	DURATEC 16V	PAM	√	√	√	√
2007.5	Focus	1.4L	DURATEC 16V	PCM	√	√	√	√
2007.5	Focus	1.4L	DURATEC 16V	P_DCU	√	√	√	√
2007.5	Focus	1.4L	DURATEC 16V	RCM	√	√	√	√
2007.5	Focus	1.4L	DURATEC 16V	RETM	√	√	√	√
2007.5	Focus	1.4L	DURATEC 16V	RKE	√	√	√	√
2007.5	Focus	1.4L	DURATEC 16V	SRM	√	√	√	√
2007.5	Focus	1.6L	DURATEC 16V	ABS	√	√	√	√
2007.5	Focus	1.6L	DURATEC 16V	ACM	√	√	√	√
2007.5	Focus	1.6L	DURATEC 16V	CDP	√	√	√	√
2007.5	Focus	1.6L	DURATEC 16V	D_DCU	√	√	√	√
2007.5	Focus	1.6L	DURATEC 16V	EATC	√	√	√	√
2007.5	Focus	1.6L	DURATEC 16V	FFH	√	√	√	√
2007.5	Focus	1.6L	DURATEC 16V	GDM	√	√	√	√
2007.5	Focus	1.6L	DURATEC 16V	GEM	√	√	√	√
2007.5	Focus	1.6L	DURATEC 16V	HCM	√	√	√	√
2007.5	Focus	1.6L	DURATEC 16V	IC	√	√	√	√
2007.5	Focus	1.6L	DURATEC 16V	NAV	√	√	√	√
2007.5	Focus	1.6L	DURATEC 16V	PAM	√	√	√	√
2007.5	Focus	1.6L	DURATEC 16V	PCM	√	√	√	√
2007.5	Focus	1.6L	DURATEC 16V	P_DCU	√	√	√	√
2007.5	Focus	1.6L	DURATEC 16V	RCM	√	√	√	√
2007.5	Focus	1.6L	DURATEC 16V	RETM	√	√	√	√
2007.5	Focus	1.6L	DURATEC 16V	RKE	√	√	√	√
2007.5	Focus	1.6L	DURATEC 16V	SRM	√	√	√	√
2007.5	Focus	1.6L	DURATEC 16V	TCM	√	√	√	√
2007.5	Focus	1.6L	DURATEC VCT	ABS	√	√	√	√
2007.5	Focus	1.6L	DURATEC VCT	ACM	√	√	√	√
2007.5	Focus	1.6L	DURATEC VCT	CDP	√	√	√	√
2007.5	Focus	1.6L	DURATEC VCT	D_DCU	√	√	√	√
2007.5	Focus	1.6L	DURATEC VCT	EATC	√	√	√	√
2007.5	Focus	1.6L	DURATEC VCT	FFH	√	√	√	√
2007.5	Focus	1.6L	DURATEC VCT	GDM	√	√	√	√
2007.5	Focus	1.6L	DURATEC VCT	GEM	√	√	√	√
2007.5	Focus	1.6L	DURATEC VCT	HCM	√	√	√	√
2007.5	Focus	1.6L	DURATEC VCT	IC	√	√	√	√
2007.5	Focus	1.6L	DURATEC VCT	NAV	√	√	√	√
2007.5	Focus	1.6L	DURATEC VCT	PAM	√	√	√	√
2007.5	Focus	1.6L	DURATEC VCT	P_DCU	√	√	√	√
2007.5	Focus	1.6L	DURATEC VCT	RCM	√	√	√	√
2007.5	Focus	1.6L	DURATEC VCT	RETM	√	√	√	√

2007.5	Focus	1.6L	DURATEC VCT	RKE	√	√	√	√
2007.5	Focus	1.6L	DURATEC VCT	SRM	√	√	√	√
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail	CDP	√	√	√	√
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail	D_DCU	√	√	√	√
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail	EATC	√	√	√	√
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail	EPS	√	√	√	√
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail	FACM	√	√	√	√
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail	FFH	√	√	√	√
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail	GDM	√	√	√	√
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail	GEM	√	√	√	√
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	√
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail	IC	√	√	√	√
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail	NAV	√	√	√	√
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail	PAM	√	√	√	√
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail	P_DCU	√	√	√	√
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail	RETM	√	√	√	√
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail	RKE	√	√	√	√
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	ABS	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	ABS	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	ABS	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	ACM	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	ACM	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	CDP	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	CDP	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	D_DCU	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	D_DCU	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	EATC	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	EATC	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	EPS	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	FFH	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	FFH	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	GDM	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	GDM	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	GDM	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	GEM	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	GEM	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	HCM	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	HCM	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	HCM	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	IC	√	√	√	√



2007.5	Focus	1.8L	DURATEC-HE / I4	IC	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	NAV	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	PAM	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	PAM	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	PCM	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	PCM	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	P_DCU	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	P_DCU	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	RCM	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	RCM	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	RETM	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	RETM	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	RKE	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	RKE	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	SRM	√	√	√	√
2007.5	Focus	1.8L	DURATEC-HE / I4	TCM	√	√	√	√
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail	CDP	√	√	√	√
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail	D_DCU	√	√	√	√
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail	EATC	√	√	√	√
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail	EPS	√	√	√	√
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail	FFH	√	√	√	√
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail	GDM	√	√	√	√
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail	GEM	√	√	√	√
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	√
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail	IC	√	√	√	√
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail	NAV	√	√	√	√
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail	PAM	√	√	√	√
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail	P_DCU	√	√	√	√
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail	RETM	√	√	√	√
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail	RKE	√	√	√	√
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	√
2007.5	Focus	2.0L	DURATEC-HE / I4	ABS	√	√	√	√
2007.5	Focus	2.0L	DURATEC-HE / I4	ABS	√	√	√	√
2007.5	Focus	2.0L	DURATEC-HE / I4	ABS	√	√	√	√
2007.5	Focus	2.0L	DURATEC-HE / I4	ACM	√	√	√	√
2007.5	Focus	2.0L	DURATEC-HE / I4	CDP	√	√	√	√
2007.5	Focus	2.0L	DURATEC-HE / I4	D_DCU	√	√	√	√
2007.5	Focus	2.0L	DURATEC-HE / I4	EATC	√	√	√	√
2007.5	Focus	2.0L	DURATEC-HE / I4	EPS	√	√	√	√
2007.5	Focus	2.0L	DURATEC-HE / I4	FFH	√	√	√	√
2007.5	Focus	2.0L	DURATEC-HE / I4	FFH	√	√	√	√

2007.5	Focus	2.0L	DURATEC-HE / I4	GDM	√	√	√	√
2007.5	Focus	2.0L	DURATEC-HE / I4	GDM	√	√	√	√
2007.5	Focus	2.0L	DURATEC-HE / I4	GEM	√	√	√	√
2007.5	Focus	2.0L	DURATEC-HE / I4	HCM	√	√	√	√
2007.5	Focus	2.0L	DURATEC-HE / I4	HCM	√	√	√	√
2007.5	Focus	2.0L	DURATEC-HE / I4	IC	√	√	√	√
2007.5	Focus	2.0L	DURATEC-HE / I4	NAV	√	√	√	√
2007.5	Focus	2.0L	DURATEC-HE / I4	PAM	√	√	√	√
2007.5	Focus	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2007.5	Focus	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2007.5	Focus	2.0L	DURATEC-HE / I4	P_DCU	√	√	√	√
2007.5	Focus	2.0L	DURATEC-HE / I4	RCM	√	√	√	√
2007.5	Focus	2.0L	DURATEC-HE / I4	RETM	√	√	√	√
2007.5	Focus	2.0L	DURATEC-HE / I4	RKE	√	√	√	√
2007.5	Focus	2.0L	DURATEC-HE / I4	SRM	√	√	√	√
2007.5	Focus	2.0L	DURATEC-HE / I4	TCM	√	√	√	√
2007.5	Focus	2.0L	DURATEC-HE / I4	TCM	√	√	√	√
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail	CDP	√	√	√	√
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail	D_DCU	√	√	√	√
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail	EATC	√	√	√	√
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail	EPS	√	√	√	√
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail	FACM	√	√	√	√
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail	GDM	√	√	√	√
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail	GEM	√	√	√	√
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	√
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail	IC	√	√	√	√
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail	NAV	√	√	√	√
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail	PAM	√	√	√	√
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail	P_DCU	√	√	√	√
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail	RETM	√	√	√	√
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail	RKE	√	√	√	√
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	√
2007.5	Focus	2.5L	I5	ABS	√	√	√	√
2007.5	Focus	2.5L	I5	ACM	√	√	√	√
2007.5	Focus	2.5L	I5	CDP	√	√	√	√
2007.5	Focus	2.5L	I5	D_DCU	√	√	√	√
2007.5	Focus	2.5L	I5	EATC	√	√	√	√
2007.5	Focus	2.5L	I5	EPS	√	√	√	√
2007.5	Focus	2.5L	I5	FFH	√	√	√	√
2007.5	Focus	2.5L	I5	GDM	√	√	√	√
2007.5	Focus	2.5L	I5	GEM	√	√	√	√

2007.5	Focus	2.5L	I5	HCM	√	√	√	√
2007.5	Focus	2.5L	I5	IC	√	√	√	√
2007.5	Focus	2.5L	I5	MC	√	√	√	√
2007.5	Focus	2.5L	I5	NAV	√	√	√	√
2007.5	Focus	2.5L	I5	PAM	√	√	√	√
2007.5	Focus	2.5L	I5	PCM	√	√	√	√
2007.5	Focus	2.5L	I5	P_DCU	√	√	√	√
2007.5	Focus	2.5L	I5	RCM	√	√	√	√
2007.5	Focus	2.5L	I5	RETM	√	√	√	√
2007.5	Focus	2.5L	I5	RKE	√	√	√	√
2007.5	Focus	2.5L	I5	SRM	√	√	√	√
2008	Focus	2.0L	DURATEC-HE / I4	ABS	√	√	√	√
2008	Focus	2.0L	DURATEC-HE / I4	ACM	√	√	√	√
2008	Focus	2.0L	DURATEC-HE / I4	ACM	√	√	√	√
2008	Focus	2.0L	DURATEC-HE / I4	APIM	√	√	√	√
2008	Focus	2.0L	DURATEC-HE / I4	FCIM	√	√	√	√
2008	Focus	2.0L	DURATEC-HE / I4	FDIM	√	√	√	√
2008	Focus	2.0L	DURATEC-HE / I4	FDIM	√	√	√	√
2008	Focus	2.0L	DURATEC-HE / I4	GEM / SJB	√	√	√	√
2008	Focus	2.0L	DURATEC-HE / I4	GEM / SJB	√	√	√	√
2008	Focus	2.0L	DURATEC-HE / I4	HVAC	√	√	√	√
2008	Focus	2.0L	DURATEC-HE / I4	IC	√	√	√	√
2008	Focus	2.0L	DURATEC-HE / I4	IC	√	√	√	√
2008	Focus	2.0L	DURATEC-HE / I4	OCSM	√	√	√	√
2008	Focus	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2008	Focus	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2008	Focus	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2008	Focus	2.0L	DURATEC-HE / I4	RCM	√	√	√	√
2008	Focus	2.0L	DURATEC-HE / I4	RCM	√	√	√	√
2008	Focus	2.0L	DURATEC-HE / I4	SDARS	√	√	√	√
2008	Focus	2.0L	DURATEC-HE / I4	SDARS	√	√	√	√
2008.25	Focus	1.4L	DURATEC 16V	ABS	√	√	√	√
2008.25	Focus	1.4L	DURATEC 16V	ACM	√	√	√	√
2008.25	Focus	1.4L	DURATEC 16V	CDP	√	√	√	√
2008.25	Focus	1.4L	DURATEC 16V	CMR	√	√	√	√
2008.25	Focus	1.4L	DURATEC 16V	D_DCU	√	√	√	√
2008.25	Focus	1.4L	DURATEC 16V	EATC	√	√	√	√
2008.25	Focus	1.4L	DURATEC 16V	EPS	√	√	√	√
2008.25	Focus	1.4L	DURATEC 16V	FFH	√	√	√	√
2008.25	Focus	1.4L	DURATEC 16V	GEM	√	√	√	√
2008.25	Focus	1.4L	DURATEC 16V	HCM	√	√	√	√
2008.25	Focus	1.4L	DURATEC 16V	IC	√	√	√	√
2008.25	Focus	1.4L	DURATEC 16V	PAM	√	√	√	√
2008.25	Focus	1.4L	DURATEC 16V	PCM	√	√	√	√
2008.25	Focus	1.4L	DURATEC 16V	P_DCU	√	√	√	√

2008.25	Focus	1.4L	DURATEC 16V	RCM	√	√	√	√
2008.25	Focus	1.4L	DURATEC 16V	RETM	√	√	√	√
2008.25	Focus	1.4L	DURATEC 16V	RKE	√	√	√	√
2008.25	Focus	1.6L	DURATEC 16V	ABS	√	√	√	√
2008.25	Focus	1.6L	DURATEC 16V	ACM	√	√	√	√
2008.25	Focus	1.6L	DURATEC 16V	CDP	√	√	√	√
2008.25	Focus	1.6L	DURATEC 16V	CMR	√	√	√	√
2008.25	Focus	1.6L	DURATEC 16V	D_DCU	√	√	√	√
2008.25	Focus	1.6L	DURATEC 16V	EATC	√	√	√	√
2008.25	Focus	1.6L	DURATEC 16V	EPS	√	√	√	√
2008.25	Focus	1.6L	DURATEC 16V	FFH	√	√	√	√
2008.25	Focus	1.6L	DURATEC 16V	GEM	√	√	√	√
2008.25	Focus	1.6L	DURATEC 16V	HCM	√	√	√	√
2008.25	Focus	1.6L	DURATEC 16V	IC	√	√	√	√
2008.25	Focus	1.6L	DURATEC 16V	PAM	√	√	√	√
2008.25	Focus	1.6L	DURATEC 16V	PCM	√	√	√	√
2008.25	Focus	1.6L	DURATEC 16V	P_DCU	√	√	√	√
2008.25	Focus	1.6L	DURATEC 16V	RCM	√	√	√	√
2008.25	Focus	1.6L	DURATEC 16V	RETM	√	√	√	√
2008.25	Focus	1.6L	DURATEC 16V	RKE	√	√	√	√
2008.25	Focus	1.6L	DURATEC 16V	SRM	√	√	√	√
2008.25	Focus	1.6L	DURATEC 16V	TCM	√	√	√	√
2008.25	Focus	1.6L	DURATEC VCT	ABS	√	√	√	√
2008.25	Focus	1.6L	DURATEC VCT	ACM	√	√	√	√
2008.25	Focus	1.6L	DURATEC VCT	CDP	√	√	√	√
2008.25	Focus	1.6L	DURATEC VCT	CMR	√	√	√	√
2008.25	Focus	1.6L	DURATEC VCT	D_DCU	√	√	√	√
2008.25	Focus	1.6L	DURATEC VCT	EATC	√	√	√	√
2008.25	Focus	1.6L	DURATEC VCT	EPS	√	√	√	√
2008.25	Focus	1.6L	DURATEC VCT	FFH	√	√	√	√
2008.25	Focus	1.6L	DURATEC VCT	GEM	√	√	√	√
2008.25	Focus	1.6L	DURATEC VCT	HCM	√	√	√	√
2008.25	Focus	1.6L	DURATEC VCT	IC	√	√	√	√
2008.25	Focus	1.6L	DURATEC VCT	PAM	√	√	√	√
2008.25	Focus	1.6L	DURATEC VCT	PCM	√	√	√	√
2008.25	Focus	1.6L	DURATEC VCT	P_DCU	√	√	√	√
2008.25	Focus	1.6L	DURATEC VCT	RCM	√	√	√	√
2008.25	Focus	1.6L	DURATEC VCT	RETM	√	√	√	√
2008.25	Focus	1.6L	DURATEC VCT	RKE	√	√	√	√
2008.25	Focus	1.6L	DURATEC VCT	SRM	√	√	√	√
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	CDP	√	√	√	√
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	CMR	√	√	√	√
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	D_DCU	√	√	√	√





2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail	GEM	√	√	√	√
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	√
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail	IC	√	√	√	√
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail	PAM	√	√	√	√
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail	P_DCU	√	√	√	√
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail	RETM	√	√	√	√
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail	RKE	√	√	√	√
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	√
2008.25	Focus	2.0L	DURATEC-HE / I4	ABS	√	√	√	√
2008.25	Focus	2.0L	DURATEC-HE / I4	ABS	√	√	√	√
2008.25	Focus	2.0L	DURATEC-HE / I4	ACM	√	√	√	√
2008.25	Focus	2.0L	DURATEC-HE / I4	ACM	√	√	√	√
2008.25	Focus	2.0L	DURATEC-HE / I4	CDP	√	√	√	√
2008.25	Focus	2.0L	DURATEC-HE / I4	CMR	√	√	√	√
2008.25	Focus	2.0L	DURATEC-HE / I4	D_DCU	√	√	√	√
2008.25	Focus	2.0L	DURATEC-HE / I4	D_DCU	√	√	√	√
2008.25	Focus	2.0L	DURATEC-HE / I4	EATC	√	√	√	√
2008.25	Focus	2.0L	DURATEC-HE / I4	EPS	√	√	√	√
2008.25	Focus	2.0L	DURATEC-HE / I4	FFH	√	√	√	√
2008.25	Focus	2.0L	DURATEC-HE / I4	FFH	√	√	√	√
2008.25	Focus	2.0L	DURATEC-HE / I4	GEM	√	√	√	√
2008.25	Focus	2.0L	DURATEC-HE / I4	GEM	√	√	√	√
2008.25	Focus	2.0L	DURATEC-HE / I4	HCM	√	√	√	√
2008.25	Focus	2.0L	DURATEC-HE / I4	HCM	√	√	√	√
2008.25	Focus	2.0L	DURATEC-HE / I4	IC	√	√	√	√
2008.25	Focus	2.0L	DURATEC-HE / I4	IC	√	√	√	√
2008.25	Focus	2.0L	DURATEC-HE / I4	PAM	√	√	√	√
2008.25	Focus	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2008.25	Focus	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2008.25	Focus	2.0L	DURATEC-HE / I4	P_DCU	√	√	√	√
2008.25	Focus	2.0L	DURATEC-HE / I4	P_DCU	√	√	√	√
2008.25	Focus	2.0L	DURATEC-HE / I4	RCM	√	√	√	√
2008.25	Focus	2.0L	DURATEC-HE / I4	RCM	√	√	√	√
2008.25	Focus	2.0L	DURATEC-HE / I4	RCM	√	√	√	√
2008.25	Focus	2.0L	DURATEC-HE / I4	RETM	√	√	√	√
2008.25	Focus	2.0L	DURATEC-HE / I4	RKE	√	√	√	√
2008.25	Focus	2.0L	DURATEC-HE / I4	SRM	√	√	√	√
2008.25	Focus	2.0L	DURATEC-HE / I4	TCM	√	√	√	√
2008.25	Focus	2.0L	DURATEC-HE / I4	TCM	√	√	√	√
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√

2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	CDP	√	√	√	√
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	CMR	√	√	√	√
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	D_DCU	√	√	√	√
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	D_DCU	√	√	√	√
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	EATC	√	√	√	√
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	EPS	√	√	√	√
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	FACM	√	√	√	√
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	FACM	√	√	√	√
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	FFH	√	√	√	√
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	FFH	√	√	√	√
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	GEM	√	√	√	√
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	GEM	√	√	√	√
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	√
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	√
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	IC	√	√	√	√
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	PAM	√	√	√	√
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	P_DCU	√	√	√	√
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	P_DCU	√	√	√	√
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	RETM	√	√	√	√
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	RKE	√	√	√	√
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	√
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	TCM	√	√	√	√
2008.25	Focus	2.5L	Duratec RS	ABS	√	√	√	√
2008.25	Focus	2.5L	Duratec RS	ABS	√	√	√	√
2008.25	Focus	2.5L	Duratec RS	ACM	√	√	√	√
2008.25	Focus	2.5L	Duratec RS	CDP	√	√	√	√
2008.25	Focus	2.5L	Duratec RS	CMR	√	√	√	√
2008.25	Focus	2.5L	Duratec RS	D_DCU	√	√	√	√
2008.25	Focus	2.5L	Duratec RS	EATC	√	√	√	√
2008.25	Focus	2.5L	Duratec RS	EPS	√	√	√	√
2008.25	Focus	2.5L	Duratec RS	FFH	√	√	√	√
2008.25	Focus	2.5L	Duratec RS	GEM	√	√	√	√
2008.25	Focus	2.5L	Duratec RS	HCM	√	√	√	√
2008.25	Focus	2.5L	Duratec RS	IC	√	√	√	√
2008.25	Focus	2.5L	Duratec RS	MC	√	√	√	√
2008.25	Focus	2.5L	Duratec RS	PAM	√	√	√	√
2008.25	Focus	2.5L	Duratec RS	PCM	√	√	√	√
2008.25	Focus	2.5L	Duratec RS	P_DCU	√	√	√	√
2008.25	Focus	2.5L	Duratec RS	RCM	√	√	√	√
2008.25	Focus	2.5L	Duratec RS	RETM	√	√	√	√
2008.25	Focus	2.5L	Duratec RS	RKE	√	√	√	√



2008.25	Focus	2.5L	Duratec RS	SRM	√	√	√	√
2008.25	Focus	2.5L	I5	ABS	√	√	√	√
2008.25	Focus	2.5L	I5	ABS	√	√	√	√
2008.25	Focus	2.5L	I5	ACM	√	√	√	√
2008.25	Focus	2.5L	I5	ACM	√	√	√	√
2008.25	Focus	2.5L	I5	CDP	√	√	√	√
2008.25	Focus	2.5L	I5	CDP	√	√	√	√
2008.25	Focus	2.5L	I5	CMR	√	√	√	√
2008.25	Focus	2.5L	I5	D_DCU	√	√	√	√
2008.25	Focus	2.5L	I5	EATC	√	√	√	√
2008.25	Focus	2.5L	I5	EPS	√	√	√	√
2008.25	Focus	2.5L	I5	FFH	√	√	√	√
2008.25	Focus	2.5L	I5	GEM	√	√	√	√
2008.25	Focus	2.5L	I5	GEM	√	√	√	√
2008.25	Focus	2.5L	I5	HCM	√	√	√	√
2008.25	Focus	2.5L	I5	HCM	√	√	√	√
2008.25	Focus	2.5L	I5	IC	√	√	√	√
2008.25	Focus	2.5L	I5	IC	√	√	√	√
2008.25	Focus	2.5L	I5	MC	√	√	√	√
2008.25	Focus	2.5L	I5	PAM	√	√	√	√
2008.25	Focus	2.5L	I5	PCM	√	√	√	√
2008.25	Focus	2.5L	I5	P_DCU	√	√	√	√
2008.25	Focus	2.5L	I5	RCM	√	√	√	√
2008.25	Focus	2.5L	I5	RCM	√	√	√	√
2008.25	Focus	2.5L	I5	RETM	√	√	√	√
2008.25	Focus	2.5L	I5	RETM	√	√	√	√
2008.25	Focus	2.5L	I5	RKE	√	√	√	√
2008.25	Focus	2.5L	I5	SRM	√	√	√	√
2008.25	Focus	2.5L	I5	SRM	√	√	√	√
2009	Focus	1.6L	FFV	ABS/TCS	√	√	√	√
2009	Focus	1.6L	FFV	EATC	√	√	√	√
2009	Focus	1.6L	FFV	GEM	√	√	√	√
2009	Focus	1.6L	FFV	HCM	√	√	√	√
2009	Focus	1.6L	FFV	IC	√	√	√	√
2009	Focus	1.6L	FFV	MC	√	√	√	√
2009	Focus	1.6L	FFV	PCM	√	√	√	√
2009	Focus	1.6L	FFV	RCM	√	√	√	√
2009	Focus	1.6L	OHC	ABS/TCS	√	√	√	√
2009	Focus	1.6L	OHC	EATC	√	√	√	√
2009	Focus	1.6L	OHC	GEM	√	√	√	√
2009	Focus	1.6L	OHC	HCM	√	√	√	√
2009	Focus	1.6L	OHC	IC	√	√	√	√
2009	Focus	1.6L	OHC	MC	√	√	√	√
2009	Focus	1.6L	OHC	PCM	√	√	√	√
2009	Focus	1.6L	OHC	RCM	√	√	√	√

2009	Focus	2.0L	DURATEC-HE / I4	ABS	√	√	√	√
2009	Focus	2.0L	DURATEC-HE / I4	APIM	√	√	√	√
2009	Focus	2.0L	DURATEC-HE / I4	FCIM	√	√	√	√
2009	Focus	2.0L	DURATEC-HE / I4	FDIM	√	√	√	√
2009	Focus	2.0L	DURATEC-HE / I4	GEM / SJB	√	√	√	√
2009	Focus	2.0L	DURATEC-HE / I4	HVAC	√	√	√	√
2009	Focus	2.0L	DURATEC-HE / I4	IC	√	√	√	√
2009	Focus	2.0L	DURATEC-HE / I4	OCSM	√	√	√	√
2009	Focus	2.0L	DURATEC-HE / I4	OCSM	√	√	√	√
2009	Focus	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2009	Focus	2.0L	DURATEC-HE / I4	RCM	√	√	√	√
2010	Focus	1.6L	FFV	ABS	√	√	√	√
2010	Focus	1.6L	FFV	ACM	√	√	√	√
2010	Focus	1.6L	FFV	D_DCU	√	√	√	√
2010	Focus	1.6L	FFV	EATC	√	√	√	√
2010	Focus	1.6L	FFV	EPS	√	√	√	√
2010	Focus	1.6L	FFV	GEM	√	√	√	√
2010	Focus	1.6L	FFV	HCM	√	√	√	√
2010	Focus	1.6L	FFV	IC	√	√	√	√
2010	Focus	1.6L	FFV	PAM	√	√	√	√
2010	Focus	1.6L	FFV	PCM	√	√	√	√
2010	Focus	1.6L	FFV	PCM	√	√	√	√
2010	Focus	1.6L	FFV	P_DCU	√	√	√	√
2010	Focus	1.6L	FFV	RCM	√	√	√	√
2010	Focus	1.6L	FFV	RKE	√	√	√	√
2010	Focus	1.6L	FFV	SRM	√	√	√	√
2010	Focus	1.6L	FFV	TBM	√	√	√	√
2010	Focus	1.6L	FFV	TCM	√	√	√	√
2010	Focus	1.6L	FFV	TCM	√	√	√	√
2010	Focus	1.6L	Sigma	ABS	√	√	√	√
2010	Focus	1.6L	Sigma	ACM	√	√	√	√
2010	Focus	1.6L	Sigma	D_DCU	√	√	√	√
2010	Focus	1.6L	Sigma	EATC	√	√	√	√
2010	Focus	1.6L	Sigma	EPS	√	√	√	√
2010	Focus	1.6L	Sigma	GEM	√	√	√	√
2010	Focus	1.6L	Sigma	HCM	√	√	√	√
2010	Focus	1.6L	Sigma	IC	√	√	√	√
2010	Focus	1.6L	Sigma	PAM	√	√	√	√
2010	Focus	1.6L	Sigma	PCM	√	√	√	√
2010	Focus	1.6L	Sigma	P_DCU	√	√	√	√
2010	Focus	1.6L	Sigma	RCM	√	√	√	√
2010	Focus	1.6L	Sigma	RKE	√	√	√	√
2010	Focus	1.6L	Sigma	SRM	√	√	√	√
2010	Focus	1.6L	Sigma	TBM	√	√	√	√
2010	Focus	1.6L	Sigma	TCM	√	√	√	√

2010	Focus	2.0L	DURATEC-HE / I4	ABS	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	ABS	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	ABS	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	ACM	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	ACM	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	APIM	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	D_DCU	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	EATC	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	EPS	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	FCIM	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	FDIM	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	GEM	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	GEM / SJB	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	GPSM	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	HCM	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	HCM	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	HVAC	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	IC	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	IC	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	OCSM	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	PAM	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	P_DCU	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	RCM	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	RCM	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	RKE	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	SRM	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	TBM	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	TBM	√	√	√	√
2010	Focus	2.0L	DURATEC-HE / I4	TCM	√	√	√	√
2010	Focus	2.0L	FFV	ABS	√	√	√	√
2010	Focus	2.0L	FFV	ABS	√	√	√	√
2010	Focus	2.0L	FFV	D_DCU	√	√	√	√
2010	Focus	2.0L	FFV	EATC	√	√	√	√
2010	Focus	2.0L	FFV	EPS	√	√	√	√
2010	Focus	2.0L	FFV	GEM	√	√	√	√
2010	Focus	2.0L	FFV	HCM	√	√	√	√
2010	Focus	2.0L	FFV	HCM	√	√	√	√
2010	Focus	2.0L	FFV	IC	√	√	√	√
2010	Focus	2.0L	FFV	PAM	√	√	√	√
2010	Focus	2.0L	FFV	PCM	√	√	√	√
2010	Focus	2.0L	FFV	PCM	√	√	√	√

2010	Focus	2.0L	FFV	PCM	✓	✓	✓	✓
2010	Focus	2.0L	FFV	P_DCU	✓	✓	✓	✓
2010	Focus	2.0L	FFV	RCM	✓	✓	✓	✓
2010	Focus	2.0L	FFV	RKE	✓	✓	✓	✓
2010	Focus	2.0L	FFV	SRM	✓	✓	✓	✓
2010	Focus	2.0L	FFV	TBM	✓	✓	✓	✓
2010	Focus	2.0L	FFV	TBM	✓	✓	✓	✓
2010	Focus	2.0L	FFV	TCM	✓	✓	✓	✓
2010	Focus	2.0L	FFV	TCM	✓	✓	✓	✓
2011	Focus	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓
2011	Focus	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓
2011	Focus	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓
2011	Focus	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓
2011	Focus	2.0L	DURATEC-HE / I4	APIM	✓	✓	✓	✓
2011	Focus	2.0L	DURATEC-HE / I4	FCIM	✓	✓	✓	✓
2011	Focus	2.0L	DURATEC-HE / I4	FDIM	✓	✓	✓	✓
2011	Focus	2.0L	DURATEC-HE / I4	FDIM	✓	✓	✓	✓
2011	Focus	2.0L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓
2011	Focus	2.0L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓
2011	Focus	2.0L	DURATEC-HE / I4	GPSM	✓	✓	✓	✓
2011	Focus	2.0L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓
2011	Focus	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓
2011	Focus	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓
2011	Focus	2.0L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓
2011	Focus	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓
2011	Focus	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓
2011	Focus	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓
2011.25	Focus	1.0L	EcoBoost - Gas Turbocharged Direct	ABS	✓	✓	✓	
2011.25	Focus	1.0L	EcoBoost - Gas Turbocharged Direct	ACM	✓	✓	✓	✓
2011.25	Focus	1.0L	EcoBoost - Gas Turbocharged Direct	AHCM	✓	✓	✓	✓
2011.25	Focus	1.0L	EcoBoost - Gas Turbocharged Direct	APIM	✓	✓	✓	✓
2011.25	Focus	1.0L	EcoBoost - Gas Turbocharged Direct	BCMii	✓	✓	✓	
2011.25	Focus	1.0L	EcoBoost - Gas Turbocharged Direct	BCMii	✓	✓	✓	✓
2011.25	Focus	1.0L	EcoBoost - Gas Turbocharged Direct	CCMii	✓	✓	✓	✓
2011.25	Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓
2011.25	Focus	1.0L	EcoBoost - Gas Turbocharged Direct	DSP	✓	✓	✓	✓
2011.25	Focus	1.0L	EcoBoost - Gas Turbocharged Direct	FCDIM	✓	✓	✓	✓
2011.25	Focus	1.0L	EcoBoost - Gas Turbocharged Direct	FCIM	✓	✓	✓	
2011.25	Focus	1.0L	EcoBoost - Gas Turbocharged Direct	FDSM	✓	✓	✓	
2011.25	Focus	1.0L	EcoBoost - Gas Turbocharged Direct	GPSM	✓	✓	✓	
2011.25	Focus	1.0L	EcoBoost - Gas Turbocharged Direct	HCM	✓	✓	✓	
2011.25	Focus	1.0L	EcoBoost - Gas Turbocharged Direct	HVAC	✓	✓	✓	
2011.25	Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓

2011.25	Focus	1.0L	EcoBoost - Gas Turbocharged Direct	IPM-B	√	√	√	√
2011.25	Focus	1.0L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2011.25	Focus	1.0L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2011.25	Focus	1.0L	EcoBoost - Gas Turbocharged Direct	PDM	√	√	√	√
2011.25	Focus	1.0L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2011.25	Focus	1.0L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2011.25	Focus	1.0L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	√
2011.25	Focus	1.0L	EcoBoost - Gas Turbocharged Direct	SASM	√	√	√	√
2011.25	Focus	1.0L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	
2011.25	Focus	1.0L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	
2011.25	Focus	1.0L	EcoBoost - Gas Turbocharged Direct	SRM	√	√	√	
2011.25	Focus	1.0L	EcoBoost - Gas Turbocharged Direct	TRM	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	ABS	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	ABS	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	ACM	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	AHCM	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	AHCM	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	APIM	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	BCMii	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	BCMii	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	BCMii	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	CCMii	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	CCMii	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	DDM	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	DDM	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	DDM	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	DSP	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	FCDIM	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	FCIM	√	√	√	
2011.25	Focus	1.6L	DURATEC VCT	FDSM	√	√	√	
2011.25	Focus	1.6L	DURATEC VCT	GPSM	√	√	√	
2011.25	Focus	1.6L	DURATEC VCT	HCM	√	√	√	
2011.25	Focus	1.6L	DURATEC VCT	HCM	√	√	√	
2011.25	Focus	1.6L	DURATEC VCT	HVAC	√	√	√	
2011.25	Focus	1.6L	DURATEC VCT	IPC	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	IPC	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	IPM-A	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	IPM-A	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	IPM-B	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	PAM	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	PCM	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	PCM	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	PCM	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	PDM	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	PDM	√	√	√	√

2011.25	Focus	1.6L	DURATEC VCT	PDM	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	PSCM	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	PSCM	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	RCM	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	RCM	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	RFA	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	SASM	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	SOD-L	√	√	√	
2011.25	Focus	1.6L	DURATEC VCT	SOD-R	√	√	√	
2011.25	Focus	1.6L	DURATEC VCT	SRM	√	√	√	
2011.25	Focus	1.6L	DURATEC VCT	TCM	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	TCM	√	√	√	√
2011.25	Focus	1.6L	DURATEC VCT	TRM	√	√	√	√
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	APIM	√	√	√	√
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	BCMii	√	√	√	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	BCMii	√	√	√	√
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	CCMii	√	√	√	√
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	DDM	√	√	√	√
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	DSP	√	√	√	√
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	FCDIM	√	√	√	√
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	FCIM	√	√	√	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	FDSM	√	√	√	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	GPSM	√	√	√	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	HVAC	√	√	√	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	IPC	√	√	√	√
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	IPM-A	√	√	√	√
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	IPM-B	√	√	√	√
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	PAM	√	√	√	√
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	PDM	√	√	√	√
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	PSCM	√	√	√	√
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	RFA	√	√	√	√
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	SASM	√	√	√	√
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	SOD-L	√	√	√	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	SOD-R	√	√	√	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail	TRM	√	√	√	√
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct	AHCM	√	√	√	√

2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct	BCMii	√	√	√	
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct	BCMii	√	√	√	√
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct	CCMii	√	√	√	√
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	√
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	√
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSP	√	√	√	√
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct	FDSM	√	√	√	
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct	HCM	√	√	√	
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct	IPM-A	√	√	√	√
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct	IPM-A	√	√	√	√
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct	IPM-B	√	√	√	√
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct	PDM	√	√	√	√
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct	PDM	√	√	√	√
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	√
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct	SASM	√	√	√	√
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM	√	√	√	
2011.25	Focus	1.6L	EcoBoost - Gas Turbocharged Direct	TRM	√	√	√	√
2011.25	Focus	1.6L	TDCi ECO III	ABS	√	√	√	
2011.25	Focus	1.6L	TDCi ECO III	ACM	√	√	√	√
2011.25	Focus	1.6L	TDCi ECO III	AHCM	√	√	√	√
2011.25	Focus	1.6L	TDCi ECO III	APIM	√	√	√	√
2011.25	Focus	1.6L	TDCi ECO III	BCMii	√	√	√	
2011.25	Focus	1.6L	TDCi ECO III	BCMii	√	√	√	
2011.25	Focus	1.6L	TDCi ECO III	BCMii	√	√	√	√
2011.25	Focus	1.6L	TDCi ECO III	CCMii	√	√	√	√
2011.25	Focus	1.6L	TDCi ECO III	DDM	√	√	√	√
2011.25	Focus	1.6L	TDCi ECO III	DSP	√	√	√	√
2011.25	Focus	1.6L	TDCi ECO III	FCDIM	√	√	√	√
2011.25	Focus	1.6L	TDCi ECO III	FCIM	√	√	√	
2011.25	Focus	1.6L	TDCi ECO III	FDSM	√	√	√	
2011.25	Focus	1.6L	TDCi ECO III	GPSM	√	√	√	

2011.25	Focus	1.6L	TDCi ECO III	HCM	√	√	√	
2011.25	Focus	1.6L	TDCi ECO III	HVAC	√	√	√	
2011.25	Focus	1.6L	TDCi ECO III	IPC	√	√	√	√
2011.25	Focus	1.6L	TDCi ECO III	IPM-A	√	√	√	√
2011.25	Focus	1.6L	TDCi ECO III	IPM-B	√	√	√	√
2011.25	Focus	1.6L	TDCi ECO III	PAM	√	√	√	√
2011.25	Focus	1.6L	TDCi ECO III	PCM	√	√	√	√
2011.25	Focus	1.6L	TDCi ECO III	PDM	√	√	√	√
2011.25	Focus	1.6L	TDCi ECO III	PSCM	√	√	√	√
2011.25	Focus	1.6L	TDCi ECO III	RCM	√	√	√	√
2011.25	Focus	1.6L	TDCi ECO III	RFA	√	√	√	√
2011.25	Focus	1.6L	TDCi ECO III	SASM	√	√	√	√
2011.25	Focus	1.6L	TDCi ECO III	SOD-L	√	√	√	
2011.25	Focus	1.6L	TDCi ECO III	SOD-R	√	√	√	
2011.25	Focus	1.6L	TDCi ECO III	SRM	√	√	√	
2011.25	Focus	1.6L	TDCi ECO III	TRM	√	√	√	√
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	AHCM	√	√	√	√
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	APIM	√	√	√	√
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	BCMii	√	√	√	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	BCMii	√	√	√	√
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	CCMii	√	√	√	√
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	DDM	√	√	√	√
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	DSP	√	√	√	√
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	FCDIM	√	√	√	√
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	FCIM	√	√	√	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	FDSM	√	√	√	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	GPSM	√	√	√	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	HVAC	√	√	√	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	IPC	√	√	√	√
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	IPM-A	√	√	√	√
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	IPM-B	√	√	√	√
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	PAM	√	√	√	√
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	PDM	√	√	√	√
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	PSCM	√	√	√	√
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	RFA	√	√	√	√
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	SASM	√	√	√	√
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	SOD-L	√	√	√	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	SOD-R	√	√	√	



2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	TCM	√	√	√	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail	TRM	√	√	√	√
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	BCMii	√	√	√	
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	BCMii	√	√	√	
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	BCMii	√	√	√	√
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	CCMii	√	√	√	√
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	√
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	DSP	√	√	√	√
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	FCDIM	√	√	√	√
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	FDSM	√	√	√	
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	HCM	√	√	√	
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	ICM#1	√	√	√	
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	IPM-A	√	√	√	√
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	IPM-B	√	√	√	√
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	PDM	√	√	√	√
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	√	√	√	√
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	√
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	SASM	√	√	√	√
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	SRM	√	√	√	
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	TRM	√	√	√	√
2011.25	Focus	2.0L	Gasoline Direct injection	ABS	√	√	√	√
2011.25	Focus	2.0L	Gasoline Direct injection	AHCM	√	√	√	√
2011.25	Focus	2.0L	Gasoline Direct injection	APIM	√	√	√	√
2011.25	Focus	2.0L	Gasoline Direct injection	BCMii	√	√	√	√
2011.25	Focus	2.0L	Gasoline Direct injection	CCMii	√	√	√	√
2011.25	Focus	2.0L	Gasoline Direct injection	DDM	√	√	√	√
2011.25	Focus	2.0L	Gasoline Direct injection	DSP	√	√	√	√
2011.25	Focus	2.0L	Gasoline Direct injection	FCDIM	√	√	√	√
2011.25	Focus	2.0L	Gasoline Direct injection	FCIM	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	FDSM	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	GPSM	√	√	√	





2012	Focus	2.0L	Gasoline_Direct_injecti on	PSCM	√	√	√	
2012	Focus	2.0L	Gasoline_Direct_injecti on	PSCM	√	√	√	√
2012	Focus	2.0L	Gasoline_Direct_injecti on	PSCM	√	√	√	√
2012	Focus	2.0L	Gasoline_Direct_injecti on	RCM	√	√	√	
2012	Focus	2.0L	Gasoline_Direct_injecti on	RCM	√	√	√	√
2012	Focus	2.0L	Gasoline_Direct_injecti on	RFA	√	√	√	
2012	Focus	2.0L	Gasoline_Direct_injecti on	RFA	√	√	√	√
2012	Focus	2.0L	Gasoline_Direct_injecti on	SASM	√	√	√	
2012	Focus	2.0L	Gasoline_Direct_injecti on	SASM	√	√	√	√
2012	Focus	2.0L	Gasoline_Direct_injecti on	TCM	√	√	√	√
2012	Focus	2.0L	Gasoline_Direct_injecti on	TCM	√	√	√	√
2012	Focus	23kWh	Battery_Electric_Vehicl	ABS	√	√	√	√
2012	Focus	23kWh	Battery_Electric_Vehicl	ABS	√	√	√	√
2012	Focus	23kWh	Battery_Electric_Vehicl	ABS	√	√	√	√
2012	Focus	23kWh	Battery_Electric_Vehicl	ACCM#2	√	√	√	√
2012	Focus	23kWh	Battery_Electric_Vehicl	ACM	√	√	√	√
2012	Focus	23kWh	Battery_Electric_Vehicl	APIM	√	√	√	√
2012	Focus	23kWh	Battery_Electric_Vehicl	BCCM	√	√	√	√
2012	Focus	23kWh	Battery_Electric_Vehicl	BCM#1	√	√	√	√
2012	Focus	23kWh	Battery_Electric_Vehicl	BCM#1	√	√	√	√
2012	Focus	23kWh	Battery_Electric_Vehicl	BECM	√	√	√	
2012	Focus	23kWh	Battery_Electric_Vehicl	BECM	√	√	√	√
2012	Focus	23kWh	Battery_Electric_Vehicl	DCDC	√	√	√	
2012	Focus	23kWh	Battery_Electric_Vehicl	DCDC	√	√	√	√
2012	Focus	23kWh	Battery_Electric_Vehicl	DDM	√	√	√	
2012	Focus	23kWh	Battery_Electric_Vehicl	DDM	√	√	√	√
2012	Focus	23kWh	Battery_Electric_Vehicl	DSP	√	√	√	
2012	Focus	23kWh	Battery_Electric_Vehicl	DSP	√	√	√	√
2012	Focus	23kWh	Battery_Electric_Vehicl	FCDIM	√	√	√	√
2012	Focus	23kWh	Battery_Electric_Vehicl	FCIM	√	√	√	√
2012	Focus	23kWh	Battery_Electric_Vehicl	GFM	√	√	√	√
2012	Focus	23kWh	Battery_Electric_Vehicl	GPSM	√	√	√	√
2012	Focus	23kWh	Battery_Electric_Vehicl	GWM	√	√	√	√
2012	Focus	23kWh	Battery_Electric_Vehicl	HCM	√	√	√	√
2012	Focus	23kWh	Battery_Electric_Vehicl	HVAC	√	√	√	√
2012	Focus	23kWh	Battery_Electric_Vehicl	IPC	√	√	√	√
2012	Focus	23kWh	Battery_Electric_Vehicl	IPM-B	√	√	√	√
2012	Focus	23kWh	Battery_Electric_Vehicl	OCSM	√	√	√	√
2012	Focus	23kWh	Battery_Electric_Vehicl	OCSM	√	√	√	√
2012	Focus	23kWh	Battery_Electric_Vehicl	PAM	√	√	√	√
2012	Focus	23kWh	Battery_Electric_Vehicl	PCM	√	√	√	√
2012	Focus	23kWh	Battery_Electric_Vehicl	PCM	√	√	√	√
2012	Focus	23kWh	Battery_Electric_Vehicl	PDM	√	√	√	
2012	Focus	23kWh	Battery_Electric_Vehicl	PDM	√	√	√	√
2012	Focus	23kWh	Battery_Electric_Vehicl	PSCM	√	√	√	

2012	Focus	23kWh	Battery_Electric_Vehicl	PSCM	✓	✓	✓	
2012	Focus	23kWh	Battery_Electric_Vehicl	PSCM	✓	✓	✓	✓
2012	Focus	23kWh	Battery_Electric_Vehicl	RCM	✓	✓	✓	
2012	Focus	23kWh	Battery_Electric_Vehicl	RFA	✓	✓	✓	
2012	Focus	23kWh	Battery_Electric_Vehicl	RFA	✓	✓	✓	✓
2012	Focus	23kWh	Battery_Electric_Vehicl	SASM	✓	✓	✓	
2012	Focus	23kWh	Battery_Electric_Vehicl	SASM	✓	✓	✓	✓
2012	Focus	23kWh	Battery_Electric_Vehicl	SOBDM	✓	✓	✓	
2012	Focus	23kWh	Battery_Electric_Vehicl	SOBDM	✓	✓	✓	✓
2012	Focus	23kWh	Battery_Electric_Vehicl	TCM	✓	✓	✓	
2012	Focus	23kWh	Battery_Electric_Vehicl	TCM	✓	✓	✓	✓
2012	Focus	23kWh	Battery_Electric_Vehicl	TCU#1	✓	✓	✓	
2012	Focus	23kWh	Battery_Electric_Vehicl	TCU#1	✓	✓	✓	✓
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	ABS	✓	✓	✓	✓
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	ACM	✓	✓	✓	✓
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	BCM#1	✓	✓	✓	✓
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	BCM#1	✓	✓	✓	✓
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	DDM	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	DSP	✓	✓	✓	✓
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	FCDIM	✓	✓	✓	✓
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	FCIM	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	GPSM	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	HVAC	✓	✓	✓	✓
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	ICM#1	✓	✓	✓	✓
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	IPC	✓	✓	✓	✓
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	IPM-B	✓	✓	✓	✓
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	OCSM	✓	✓	✓	✓
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	PAM	✓	✓	✓	✓
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	PDM	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	PSCM	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	RCM	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	RFA	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	SASM	✓	✓	✓	
2013	Focus	2.0L	Gasoline_Direct_injecti on	ABS	✓	✓	✓	✓
2013	Focus	2.0L	Gasoline_Direct_injecti on	ACM	✓	✓	✓	
2013	Focus	2.0L	Gasoline_Direct_injecti on	APIM	✓	✓	✓	
2013	Focus	2.0L	Gasoline_Direct_injecti on	BCM#1	✓	✓	✓	✓
2013	Focus	2.0L	Gasoline_Direct_injecti on	DDM	✓	✓	✓	
2013	Focus	2.0L	Gasoline_Direct_injecti on	FCDIM	✓	✓	✓	✓
2013	Focus	2.0L	Gasoline_Direct_injecti on	FCIM	✓	✓	✓	✓

2013	Focus	2.0L	Gasoline_Direct_injecti on	GPSM	√	√	√	√
2013	Focus	2.0L	Gasoline_Direct_injecti on	HVAC	√	√	√	√
2013	Focus	2.0L	Gasoline_Direct_injecti on	IPC	√	√	√	√
2013	Focus	2.0L	Gasoline_Direct_injecti on	IPM-B	√	√	√	√
2013	Focus	2.0L	Gasoline_Direct_injecti on	OCSM	√	√	√	√
2013	Focus	2.0L	Gasoline_Direct_injecti on	PAM	√	√	√	√
2013	Focus	2.0L	Gasoline_Direct_injecti on	PCM	√	√	√	√
2013	Focus	2.0L	Gasoline_Direct_injecti on	PDM	√	√	√	
2013	Focus	2.0L	Gasoline_Direct_injecti on	PSCM	√	√	√	
2013	Focus	2.0L	Gasoline_Direct_injecti on	RCM	√	√	√	
2013	Focus	2.0L	Gasoline_Direct_injecti on	RFA	√	√	√	
2013	Focus	2.0L	Gasoline_Direct_injecti on	SASM	√	√	√	
2013	Focus	2.0L	Gasoline_Direct_injecti on	TCM	√	√	√	√
2013	Focus	23kWh	Battery_Electric_Vehicl	ABS	√	√	√	√
2013	Focus	23kWh	Battery_Electric_Vehicl	ACCM#2	√	√	√	√
2013	Focus	23kWh	Battery_Electric_Vehicl	ACM	√	√	√	√
2013	Focus	23kWh	Battery_Electric_Vehicl	APIM	√	√	√	√
2013	Focus	23kWh	Battery_Electric_Vehicl	BCM#1	√	√	√	√
2013	Focus	23kWh	Battery_Electric_Vehicl	BCMii	√	√	√	√
2013	Focus	23kWh	Battery_Electric_Vehicl	BECM	√	√	√	√
2013	Focus	23kWh	Battery_Electric_Vehicl	DCDC	√	√	√	√
2013	Focus	23kWh	Battery_Electric_Vehicl	DDM	√	√	√	
2013	Focus	23kWh	Battery_Electric_Vehicl	DDM	√	√	√	√
2013	Focus	23kWh	Battery_Electric_Vehicl	DSP	√	√	√	√
2013	Focus	23kWh	Battery_Electric_Vehicl	FCDIM	√	√	√	√
2013	Focus	23kWh	Battery_Electric_Vehicl	FCIM	√	√	√	√
2013	Focus	23kWh	Battery_Electric_Vehicl	GFM	√	√	√	√
2013	Focus	23kWh	Battery_Electric_Vehicl	GPSM	√	√	√	√
2013	Focus	23kWh	Battery_Electric_Vehicl	GWM	√	√	√	√
2013	Focus	23kWh	Battery_Electric_Vehicl	HCM	√	√	√	√
2013	Focus	23kWh	Battery_Electric_Vehicl	HVAC	√	√	√	√
2013	Focus	23kWh	Battery_Electric_Vehicl	IPC	√	√	√	√
2013	Focus	23kWh	Battery_Electric_Vehicl	IPM-B	√	√	√	√
2013	Focus	23kWh	Battery_Electric_Vehicl	OCSM	√	√	√	√
2013	Focus	23kWh	Battery_Electric_Vehicl	PAM	√	√	√	√
2013	Focus	23kWh	Battery_Electric_Vehicl	PCM	√	√	√	√
2013	Focus	23kWh	Battery_Electric_Vehicl	PDM	√	√	√	
2013	Focus	23kWh	Battery_Electric_Vehicl	PDM	√	√	√	√
2013	Focus	23kWh	Battery_Electric_Vehicl	PSCM	√	√	√	
2013	Focus	23kWh	Battery_Electric_Vehicl	PSCM	√	√	√	√
2013	Focus	23kWh	Battery_Electric_Vehicl	RCM	√	√	√	
2013	Focus	23kWh	Battery_Electric_Vehicl	RCM	√	√	√	√
2013	Focus	23kWh	Battery_Electric_Vehicl	RFA	√	√	√	
2013	Focus	23kWh	Battery_Electric_Vehicl	RFA	√	√	√	√
2013	Focus	23kWh	Battery_Electric_Vehicl	SASM	√	√	√	

2013	Focus	23kWh	Battery_Electric_Vehicl	SASM	√	√	√	√
2013	Focus	23kWh	Battery_Electric_Vehicl	SOBDM	√	√	√	
2013	Focus	23kWh	Battery_Electric_Vehicl	TCM	√	√	√	
2013	Focus	23kWh	Battery_Electric_Vehicl	TCU#1	√	√	√	
2013	Focus	Other	Other	ABS	√	√	√	√
2013	Focus	Other	Other	ACM	√	√	√	√
2013	Focus	Other	Other	APIM	√	√	√	√
2013	Focus	Other	Other	BCM#1	√	√	√	√
2013	Focus	Other	Other	BCM#1	√	√	√	√
2013	Focus	Other	Other	DDM	√	√	√	
2013	Focus	Other	Other	DSP	√	√	√	√
2013	Focus	Other	Other	FCDIM	√	√	√	√
2013	Focus	Other	Other	FCIM	√	√	√	
2013	Focus	Other	Other	GPSM	√	√	√	
2013	Focus	Other	Other	HVAC	√	√	√	√
2013	Focus	Other	Other	IPC	√	√	√	√
2013	Focus	Other	Other	IPM-B	√	√	√	√
2013	Focus	Other	Other	OCSM	√	√	√	√
2013	Focus	Other	Other	PAM	√	√	√	√
2013	Focus	Other	Other	PDM	√	√	√	
2013	Focus	Other	Other	PSCM	√	√	√	
2013	Focus	Other	Other	RCM	√	√	√	
2013	Focus	Other	Other	RFA	√	√	√	
2013	Focus	Other	Other	SASM	√	√	√	
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	BCM#1	√	√	√	√
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	DSP	√	√	√	√
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	FCDIM	√	√	√	√
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	√
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	√
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	HCM	√	√	√	
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	√
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	ICM#1	√	√	√	√
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	IPM-B	√	√	√	√
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	OCSM	√	√	√	√
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	PDM	√	√	√	
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	
2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	

2014	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM	√	√	√	
2014	Focus	2.0L	Gasoline_Direct_injection	ABS	√	√	√	√
2014	Focus	2.0L	Gasoline_Direct_injection	ACM	√	√	√	
2014	Focus	2.0L	Gasoline_Direct_injection	APIM	√	√	√	
2014	Focus	2.0L	Gasoline_Direct_injection	BCM#1	√	√	√	√
2014	Focus	2.0L	Gasoline_Direct_injection	DDM	√	√	√	
2014	Focus	2.0L	Gasoline_Direct_injection	DSP	√	√	√	√
2014	Focus	2.0L	Gasoline_Direct_injection	FCDIM	√	√	√	√
2014	Focus	2.0L	Gasoline_Direct_injection	FCIM	√	√	√	√
2014	Focus	2.0L	Gasoline_Direct_injection	GPSM	√	√	√	√
2014	Focus	2.0L	Gasoline_Direct_injection	HVAC	√	√	√	√
2014	Focus	2.0L	Gasoline_Direct_injection	IPC	√	√	√	√
2014	Focus	2.0L	Gasoline_Direct_injection	IPM-B	√	√	√	√
2014	Focus	2.0L	Gasoline_Direct_injection	PAM	√	√	√	√
2014	Focus	2.0L	Gasoline_Direct_injection	PCM	√	√	√	√
2014	Focus	2.0L	Gasoline_Direct_injection	PDM	√	√	√	
2014	Focus	2.0L	Gasoline_Direct_injection	PSCM	√	√	√	
2014	Focus	2.0L	Gasoline_Direct_injection	RCM	√	√	√	
2014	Focus	2.0L	Gasoline_Direct_injection	RFA	√	√	√	
2014	Focus	2.0L	Gasoline_Direct_injection	SASM	√	√	√	
2014	Focus	2.0L	Gasoline_Direct_injection	TCM	√	√	√	√
2014	Focus	23kWh	Battery_Electric_Vehicl	ABS	√	√	√	√
2014	Focus	23kWh	Battery_Electric_Vehicl	ACCM#2	√	√	√	√
2014	Focus	23kWh	Battery_Electric_Vehicl	ACM	√	√	√	√
2014	Focus	23kWh	Battery_Electric_Vehicl	APIM	√	√	√	√
2014	Focus	23kWh	Battery_Electric_Vehicl	BCM#1	√	√	√	√
2014	Focus	23kWh	Battery_Electric_Vehicl	BECM	√	√	√	√
2014	Focus	23kWh	Battery_Electric_Vehicl	DCDC	√	√	√	√
2014	Focus	23kWh	Battery_Electric_Vehicl	DDM	√	√	√	
2014	Focus	23kWh	Battery_Electric_Vehicl	DSP	√	√	√	√
2014	Focus	23kWh	Battery_Electric_Vehicl	FCDIM	√	√	√	√
2014	Focus	23kWh	Battery_Electric_Vehicl	FCIM	√	√	√	√
2014	Focus	23kWh	Battery_Electric_Vehicl	GFM	√	√	√	√
2014	Focus	23kWh	Battery_Electric_Vehicl	GPSM	√	√	√	√
2014	Focus	23kWh	Battery_Electric_Vehicl	GWM	√	√	√	√
2014	Focus	23kWh	Battery_Electric_Vehicl	HCM	√	√	√	
2014	Focus	23kWh	Battery_Electric_Vehicl	HVAC	√	√	√	√
2014	Focus	23kWh	Battery_Electric_Vehicl	IPC	√	√	√	√
2014	Focus	23kWh	Battery_Electric_Vehicl	IPM-B	√	√	√	√
2014	Focus	23kWh	Battery_Electric_Vehicl	OCSM	√	√	√	√
2014	Focus	23kWh	Battery_Electric_Vehicl	PAM	√	√	√	√
2014	Focus	23kWh	Battery_Electric_Vehicl	PCM	√	√	√	√
2014	Focus	23kWh	Battery_Electric_Vehicl	PDM	√	√	√	
2014	Focus	23kWh	Battery_Electric_Vehicl	PSCM	√	√	√	



2014	Focus	23kWh	Battery_Electric_Vehicl	RCM	√	√	√	
2014	Focus	23kWh	Battery_Electric_Vehicl	RFA	√	√	√	
2014	Focus	23kWh	Battery_Electric_Vehicl	SASM	√	√	√	
2014	Focus	23kWh	Battery_Electric_Vehicl	SOBDM	√	√	√	
2014	Focus	23kWh	Battery_Electric_Vehicl	TCM	√	√	√	
2014	Focus	23kWh	Battery_Electric_Vehicl	TCU#1	√	√	√	
2008.25	Focus C-MAX	1.6L	DA	FACM	6E	0x0007 A120	√	√
2002.75	Focus C-MAX	1.4L	DURATEC 16V	ABS	√	√	√	√
2002.75	Focus C-MAX	1.4L	DURATEC 16V	ACM	√	√	√	√
2002.75	Focus C-MAX	1.4L	DURATEC 16V	CDP	√	√	√	√
2002.75	Focus C-MAX	1.4L	DURATEC 16V	D_DCU	√	√	√	√
2002.75	Focus C-MAX	1.4L	DURATEC 16V	EATC	√	√	√	√
2002.75	Focus C-MAX	1.4L	DURATEC 16V	EPB	√	√	√	√
2002.75	Focus C-MAX	1.4L	DURATEC 16V	FFH	√	√	√	√
2002.75	Focus C-MAX	1.4L	DURATEC 16V	GDM	√	√	√	√
2002.75	Focus C-MAX	1.4L	DURATEC 16V	GEM	√	√	√	√
2002.75	Focus C-MAX	1.4L	DURATEC 16V	HCM	√	√	√	√
2002.75	Focus C-MAX	1.4L	DURATEC 16V	IC	√	√	√	√
2002.75	Focus C-MAX	1.4L	DURATEC 16V	NAV	√	√	√	√
2002.75	Focus C-MAX	1.4L	DURATEC 16V	PAM	√	√	√	√
2002.75	Focus C-MAX	1.4L	DURATEC 16V	PCM	√	√	√	√
2002.75	Focus C-MAX	1.4L	DURATEC 16V	P_DCU	√	√	√	√
2002.75	Focus C-MAX	1.4L	DURATEC 16V	RCM	√	√	√	√
2002.75	Focus C-MAX	1.4L	DURATEC 16V	RETM	√	√	√	√
2002.75	Focus C-MAX	1.4L	DURATEC 16V	RKE	√	√	√	√
2002.75	Focus C-MAX	1.4L	DURATEC 16V	RL_DCU	√	√	√	√
2002.75	Focus C-MAX	1.4L	DURATEC 16V	RR_DCU	√	√	√	√
2002.75	Focus C-MAX	1.4L	DURATEC 16V	SRM	√	√	√	√
2002.75	Focus C-MAX	1.6L	DURATEC 16V	ABS	√	√	√	√
2002.75	Focus C-MAX	1.6L	DURATEC 16V	ACM	√	√	√	√
2002.75	Focus C-MAX	1.6L	DURATEC 16V	CDP	√	√	√	√
2002.75	Focus C-MAX	1.6L	DURATEC 16V	D_DCU	√	√	√	√
2002.75	Focus C-MAX	1.6L	DURATEC 16V	EATC	√	√	√	√
2002.75	Focus C-MAX	1.6L	DURATEC 16V	EATC	√	√	√	√
2002.75	Focus C-MAX	1.6L	DURATEC 16V	EPB	√	√	√	√
2002.75	Focus C-MAX	1.6L	DURATEC 16V	FFH	√	√	√	√
2002.75	Focus C-MAX	1.6L	DURATEC 16V	GDM	√	√	√	√
2002.75	Focus C-MAX	1.6L	DURATEC 16V	GEM	√	√	√	√
2002.75	Focus C-MAX	1.6L	DURATEC 16V	HCM	√	√	√	√
2002.75	Focus C-MAX	1.6L	DURATEC 16V	IC	√	√	√	√
2002.75	Focus C-MAX	1.6L	DURATEC 16V	NAV	√	√	√	√
2002.75	Focus C-MAX	1.6L	DURATEC 16V	PAM	√	√	√	√
2002.75	Focus C-MAX	1.6L	DURATEC 16V	P_DCU	√	√	√	√
2002.75	Focus C-MAX	1.6L	DURATEC 16V	RCM	√	√	√	√





2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	RCM	√	√	√	√
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	RETM	√	√	√	√
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	RKE	√	√	√	√
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	RL_DCU	√	√	√	√
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	RR_DCU	√	√	√	√
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	SRM	√	√	√	√
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	TCM	√	√	√	√
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	CDP	√	√	√	√
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	D_DCU	√	√	√	√
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	EATC	√	√	√	√
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	EPB	√	√	√	√
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	EPS	√	√	√	√
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	FFH	√	√	√	√
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	GDM	√	√	√	√
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	GEM	√	√	√	√
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	√
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	IC	√	√	√	√
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	PAM	√	√	√	√
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	P_DCU	√	√	√	√
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	RETM	√	√	√	√
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	RKE	√	√	√	√
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	RL_DCU	√	√	√	√
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	RR_DCU	√	√	√	√
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	√
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	ABS	√	√	√	√
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	ACM	√	√	√	√
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	CDP	√	√	√	√
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	D_DCU	√	√	√	√
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	EATC	√	√	√	√
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	EPB	√	√	√	√
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	EPS	√	√	√	√
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	FFH	√	√	√	√
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	GDM	√	√	√	√
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	GEM	√	√	√	√
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	HCM	√	√	√	√
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	IC	√	√	√	√
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	NAV	√	√	√	√
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	PAM	√	√	√	√
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	P_DCU	√	√	√	√

2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	RCM	√	√	√	√
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	RETM	√	√	√	√
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	RKE	√	√	√	√
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	RL_DCU	√	√	√	√
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	RR_DCU	√	√	√	√
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	SRM	√	√	√	√
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	TCM	√	√	√	√
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	CDP	√	√	√	√
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	D_DCU	√	√	√	√
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	EATC	√	√	√	√
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	EPB	√	√	√	√
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	EPS	√	√	√	√
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	FACM	√	√	√	√
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	FFH	√	√	√	√
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	GDM	√	√	√	√
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	GEM	√	√	√	√
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	√
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	IC	√	√	√	√
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	NAV	√	√	√	√
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	PAM	√	√	√	√
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	P_DCU	√	√	√	√
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	RETM	√	√	√	√
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	RKE	√	√	√	√
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	RL_DCU	√	√	√	√
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	RR_DCU	√	√	√	√
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	√
2007.5	Focus C-MAX	1.4L	DURATEC 16V	ABS	√	√	√	√
2007.5	Focus C-MAX	1.4L	DURATEC 16V	ACM	√	√	√	√
2007.5	Focus C-MAX	1.4L	DURATEC 16V	CDP	√	√	√	√
2007.5	Focus C-MAX	1.4L	DURATEC 16V	D_DCU	√	√	√	√
2007.5	Focus C-MAX	1.4L	DURATEC 16V	EATC	√	√	√	√
2007.5	Focus C-MAX	1.4L	DURATEC 16V	EPB	√	√	√	√
2007.5	Focus C-MAX	1.4L	DURATEC 16V	FFH	√	√	√	√
2007.5	Focus C-MAX	1.4L	DURATEC 16V	GDM	√	√	√	√
2007.5	Focus C-MAX	1.4L	DURATEC 16V	GEM	√	√	√	√
2007.5	Focus C-MAX	1.4L	DURATEC 16V	HCM	√	√	√	√
2007.5	Focus C-MAX	1.4L	DURATEC 16V	IC	√	√	√	√
2007.5	Focus C-MAX	1.4L	DURATEC 16V	NAV	√	√	√	√
2007.5	Focus C-MAX	1.4L	DURATEC 16V	PAM	√	√	√	√
2007.5	Focus C-MAX	1.4L	DURATEC 16V	PCM	√	√	√	√
2007.5	Focus C-MAX	1.4L	DURATEC 16V	P_DCU	√	√	√	√

2007.5	Focus C-MAX	1.4L	DURATEC 16V	RCM	√	√	√	√
2007.5	Focus C-MAX	1.4L	DURATEC 16V	RETM	√	√	√	√
2007.5	Focus C-MAX	1.4L	DURATEC 16V	RKE	√	√	√	√
2007.5	Focus C-MAX	1.4L	DURATEC 16V	SRM	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC 16V	ABS	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC 16V	ACM	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC 16V	CDP	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC 16V	D_DCU	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC 16V	EATC	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC 16V	EPB	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC 16V	FFH	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC 16V	GDM	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC 16V	GEM	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC 16V	HCM	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC 16V	IC	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC 16V	NAV	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC 16V	PAM	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC 16V	PCM	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC 16V	P_DCU	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC 16V	RCM	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC 16V	RETM	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC 16V	RKE	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC 16V	SRM	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC VCT	ABS	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC VCT	ACM	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC VCT	CDP	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC VCT	D_DCU	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC VCT	EATC	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC VCT	EPB	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC VCT	FFH	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC VCT	GDM	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC VCT	GEM	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC VCT	HCM	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC VCT	IC	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC VCT	NAV	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC VCT	PAM	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC VCT	PCM	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC VCT	P_DCU	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC VCT	RCM	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC VCT	RETM	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC VCT	RKE	√	√	√	√
2007.5	Focus C-MAX	1.6L	DURATEC VCT	SRM	√	√	√	√
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	CDP	√	√	√	√

2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	D_DCU	√	√	√	√
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	EATC	√	√	√	√
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	EPB	√	√	√	√
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	EPS	√	√	√	√
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	FACM	√	√	√	√
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	GDM	√	√	√	√
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	GEM	√	√	√	√
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	√
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	IC	√	√	√	√
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	NAV	√	√	√	√
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	PAM	√	√	√	√
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	P_DCU	√	√	√	√
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	RETM	√	√	√	√
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	RKE	√	√	√	√
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	√
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	TCM	√	√	√	√
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	ABS	√	√	√	√
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	ACM	√	√	√	√
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	CDP	√	√	√	√
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	D_DCU	√	√	√	√
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	EATC	√	√	√	√
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	EPB	√	√	√	√
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	EPS	√	√	√	√
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	FFH	√	√	√	√
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	GDM	√	√	√	√
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	GEM	√	√	√	√
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	HCM	√	√	√	√
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	IC	√	√	√	√
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	NAV	√	√	√	√
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	PAM	√	√	√	√
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	PCM	√	√	√	√
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	P_DCU	√	√	√	√
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	RCM	√	√	√	√
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	RETM	√	√	√	√
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	RKE	√	√	√	√
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	SRM	√	√	√	√
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	TCM	√	√	√	√
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	CDP	√	√	√	√
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	D_DCU	√	√	√	√
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	EATC	√	√	√	√
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	EPB	√	√	√	√

2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	EPS	√	√	√	√
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	FFH	√	√	√	√
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	GDM	√	√	√	√
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	GEM	√	√	√	√
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	√
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	IC	√	√	√	√
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	NAV	√	√	√	√
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	PAM	√	√	√	√
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	P_DCU	√	√	√	√
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	RETM	√	√	√	√
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	√
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	ABS	√	√	√	√
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	ACM	√	√	√	√
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	CDP	√	√	√	√
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	D_DCU	√	√	√	√
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	EATC	√	√	√	√
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	EPB	√	√	√	√
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	EPS	√	√	√	√
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	FFH	√	√	√	√
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	GDM	√	√	√	√
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	GEM	√	√	√	√
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	HCM	√	√	√	√
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	IC	√	√	√	√
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	NAV	√	√	√	√
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	PAM	√	√	√	√
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	P_DCU	√	√	√	√
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	RCM	√	√	√	√
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	RETM	√	√	√	√
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	RKE	√	√	√	√
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	SRM	√	√	√	√
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	TCM	√	√	√	√
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	CDP	√	√	√	√
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	D_DCU	√	√	√	√
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	EATC	√	√	√	√
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	EPB	√	√	√	√
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	EPS	√	√	√	√
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	FACM	√	√	√	√
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	FFH	√	√	√	√
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	GDM	√	√	√	√
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	GEM	√	√	√	√



2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	√
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	IC	√	√	√	√
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	NAV	√	√	√	√
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	PAM	√	√	√	√
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	P_DCU	√	√	√	√
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	RETM	√	√	√	√
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	RKE	√	√	√	√
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC 16V	ABS	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC 16V	ACM	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC 16V	CDP	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC 16V	CMR	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC 16V	D_DCU	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC 16V	EATC	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC 16V	EPS	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC 16V	FFH	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC 16V	GEM	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC 16V	HCM	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC 16V	IC	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC 16V	IC	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC 16V	PAM	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC 16V	PCM	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC 16V	RCM	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC 16V	RETM	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC 16V	RKE	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC 16V	SRM	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC 16V	TCM	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC VCT	ABS	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC VCT	ACM	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC VCT	CDP	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC VCT	CMR	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC VCT	D_DCU	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC VCT	EATC	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC VCT	EPS	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC VCT	FFH	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC VCT	GEM	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC VCT	HCM	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC VCT	IC	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC VCT	IC	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC VCT	PAM	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC VCT	PCM	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC VCT	P_DCU	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC VCT	RCM	√	√	√	√

2008.25	Focus C-MAX	1.6L	DURATEC VCT	RETM	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC VCT	RKE	√	√	√	√
2008.25	Focus C-MAX	1.6L	DURATEC VCT	SRM	√	√	√	√
2008.25	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	ABS	√	√	√	√
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	ACM	√	√	√	√
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	CDP	√	√	√	√
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	CMR	√	√	√	√
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	D_DCU	√	√	√	√
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	EATC	√	√	√	√
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	EPS	√	√	√	√
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	FFH	√	√	√	√
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	GEM	√	√	√	√
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	HCM	√	√	√	√
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	IC	√	√	√	√
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	IC	√	√	√	√
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	PAM	√	√	√	√
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	PCM	√	√	√	√
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	P_DCU	√	√	√	√
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	RCM	√	√	√	√
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	RETM	√	√	√	√
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	RKE	√	√	√	√
2008.25	Focus C-MAX	1.8L	DURATEC-HE / I4	SRM	√	√	√	√
2008.25	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	FFH	√	√	√	√
2008.25	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	GEM	√	√	√	√
2008.25	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	√
2008.25	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	IC	√	√	√	√
2008.25	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	PAM	√	√	√	√
2008.25	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2008.25	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	P_DCU	√	√	√	√
2008.25	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2008.25	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	RETM	√	√	√	√
2008.25	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	RKE	√	√	√	√
2008.25	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	√
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	ABS	√	√	√	√
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	ABS	√	√	√	√
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	ABS	√	√	√	√
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	ACM	√	√	√	√
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	CDP	√	√	√	√
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	CDP	√	√	√	√
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	CMR	√	√	√	√
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	D_DCU	√	√	√	√
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	EATC	√	√	√	√
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	EATC	√	√	√	√
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	EPS	√	√	√	√



2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	RETM	√	√	√	√
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	RKE	√	√	√	√
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	√
2011	Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2011	Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2011	Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct	AHCM	√	√	√	√
2011	Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2011	Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct	BCMii	√	√	√	√
2011	Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	√	√	√	√
2011	Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct	FCDIM	√	√	√	√
2011	Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct	FDSM	√	√	√	√
2011	Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct	HCM	√	√	√	√
2011	Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	√
2011	Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2011	Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct	IPM-A	√	√	√	√
2011	Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct	IPM-B	√	√	√	√
2011	Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2011	Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2011	Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct	PDM	√	√	√	√
2011	Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2011	Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2011	Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	√
2011	Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct	RGTM	√	√	√	√
2011	Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct	SASM	√	√	√	√
2011	Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	√
2011	Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2011	Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct	SRM	√	√	√	√
2011	Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct	TRM	√	√	√	√
2011	Focus C-MAX	1.6L	DURATEC VCT	ABS	√	√	√	√
2011	Focus C-MAX	1.6L	DURATEC VCT	ABS	√	√	√	√
2011	Focus C-MAX	1.6L	DURATEC VCT	ACM	√	√	√	
2011	Focus C-MAX	1.6L	DURATEC VCT	AHCM	√	√	√	
2011	Focus C-MAX	1.6L	DURATEC VCT	AHCM	√	√	√	
2011	Focus C-MAX	1.6L	DURATEC VCT	APIM	√	√	√	
2011	Focus C-MAX	1.6L	DURATEC VCT	BCMii	√	√	√	√
2011	Focus C-MAX	1.6L	DURATEC VCT	DDM	√	√	√	√
2011	Focus C-MAX	1.6L	DURATEC VCT	DDM	√	√	√	√
2011	Focus C-MAX	1.6L	DURATEC VCT	FCDIM	√	√	√	
2011	Focus C-MAX	1.6L	DURATEC VCT	FDSM	√	√	√	
2011	Focus C-MAX	1.6L	DURATEC VCT	HCM	√	√	√	
2011	Focus C-MAX	1.6L	DURATEC VCT	HVAC	√	√	√	
2011	Focus C-MAX	1.6L	DURATEC VCT	IPC	√	√	√	√
2011	Focus C-MAX	1.6L	DURATEC VCT	IPM-A	√	√	√	√
2011	Focus C-MAX	1.6L	DURATEC VCT	IPM-A	√	√	√	√

2011	Focus C-MAX	1.6L	DURATEC VCT	IPM-B	√	√	√	√
2011	Focus C-MAX	1.6L	DURATEC VCT	PAM	√	√	√	√
2011	Focus C-MAX	1.6L	DURATEC VCT	PCM	√	√	√	
2011	Focus C-MAX	1.6L	DURATEC VCT	PCM	√	√	√	√
2011	Focus C-MAX	1.6L	DURATEC VCT	PDM	√	√	√	
2011	Focus C-MAX	1.6L	DURATEC VCT	PDM	√	√	√	√
2011	Focus C-MAX	1.6L	DURATEC VCT	PSCM	√	√	√	
2011	Focus C-MAX	1.6L	DURATEC VCT	PSCM	√	√	√	√
2011	Focus C-MAX	1.6L	DURATEC VCT	RCM	√	√	√	
2011	Focus C-MAX	1.6L	DURATEC VCT	RCM	√	√	√	√
2011	Focus C-MAX	1.6L	DURATEC VCT	RFA	√	√	√	
2011	Focus C-MAX	1.6L	DURATEC VCT	RFA	√	√	√	√
2011	Focus C-MAX	1.6L	DURATEC VCT	RGTM	√	√	√	
2011	Focus C-MAX	1.6L	DURATEC VCT	RGTM	√	√	√	√
2011	Focus C-MAX	1.6L	DURATEC VCT	SASM	√	√	√	
2011	Focus C-MAX	1.6L	DURATEC VCT	SASM	√	√	√	√
2011	Focus C-MAX	1.6L	DURATEC VCT	SOD-L	√	√	√	
2011	Focus C-MAX	1.6L	DURATEC VCT	SOD-L	√	√	√	√
2011	Focus C-MAX	1.6L	DURATEC VCT	SOD-R	√	√	√	
2011	Focus C-MAX	1.6L	DURATEC VCT	SOD-R	√	√	√	√
2011	Focus C-MAX	1.6L	DURATEC VCT	SRM	√	√	√	
2011	Focus C-MAX	1.6L	DURATEC VCT	SRM	√	√	√	√
2011	Focus C-MAX	1.6L	DURATEC VCT	TRM	√	√	√	
2011	Focus C-MAX	1.6L	DURATEC VCT	TRM	√	√	√	√
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	AHCM	√	√	√	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	AHCM	√	√	√	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	APIM	√	√	√	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	BCMii	√	√	√	√
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	DDM	√	√	√	√
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	DDM	√	√	√	√
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	FCDIM	√	√	√	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	FDSM	√	√	√	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	HVAC	√	√	√	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	IPC	√	√	√	√
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	IPM-A	√	√	√	√
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	IPM-A	√	√	√	√
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	IPM-B	√	√	√	√
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	PAM	√	√	√	√
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√

2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	PDM	√	√	√	√
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	PDM	√	√	√	√
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	PSCM	√	√	√	√
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	PSCM	√	√	√	√
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	RFA	√	√	√	√
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	RGTM	√	√	√	√
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	SASM	√	√	√	√
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	SOD-L	√	√	√	√
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	SOD-R	√	√	√	√
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	√
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail	TRM	√	√	√	√
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct	AHCM	√	√	√	
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct	BCMii	√	√	√	√
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	√
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct	FCDIM	√	√	√	
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct	FDSM	√	√	√	
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct	HCM	√	√	√	
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct	IPM-A	√	√	√	√
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct	IPM-B	√	√	√	√
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct	PDM	√	√	√	√
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM	√	√	√	√
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	√
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct	RGTM	√	√	√	√
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct	SASM	√	√	√	√
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	√
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct	SRM	√	√	√	√
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct	TRM	√	√	√	√
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	AHCM	√	√	√	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	AHCM	√	√	√	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	APIM	√	√	√	

2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	BCMii	√	√	√	√
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	DDM	√	√	√	√
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	DDM	√	√	√	√
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	FCDIM	√	√	√	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	FDSM	√	√	√	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	HVAC	√	√	√	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	IPC	√	√	√	√
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	IPC	√	√	√	√
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	IPM-A	√	√	√	√
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	IPM-A	√	√	√	√
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	IPM-B	√	√	√	√
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	PAM	√	√	√	√
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	PDM	√	√	√	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	PDM	√	√	√	√
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	PSCM	√	√	√	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	PSCM	√	√	√	√
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	RFA	√	√	√	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	RFA	√	√	√	√
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	RGTM	√	√	√	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	RGTM	√	√	√	√
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	SASM	√	√	√	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	SASM	√	√	√	√
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	SOD-L	√	√	√	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	SOD-L	√	√	√	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	SOD-L	√	√	√	√
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	SOD-R	√	√	√	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	SOD-R	√	√	√	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	SOD-R	√	√	√	√
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	√
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	TCM	√	√	√	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	TRM	√	√	√	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail	TRM	√	√	√	√
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	ABS	√	√	√	√
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	ACM	√	√	√	√
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	CDP	√	√	√	√
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	D_DCU	√	√	√	√
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	EATC	√	√	√	√
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	FFH	√	√	√	√

2006.75	Focus Cabriolet	1.6L	DURATEC 16V	FTCM	✓	✓	✓	✓
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	GDM	✓	✓	✓	✓
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	HCM	✓	✓	✓	✓
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	IC	✓	✓	✓	✓
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	NAV	✓	✓	✓	✓
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	PAM	✓	✓	✓	✓
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	P_DCU	✓	✓	✓	✓
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	RKE	✓	✓	✓	✓
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	SRM	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	CDP	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	D_DCU	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	EPS	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	FFH	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	FTCM	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	GDM	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	NAV	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	P_DCU	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	RKE	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	TCM	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail	ABS	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail	ABS	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail	ACM	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail	ACM	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail	CDP	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail	CDP	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail	D_DCU	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail	EATC	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail	EATC	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail	EPS	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail	FACM	✓	✓	✓	✓
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail	FACM	✓	✓	✓	✓



2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail	FFH	√	√	√	√
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail	FTCM	√	√	√	√
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail	GDM	√	√	√	√
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail	GDM	√	√	√	√
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail	GEM	√	√	√	√
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	√
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail	IC	√	√	√	√
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail	IC	√	√	√	√
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail	NAV	√	√	√	√
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail	PAM	√	√	√	√
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail	PAM	√	√	√	√
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail	P_DCU	√	√	√	√
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail	RKE	√	√	√	√
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	ABS	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	ACM	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	CDP	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	D_DCU	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	EATC	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	EPS	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	FFH	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	FTCM	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	GEM	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	HCM	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	IC	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	PAM	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	PCM	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	P_DCU	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	RCM	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	RKE	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	SRM	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	ABS	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	ACM	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	CDP	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	D_DCU	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	EATC	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	EPS	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	FFH	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	FTCM	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	GEM	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	HCM	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	IC	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	PAM	√	√	√	√

2008.25	Focus Cabriolet	1.6L	DURATEC VCT	P_DCU	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	RCM	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	RKE	√	√	√	√
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	SRM	√	√	√	√
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	ABS	√	√	√	√
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	ABS	√	√	√	√
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	ABS	√	√	√	√
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	ACM	√	√	√	√
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	ACM	√	√	√	√
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	CDP	√	√	√	√
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	CDP	√	√	√	√
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	D_DCU	√	√	√	√
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	EATC	√	√	√	√
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	EATC	√	√	√	√
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	EPS	√	√	√	√
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	EPS	√	√	√	√
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	FFH	√	√	√	√
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	FFH	√	√	√	√
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	FTCM	√	√	√	√
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	GEM	√	√	√	√
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	HCM	√	√	√	√
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	HCM	√	√	√	√
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	IC	√	√	√	√
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	IC	√	√	√	√
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	PAM	√	√	√	√
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	PAM	√	√	√	√
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	P_DCU	√	√	√	√
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	RCM	√	√	√	√
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	RKE	√	√	√	√
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	RKE	√	√	√	√
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	SRM	√	√	√	√
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	TCM	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.6L	BZ	ABS	√	√	√	0012,0 029,00 2A,002 C-0051
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.6L	BZ	ABS	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	D_DCU	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	EATC	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	GEM	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	HCM	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	IC	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	PAM	√	√	√	√

2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	PCM	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	P_DCU	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	RCM	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	RL_DCU	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	RR_DCU	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.8L	DURATEC-HE / I4	ABS	√	√	√	0005,0 012,00 29,002 A,002C
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.8L	DURATEC-HE / I4	ABS	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	D_DCU	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	EATC	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	EPS	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.8L	DURATEC-HE / I4	GEM	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	HCM	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.8L	DURATEC-HE / I4	IC	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	PAM	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	PCM	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	P_DCU	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	RCM	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	RL_DCU	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	RR_DCU	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	TCM	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2.0L	DURATEC-HE / I4	ABS	√	√	√	0005,0 012,00 29,002 A,002C
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2.0L	DURATEC-HE / I4	ABS	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	D_DCU	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	EATC	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	EPS	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2.0L	DURATEC-HE / I4	GEM	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	HCM	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2.0L	DURATEC-HE / I4	IC	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	PAM	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	P_DCU	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	RCM	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	RL_DCU	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	RR_DCU	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	TCM	√	√	√	√

2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	√	√	√	0008,0 012,00 29,002 A-0054
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2.0L	Duratorq Turbo Diesel Common Rail	D_DCU	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2.0L	Duratorq Turbo Diesel Common Rail	EATC	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2.0L	Duratorq Turbo Diesel Common Rail	EPS	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2.0L	Duratorq Turbo Diesel Common Rail	FACM	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2.0L	Duratorq Turbo Diesel Common Rail	GEM	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2.0L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2.0L	Duratorq Turbo Diesel Common Rail	IC	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2.0L	Duratorq Turbo Diesel Common Rail	PAM	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2.0L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2.0L	Duratorq Turbo Diesel Common Rail	P_DCU	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2.0L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2.0L	Duratorq Turbo Diesel Common Rail	RL_DCU	√	√	√	√
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2.0L	Duratorq Turbo Diesel Common Rail	RR_DCU	√	√	√	√
2004	Freestar / Monterey	3.9L	V6 OHV	ABS/TCS	√	√	√	√
2004	Freestar / Monterey	3.9L	V6 OHV	DCSM	√	√	√	√
2004	Freestar / Monterey	3.9L	V6 OHV	DSM	√	√	√	√
2004	Freestar / Monterey	3.9L	V6 OHV	EATC	√	√	√	√
2004	Freestar / Monterey	3.9L	V6 OHV	GEM	√	√	√	√
2004	Freestar / Monterey	3.9L	V6 OHV	IC	√	√	√	√
2004	Freestar / Monterey	3.9L	V6 OHV	LPSDM	√	√	√	√
2004	Freestar / Monterey	3.9L	V6 OHV	LTM	√	√	√	√
2004	Freestar / Monterey	3.9L	V6 OHV	NGSC	√	√	√	√
2004	Freestar / Monterey	3.9L	V6 OHV	PAM	√	√	√	√
2004	Freestar / Monterey	3.9L	V6 OHV	PCM	√	√	√	√
2004	Freestar / Monterey	3.9L	V6 OHV	PCSM	√	√	√	√
2004	Freestar / Monterey	3.9L	V6 OHV	RCM	√	√	√	√
2004	Freestar / Monterey	3.9L	V6 OHV	RPSDM	√	√	√	√
2004	Freestar / Monterey	4.2L	V6 OHV	ABS/TCS	√	√	√	√
2004	Freestar / Monterey	4.2L	V6 OHV	DCSM	√	√	√	√
2004	Freestar / Monterey	4.2L	V6 OHV	DSM	√	√	√	√
2004	Freestar / Monterey	4.2L	V6 OHV	EATC	√	√	√	√
2004	Freestar / Monterey	4.2L	V6 OHV	GEM	√	√	√	√
2004	Freestar / Monterey	4.2L	V6 OHV	IC	√	√	√	√
2004	Freestar / Monterey	4.2L	V6 OHV	LPSDM	√	√	√	√
2004	Freestar / Monterey	4.2L	V6 OHV	LTM	√	√	√	√
2004	Freestar / Monterey	4.2L	V6 OHV	NGSC	√	√	√	√
2004	Freestar / Monterey	4.2L	V6 OHV	PAM	√	√	√	√
2004	Freestar / Monterey	4.2L	V6 OHV	PCM	√	√	√	√
2004	Freestar / Monterey	4.2L	V6 OHV	PCSM	√	√	√	√
2004	Freestar / Monterey	4.2L	V6 OHV	RCM	√	√	√	√
2004	Freestar / Monterey	4.2L	V6 OHV	RPSDM	√	√	√	√

2005	Freestar / Monterey	3.9L	V6 OHV	ABS/TCS	√	√	√	√
2005	Freestar / Monterey	3.9L	V6 OHV	DCSM	√	√	√	√
2005	Freestar / Monterey	3.9L	V6 OHV	DSM	√	√	√	√
2005	Freestar / Monterey	3.9L	V6 OHV	EATC	√	√	√	√
2005	Freestar / Monterey	3.9L	V6 OHV	GEM	√	√	√	√
2005	Freestar / Monterey	3.9L	V6 OHV	IC	√	√	√	√
2005	Freestar / Monterey	3.9L	V6 OHV	LPSDM	√	√	√	√
2005	Freestar / Monterey	3.9L	V6 OHV	LTM	√	√	√	√
2005	Freestar / Monterey	3.9L	V6 OHV	NGSC	√	√	√	√
2005	Freestar / Monterey	3.9L	V6 OHV	PAM	√	√	√	√
2005	Freestar / Monterey	3.9L	V6 OHV	PCM	√	√	√	√
2005	Freestar / Monterey	3.9L	V6 OHV	PCSM	√	√	√	√
2005	Freestar / Monterey	3.9L	V6 OHV	RCM	√	√	√	√
2005	Freestar / Monterey	3.9L	V6 OHV	RPSDM	√	√	√	√
2005	Freestar / Monterey	3.9L	V6 OHV	TPM	√	√	√	√
2005	Freestar / Monterey	4.2L	V6 OHV	ABS/TCS	√	√	√	√
2005	Freestar / Monterey	4.2L	V6 OHV	DCSM	√	√	√	√
2005	Freestar / Monterey	4.2L	V6 OHV	DSM	√	√	√	√
2005	Freestar / Monterey	4.2L	V6 OHV	EATC	√	√	√	√
2005	Freestar / Monterey	4.2L	V6 OHV	GEM	√	√	√	√
2005	Freestar / Monterey	4.2L	V6 OHV	IC	√	√	√	√
2005	Freestar / Monterey	4.2L	V6 OHV	LPSDM	√	√	√	√
2005	Freestar / Monterey	4.2L	V6 OHV	LTM	√	√	√	√
2005	Freestar / Monterey	4.2L	V6 OHV	NGSC	√	√	√	√
2005	Freestar / Monterey	4.2L	V6 OHV	PAM	√	√	√	√
2005	Freestar / Monterey	4.2L	V6 OHV	PCM	√	√	√	√
2005	Freestar / Monterey	4.2L	V6 OHV	PCSM	√	√	√	√
2005	Freestar / Monterey	4.2L	V6 OHV	RCM	√	√	√	√
2005	Freestar / Monterey	4.2L	V6 OHV	RPSDM	√	√	√	√
2005	Freestar / Monterey	4.2L	V6 OHV	TPM	√	√	√	√
2006	Freestar / Monterey	3.9L	V6 OHV	ABS	√	√	√	√
2006	Freestar / Monterey	3.9L	V6 OHV	DCSM	√	√	√	√
2006	Freestar / Monterey	3.9L	V6 OHV	EATC	√	√	√	√
2006	Freestar / Monterey	3.9L	V6 OHV	GEM	√	√	√	√
2006	Freestar / Monterey	3.9L	V6 OHV	IC	√	√	√	√
2006	Freestar / Monterey	3.9L	V6 OHV	LPSDM	√	√	√	√
2006	Freestar / Monterey	3.9L	V6 OHV	LTM	√	√	√	√
2006	Freestar / Monterey	3.9L	V6 OHV	NGSC	√	√	√	√
2006	Freestar / Monterey	3.9L	V6 OHV	PAM	√	√	√	√
2006	Freestar / Monterey	3.9L	V6 OHV	PCM	√	√	√	√
2006	Freestar / Monterey	3.9L	V6 OHV	PCSM	√	√	√	√
2006	Freestar / Monterey	3.9L	V6 OHV	RCM	√	√	√	√
2006	Freestar / Monterey	3.9L	V6 OHV	RPSDM	√	√	√	√
2006	Freestar / Monterey	4.2L	V6 OHV	ABS	√	√	√	√
2006	Freestar / Monterey	4.2L	V6 OHV	DCSM	√	√	√	√

2006	Freestar / Monterey	4.2L	V6 OHV	DSM	√	√	√	√
2006	Freestar / Monterey	4.2L	V6 OHV	EATC	√	√	√	√
2006	Freestar / Monterey	4.2L	V6 OHV	GEM	√	√	√	√
2006	Freestar / Monterey	4.2L	V6 OHV	IC	√	√	√	√
2006	Freestar / Monterey	4.2L	V6 OHV	LPSDM	√	√	√	√
2006	Freestar / Monterey	4.2L	V6 OHV	LTM	√	√	√	√
2006	Freestar / Monterey	4.2L	V6 OHV	NGSC	√	√	√	√
2006	Freestar / Monterey	4.2L	V6 OHV	PAM	√	√	√	√
2006	Freestar / Monterey	4.2L	V6 OHV	PCM	√	√	√	√
2006	Freestar / Monterey	4.2L	V6 OHV	PCSM	√	√	√	√
2006	Freestar / Monterey	4.2L	V6 OHV	RCM	√	√	√	√
2006	Freestar / Monterey	4.2L	V6 OHV	RPSDM	√	√	√	√
2007	Freestar / Monterey	3.9L	V6 OHV	ABS	√	√	√	√
2007	Freestar / Monterey	3.9L	V6 OHV	DCSM	√	√	√	√
2007	Freestar / Monterey	3.9L	V6 OHV	DSM	√	√	√	√
2007	Freestar / Monterey	3.9L	V6 OHV	EATC	√	√	√	√
2007	Freestar / Monterey	3.9L	V6 OHV	GEM	√	√	√	√
2007	Freestar / Monterey	3.9L	V6 OHV	IC	√	√	√	√
2007	Freestar / Monterey	3.9L	V6 OHV	LPSDM	√	√	√	√
2007	Freestar / Monterey	3.9L	V6 OHV	LTM	√	√	√	√
2007	Freestar / Monterey	3.9L	V6 OHV	NGSC	√	√	√	√
2007	Freestar / Monterey	3.9L	V6 OHV	PAM	√	√	√	√
2007	Freestar / Monterey	3.9L	V6 OHV	PCM	√	√	√	√
2007	Freestar / Monterey	3.9L	V6 OHV	PCSM	√	√	√	√
2007	Freestar / Monterey	3.9L	V6 OHV	RCM	√	√	√	√
2007	Freestar / Monterey	3.9L	V6 OHV	RPSDM	√	√	√	√
2007	Freestar / Monterey	4.2L	V6 OHV	ABS	√	√	√	√
2007	Freestar / Monterey	4.2L	V6 OHV	DCSM	√	√	√	√
2007	Freestar / Monterey	4.2L	V6 OHV	DSM	√	√	√	√
2007	Freestar / Monterey	4.2L	V6 OHV	EATC	√	√	√	√
2007	Freestar / Monterey	4.2L	V6 OHV	GEM	√	√	√	√
2007	Freestar / Monterey	4.2L	V6 OHV	IC	√	√	√	√
2007	Freestar / Monterey	4.2L	V6 OHV	LPSDM	√	√	√	√
2007	Freestar / Monterey	4.2L	V6 OHV	LTM	√	√	√	√
2007	Freestar / Monterey	4.2L	V6 OHV	NGSC	√	√	√	√
2007	Freestar / Monterey	4.2L	V6 OHV	PAM	√	√	√	√
2007	Freestar / Monterey	4.2L	V6 OHV	PCM	√	√	√	√
2007	Freestar / Monterey	4.2L	V6 OHV	PCSM	√	√	√	√
2007	Freestar / Monterey	4.2L	V6 OHV	RCM	√	√	√	√
2007	Freestar / Monterey	4.2L	V6 OHV	RPSDM	√	√	√	√
2005	Freestyle	3.0L	4V	4X4	√	√	√	√
2005	Freestyle	3.0L	4V	ABS	√	√	√	√
2005	Freestyle	3.0L	4V	ABS	√	√	√	√
2005	Freestyle	3.0L	4V	ACM	√	√	√	√
2005	Freestyle	3.0L	4V	ACM	√	√	√	√

2005	Freestyle	3.0L	4V	DSM	✓	✓	✓	✓
2005	Freestyle	3.0L	4V	EATC	✓	✓	✓	✓
2005	Freestyle	3.0L	4V	GEM	✓	✓	✓	✓
2005	Freestyle	3.0L	4V	IC	✓	✓	✓	✓
2005	Freestyle	3.0L	4V	PAM	✓	✓	✓	✓
2005	Freestyle	3.0L	4V	PAM	✓	✓	✓	✓
2005	Freestyle	3.0L	4V	PCM	✓	✓	✓	✓
2005	Freestyle	3.0L	4V	PCM	✓	✓	✓	✓
2005	Freestyle	3.0L	4V	RCM	✓	✓	✓	✓
2005	Freestyle	3.0L	4V	RCM	✓	✓	✓	✓
2005	Freestyle	3.0L	4V	RETM	✓	✓	✓	✓
2005	Freestyle	3.0L	4V	TCM	✓	✓	✓	✓
2006	Freestyle	3.0L	4V	4X4	✓	✓	✓	✓
2006	Freestyle	3.0L	4V	ABS	✓	✓	✓	✓
2006	Freestyle	3.0L	4V	ABS	✓	✓	✓	✓
2006	Freestyle	3.0L	4V	ACM	✓	✓	✓	✓
2006	Freestyle	3.0L	4V	ACM	✓	✓	✓	✓
2006	Freestyle	3.0L	4V	DSM	✓	✓	✓	✓
2006	Freestyle	3.0L	4V	EATC	✓	✓	✓	✓
2006	Freestyle	3.0L	4V	GEM	✓	✓	✓	✓
2006	Freestyle	3.0L	4V	IC	✓	✓	✓	✓
2006	Freestyle	3.0L	4V	PAM	✓	✓	✓	✓
2006	Freestyle	3.0L	4V	PAM	✓	✓	✓	✓
2006	Freestyle	3.0L	4V	PCM	✓	✓	✓	✓
2006	Freestyle	3.0L	4V	PCM	✓	✓	✓	✓
2006	Freestyle	3.0L	4V	RCM	✓	✓	✓	✓
2006	Freestyle	3.0L	4V	RCM	✓	✓	✓	✓
2006	Freestyle	3.0L	4V	RETM	✓	✓	✓	✓
2006	Freestyle	3.0L	4V	TCM	✓	✓	✓	✓
2007	Freestyle	3.0L	4V	4X4	✓	✓	✓	✓
2007	Freestyle	3.0L	4V	ABS	✓	✓	✓	✓
2007	Freestyle	3.0L	4V	ACM	✓	✓	✓	✓
2007	Freestyle	3.0L	4V	ACM	✓	✓	✓	✓
2007	Freestyle	3.0L	4V	DSM	✓	✓	✓	✓
2007	Freestyle	3.0L	4V	EATC	✓	✓	✓	✓
2007	Freestyle	3.0L	4V	GEM	✓	✓	✓	✓
2007	Freestyle	3.0L	4V	IC	✓	✓	✓	✓
2007	Freestyle	3.0L	4V	PAM	✓	✓	✓	✓
2007	Freestyle	3.0L	4V	PAM	✓	✓	✓	✓
2007	Freestyle	3.0L	4V	PCM	✓	✓	✓	✓
2007	Freestyle	3.0L	4V	PCM	✓	✓	✓	✓
2007	Freestyle	3.0L	4V	RCM	✓	✓	✓	✓
2007	Freestyle	3.0L	4V	RCM	✓	✓	✓	✓
2007	Freestyle	3.0L	4V	RCM	✓	✓	✓	✓
2007	Freestyle	3.0L	4V	RETM	✓	✓	✓	✓

2007	Freestyle	3.0L	4V	SDARS	✓	✓	✓	✓
2007	Freestyle	3.0L	4V	SDARS	✓	✓	✓	✓
2007	Freestyle	3.0L	4V	TCM	✓	✓	✓	✓
2002	Fusion	1.25L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓
2002	Fusion	1.25L	DURATEC 16V	GEM	✓	✓	✓	✓
2002	Fusion	1.25L	DURATEC 16V	IC	✓	✓	✓	✓
2002	Fusion	1.25L	DURATEC 16V	PCM	✓	✓	✓	✓
2002	Fusion	1.25L	DURATEC 16V	RCM	✓	✓	✓	✓
2002	Fusion	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓
2002	Fusion	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓
2002	Fusion	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓
2002	Fusion	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓
2002	Fusion	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓
2002	Fusion	1.4L	DURATEC 16V	IC	✓	✓	✓	✓
2002	Fusion	1.4L	DURATEC 16V	IC	✓	✓	✓	✓
2002	Fusion	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓
2002	Fusion	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓
2002	Fusion	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓
2002	Fusion	1.4L	DURATEC 16V	TCM	✓	✓	✓	✓
2002	Fusion	1.4L	DURATEC 16V	TCM	✓	✓	✓	✓
2002	Fusion	1.4L	Duratorq Turbo Diesel Common Rail	ABS/TCS	✓	✓	✓	✓
2002	Fusion	1.4L	Duratorq Turbo Diesel Common Rail	ABS/TCS	✓	✓	✓	✓
2002	Fusion	1.4L	Duratorq Turbo Diesel Common Rail	GEM	✓	✓	✓	✓
2002	Fusion	1.4L	Duratorq Turbo Diesel Common Rail	IC	✓	✓	✓	✓
2002	Fusion	1.4L	Duratorq Turbo Diesel Common Rail	PCM	✓	✓	✓	✓
2002	Fusion	1.4L	Duratorq Turbo Diesel Common Rail	RCM	✓	✓	✓	✓
2002	Fusion	1.4L	Duratorq Turbo Diesel Common Rail	TCM	✓	✓	✓	✓
2002	Fusion	1.6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓
2002	Fusion	1.6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓
2002	Fusion	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓
2002	Fusion	1.6L	DURATEC 16V	IC	✓	✓	✓	✓
2002	Fusion	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓
2002	Fusion	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓
2002	Fusion	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓
2002	Fusion	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓
2002	Fusion	1.6L	DURATEC 16V	TCM	✓	✓	✓	✓
2002	Fusion	1.6L	DURATEC 16V	TCM	✓	✓	✓	✓
2002	Fusion	1.6L	Duratorq Turbo Diesel Common Rail	ABS/TCS	✓	✓	✓	✓
2002	Fusion	1.6L	Duratorq Turbo Diesel Common Rail	EPS	✓	✓	✓	✓
2002	Fusion	1.6L	Duratorq Turbo Diesel Common Rail	GEM	✓	✓	✓	✓
2002	Fusion	1.6L	Duratorq Turbo Diesel Common Rail	IC	✓	✓	✓	✓
2002	Fusion	1.6L	Duratorq Turbo Diesel Common Rail	PCM	✓	✓	✓	✓
2002	Fusion	1.6L	Duratorq Turbo Diesel Common Rail	RCM	✓	✓	✓	✓
2006	Fusion	1.25L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓
2006	Fusion	1.25L	DURATEC 16V	ACM	✓	✓	✓	✓



2006	Fusion	1.25L	DURATEC 16V	EATC	✓	✓	✓	✓
2006	Fusion	1.25L	DURATEC 16V	GEM	✓	✓	✓	✓
2006	Fusion	1.25L	DURATEC 16V	IC	✓	✓	✓	✓
2006	Fusion	1.25L	DURATEC 16V	PCM	✓	✓	✓	✓
2006	Fusion	1.25L	DURATEC 16V	RCM	✓	✓	✓	✓
2006	Fusion	1.25L	DURATEC 16V	SRM	✓	✓	✓	✓
2006	Fusion	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓
2006	Fusion	1.4L	DURATEC 16V	ACM	✓	✓	✓	✓
2006	Fusion	1.4L	DURATEC 16V	EATC	✓	✓	✓	✓
2006	Fusion	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓
2006	Fusion	1.4L	DURATEC 16V	IC	✓	✓	✓	✓
2006	Fusion	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓
2006	Fusion	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓
2006	Fusion	1.4L	DURATEC 16V	TCM	✓	✓	✓	✓
2006	Fusion	1.4L	Duratorq Turbo Diesel Common Rail	ABS/TCS	✓	✓	✓	✓
2006	Fusion	1.4L	Duratorq Turbo Diesel Common Rail	ACM	✓	✓	✓	✓
2006	Fusion	1.4L	Duratorq Turbo Diesel Common Rail	EATC	✓	✓	✓	✓
2006	Fusion	1.4L	Duratorq Turbo Diesel Common Rail	GEM	✓	✓	✓	✓
2006	Fusion	1.4L	Duratorq Turbo Diesel Common Rail	IC	✓	✓	✓	✓
2006	Fusion	1.4L	Duratorq Turbo Diesel Common Rail	IC	✓	✓	✓	✓
2006	Fusion	1.4L	Duratorq Turbo Diesel Common Rail	PCM	✓	✓	✓	✓
2006	Fusion	1.4L	Duratorq Turbo Diesel Common Rail	RCM	✓	✓	✓	✓
2006	Fusion	1.4L	Duratorq Turbo Diesel Common Rail	SRM	✓	✓	✓	✓
2006	Fusion	1.4L	Duratorq Turbo Diesel Common Rail	TCM	✓	✓	✓	✓
2006	Fusion	1.6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓
2006	Fusion	1.6L	DURATEC 16V	ACM	✓	✓	✓	✓
2006	Fusion	1.6L	DURATEC 16V	EATC	✓	✓	✓	✓
2006	Fusion	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓
2006	Fusion	1.6L	DURATEC 16V	IC	✓	✓	✓	✓
2006	Fusion	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓
2006	Fusion	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓
2006	Fusion	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓
2006	Fusion	1.6L	DURATEC 16V	SRM	✓	✓	✓	✓
2006	Fusion	1.6L	DURATEC 16V	TCM	✓	✓	✓	✓
2006	Fusion	1.6L	Duratorq Turbo Diesel Common Rail	ABS/TCS	✓	✓	✓	✓
2006	Fusion	1.6L	Duratorq Turbo Diesel Common Rail	ACM	✓	✓	✓	✓
2006	Fusion	1.6L	Duratorq Turbo Diesel Common Rail	EATC	✓	✓	✓	✓
2006	Fusion	1.6L	Duratorq Turbo Diesel Common Rail	EPS	✓	✓	✓	✓
2006	Fusion	1.6L	Duratorq Turbo Diesel Common Rail	GEM	✓	✓	✓	✓
2006	Fusion	1.6L	Duratorq Turbo Diesel Common Rail	IC	✓	✓	✓	✓
2006	Fusion	1.6L	Duratorq Turbo Diesel Common Rail	PCM	✓	✓	✓	✓
2006	Fusion	1.6L	Duratorq Turbo Diesel Common Rail	RCM	✓	✓	✓	✓
2006	Fusion	1.6L	Duratorq Turbo Diesel Common Rail	SRM	✓	✓	✓	✓
2006	Fusion	2.3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓
2006	Fusion	2.3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓

2006	Fusion	2.3L	DURATEC-HE / I4	ACM	√	√	√	√
2006	Fusion	2.3L	DURATEC-HE / I4	ACM	√	√	√	√
2006	Fusion	2.3L	DURATEC-HE / I4	EATC	√	√	√	√
2006	Fusion	2.3L	DURATEC-HE / I4	GEM	√	√	√	√
2006	Fusion	2.3L	DURATEC-HE / I4	GEM	√	√	√	√
2006	Fusion	2.3L	DURATEC-HE / I4	IC	√	√	√	√
2006	Fusion	2.3L	DURATEC-HE / I4	OCSM	√	√	√	√
2006	Fusion	2.3L	DURATEC-HE / I4	OCSM	√	√	√	√
2006	Fusion	2.3L	DURATEC-HE / I4	OCSM	√	√	√	√
2006	Fusion	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2006	Fusion	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2006	Fusion	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2006	Fusion	2.3L	DURATEC-HE / I4	RCM	√	√	√	√
2006	Fusion	2.3L	DURATEC-HE / I4	RCM	√	√	√	√
2006	Fusion	2.3L	DURATEC-HE / I4	TBM	√	√	√	√
2006	Fusion	2.3L	DURATEC-HE / I4	TBM	√	√	√	√
2006	Fusion	2.3L	DURATEC-HE / I4	TCM	√	√	√	√
2006	Fusion	3.0L	4V	ABS	√	√	√	√
2006	Fusion	3.0L	4V	ABS	√	√	√	√
2006	Fusion	3.0L	4V	ACM	√	√	√	√
2006	Fusion	3.0L	4V	ACM	√	√	√	√
2006	Fusion	3.0L	4V	EATC	√	√	√	√
2006	Fusion	3.0L	4V	GEM	√	√	√	√
2006	Fusion	3.0L	4V	IC	√	√	√	√
2006	Fusion	3.0L	4V	OCSM	√	√	√	√
2006	Fusion	3.0L	4V	OCSM	√	√	√	√
2006	Fusion	3.0L	4V	PCM	√	√	√	√
2006	Fusion	3.0L	4V	PCM	√	√	√	√
2006	Fusion	3.0L	4V	RCM	√	√	√	√
2006	Fusion	3.0L	4V	TBM	√	√	√	√
2006	Fusion	3.0L	4V	TBM	√	√	√	√
2006	Fusion	3.0L	4V	TCM	√	√	√	√
2007	Fusion	2.3L	DURATEC-HE / I4	4X4	√	√	√	√
2007	Fusion	2.3L	DURATEC-HE / I4	ABS	√	√	√	√
2007	Fusion	2.3L	DURATEC-HE / I4	ABS	√	√	√	√
2007	Fusion	2.3L	DURATEC-HE / I4	ACM	√	√	√	√
2007	Fusion	2.3L	DURATEC-HE / I4	EATC	√	√	√	√
2007	Fusion	2.3L	DURATEC-HE / I4	GEM	√	√	√	√
2007	Fusion	2.3L	DURATEC-HE / I4	GEM	√	√	√	√
2007	Fusion	2.3L	DURATEC-HE / I4	IC	√	√	√	√
2007	Fusion	2.3L	DURATEC-HE / I4	IC	√	√	√	√
2007	Fusion	2.3L	DURATEC-HE / I4	OCSM	√	√	√	√
2007	Fusion	2.3L	DURATEC-HE / I4	OCSM	√	√	√	√
2007	Fusion	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2007	Fusion	2.3L	DURATEC-HE / I4	PCM	√	√	√	√

2007	Fusion	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2007	Fusion	2.3L	DURATEC-HE / I4	RCM	√	√	√	√
2007	Fusion	2.3L	DURATEC-HE / I4	RCM	√	√	√	√
2007	Fusion	2.3L	DURATEC-HE / I4	SDARS	√	√	√	√
2007	Fusion	2.3L	DURATEC-HE / I4	SDARS	√	√	√	√
2007	Fusion	2.3L	DURATEC-HE / I4	TBM	√	√	√	√
2007	Fusion	2.3L	DURATEC-HE / I4	TBM	√	√	√	√
2007	Fusion	2.3L	DURATEC-HE / I4	TCM	√	√	√	√
2007	Fusion	3.0L	4V	4X4	√	√	√	√
2007	Fusion	3.0L	4V	ABS	√	√	√	√
2007	Fusion	3.0L	4V	ABS	√	√	√	√
2007	Fusion	3.0L	4V	ACM	√	√	√	√
2007	Fusion	3.0L	4V	ACM	√	√	√	√
2007	Fusion	3.0L	4V	EATC	√	√	√	√
2007	Fusion	3.0L	4V	GEM	√	√	√	√
2007	Fusion	3.0L	4V	IC	√	√	√	√
2007	Fusion	3.0L	4V	IC	√	√	√	√
2007	Fusion	3.0L	4V	OCSM	√	√	√	√
2007	Fusion	3.0L	4V	OCSM	√	√	√	√
2007	Fusion	3.0L	4V	PCM	√	√	√	√
2007	Fusion	3.0L	4V	PCM	√	√	√	√
2007	Fusion	3.0L	4V	RCM	√	√	√	√
2007	Fusion	3.0L	4V	RCM	√	√	√	√
2007	Fusion	3.0L	4V	SDARS	√	√	√	√
2007	Fusion	3.0L	4V	SDARS	√	√	√	√
2007	Fusion	3.0L	4V	TBM	√	√	√	√
2007	Fusion	3.0L	4V	TBM	√	√	√	√
2007	Fusion	3.0L	4V	TCM	√	√	√	√
2008	Fusion	2.3L	DURATEC-HE / I4	4X4	√	√	√	√
2008	Fusion	2.3L	DURATEC-HE / I4	ABS	√	√	√	√
2008	Fusion	2.3L	DURATEC-HE / I4	ABS	√	√	√	√
2008	Fusion	2.3L	DURATEC-HE / I4	ACM	√	√	√	√
2008	Fusion	2.3L	DURATEC-HE / I4	ACM	√	√	√	√
2008	Fusion	2.3L	DURATEC-HE / I4	ACM	√	√	√	√
2008	Fusion	2.3L	DURATEC-HE / I4	APIM	√	√	√	√
2008	Fusion	2.3L	DURATEC-HE / I4	APIM	√	√	√	√
2008	Fusion	2.3L	DURATEC-HE / I4	GEM / SJB	√	√	√	√
2008	Fusion	2.3L	DURATEC-HE / I4	GEM / SJB	√	√	√	√
2008	Fusion	2.3L	DURATEC-HE / I4	GEM / SJB	√	√	√	√
2008	Fusion	2.3L	DURATEC-HE / I4	HVAC	√	√	√	√
2008	Fusion	2.3L	DURATEC-HE / I4	IC	√	√	√	√
2008	Fusion	2.3L	DURATEC-HE / I4	IC	√	√	√	√
2008	Fusion	2.3L	DURATEC-HE / I4	OCSM	√	√	√	√
2008	Fusion	2.3L	DURATEC-HE / I4	OCSM	√	√	√	√
2008	Fusion	2.3L	DURATEC-HE / I4	OCSM	√	√	√	√

2008	Fusion	2.3L	DURATEC-HE / I4	PAM	√	√	√	√
2008	Fusion	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2008	Fusion	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2008	Fusion	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2008	Fusion	2.3L	DURATEC-HE / I4	RCM	√	√	√	√
2008	Fusion	2.3L	DURATEC-HE / I4	RCM	√	√	√	√
2008	Fusion	2.3L	DURATEC-HE / I4	SDARS	√	√	√	√
2008	Fusion	2.3L	DURATEC-HE / I4	TBM	√	√	√	√
2008	Fusion	2.3L	DURATEC-HE / I4	TBM	√	√	√	√
2008	Fusion	2.3L	DURATEC-HE / I4	TCM	√	√	√	√
2008	Fusion	3.0L	4V	4X4	√	√	√	√
2008	Fusion	3.0L	4V	ABS	√	√	√	√
2008	Fusion	3.0L	4V	ABS	√	√	√	√
2008	Fusion	3.0L	4V	ACM	√	√	√	√
2008	Fusion	3.0L	4V	ACM	√	√	√	√
2008	Fusion	3.0L	4V	APIM	√	√	√	√
2008	Fusion	3.0L	4V	APIM	√	√	√	√
2008	Fusion	3.0L	4V	GEM / SJB	√	√	√	√
2008	Fusion	3.0L	4V	GEM / SJB	√	√	√	√
2008	Fusion	3.0L	4V	HVAC	√	√	√	√
2008	Fusion	3.0L	4V	IC	√	√	√	√
2008	Fusion	3.0L	4V	OCSM	√	√	√	√
2008	Fusion	3.0L	4V	OCSM	√	√	√	√
2008	Fusion	3.0L	4V	PAM	√	√	√	√
2008	Fusion	3.0L	4V	PCM	√	√	√	√
2008	Fusion	3.0L	4V	PCM	√	√	√	√
2008	Fusion	3.0L	4V	RCM	√	√	√	√
2008	Fusion	3.0L	4V	SDARS	√	√	√	√
2008	Fusion	3.0L	4V	TBM	√	√	√	√
2008	Fusion	3.0L	4V	TBM	√	√	√	√
2009	Fusion	2.3L	DURATEC-HE / I4	4X4	√	√	√	√
2009	Fusion	2.3L	DURATEC-HE / I4	ABS	√	√	√	√
2009	Fusion	2.3L	DURATEC-HE / I4	ABS	√	√	√	√
2009	Fusion	2.3L	DURATEC-HE / I4	ACM	√	√	√	√
2009	Fusion	2.3L	DURATEC-HE / I4	ACM	√	√	√	√
2009	Fusion	2.3L	DURATEC-HE / I4	APIM	√	√	√	√
2009	Fusion	2.3L	DURATEC-HE / I4	APIM	√	√	√	√
2009	Fusion	2.3L	DURATEC-HE / I4	GEM / SJB	√	√	√	√
2009	Fusion	2.3L	DURATEC-HE / I4	GEM / SJB	√	√	√	√
2009	Fusion	2.3L	DURATEC-HE / I4	HVAC	√	√	√	√
2009	Fusion	2.3L	DURATEC-HE / I4	IC	√	√	√	√
2009	Fusion	2.3L	DURATEC-HE / I4	IC	√	√	√	√
2009	Fusion	2.3L	DURATEC-HE / I4	OCSM	√	√	√	√
2009	Fusion	2.3L	DURATEC-HE / I4	OCSM	√	√	√	√
2009	Fusion	2.3L	DURATEC-HE / I4	PAM	√	√	√	√

2009	Fusion	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2009	Fusion	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2009	Fusion	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2009	Fusion	2.3L	DURATEC-HE / I4	RCM	√	√	√	√
2009	Fusion	2.3L	DURATEC-HE / I4	RCM	√	√	√	√
2009	Fusion	2.3L	DURATEC-HE / I4	SDARS	√	√	√	√
2009	Fusion	2.3L	DURATEC-HE / I4	SDARS	√	√	√	√
2009	Fusion	2.3L	DURATEC-HE / I4	TBM	√	√	√	√
2009	Fusion	2.3L	DURATEC-HE / I4	TBM	√	√	√	√
2009	Fusion	2.3L	DURATEC-HE / I4	TCM	√	√	√	√
2009	Fusion	3.0L	4V	4X4	√	√	√	√
2009	Fusion	3.0L	4V	ABS	√	√	√	√
2009	Fusion	3.0L	4V	ABS	√	√	√	√
2009	Fusion	3.0L	4V	ACM	√	√	√	√
2009	Fusion	3.0L	4V	ACM	√	√	√	√
2009	Fusion	3.0L	4V	APIM	√	√	√	√
2009	Fusion	3.0L	4V	APIM	√	√	√	√
2009	Fusion	3.0L	4V	GEM / SJB	√	√	√	√
2009	Fusion	3.0L	4V	GEM / SJB	√	√	√	√
2009	Fusion	3.0L	4V	HVAC	√	√	√	√
2009	Fusion	3.0L	4V	IC	√	√	√	√
2009	Fusion	3.0L	4V	OCSM	√	√	√	√
2009	Fusion	3.0L	4V	OCSM	√	√	√	√
2009	Fusion	3.0L	4V	PAM	√	√	√	√
2009	Fusion	3.0L	4V	PCM	√	√	√	√
2009	Fusion	3.0L	4V	PCM	√	√	√	√
2009	Fusion	3.0L	4V	RCM	√	√	√	√
2009	Fusion	3.0L	4V	SDARS	√	√	√	√
2009	Fusion	3.0L	4V	TBM	√	√	√	√
2009	Fusion	3.0L	4V	TBM	√	√	√	√
2009	Fusion	3.0L	4V	TCM	√	√	√	√
2010	Fusion	2.5L	DURATEC-HE / I4	4X4	√	√	√	√
2010	Fusion	2.5L	DURATEC-HE / I4	ABS	√	√	√	√
2010	Fusion	2.5L	DURATEC-HE / I4	ABS	√	√	√	√
2010	Fusion	2.5L	DURATEC-HE / I4	ACM	√	√	√	√
2010	Fusion	2.5L	DURATEC-HE / I4	ACM	√	√	√	√
2010	Fusion	2.5L	DURATEC-HE / I4	APIM	√	√	√	√
2010	Fusion	2.5L	DURATEC-HE / I4	DSP	√	√	√	
2010	Fusion	2.5L	DURATEC-HE / I4	DSP	√	√	√	
2010	Fusion	2.5L	DURATEC-HE / I4	FCIM	√	√	√	
2010	Fusion	2.5L	DURATEC-HE / I4	FCIM	√	√	√	√
2010	Fusion	2.5L	DURATEC-HE / I4	FDIM	√	√	√	√
2010	Fusion	2.5L	DURATEC-HE / I4	FDIM	√	√	√	√
2010	Fusion	2.5L	DURATEC-HE / I4	GEM / SJB	√	√	√	√
2010	Fusion	2.5L	DURATEC-HE / I4	GEM / SJB	√	√	√	√

2010	Fusion	2.5L	DURATEC-HE / I4	GPSM	√	√	√	√
2010	Fusion	2.5L	DURATEC-HE / I4	HVAC	√	√	√	√
2010	Fusion	2.5L	DURATEC-HE / I4	IPC	√	√	√	√
2010	Fusion	2.5L	DURATEC-HE / I4	IPC	√	√	√	√
2010	Fusion	2.5L	DURATEC-HE / I4	OCSM	√	√	√	√
2010	Fusion	2.5L	DURATEC-HE / I4	PAM	√	√	√	√
2010	Fusion	2.5L	DURATEC-HE / I4	PAM	√	√	√	√
2010	Fusion	2.5L	DURATEC-HE / I4	PCM	√	√	√	√
2010	Fusion	2.5L	DURATEC-HE / I4	PCM	√	√	√	√
2010	Fusion	2.5L	DURATEC-HE / I4	PCM	√	√	√	√
2010	Fusion	2.5L	DURATEC-HE / I4	PSCM	√	√	√	√
2010	Fusion	2.5L	DURATEC-HE / I4	PSCM	√	√	√	√
2010	Fusion	2.5L	DURATEC-HE / I4	RCM	√	√	√	√
2010	Fusion	2.5L	DURATEC-HE / I4	RCM	√	√	√	√
2010	Fusion	2.5L	DURATEC-HE / I4	SOD-L	√	√	√	√
2010	Fusion	2.5L	DURATEC-HE / I4	SOD-R	√	√	√	√
2010	Fusion	2.5L	DURATEC-HE / I4	TBM	√	√	√	√
2010	Fusion	2.5L	HEV / ATKINSON 4V	4X4	√	√	√	√
2010	Fusion	2.5L	HEV / ATKINSON 4V	ABS	√	√	√	√
2010	Fusion	2.5L	HEV / ATKINSON 4V	ACCM#2	√	√	√	√
2010	Fusion	2.5L	HEV / ATKINSON 4V	ACM	√	√	√	√
2010	Fusion	2.5L	HEV / ATKINSON 4V	ACM	√	√	√	√
2010	Fusion	2.5L	HEV / ATKINSON 4V	APIM	√	√	√	√
2010	Fusion	2.5L	HEV / ATKINSON 4V	BECM	√	√	√	√
2010	Fusion	2.5L	HEV / ATKINSON 4V	DSP	√	√	√	
2010	Fusion	2.5L	HEV / ATKINSON 4V	DSP	√	√	√	
2010	Fusion	2.5L	HEV / ATKINSON 4V	FCIM	√	√	√	
2010	Fusion	2.5L	HEV / ATKINSON 4V	FCIM	√	√	√	√
2010	Fusion	2.5L	HEV / ATKINSON 4V	FDIM	√	√	√	√
2010	Fusion	2.5L	HEV / ATKINSON 4V	FDIM	√	√	√	√
2010	Fusion	2.5L	HEV / ATKINSON 4V	GEM / SJB	√	√	√	√
2010	Fusion	2.5L	HEV / ATKINSON 4V	GPSM	√	√	√	√
2010	Fusion	2.5L	HEV / ATKINSON 4V	HVAC	√	√	√	√
2010	Fusion	2.5L	HEV / ATKINSON 4V	IPC	√	√	√	√
2010	Fusion	2.5L	HEV / ATKINSON 4V	OCSM	√	√	√	√
2010	Fusion	2.5L	HEV / ATKINSON 4V	PAM	√	√	√	√
2010	Fusion	2.5L	HEV / ATKINSON 4V	PAM	√	√	√	√
2010	Fusion	2.5L	HEV / ATKINSON 4V	PCM	√	√	√	√
2010	Fusion	2.5L	HEV / ATKINSON 4V	PCM	√	√	√	√
2010	Fusion	2.5L	HEV / ATKINSON 4V	PSCM	√	√	√	√
2010	Fusion	2.5L	HEV / ATKINSON 4V	PSCM	√	√	√	√
2010	Fusion	2.5L	HEV / ATKINSON 4V	RCM	√	√	√	√
2010	Fusion	2.5L	HEV / ATKINSON 4V	RCM	√	√	√	√
2010	Fusion	2.5L	HEV / ATKINSON 4V	SOD-L	√	√	√	√
2010	Fusion	2.5L	HEV / ATKINSON 4V	SOD-R	√	√	√	√

2010	Fusion	2.5L	HEV / ATKINSON 4V	TBM	✓	✓	✓	✓
2010	Fusion	2.5L	HEV / ATKINSON 4V	TCM	✓	✓	✓	✓
2010	Fusion	3.0L	4V	4X4	✓	✓	✓	✓
2010	Fusion	3.0L	4V	ABS	✓	✓	✓	✓
2010	Fusion	3.0L	4V	ACM	✓	✓	✓	✓
2010	Fusion	3.0L	4V	APIM	✓	✓	✓	✓
2010	Fusion	3.0L	4V	DSP	✓	✓	✓	
2010	Fusion	3.0L	4V	FCIM	✓	✓	✓	
2010	Fusion	3.0L	4V	FCIM	✓	✓	✓	✓
2010	Fusion	3.0L	4V	FDIM	✓	✓	✓	✓
2010	Fusion	3.0L	4V	GEM / SJB	✓	✓	✓	✓
2010	Fusion	3.0L	4V	GPSM	✓	✓	✓	✓
2010	Fusion	3.0L	4V	HVAC	✓	✓	✓	✓
2010	Fusion	3.0L	4V	IPC	✓	✓	✓	✓
2010	Fusion	3.0L	4V	OCSM	✓	✓	✓	✓
2010	Fusion	3.0L	4V	PAM	✓	✓	✓	✓
2010	Fusion	3.0L	4V	PCM	✓	✓	✓	✓
2010	Fusion	3.0L	4V	PSCM	✓	✓	✓	✓
2010	Fusion	3.0L	4V	RCM	✓	✓	✓	✓
2010	Fusion	3.0L	4V	SOD-L	✓	✓	✓	✓
2010	Fusion	3.0L	4V	SOD-R	✓	✓	✓	✓
2010	Fusion	3.0L	4V	TBM	✓	✓	✓	✓
2010	Fusion	3.5L	4V	4X4	✓	✓	✓	✓
2010	Fusion	3.5L	4V	ABS	✓	✓	✓	✓
2010	Fusion	3.5L	4V	ABS	✓	✓	✓	✓
2010	Fusion	3.5L	4V	ABS	✓	✓	✓	✓
2010	Fusion	3.5L	4V	ACM	✓	✓	✓	✓
2010	Fusion	3.5L	4V	ACM	✓	✓	✓	✓
2010	Fusion	3.5L	4V	ACM	✓	✓	✓	✓
2010	Fusion	3.5L	4V	APIM	✓	✓	✓	✓
2010	Fusion	3.5L	4V	APIM	✓	✓	✓	✓
2010	Fusion	3.5L	4V	DSP	✓	✓	✓	
2010	Fusion	3.5L	4V	FCIM	✓	✓	✓	
2010	Fusion	3.5L	4V	FCIM	✓	✓	✓	✓
2010	Fusion	3.5L	4V	FDIM	✓	✓	✓	✓
2010	Fusion	3.5L	4V	FDIM	✓	✓	✓	✓
2010	Fusion	3.5L	4V	GEM / SJB	✓	✓	✓	✓
2010	Fusion	3.5L	4V	GEM / SJB	✓	✓	✓	✓
2010	Fusion	3.5L	4V	GEM / SJB	✓	✓	✓	✓
2010	Fusion	3.5L	4V	GPSM	✓	✓	✓	✓
2010	Fusion	3.5L	4V	HVAC	✓	✓	✓	✓
2010	Fusion	3.5L	4V	IPC	✓	✓	✓	✓
2010	Fusion	3.5L	4V	OCSM	✓	✓	✓	✓
2010	Fusion	3.5L	4V	OCSM	✓	✓	✓	✓
2010	Fusion	3.5L	4V	PAM	✓	✓	✓	✓

2010	Fusion	3.5L	4V	PAM	√	√	√	√
2010	Fusion	3.5L	4V	PCM	√	√	√	√
2010	Fusion	3.5L	4V	PCM	√	√	√	√
2010	Fusion	3.5L	4V	PSCM	√	√	√	√
2010	Fusion	3.5L	4V	RCM	√	√	√	√
2010	Fusion	3.5L	4V	RCM	√	√	√	√
2010	Fusion	3.5L	4V	SOD-L	√	√	√	√
2010	Fusion	3.5L	4V	SOD-R	√	√	√	√
2010	Fusion	3.5L	4V	TBM	√	√	√	√
2010	Fusion	3.5L	4V	TBM	√	√	√	√
2010	Fusion	3.5L	4V	TCM	√	√	√	√
2011	Fusion	2.5L	DURATEC-HE / I4	4X4	√	√	√	√
2011	Fusion	2.5L	DURATEC-HE / I4	ABS	√	√	√	√
2011	Fusion	2.5L	DURATEC-HE / I4	ACM	√	√	√	√
2011	Fusion	2.5L	DURATEC-HE / I4	APIM	√	√	√	√
2011	Fusion	2.5L	DURATEC-HE / I4	DSP	√	√	√	
2011	Fusion	2.5L	DURATEC-HE / I4	FCIM	√	√	√	
2011	Fusion	2.5L	DURATEC-HE / I4	FCIM	√	√	√	√
2011	Fusion	2.5L	DURATEC-HE / I4	FDIM	√	√	√	√
2011	Fusion	2.5L	DURATEC-HE / I4	GEM / SJB	√	√	√	√
2011	Fusion	2.5L	DURATEC-HE / I4	GPSM	√	√	√	√
2011	Fusion	2.5L	DURATEC-HE / I4	IPC	√	√	√	√
2011	Fusion	2.5L	DURATEC-HE / I4	OCSM	√	√	√	√
2011	Fusion	2.5L	DURATEC-HE / I4	PAM	√	√	√	√
2011	Fusion	2.5L	DURATEC-HE / I4	PCM	√	√	√	√
2011	Fusion	2.5L	DURATEC-HE / I4	PCM	√	√	√	√
2011	Fusion	2.5L	DURATEC-HE / I4	PCM	√	√	√	√
2011	Fusion	2.5L	DURATEC-HE / I4	PSCM	√	√	√	√
2011	Fusion	2.5L	DURATEC-HE / I4	RCM	√	√	√	√
2011	Fusion	2.5L	DURATEC-HE / I4	SOD-L	√	√	√	√
2011	Fusion	2.5L	DURATEC-HE / I4	SOD-R	√	√	√	√
2011	Fusion	2.5L	DURATEC-HE / I4	TBM	√	√	√	√
2011	Fusion	2.5L	HEV / ATKINSON 4V	4X4	√	√	√	√
2011	Fusion	2.5L	HEV / ATKINSON 4V	ABS	√	√	√	√
2011	Fusion	2.5L	HEV / ATKINSON 4V	ACCM#2	√	√	√	√
2011	Fusion	2.5L	HEV / ATKINSON 4V	ACM	√	√	√	√
2011	Fusion	2.5L	HEV / ATKINSON 4V	ACM	√	√	√	√
2011	Fusion	2.5L	HEV / ATKINSON 4V	APIM	√	√	√	√
2011	Fusion	2.5L	HEV / ATKINSON 4V	BECM	√	√	√	√
2011	Fusion	2.5L	HEV / ATKINSON 4V	DCDC	√	√	√	√
2011	Fusion	2.5L	HEV / ATKINSON 4V	DSP	√	√	√	
2011	Fusion	2.5L	HEV / ATKINSON 4V	FCIM	√	√	√	
2011	Fusion	2.5L	HEV / ATKINSON 4V	FCIM	√	√	√	√
2011	Fusion	2.5L	HEV / ATKINSON 4V	FDIM	√	√	√	√
2011	Fusion	2.5L	HEV / ATKINSON 4V	GEM / SJB	√	√	√	√



2011	Fusion	2.5L	HEV / ATKINSON 4V	GPSM	√	√	√	√
2011	Fusion	2.5L	HEV / ATKINSON 4V	HVAC	√	√	√	√
2011	Fusion	2.5L	HEV / ATKINSON 4V	IPC	√	√	√	√
2011	Fusion	2.5L	HEV / ATKINSON 4V	OCSM	√	√	√	√
2011	Fusion	2.5L	HEV / ATKINSON 4V	PAM	√	√	√	√
2011	Fusion	2.5L	HEV / ATKINSON 4V	PCM	√	√	√	√
2011	Fusion	2.5L	HEV / ATKINSON 4V	PCM	√	√	√	√
2011	Fusion	2.5L	HEV / ATKINSON 4V	PSCM	√	√	√	√
2011	Fusion	2.5L	HEV / ATKINSON 4V	RCM	√	√	√	√
2011	Fusion	2.5L	HEV / ATKINSON 4V	SOD-L	√	√	√	√
2011	Fusion	2.5L	HEV / ATKINSON 4V	SOD-R	√	√	√	√
2011	Fusion	2.5L	HEV / ATKINSON 4V	TBM	√	√	√	√
2011	Fusion	2.5L	HEV / ATKINSON 4V	TCM	√	√	√	√
2011	Fusion	3.0L	4V	4X4	√	√	√	√
2011	Fusion	3.0L	4V	ABS	√	√	√	√
2011	Fusion	3.0L	4V	ACM	√	√	√	√
2011	Fusion	3.0L	4V	APIM	√	√	√	√
2011	Fusion	3.0L	4V	DSP	√	√	√	
2011	Fusion	3.0L	4V	FCIM	√	√	√	
2011	Fusion	3.0L	4V	FCIM	√	√	√	√
2011	Fusion	3.0L	4V	FDIM	√	√	√	√
2011	Fusion	3.0L	4V	GEM / SJB	√	√	√	√
2011	Fusion	3.0L	4V	GPSM	√	√	√	√
2011	Fusion	3.0L	4V	HVAC	√	√	√	√
2011	Fusion	3.0L	4V	IPC	√	√	√	√
2011	Fusion	3.0L	4V	OCSM	√	√	√	√
2011	Fusion	3.0L	4V	PAM	√	√	√	√
2011	Fusion	3.0L	4V	PCM	√	√	√	√
2011	Fusion	3.0L	4V	PSCM	√	√	√	√
2011	Fusion	3.0L	4V	RCM	√	√	√	√
2011	Fusion	3.0L	4V	SOD-L	√	√	√	√
2011	Fusion	3.0L	4V	SOD-R	√	√	√	√
2011	Fusion	3.0L	4V	TBM	√	√	√	√
2011	Fusion	3.5L	4V	4X4	√	√	√	√
2011	Fusion	3.5L	4V	ABS	√	√	√	√
2011	Fusion	3.5L	4V	ABS	√	√	√	√
2011	Fusion	3.5L	4V	ACM	√	√	√	√
2011	Fusion	3.5L	4V	ACM	√	√	√	√
2011	Fusion	3.5L	4V	APIM	√	√	√	√
2011	Fusion	3.5L	4V	APIM	√	√	√	√
2011	Fusion	3.5L	4V	DSP	√	√	√	
2011	Fusion	3.5L	4V	FCIM	√	√	√	
2011	Fusion	3.5L	4V	FCIM	√	√	√	√
2011	Fusion	3.5L	4V	FDIM	√	√	√	√
2011	Fusion	3.5L	4V	GEM / SJB	√	√	√	√

2011	Fusion	3.5L	4V	GEM / SJB	√	√	√	√
2011	Fusion	3.5L	4V	GPSM	√	√	√	√
2011	Fusion	3.5L	4V	HVAC	√	√	√	√
2011	Fusion	3.5L	4V	IPC	√	√	√	√
2011	Fusion	3.5L	4V	OCSM	√	√	√	√
2011	Fusion	3.5L	4V	OCSM	√	√	√	√
2011	Fusion	3.5L	4V	PAM	√	√	√	√
2011	Fusion	3.5L	4V	PCM	√	√	√	√
2011	Fusion	3.5L	4V	PCM	√	√	√	√
2011	Fusion	3.5L	4V	PSCM	√	√	√	√
2011	Fusion	3.5L	4V	RCM	√	√	√	√
2011	Fusion	3.5L	4V	SOD-L	√	√	√	√
2011	Fusion	3.5L	4V	SOD-R	√	√	√	√
2011	Fusion	3.5L	4V	TBM	√	√	√	√
2011	Fusion	3.5L	4V	TBM	√	√	√	√
2011	Fusion	3.5L	4V	TCM	√	√	√	√
2012	Fusion	2.5L	DURATEC-HE / I4	4X4	√	√	√	√
2012	Fusion	2.5L	DURATEC-HE / I4	ABS	√	√	√	√
2012	Fusion	2.5L	DURATEC-HE / I4	ACM	√	√	√	√
2012	Fusion	2.5L	DURATEC-HE / I4	APIM	√	√	√	√
2012	Fusion	2.5L	DURATEC-HE / I4	APIM	√	√	√	√
2012	Fusion	2.5L	DURATEC-HE / I4	DSP	√	√	√	
2012	Fusion	2.5L	DURATEC-HE / I4	FCIM	√	√	√	
2012	Fusion	2.5L	DURATEC-HE / I4	FCIM	√	√	√	√
2012	Fusion	2.5L	DURATEC-HE / I4	FDIM	√	√	√	√
2012	Fusion	2.5L	DURATEC-HE / I4	GEM / SJB	√	√	√	√
2012	Fusion	2.5L	DURATEC-HE / I4	GEM / SJB	√	√	√	√
2012	Fusion	2.5L	DURATEC-HE / I4	GPSM	√	√	√	√
2012	Fusion	2.5L	DURATEC-HE / I4	HVAC	√	√	√	√
2012	Fusion	2.5L	DURATEC-HE / I4	IPC	√	√	√	√
2012	Fusion	2.5L	DURATEC-HE / I4	OCSM	√	√	√	√
2012	Fusion	2.5L	DURATEC-HE / I4	OCSM	√	√	√	√
2012	Fusion	2.5L	DURATEC-HE / I4	PAM	√	√	√	√
2012	Fusion	2.5L	DURATEC-HE / I4	PCM	√	√	√	√
2012	Fusion	2.5L	DURATEC-HE / I4	PCM	√	√	√	√
2012	Fusion	2.5L	DURATEC-HE / I4	PSCM	√	√	√	√
2012	Fusion	2.5L	DURATEC-HE / I4	RCM	√	√	√	√
2012	Fusion	2.5L	DURATEC-HE / I4	SOD-L	√	√	√	√
2012	Fusion	2.5L	DURATEC-HE / I4	SOD-R	√	√	√	√
2012	Fusion	2.5L	DURATEC-HE / I4	TBM	√	√	√	√
2012	Fusion	2.5L	DURATEC-HE / I4	TBM	√	√	√	√
2012	Fusion	2.5L	HEV / ATKINSON 4V	4X4	√	√	√	√
2012	Fusion	2.5L	HEV / ATKINSON 4V	ABS	√	√	√	√
2012	Fusion	2.5L	HEV / ATKINSON 4V	ACCM#2	√	√	√	√
2012	Fusion	2.5L	HEV / ATKINSON 4V	ACM	√	√	√	√

2012	Fusion	2.5L	HEV / ATKINSON 4V	ACM	√	√	√	√
2012	Fusion	2.5L	HEV / ATKINSON 4V	APIM	√	√	√	√
2012	Fusion	2.5L	HEV / ATKINSON 4V	BECM	√	√	√	√
2012	Fusion	2.5L	HEV / ATKINSON 4V	DCDC	√	√	√	√
2012	Fusion	2.5L	HEV / ATKINSON 4V	DSP	√	√	√	
2012	Fusion	2.5L	HEV / ATKINSON 4V	FCIM	√	√	√	
2012	Fusion	2.5L	HEV / ATKINSON 4V	FCIM	√	√	√	√
2012	Fusion	2.5L	HEV / ATKINSON 4V	FDIM	√	√	√	√
2012	Fusion	2.5L	HEV / ATKINSON 4V	GEM / SJB	√	√	√	√
2012	Fusion	2.5L	HEV / ATKINSON 4V	GPSM	√	√	√	√
2012	Fusion	2.5L	HEV / ATKINSON 4V	HVAC	√	√	√	√
2012	Fusion	2.5L	HEV / ATKINSON 4V	IPC	√	√	√	√
2012	Fusion	2.5L	HEV / ATKINSON 4V	OCSM	√	√	√	√
2012	Fusion	2.5L	HEV / ATKINSON 4V	PAM	√	√	√	√
2012	Fusion	2.5L	HEV / ATKINSON 4V	PCM	√	√	√	√
2012	Fusion	2.5L	HEV / ATKINSON 4V	PCM	√	√	√	√
2012	Fusion	2.5L	HEV / ATKINSON 4V	PSCM	√	√	√	√
2012	Fusion	2.5L	HEV / ATKINSON 4V	RCM	√	√	√	√
2012	Fusion	2.5L	HEV / ATKINSON 4V	SOD-L	√	√	√	√
2012	Fusion	2.5L	HEV / ATKINSON 4V	SOD-R	√	√	√	√
2012	Fusion	2.5L	HEV / ATKINSON 4V	TBM	√	√	√	√
2012	Fusion	2.5L	HEV / ATKINSON 4V	TCM	√	√	√	√
2012	Fusion	3.0L	4V	4X4	√	√	√	√
2012	Fusion	3.0L	4V	ABS	√	√	√	√
2012	Fusion	3.0L	4V	ACM	√	√	√	√
2012	Fusion	3.0L	4V	APIM	√	√	√	√
2012	Fusion	3.0L	4V	DSP	√	√	√	
2012	Fusion	3.0L	4V	FCIM	√	√	√	
2012	Fusion	3.0L	4V	FCIM	√	√	√	√
2012	Fusion	3.0L	4V	FDIM	√	√	√	√
2012	Fusion	3.0L	4V	GEM / SJB	√	√	√	√
2012	Fusion	3.0L	4V	GPSM	√	√	√	√
2012	Fusion	3.0L	4V	HVAC	√	√	√	√
2012	Fusion	3.0L	4V	IPC	√	√	√	√
2012	Fusion	3.0L	4V	OCSM	√	√	√	√
2012	Fusion	3.0L	4V	PAM	√	√	√	√
2012	Fusion	3.0L	4V	PCM	√	√	√	√
2012	Fusion	3.0L	4V	PSCM	√	√	√	√
2012	Fusion	3.0L	4V	RCM	√	√	√	√
2012	Fusion	3.0L	4V	SOD-L	√	√	√	√
2012	Fusion	3.0L	4V	SOD-R	√	√	√	√
2012	Fusion	3.0L	4V	TBM	√	√	√	√
2012	Fusion	3.5L	4V	4X4	√	√	√	√
2012	Fusion	3.5L	4V	ABS	√	√	√	√
2012	Fusion	3.5L	4V	ABS	√	√	√	√

2012	Fusion	3.5L	4V	ACM	√	√	√	√
2012	Fusion	3.5L	4V	ACM	√	√	√	√
2012	Fusion	3.5L	4V	ACM	√	√	√	√
2012	Fusion	3.5L	4V	APIM	√	√	√	√
2012	Fusion	3.5L	4V	APIM	√	√	√	√
2012	Fusion	3.5L	4V	DSP	√	√	√	
2012	Fusion	3.5L	4V	FCIM	√	√	√	
2012	Fusion	3.5L	4V	FCIM	√	√	√	√
2012	Fusion	3.5L	4V	FDIM	√	√	√	√
2012	Fusion	3.5L	4V	GEM / SJB	√	√	√	√
2012	Fusion	3.5L	4V	GEM / SJB	√	√	√	√
2012	Fusion	3.5L	4V	GPSM	√	√	√	√
2012	Fusion	3.5L	4V	HVAC	√	√	√	√
2012	Fusion	3.5L	4V	IPC	√	√	√	√
2012	Fusion	3.5L	4V	OCSM	√	√	√	√
2012	Fusion	3.5L	4V	OCSM	√	√	√	√
2012	Fusion	3.5L	4V	PAM	√	√	√	√
2012	Fusion	3.5L	4V	PCM	√	√	√	√
2012	Fusion	3.5L	4V	PSCM	√	√	√	√
2012	Fusion	3.5L	4V	RCM	√	√	√	√
2012	Fusion	3.5L	4V	SOD-L	√	√	√	√
2012	Fusion	3.5L	4V	SOD-R	√	√	√	√
2012	Fusion	3.5L	4V	TBM	√	√	√	√
2012	Fusion	3.5L	4V	TBM	√	√	√	√
2012	Fusion	3.5L	4V	TCM	√	√	√	√
2012	Fusion	Other	Other	4X4	√	√	√	√
2012	Fusion	Other	Other	ABS	√	√	√	√
2012	Fusion	Other	Other	ACM	√	√	√	√
2012	Fusion	Other	Other	APIM	√	√	√	√
2012	Fusion	Other	Other	DSP	√	√	√	
2012	Fusion	Other	Other	FCIM	√	√	√	
2012	Fusion	Other	Other	FCIM	√	√	√	√
2012	Fusion	Other	Other	FDIM	√	√	√	√
2012	Fusion	Other	Other	GEM / SJB	√	√	√	√
2012	Fusion	Other	Other	GPSM	√	√	√	√
2012	Fusion	Other	Other	HVAC	√	√	√	√
2012	Fusion	Other	Other	IPC	√	√	√	√
2012	Fusion	Other	Other	OCSM	√	√	√	√
2012	Fusion	Other	Other	PAM	√	√	√	√
2012	Fusion	Other	Other	PSCM	√	√	√	√
2012	Fusion	Other	Other	RCM	√	√	√	√
2012	Fusion	Other	Other	SOD-L	√	√	√	√
2012	Fusion	Other	Other	SOD-R	√	√	√	√
2012	Fusion	Other	Other	TBM	√	√	√	√
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	

2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	BCM#1	√	√	√	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	√	√	√	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	DACM-C	√	√	√	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	DCDC	√	√	√	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	DSM	√	√	√	√
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	DSP	√	√	√	√
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	FCDIM	√	√	√	√
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	√
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GFM	√	√	√	√
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	√
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	GWM	√	√	√	√
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	HCM	√	√	√	√
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	HSWM	√	√	√	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	HUD	√	√	√	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	IPM-A	√	√	√	√
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	PDM	√	√	√	√
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	RACM	√	√	√	√
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	RGTM	√	√	√	√
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	RTM	√	√	√	√
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	SCCM	√	√	√	√
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	SCM-E	√	√	√	√
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	SCM-G	√	√	√	√
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	SCM-H	√	√	√	√
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√		√
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	√
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct	VDM	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	√	√	√	
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	

2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	BCM#1	√	√	√	
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	BCM#1	√	√	√	
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	BCM#1	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	C-CM	√	√	√	
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	DACM-C	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	DSM	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	DSP	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	FCDIM	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	GFM	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	GWM	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	HCM	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	HSWM	√	√	√	
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	HUD	√	√	√	
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	IPM-A	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	OCSM	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	OCSM	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	PDM	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	RACM	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	RGTM	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	RTM	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	SCCM	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-E	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	SCM-H	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	VDM	√	√	√	√
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	ABS	√	√	√	√
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	ACCM#2	√	√	√	√
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	ACM	√	√	√	√

2013	Fusion	2.0L	Full Hybrid Electric Vehicle	APIM	✓	✓	✓	✓
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	BCM#1	✓	✓	✓	✓
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	BECM	✓	✓	✓	✓
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	C-CM	✓	✓	✓	✓
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	DACM-C	✓	✓	✓	✓
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	DCDC	✓	✓	✓	✓
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	DDM	✓	✓	✓	✓
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	DSM	✓	✓	✓	✓
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	DSP	✓	✓	✓	✓
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	FCDIM	✓	✓	✓	✓
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	FCIM	✓	✓	✓	✓
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	GPSM	✓	✓	✓	✓
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	GWM	✓	✓	✓	✓
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	HUD	✓	✓	✓	✓
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	IPC	✓	✓	✓	✓
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	IPM-A	✓	✓	✓	✓
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	OCSM	✓	✓	✓	✓
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	PAM	✓	✓	✓	✓
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	PCM	✓	✓	✓	✓
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	PDM	✓	✓	✓	✓
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	PSCM	✓	✓	✓	✓
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	RACM	✓	✓	✓	✓
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	RCM	✓	✓	✓	✓
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	RTM	✓	✓	✓	✓
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	SCCM	✓	✓	✓	✓
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	SCM-E	✓	✓	✓	✓
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	SOBDM-C	✓	✓	✓	✓
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	SOD-L	✓	✓	✓	✓
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	SOD-R	✓	✓	✓	✓
2013	Fusion	2.0L	HEV / ATKINSON 4V	ABS	✓	✓	✓	
2013	Fusion	2.0L	HEV / ATKINSON 4V	ACCM#2	✓	✓	✓	
2013	Fusion	2.0L	HEV / ATKINSON 4V	ACM	✓	✓	✓	
2013	Fusion	2.0L	HEV / ATKINSON 4V	APIM	✓	✓	✓	
2013	Fusion	2.0L	HEV / ATKINSON 4V	BCM#1	✓	✓	✓	
2013	Fusion	2.0L	HEV / ATKINSON 4V	BECM	✓	✓	✓	
2013	Fusion	2.0L	HEV / ATKINSON 4V	C-CM	✓	✓	✓	
2013	Fusion	2.0L	HEV / ATKINSON 4V	DACM-C	✓	✓	✓	
2013	Fusion	2.0L	HEV / ATKINSON 4V	DCDC	✓	✓	✓	
2013	Fusion	2.0L	HEV / ATKINSON 4V	DDM	✓	✓	✓	
2013	Fusion	2.0L	HEV / ATKINSON 4V	DSP	✓	✓	✓	✓
2013	Fusion	2.0L	HEV / ATKINSON 4V	FCDIM	✓	✓	✓	
2013	Fusion	2.0L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	
2013	Fusion	2.0L	HEV / ATKINSON 4V	GFM	✓	✓	✓	
2013	Fusion	2.0L	HEV / ATKINSON 4V	GPSM	✓	✓	✓	
2013	Fusion	2.0L	HEV / ATKINSON 4V	GWM	✓	✓	✓	

2013	Fusion	2.0L	HEV / ATKINSON 4V	HCM	√	√	√	
2013	Fusion	2.0L	HEV / ATKINSON 4V	HSWM	√	√	√	
2013	Fusion	2.0L	HEV / ATKINSON 4V	HUD	√	√	√	
2013	Fusion	2.0L	HEV / ATKINSON 4V	IPC	√	√	√	√
2013	Fusion	2.0L	HEV / ATKINSON 4V	IPM-A	√	√	√	√
2013	Fusion	2.0L	HEV / ATKINSON 4V	OCSM	√	√	√	√
2013	Fusion	2.0L	HEV / ATKINSON 4V	PAM	√	√	√	√
2013	Fusion	2.0L	HEV / ATKINSON 4V	PCM	√	√	√	√
2013	Fusion	2.0L	HEV / ATKINSON 4V	PDM	√	√	√	√
2013	Fusion	2.0L	HEV / ATKINSON 4V	PSCM	√	√	√	√
2013	Fusion	2.0L	HEV / ATKINSON 4V	RACM	√	√	√	√
2013	Fusion	2.0L	HEV / ATKINSON 4V	RCM	√	√	√	√
2013	Fusion	2.0L	HEV / ATKINSON 4V	RGTM	√	√	√	√
2013	Fusion	2.0L	HEV / ATKINSON 4V	RTM	√	√	√	√
2013	Fusion	2.0L	HEV / ATKINSON 4V	SCCM	√	√	√	√
2013	Fusion	2.0L	HEV / ATKINSON 4V	SCM-E	√	√	√	√
2013	Fusion	2.0L	HEV / ATKINSON 4V	SCM-G	√	√	√	√
2013	Fusion	2.0L	HEV / ATKINSON 4V	SCM-H	√	√	√	√
2013	Fusion	2.0L	HEV / ATKINSON 4V	SOBDM-C	√	√	√	√
2013	Fusion	2.0L	HEV / ATKINSON 4V	SOD-L	√	√	√	√
2013	Fusion	2.0L	HEV / ATKINSON 4V	SOD-R	√	√	√	√
2013	Fusion	2.0L	HEV / ATKINSON 4V	VDM	√	√	√	√
2013	Fusion	2.0L	PHEV	ABS	√	√	√	
2013	Fusion	2.0L	PHEV	ABS	√	√	√	√
2013	Fusion	2.0L	PHEV	ACCM#2	√	√	√	
2013	Fusion	2.0L	PHEV	ACCM#2	√	√	√	√
2013	Fusion	2.0L	PHEV	ACM	√	√	√	
2013	Fusion	2.0L	PHEV	ACM	√	√	√	√
2013	Fusion	2.0L	PHEV	APIM	√	√	√	
2013	Fusion	2.0L	PHEV	APIM	√	√	√	√
2013	Fusion	2.0L	PHEV	BCM#1	√	√	√	
2013	Fusion	2.0L	PHEV	BCM#1	√	√	√	√
2013	Fusion	2.0L	PHEV	BECM	√	√	√	√
2013	Fusion	2.0L	PHEV	C-CM	√	√	√	√
2013	Fusion	2.0L	PHEV	C-CM	√	√	√	√
2013	Fusion	2.0L	PHEV	DACM-C	√	√	√	√
2013	Fusion	2.0L	PHEV	DCDC	√	√	√	√
2013	Fusion	2.0L	PHEV	DDM	√	√	√	√
2013	Fusion	2.0L	PHEV	DSM	√	√	√	√
2013	Fusion	2.0L	PHEV	DSP	√	√	√	√
2013	Fusion	2.0L	PHEV	FCDIM	√	√	√	√
2013	Fusion	2.0L	PHEV	FCIM	√	√	√	√
2013	Fusion	2.0L	PHEV	GFM	√	√	√	√
2013	Fusion	2.0L	PHEV	GPSM	√	√	√	√
2013	Fusion	2.0L	PHEV	GWM	√	√	√	√



2013	Fusion	2.0L	PHEV	HCM	√	√	√	√
2013	Fusion	2.0L	PHEV	HSWM	√	√	√	
2013	Fusion	2.0L	PHEV	HUD	√	√	√	
2013	Fusion	2.0L	PHEV	HUD	√	√	√	√
2013	Fusion	2.0L	PHEV	IPC	√	√	√	√
2013	Fusion	2.0L	PHEV	IPM-A	√	√	√	√
2013	Fusion	2.0L	PHEV	IPM-A	√	√	√	√
2013	Fusion	2.0L	PHEV	OCSM	√	√	√	√
2013	Fusion	2.0L	PHEV	PAM	√	√	√	√
2013	Fusion	2.0L	PHEV	PCM	√	√	√	√
2013	Fusion	2.0L	PHEV	PDM	√	√	√	√
2013	Fusion	2.0L	PHEV	PSCM	√	√	√	√
2013	Fusion	2.0L	PHEV	RACM	√	√	√	√
2013	Fusion	2.0L	PHEV	RCM	√	√	√	√
2013	Fusion	2.0L	PHEV	RGTM	√	√	√	√
2013	Fusion	2.0L	PHEV	RTM	√	√	√	√
2013	Fusion	2.0L	PHEV	SCCM	√	√	√	√
2013	Fusion	2.0L	PHEV	SCM-E	√	√	√	√
2013	Fusion	2.0L	PHEV	SCM-G	√	√	√	√
2013	Fusion	2.0L	PHEV	SCM-H	√	√	√	√
2013	Fusion	2.0L	PHEV	SOBDM	√	√	√	√
2013	Fusion	2.0L	PHEV	SOBDM-C	√	√	√	√
2013	Fusion	2.0L	PHEV	SOBDM-C	√	√	√	√
2013	Fusion	2.0L	PHEV	SOD-L	√	√	√	√
2013	Fusion	2.0L	PHEV	SOD-R	√	√	√	√
2013	Fusion	2.0L	PHEV	TCU#1	√	√	√	√
2013	Fusion	2.0L	PHEV	VDM	√	√	√	√
2013	Fusion	2.5L	IVCT	ABS	√	√	√	
2013	Fusion	2.5L	IVCT	ABS	√	√	√	√
2013	Fusion	2.5L	IVCT	ACM	√	√	√	
2013	Fusion	2.5L	IVCT	ACM	√	√	√	√
2013	Fusion	2.5L	IVCT	APIM	√	√	√	
2013	Fusion	2.5L	IVCT	APIM	√	√	√	√
2013	Fusion	2.5L	IVCT	BCM#1	√	√	√	
2013	Fusion	2.5L	IVCT	C-CM	√	√	√	
2013	Fusion	2.5L	IVCT	C-CM	√	√	√	√
2013	Fusion	2.5L	IVCT	DACM-C	√	√	√	
2013	Fusion	2.5L	IVCT	DACM-C	√	√	√	√
2013	Fusion	2.5L	IVCT	DDM	√	√	√	
2013	Fusion	2.5L	IVCT	DDM	√	√	√	√
2013	Fusion	2.5L	IVCT	DSM	√	√	√	√
2013	Fusion	2.5L	IVCT	DSP	√	√	√	√
2013	Fusion	2.5L	IVCT	FCDIM	√	√	√	√
2013	Fusion	2.5L	IVCT	FCIM	√	√	√	√
2013	Fusion	2.5L	IVCT	GFM	√	√	√	√

2013	Fusion	2.5L	IVCT	GPSM	√	√	√	√
2013	Fusion	2.5L	IVCT	GWM	√	√	√	√
2013	Fusion	2.5L	IVCT	HCM	√	√	√	√
2013	Fusion	2.5L	IVCT	HSWM	√	√	√	
2013	Fusion	2.5L	IVCT	HUD	√	√	√	
2013	Fusion	2.5L	IVCT	HUD	√	√	√	√
2013	Fusion	2.5L	IVCT	IPC	√	√	√	√
2013	Fusion	2.5L	IVCT	IPM-A	√	√	√	√
2013	Fusion	2.5L	IVCT	OCSM	√	√	√	√
2013	Fusion	2.5L	IVCT	OCSM	√	√	√	√
2013	Fusion	2.5L	IVCT	PAM	√	√	√	√
2013	Fusion	2.5L	IVCT	PCM	√	√	√	√
2013	Fusion	2.5L	IVCT	PCM	√	√	√	√
2013	Fusion	2.5L	IVCT	PDM	√	√	√	√
2013	Fusion	2.5L	IVCT	PSCM	√	√	√	√
2013	Fusion	2.5L	IVCT	RACM	√	√	√	√
2013	Fusion	2.5L	IVCT	RCM	√	√	√	√
2013	Fusion	2.5L	IVCT	RGTM	√	√	√	√
2013	Fusion	2.5L	IVCT	RTM	√	√	√	√
2013	Fusion	2.5L	IVCT	SCCM	√	√	√	√
2013	Fusion	2.5L	IVCT	SCM-E	√	√	√	√
2013	Fusion	2.5L	IVCT	SCM-G	√	√	√	√
2013	Fusion	2.5L	IVCT	SCM-H	√	√	√	√
2013	Fusion	2.5L	IVCT	SOD-L	√	√	√	√
2013	Fusion	2.5L	IVCT	SOD-R	√	√	√	√
2013	Fusion	2.5L	IVCT	VDM	√	√	√	√
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct	BCM#1	√	√	√	√
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct	C-CM	√	√	√	√
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct	DACM-C	√	√	√	√
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct	DCDC	√	√	√	√
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	√
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM	√	√	√	√
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct	DSP	√	√	√	√
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct	FCDIM	√	√	√	√
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	√
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	√
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct	GWM	√	√	√	√
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct	HUD	√	√	√	√
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct	OCSM	√	√	√	√
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√



2014	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	DACM-C	✓	✓	✓	✓
2014	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	DDM	✓	✓	✓	✓
2014	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	DSM	✓	✓	✓	✓
2014	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	DSP	✓	✓	✓	✓
2014	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓
2014	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	FCIM	✓	✓	✓	✓
2014	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	GPSM	✓	✓	✓	✓
2014	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	GWM	✓	✓	✓	✓
2014	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	HUD	✓	✓	✓	✓
2014	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	IPC	✓	✓	✓	✓
2014	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	IPM-A	✓	✓	✓	✓
2014	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	OCSM	✓	✓	✓	✓
2014	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓
2014	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	PDM	✓	✓	✓	✓
2014	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	PSCM	✓	✓	✓	✓
2014	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	RACM	✓	✓	✓	✓
2014	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	RCM	✓	✓	✓	✓
2014	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	RTM	✓	✓	✓	✓
2014	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	SCCM	✓	✓	✓	✓
2014	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	SCM-E	✓	✓	✓	✓
2014	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-L	✓	✓	✓	✓
2014	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-R	✓	✓	✓	✓
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	ABS	✓	✓	✓	✓
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	ACCM#2	✓	✓	✓	✓
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	ACM	✓	✓	✓	✓
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	APIM	✓	✓	✓	✓
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	BCM#1	✓	✓	✓	✓
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	BECM	✓	✓	✓	✓
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	C-CM	✓	✓	✓	✓
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	DACM-C	✓	✓	✓	✓
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	DCDC	✓	✓	✓	✓
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	DDM	✓	✓	✓	✓
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	DSM	✓	✓	✓	✓
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	DSP	✓	✓	✓	✓
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	FCDIM	✓	✓	✓	✓
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	FCIM	✓	✓	✓	✓
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	GPSM	✓	✓	✓	✓
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	GWM	✓	✓	✓	✓
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	HUD	✓	✓	✓	✓
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	IPC	✓	✓	✓	✓
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	IPM-A	✓	✓	✓	✓
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	OCSM	✓	✓	✓	✓
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	PAM	✓	✓	✓	✓

2014	Fusion	2.0L	Full Hybrid Electric Vehicle	PCM	√	√	√	√
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	PCM	√	√	√	√
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	PDM	√	√	√	√
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	PSCM	√	√	√	√
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	RACM	√	√	√	√
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	RCM	√	√	√	√
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	RTM	√	√	√	√
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	SCCM	√	√	√	√
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	SOBDM-C	√	√	√	√
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	SOD-L	√	√	√	√
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	SOD-R	√	√	√	√
2014	Fusion	2.0L	PHEV	ABS	√	√	√	√
2014	Fusion	2.0L	PHEV	ACCM#2	√	√	√	√
2014	Fusion	2.0L	PHEV	ACM	√	√	√	√
2014	Fusion	2.0L	PHEV	APIM	√	√	√	√
2014	Fusion	2.0L	PHEV	BCM#1	√	√	√	√
2014	Fusion	2.0L	PHEV	BECM	√	√	√	√
2014	Fusion	2.0L	PHEV	C-CM	√	√	√	√
2014	Fusion	2.0L	PHEV	DACM-C	√	√	√	√
2014	Fusion	2.0L	PHEV	DCDC	√	√	√	√
2014	Fusion	2.0L	PHEV	DDM	√	√	√	√
2014	Fusion	2.0L	PHEV	DSM	√	√	√	√
2014	Fusion	2.0L	PHEV	DSP	√	√	√	√
2014	Fusion	2.0L	PHEV	FCDIM	√	√	√	√
2014	Fusion	2.0L	PHEV	FCIM	√	√	√	√
2014	Fusion	2.0L	PHEV	GFM	√	√	√	√
2014	Fusion	2.0L	PHEV	GPSM	√	√	√	√
2014	Fusion	2.0L	PHEV	GWM	√	√	√	√
2014	Fusion	2.0L	PHEV	HUD	√	√	√	√
2014	Fusion	2.0L	PHEV	IPC	√	√	√	√
2014	Fusion	2.0L	PHEV	IPM-A	√	√	√	√
2014	Fusion	2.0L	PHEV	OCSM	√	√	√	√
2014	Fusion	2.0L	PHEV	PAM	√	√	√	√
2014	Fusion	2.0L	PHEV	PCM	√	√	√	√
2014	Fusion	2.0L	PHEV	PDM	√	√	√	√
2014	Fusion	2.0L	PHEV	PSCM	√	√	√	√
2014	Fusion	2.0L	PHEV	RACM	√	√	√	√
2014	Fusion	2.0L	PHEV	RCM	√	√	√	√
2014	Fusion	2.0L	PHEV	RTM	√	√	√	√
2014	Fusion	2.0L	PHEV	SCCM	√	√	√	√
2014	Fusion	2.0L	PHEV	SCM-E	√	√	√	√
2014	Fusion	2.0L	PHEV	SOBDM	√	√	√	√
2014	Fusion	2.0L	PHEV	SOBDM-C	√	√	√	√
2014	Fusion	2.0L	PHEV	SOD-L	√	√	√	√
2014	Fusion	2.0L	PHEV	SOD-R	√	√	√	√

2014	Fusion	2.0L	PHEV	TCU#1	✓	✓	✓	✓
2014	Fusion	2.5L	IVCT	ABS	✓	✓	✓	✓
2014	Fusion	2.5L	IVCT	ACM	✓	✓	✓	✓
2014	Fusion	2.5L	IVCT	APIM	✓	✓	✓	✓
2014	Fusion	2.5L	IVCT	BCM#1	✓	✓	✓	✓
2014	Fusion	2.5L	IVCT	C-CM	✓	✓	✓	✓
2014	Fusion	2.5L	IVCT	DACM-C	✓	✓	✓	✓
2014	Fusion	2.5L	IVCT	DDM	✓	✓	✓	✓
2014	Fusion	2.5L	IVCT	DSM	✓	✓	✓	✓
2014	Fusion	2.5L	IVCT	DSP	✓	✓	✓	✓
2014	Fusion	2.5L	IVCT	FCDIM	✓	✓	✓	✓
2014	Fusion	2.5L	IVCT	FCIM	✓	✓	✓	✓
2014	Fusion	2.5L	IVCT	GPSM	✓	✓	✓	✓
2014	Fusion	2.5L	IVCT	GWM	✓	✓	✓	✓
2014	Fusion	2.5L	IVCT	HUD	✓	✓	✓	✓
2014	Fusion	2.5L	IVCT	IPC	✓	✓	✓	✓
2014	Fusion	2.5L	IVCT	IPM-A	✓	✓	✓	✓
2014	Fusion	2.5L	IVCT	OCSM	✓	✓	✓	✓
2014	Fusion	2.5L	IVCT	PAM	✓	✓	✓	✓
2014	Fusion	2.5L	IVCT	PCM	✓	✓	✓	✓
2014	Fusion	2.5L	IVCT	PCM	✓	✓	✓	✓
2014	Fusion	2.5L	IVCT	PCM	✓	✓	✓	✓
2014	Fusion	2.5L	IVCT	PDM	✓	✓	✓	✓
2014	Fusion	2.5L	IVCT	PSCM	✓	✓	✓	✓
2014	Fusion	2.5L	IVCT	RACM	✓	✓	✓	✓
2014	Fusion	2.5L	IVCT	RCM	✓	✓	✓	✓
2014	Fusion	2.5L	IVCT	RTM	✓	✓	✓	✓
2014	Fusion	2.5L	IVCT	SCCM	✓	✓	✓	✓
2014	Fusion	2.5L	IVCT	SCM-E	✓	✓	✓	✓
2014	Fusion	2.5L	IVCT	SOD-L	✓	✓	✓	✓
2014	Fusion	2.5L	IVCT	SOD-R	✓	✓	✓	✓
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail	ABS	✓	✓	✓	✓
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail	ACM	✓	✓	✓	✓
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail	AHCM	✓	✓	✓	✓
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail	BCMii	✓	✓	✓	✓
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail	CCMii	✓	✓	✓	✓
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail	CDP	✓	✓	✓	✓
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail	GDM	✓	✓	✓	✓
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail	HCM	✓	✓	✓	✓
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail	HVAC	✓	✓	✓	✓
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail	IPC	✓	✓	✓	✓
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail	NAV	✓	✓	✓	✓
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail	PAM	✓	✓	✓	✓
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail	PBM	✓	✓	✓	✓
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail	PCM	✓	✓	✓	✓

2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail	PDM	√	√	√	√
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail	PSCM	√	√	√	√
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail	RFA	√	√	√	√
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail	RGTM	√	√	√	√
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail	RHVAC	√	√	√	√
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail	SASM	√	√	√	√
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	√
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail	TRM	√	√	√	√
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail	VDM	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	ABS	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	ACM	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	AHCM	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	BCMii	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	CCMii	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	CDP	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	DDM	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	GDM	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	HCM	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	HVAC	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	IPC	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	NAV	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	PAM	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	PBM	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	PDM	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	PSCM	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	RCM	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	RCM	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	RFA	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	RGTM	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	RHVAC	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	SASM	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	SRM	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	TRM	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	VDM	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail	AHCM	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail	BCMii	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail	CCMii	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail	CDP	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail	DDM	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail	GDM	√	√	√	√
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	√





2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	CCMii	√	√	√	√
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	CDP	√	√	√	√
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	DDM	√	√	√	√
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	GDM	√	√	√	√
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	HCM	√	√	√	√
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	HVAC	√	√	√	√
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	IPC	√	√	√	√
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	IPC	√	√	√	√
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	NAV	√	√	√	√
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	PAM	√	√	√	√
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	PBM	√	√	√	√
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	PDM	√	√	√	√
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	PSCM	√	√	√	√
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	RCM	√	√	√	√
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	RFA	√	√	√	√
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	RGTM	√	√	√	√
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	RHVAC	√	√	√	√
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	SASM	√	√	√	√
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	SRM	√	√	√	√
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	TCM	√	√	√	√
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	TCM	√	√	√	√
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	TRM	√	√	√	√
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	VDM	√	√	√	√
2006.5	GALAXY\S-Max	2.5L	I5	ABS	√	√	√	√
2006.5	GALAXY\S-Max	2.5L	I5	ACM	√	√	√	√
2006.5	GALAXY\S-Max	2.5L	I5	AHCM	√	√	√	√
2006.5	GALAXY\S-Max	2.5L	I5	BCMii	√	√	√	√
2006.5	GALAXY\S-Max	2.5L	I5	CCMii	√	√	√	√
2006.5	GALAXY\S-Max	2.5L	I5	CDP	√	√	√	√
2006.5	GALAXY\S-Max	2.5L	I5	DDM	√	√	√	√
2006.5	GALAXY\S-Max	2.5L	I5	GDM	√	√	√	√
2006.5	GALAXY\S-Max	2.5L	I5	HCM	√	√	√	√
2006.5	GALAXY\S-Max	2.5L	I5	HVAC	√	√	√	√
2006.5	GALAXY\S-Max	2.5L	I5	IPC	√	√	√	√
2006.5	GALAXY\S-Max	2.5L	I5	NAV	√	√	√	√
2006.5	GALAXY\S-Max	2.5L	I5	PAM	√	√	√	√
2006.5	GALAXY\S-Max	2.5L	I5	PBM	√	√	√	√
2006.5	GALAXY\S-Max	2.5L	I5	PCM	√	√	√	√
2006.5	GALAXY\S-Max	2.5L	I5	PDM	√	√	√	√
2006.5	GALAXY\S-Max	2.5L	I5	PSCM	√	√	√	√
2006.5	GALAXY\S-Max	2.5L	I5	RCM	√	√	√	√
2006.5	GALAXY\S-Max	2.5L	I5	RFA	√	√	√	√
2006.5	GALAXY\S-Max	2.5L	I5	RGTM	√	√	√	√
2006.5	GALAXY\S-Max	2.5L	I5	RHVAC	√	√	√	√

2006.5	GALAXY\S-Max	2.5L	I5	SASM	✓	✓	✓	✓
2006.5	GALAXY\S-Max	2.5L	I5	SRM	✓	✓	✓	✓
2006.5	GALAXY\S-Max	2.5L	I5	TRM	✓	✓	✓	✓
2006.5	GALAXY\S-Max	2.5L	I5	VDM	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail	ABS	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail	ACM	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail	AHCM	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail	BCMii	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail	CCMii	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail	CDP	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail	CMR	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail	DABM	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail	DDM	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail	DSM	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail	HCM	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail	HVAC	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail	IPC	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail	IPM-A	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail	NAV	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail	PAM	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail	PBM	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail	PDM	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail	PSCM	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail	RCM	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail	RFA	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail	RGTM	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail	RHVAC	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail	SASM	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail	SOD-L	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail	SOD-R	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail	SRM	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail	TRM	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail	VDM	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct	ABS	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct	ACM	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct	AHCM	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct	BCMii	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct	CDP	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct	CMR	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct	DABM	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct	DDM	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct	DSM	✓	✓	✓	✓
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct	HCM	✓	✓	✓	✓

2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	√
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC	√	√	√	√
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct	IPM-A	√	√	√	√
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct	NAV	√	√	√	√
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct	PBM	√	√	√	√
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct	PDM	√	√	√	√
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	√
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct	RGTM	√	√	√	√
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct	RHVAC	√	√	√	√
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct	SASM	√	√	√	√
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	√
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct	SRM	√	√	√	√
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct	TRM	√	√	√	√
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct	VDM	√	√	√	√
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	ABS	√	√	√	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	ACM	√	√	√	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	AHCM	√	√	√	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	BCMii	√	√	√	√
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	CCMii	√	√	√	√
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	CDP	√	√	√	√
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	CMR	√	√	√	√
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	DABM	√	√	√	√
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	DDM	√	√	√	√
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	DSM	√	√	√	√
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	HCM	√	√	√	√
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	HVAC	√	√	√	√
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	IPC	√	√	√	√
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	IPM-A	√	√	√	√
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	NAV	√	√	√	√
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	PAM	√	√	√	√
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	PBM	√	√	√	√
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	PDM	√	√	√	√
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	PSCM	√	√	√	√
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	RCM	√	√	√	√
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	RFA	√	√	√	√
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	RGTM	√	√	√	√
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	RHVAC	√	√	√	√
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	SASM	√	√	√	√
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	SOD-L	√	√	√	√









2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail	PDM	√	√	√	√
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail	PSCM	√	√	√	√
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail	RFA	√	√	√	√
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail	RGTM	√	√	√	√
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail	RHVAC	√	√	√	√
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail	SASM	√	√	√	√
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail	SOD-L	√	√	√	√
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail	SOD-R	√	√	√	√
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	√
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail	TCM	√	√	√	√
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail	TRM	√	√	√	√
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail	VDM	√	√	√	√
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	ABS	√	√	√	√
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	ACM	√	√	√	√
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	AHCM	√	√	√	√
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	BCMii	√	√	√	√
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	CCMii	√	√	√	√
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	CDP	√	√	√	√
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	CMR	√	√	√	√
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	DABM	√	√	√	√
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	DDM	√	√	√	√
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	DSM	√	√	√	√
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	HCM	√	√	√	√
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	HVAC	√	√	√	√
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	IPC	√	√	√	√
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	IPM-A	√	√	√	√
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	NAV	√	√	√	√
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	PAM	√	√	√	√
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	PBM	√	√	√	√
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	PDM	√	√	√	√
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	PSCM	√	√	√	√
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	RCM	√	√	√	√
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	RFA	√	√	√	√
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	RGTM	√	√	√	√
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	RHVAC	√	√	√	√
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	SASM	√	√	√	√
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	SOD-L	√	√	√	√
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	SOD-R	√	√	√	√
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	SRM	√	√	√	√
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	TCM	√	√	√	√



2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	TRM	✓	✓	✓	✓
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	VDM	✓	✓	✓	✓
1995.5	Galaxy	2.0L	2.0 DOHC SFI (8V)	ABS	✓	✓	✓	✓
1995.5	Galaxy	2.0L	2.0 DOHC SFI (8V)	CCM	✓	✓	✓	✓
1995.5	Galaxy	2.0L	2.0 DOHC SFI (8V)	CJB	✓	✓	✓	✓
1995.5	Galaxy	2.0L	2.0 DOHC SFI (8V)	IC	✓	✓	✓	✓
1995.5	Galaxy	2.0L	2.0 DOHC SFI (8V)	PATS	✓	✓	✓	✓
1995.5	Galaxy	2.0L	2.0 DOHC SFI (8V)	RCM	✓	✓	✓	✓
1995.5	Galaxy	2.0L	2.0 DOHC SFI (8V)	TCM	✓	✓	✓	✓
1997	Galaxy	2.0L	2.0 DOHC SFI (8V)	ABS	✓	✓	✓	✓
1997	Galaxy	2.0L	2.0 DOHC SFI (8V)	CCM	✓	✓	✓	✓
1997	Galaxy	2.0L	2.0 DOHC SFI (8V)	CJB	✓	✓	✓	✓
1997	Galaxy	2.0L	2.0 DOHC SFI (8V)	IC	✓	✓	✓	✓
1997	Galaxy	2.0L	2.0 DOHC SFI (8V)	PATS	✓	✓	✓	✓
1997	Galaxy	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓
1997	Galaxy	2.0L	2.0 DOHC SFI (8V)	RCM	✓	✓	✓	✓
1997	Galaxy	2.0L	2.0 DOHC SFI (8V)	TCM	✓	✓	✓	✓
1997	Galaxy	2.3L	DOHC SFI (16V)	ABS	✓	✓	✓	✓
1997	Galaxy	2.3L	DOHC SFI (16V)	CCM	✓	✓	✓	✓
1997	Galaxy	2.3L	DOHC SFI (16V)	CJB	✓	✓	✓	✓
1997	Galaxy	2.3L	DOHC SFI (16V)	IC	✓	✓	✓	✓
1997	Galaxy	2.3L	DOHC SFI (16V)	PATS	✓	✓	✓	✓
1997	Galaxy	2.3L	DOHC SFI (16V)	PCM	✓	✓	✓	✓
1997	Galaxy	2.3L	DOHC SFI (16V)	RCM	✓	✓	✓	✓
1997	Galaxy	2.3L	DOHC SFI (16V)	TCM	✓	✓	✓	✓
1998	Galaxy	2.0L	2.0 DOHC SFI (8V)	ABS	✓	✓	✓	✓
1998	Galaxy	2.0L	2.0 DOHC SFI (8V)	CCM	✓	✓	✓	✓
1998	Galaxy	2.0L	2.0 DOHC SFI (8V)	CJB	✓	✓	✓	✓
1998	Galaxy	2.0L	2.0 DOHC SFI (8V)	IC	✓	✓	✓	✓
1998	Galaxy	2.0L	2.0 DOHC SFI (8V)	PATS	✓	✓	✓	✓
1998	Galaxy	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓
1998	Galaxy	2.0L	2.0 DOHC SFI (8V)	RCM	✓	✓	✓	✓
1998	Galaxy	2.0L	2.0 DOHC SFI (8V)	TCM	✓	✓	✓	✓
1998	Galaxy	2.3L	DOHC SFI (16V)	ABS	✓	✓	✓	✓
1998	Galaxy	2.3L	DOHC SFI (16V)	CCM	✓	✓	✓	✓
1998	Galaxy	2.3L	DOHC SFI (16V)	CJB	✓	✓	✓	✓
1998	Galaxy	2.3L	DOHC SFI (16V)	IC	✓	✓	✓	✓
1998	Galaxy	2.3L	DOHC SFI (16V)	PATS	✓	✓	✓	✓
1998	Galaxy	2.3L	DOHC SFI (16V)	PCM	✓	✓	✓	✓
1998	Galaxy	2.3L	DOHC SFI (16V)	RCM	✓	✓	✓	✓
1998	Galaxy	2.3L	DOHC SFI (16V)	TCM	✓	✓	✓	✓
1998.75	Galaxy	2.0L	2.0 DOHC SFI (8V)	ABS	✓	✓	✓	✓
1998.75	Galaxy	2.0L	2.0 DOHC SFI (8V)	CCM	✓	✓	✓	✓
1998.75	Galaxy	2.0L	2.0 DOHC SFI (8V)	CJB	✓	✓	✓	✓
1998.75	Galaxy	2.0L	2.0 DOHC SFI (8V)	IC	✓	✓	✓	✓

1998.75	Galaxy	2.0L	2.0 DOHC SFI (8V)	PATS	✓	✓	✓	✓
1998.75	Galaxy	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓
1998.75	Galaxy	2.0L	2.0 DOHC SFI (8V)	RCM	✓	✓	✓	✓
1998.75	Galaxy	2.0L	2.0 DOHC SFI (8V)	TCM	✓	✓	✓	✓
1998.75	Galaxy	2.3L	DOHC SFI (16V)	ABS	✓	✓	✓	✓
1998.75	Galaxy	2.3L	DOHC SFI (16V)	CCM	✓	✓	✓	✓
1998.75	Galaxy	2.3L	DOHC SFI (16V)	CJB	✓	✓	✓	✓
1998.75	Galaxy	2.3L	DOHC SFI (16V)	IC	✓	✓	✓	✓
1998.75	Galaxy	2.3L	DOHC SFI (16V)	PATS	✓	✓	✓	✓
1998.75	Galaxy	2.3L	DOHC SFI (16V)	PCM	✓	✓	✓	✓
1998.75	Galaxy	2.3L	DOHC SFI (16V)	RCM	✓	✓	✓	✓
1998.75	Galaxy	2.3L	DOHC SFI (16V)	TCM	✓	✓	✓	✓
2000.75	Galaxy	2.0L	2.0 DOHC SFI (8V)	ABS	✓	✓	✓	✓
2000.75	Galaxy	2.0L	2.0 DOHC SFI (8V)	CCM	✓	✓	✓	✓
2000.75	Galaxy	2.0L	2.0 DOHC SFI (8V)	CJB	✓	✓	✓	✓
2000.75	Galaxy	2.0L	2.0 DOHC SFI (8V)	IC	✓	✓	✓	✓
2000.75	Galaxy	2.0L	2.0 DOHC SFI (8V)	LHID	✓	✓	✓	✓
2000.75	Galaxy	2.0L	2.0 DOHC SFI (8V)	MFSW	✓	✓	✓	✓
2000.75	Galaxy	2.0L	2.0 DOHC SFI (8V)	PAM	✓	✓	✓	✓
2000.75	Galaxy	2.0L	2.0 DOHC SFI (8V)	PATS	✓	✓	✓	✓
2000.75	Galaxy	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓
2000.75	Galaxy	2.0L	2.0 DOHC SFI (8V)	RADIO	✓	✓	✓	✓
2000.75	Galaxy	2.0L	2.0 DOHC SFI (8V)	RCC	✓	✓	✓	✓
2000.75	Galaxy	2.0L	2.0 DOHC SFI (8V)	RCM	✓	✓	✓	✓
2000.75	Galaxy	2.0L	2.0 DOHC SFI (8V)	RHID	✓	✓	✓	✓
2000.75	Galaxy	2.0L	2.0 DOHC SFI (8V)	RNS	✓	✓	✓	✓
2000.75	Galaxy	2.0L	2.0 DOHC SFI (8V)	TCM	✓	✓	✓	✓
2000.75	Galaxy	2.3L	DOHC SFI (16V)	ABS	✓	✓	✓	✓
2000.75	Galaxy	2.3L	DOHC SFI (16V)	CCM	✓	✓	✓	✓
2000.75	Galaxy	2.3L	DOHC SFI (16V)	CJB	✓	✓	✓	✓
2000.75	Galaxy	2.3L	DOHC SFI (16V)	IC	✓	✓	✓	✓
2000.75	Galaxy	2.3L	DOHC SFI (16V)	LHID	✓	✓	✓	✓
2000.75	Galaxy	2.3L	DOHC SFI (16V)	MFSW	✓	✓	✓	✓
2000.75	Galaxy	2.3L	DOHC SFI (16V)	PAM	✓	✓	✓	✓
2000.75	Galaxy	2.3L	DOHC SFI (16V)	PATS	✓	✓	✓	✓
2000.75	Galaxy	2.3L	DOHC SFI (16V)	PCM	✓	✓	✓	✓
2000.75	Galaxy	2.3L	DOHC SFI (16V)	PCM	✓	✓	✓	✓
2000.75	Galaxy	2.3L	DOHC SFI (16V)	RADIO	✓	✓	✓	✓
2000.75	Galaxy	2.3L	DOHC SFI (16V)	RCC	✓	✓	✓	✓
2000.75	Galaxy	2.3L	DOHC SFI (16V)	RCM	✓	✓	✓	✓
2000.75	Galaxy	2.3L	DOHC SFI (16V)	RHID	✓	✓	✓	✓
2000.75	Galaxy	2.3L	DOHC SFI (16V)	RNS	✓	✓	✓	✓
2000.75	Galaxy	2.3L	DOHC SFI (16V)	TCM	✓	✓	✓	✓
2001	Galaxy	1.9L	EDC 1.9	ABS	✓	✓	✓	✓
2001	Galaxy	1.9L	EDC 1.9	CCM	✓	✓	✓	✓

2001	Galaxy	1.9L	EDC 1.9	CJB	√	√	√	√
2001	Galaxy	1.9L	EDC 1.9	FFH	√	√	√	√
2001	Galaxy	1.9L	EDC 1.9	IC	√	√	√	√
2001	Galaxy	1.9L	EDC 1.9	LHID	√	√	√	√
2001	Galaxy	1.9L	EDC 1.9	MFSW	√	√	√	√
2001	Galaxy	1.9L	EDC 1.9	PATS	√	√	√	√
2001	Galaxy	1.9L	EDC 1.9	PCM	√	√	√	√
2001	Galaxy	1.9L	EDC 1.9	RADIO	√	√	√	√
2001	Galaxy	1.9L	EDC 1.9	RCC	√	√	√	√
2001	Galaxy	1.9L	EDC 1.9	RCM	√	√	√	√
2001	Galaxy	1.9L	EDC 1.9	RHID	√	√	√	√
2001	Galaxy	1.9L	EDC 1.9	RNS	√	√	√	√
2001	Galaxy	1.9L	EDC 1.9	TCM	√	√	√	√
2001	Galaxy	2.8L	2.8 CD-V6	ABS	√	√	√	√
2001	Galaxy	2.8L	2.8 CD-V6	CCM	√	√	√	√
2001	Galaxy	2.8L	2.8 CD-V6	CJB	√	√	√	√
2001	Galaxy	2.8L	2.8 CD-V6	IC	√	√	√	√
2001	Galaxy	2.8L	2.8 CD-V6	LHID	√	√	√	√
2001	Galaxy	2.8L	2.8 CD-V6	MFSW	√	√	√	√
2001	Galaxy	2.8L	2.8 CD-V6	PAM	√	√	√	√
2001	Galaxy	2.8L	2.8 CD-V6	PATS	√	√	√	√
2001	Galaxy	2.8L	2.8 CD-V6	PCM	√	√	√	√
2001	Galaxy	2.8L	2.8 CD-V6	RADIO	√	√	√	√
2001	Galaxy	2.8L	2.8 CD-V6	RCC	√	√	√	√
2001	Galaxy	2.8L	2.8 CD-V6	RCM	√	√	√	√
2001	Galaxy	2.8L	2.8 CD-V6	RHID	√	√	√	√
2001	Galaxy	2.8L	2.8 CD-V6	RNS	√	√	√	√
2001	Galaxy	2.8L	2.8 CD-V6	TCM	√	√	√	√
Other	Galaxy	1.9L	EDC 1.9	ABS	√	√	√	√
Other	Galaxy	1.9L	EDC 1.9	CCM	√	√	√	√
Other	Galaxy	1.9L	EDC 1.9	CJB	√	√	√	√
Other	Galaxy	1.9L	EDC 1.9	IC	√	√	√	√
Other	Galaxy	1.9L	EDC 1.9	PATS	√	√	√	√
Other	Galaxy	1.9L	EDC 1.9	PCM	√	√	√	√
Other	Galaxy	1.9L	EDC 1.9	RCM	√	√	√	√
Other	Galaxy	1.9L	EDC 1.9	TCM	√	√	√	√
Other	Galaxy	2.8L	2.8 CD-V6	ABS	√	√	√	√
Other	Galaxy	2.8L	2.8 CD-V6	CCM	√	√	√	√
Other	Galaxy	2.8L	2.8 CD-V6	CJB	√	√	√	√
Other	Galaxy	2.8L	2.8 CD-V6	IC	√	√	√	√
Other	Galaxy	2.8L	2.8 CD-V6	PATS	√	√	√	√
Other	Galaxy	2.8L	2.8 CD-V6	PCM	√	√	√	√
Other	Galaxy	2.8L	2.8 CD-V6	RCM	√	√	√	√
Other	Galaxy	2.8L	2.8 CD-V6	TCM	√	√	√	√
19,915	Granada / Scorpio	2.9L	2.9 V6 24V	ABS/TCS	√	√	√	√

19,915	Granada / Scorpio	2.9L	2.9 V6 24V	GEM	✓	✓	✓	✓
19,915	Granada / Scorpio	2.9L	2.9 V6 24V	PATS	✓	✓	✓	✓
19,915	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓
19,915	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓
19,915	Granada / Scorpio	2.9L	2.9 V6 24V	RCM	✓	✓	✓	✓
1993.75	Granada / Scorpio	2.9L	2.9 V6 24V	ABS/TCS	✓	✓	✓	✓
1993.75	Granada / Scorpio	2.9L	2.9 V6 24V	GEM	✓	✓	✓	✓
1993.75	Granada / Scorpio	2.9L	2.9 V6 24V	PATS	✓	✓	✓	✓
1993.75	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓
1993.75	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓
1993.75	Granada / Scorpio	2.9L	2.9 V6 24V	RCM	✓	✓	✓	✓
1995	Granada / Scorpio	2.0L	Other	ABS/TCS	✓	✓	✓	✓
1995	Granada / Scorpio	2.0L	Other	GEM	✓	✓	✓	✓
1995	Granada / Scorpio	2.0L	Other	PATS			✓	✓
1995	Granada / Scorpio	2.0L	Other	PATS	✓	✓	✓	✓
1995	Granada / Scorpio	2.0L	Other	PCM	✓	✓	✓	✓
1995	Granada / Scorpio	2.0L	Other	RCM	✓	✓	✓	✓
1995	Granada / Scorpio	2.9L	2.9 V6 24V	ABS/TCS	✓	✓	✓	✓
1995	Granada / Scorpio	2.9L	2.9 V6 24V	GEM	✓	✓	✓	✓
1995	Granada / Scorpio	2.9L	2.9 V6 24V	PATS	✓	✓	✓	✓
1995	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓
1995	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓
1995	Granada / Scorpio	2.9L	2.9 V6 24V	RCM	✓	✓	✓	✓
1995.25	Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	ABS/TCS	✓	✓	✓	✓
1995.25	Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	GEM	✓	✓	✓	✓
1995.25	Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	PATS			✓	✓
1995.25	Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓
1995.25	Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	RCM	✓	✓	✓	✓
1995.25	Granada / Scorpio	2.0L	DOHC SFI (16V)	ABS/TCS	✓	✓	✓	✓
1995.25	Granada / Scorpio	2.0L	DOHC SFI (16V)	GEM	✓	✓	✓	✓
1995.25	Granada / Scorpio	2.0L	DOHC SFI (16V)	PATS			✓	✓
1995.25	Granada / Scorpio	2.0L	DOHC SFI (16V)	PATS	✓	✓	✓	✓
1995.25	Granada / Scorpio	2.0L	DOHC SFI (16V)	PCM	✓	✓	✓	✓
1995.25	Granada / Scorpio	2.0L	DOHC SFI (16V)	RCM	✓	✓	✓	✓
1995.25	Granada / Scorpio	2.9L	2.9 V6 24V	ABS/TCS	✓	✓	✓	✓
1995.25	Granada / Scorpio	2.9L	2.9 V6 24V	GEM	✓	✓	✓	✓
1995.25	Granada / Scorpio	2.9L	2.9 V6 24V	PATS	✓	✓	✓	✓
1995.25	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓
1995.25	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓
1995.25	Granada / Scorpio	2.9L	2.9 V6 24V	RCM	✓	✓	✓	✓
1996.75	Granada / Scorpio	2.3L	DOHC SFI (16V)	ABS/TCS	✓	✓	✓	✓
1996.75	Granada / Scorpio	2.3L	DOHC SFI (16V)	GEM	✓	✓	✓	✓
1996.75	Granada / Scorpio	2.3L	DOHC SFI (16V)	PATS			✓	✓
1996.75	Granada / Scorpio	2.3L	DOHC SFI (16V)	PATS	✓	✓	✓	✓
1996.75	Granada / Scorpio	2.3L	DOHC SFI (16V)	PCM	✓	✓	✓	✓

1996.75	Granada / Scorpio	2.3L	DOHC SFI (16V)	PCM	✓	✓	✓	✓
1996.75	Granada / Scorpio	2.3L	DOHC SFI (16V)	RCM	✓	✓	✓	✓
1997	Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	ABS/TCS	✓	✓	✓	✓
1997	Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	PATS			✓	✓
1997	Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓
1997	Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	RCM	✓	✓	✓	✓
1997	Granada / Scorpio	2.9L	2.9 V6 24V	ABS/TCS	✓	✓	✓	✓
1997	Granada / Scorpio	2.9L	2.9 V6 24V	GEM	✓	✓	✓	✓
1997	Granada / Scorpio	2.9L	2.9 V6 24V	PATS	✓	✓	✓	✓
1997	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓
1997	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓
1997	Granada / Scorpio	2.9L	2.9 V6 24V	RCM	✓	✓	✓	✓
1998	Granada / Scorpio	2.3L	DOHC SFI (16V)	ABS/TCS	✓	✓	✓	✓
1998	Granada / Scorpio	2.3L	DOHC SFI (16V)	GEM	✓	✓	✓	✓
1998	Granada / Scorpio	2.3L	DOHC SFI (16V)	PATS			✓	✓
1998	Granada / Scorpio	2.3L	DOHC SFI (16V)	PATS	✓	✓	✓	✓
1998	Granada / Scorpio	2.3L	DOHC SFI (16V)	PCM	✓	✓	✓	✓
1998	Granada / Scorpio	2.3L	DOHC SFI (16V)	PCM	✓	✓	✓	✓
1998	Granada / Scorpio	2.3L	DOHC SFI (16V)	RCM	✓	✓	✓	✓
1998	Granada / Scorpio	2.9L	2.9 V6 24V	ABS/TCS	✓	✓	✓	✓
1998	Granada / Scorpio	2.9L	2.9 V6 24V	GEM	✓	✓	✓	✓
1998	Granada / Scorpio	2.9L	2.9 V6 24V	PATS	✓	✓	✓	✓
1998	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓
1998	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓
1998	Granada / Scorpio	2.9L	2.9 V6 24V	RCM	✓	✓	✓	✓
1998.25	Granada / Scorpio	2.3L	DOHC SFI (16V)	ABS/TCS	✓	✓	✓	✓
1998.25	Granada / Scorpio	2.3L	DOHC SFI (16V)	GEM	✓	✓	✓	✓
1998.25	Granada / Scorpio	2.3L	DOHC SFI (16V)	PATS	✓	✓	✓	✓
1998.25	Granada / Scorpio	2.3L	DOHC SFI (16V)	PCM	✓	✓	✓	✓
1998.25	Granada / Scorpio	2.3L	DOHC SFI (16V)	PCM	✓	✓	✓	✓
1998.25	Granada / Scorpio	2.3L	DOHC SFI (16V)	RCM	✓	✓	✓	✓
1998.25	Granada / Scorpio	2.9L	2.9 V6 24V	ABS/TCS	✓	✓	✓	✓
1998.25	Granada / Scorpio	2.9L	2.9 V6 24V	GEM	✓	✓	✓	✓
1998.25	Granada / Scorpio	2.9L	2.9 V6 24V	PATS	✓	✓	✓	✓
1998.25	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓
1998.25	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓
1998.25	Granada / Scorpio	2.9L	2.9 V6 24V	RCM	✓	✓	✓	✓
Other	Granada / Scorpio	2.5L	Other	ABS/TCS	✓	✓	✓	✓
Other	Granada / Scorpio	2.5L	Other	GEM	✓	✓	✓	✓
Other	Granada / Scorpio	2.5L	Other	PATS			✓	✓
Other	Granada / Scorpio	2.5L	Other	PATS	✓	✓	✓	✓
Other	Granada / Scorpio	2.5L	Other	PCM	✓	✓	✓	✓
Other	Granada / Scorpio	2.5L	Other	RCM	✓	✓	✓	✓
1995	Grand Marquis	4.6L	2V	ABS/TCS	✓	✓	✓	
1995	Grand Marquis	4.6L	2V	DDM	✓	✓	✓	

1995	Grand Marquis	4.6L	2V	DSM	√	√	√	
1995	Grand Marquis	4.6L	2V	EATC	√	√	√	
1995	Grand Marquis	4.6L	2V	LCM	√	√	√	
1995	Grand Marquis	4.6L	2V	PCM	√	√	√	√
1996	Grand Marquis	4.6L	2V	ABS/TCS	√	√	√	√
1996	Grand Marquis	4.6L	2V	DDM	√	√	√	√
1996	Grand Marquis	4.6L	2V	DSM	√	√	√	√
1996	Grand Marquis	4.6L	2V	EATC	√	√	√	√
1996	Grand Marquis	4.6L	2V	IAB	√	√	√	
1996	Grand Marquis	4.6L	2V	LCM	√	√	√	√
1996	Grand Marquis	4.6L	2V	PCM	√	√	√	√
1996	Grand Marquis	4.6L	2V_NGV	ABS/TCS	√	√	√	√
1996	Grand Marquis	4.6L	2V_NGV	DDM	√	√	√	√
1996	Grand Marquis	4.6L	2V_NGV	DSM	√	√	√	√
1996	Grand Marquis	4.6L	2V_NGV	FIM	√	√	√	√
1996	Grand Marquis	4.6L	2V_NGV	IAB	√	√	√	
1996	Grand Marquis	4.6L	2V_NGV	LCM	√	√	√	√
1996	Grand Marquis	4.6L	2V_NGV	PCM	√	√	√	√
1997	Grand Marquis	4.6L	2V	ABS/TCS	√	√	√	√
1997	Grand Marquis	4.6L	2V	DDM	√	√	√	√
1997	Grand Marquis	4.6L	2V	DSM	√	√	√	√
1997	Grand Marquis	4.6L	2V	EATC	√	√	√	√
1997	Grand Marquis	4.6L	2V	IAB	√	√	√	
1997	Grand Marquis	4.6L	2V	LCM	√	√	√	√
1997	Grand Marquis	4.6L	2V	PCM	√	√	√	√
1998	Grand Marquis	4.6L	2V	ABS/TCS	√	√	√	√
1998	Grand Marquis	4.6L	2V	DDM	√	√	√	√
1998	Grand Marquis	4.6L	2V	EATC	√	√	√	√
1998	Grand Marquis	4.6L	2V	ECS	√	√	√	√
1998	Grand Marquis	4.6L	2V	IAB	√	√	√	
1998	Grand Marquis	4.6L	2V	LCM	√	√	√	√
1998	Grand Marquis	4.6L	2V	PATS	√	√	√	√
1998	Grand Marquis	4.6L	2V	PCM	√	√	√	√
1999	Grand Marquis	4.6L	2V	ABS/TCS	√	√	√	√
1999	Grand Marquis	4.6L	2V	DDM	√	√	√	√
1999	Grand Marquis	4.6L	2V	EATC	√	√	√	√
1999	Grand Marquis	4.6L	2V	ECS	√	√	√	√
1999	Grand Marquis	4.6L	2V	LCM	√	√	√	√
1999	Grand Marquis	4.6L	2V	PATS	√	√	√	√
1999	Grand Marquis	4.6L	2V	PCM	√	√	√	√
2000	Grand Marquis	4.6L	2V	ABS/TCS	√	√	√	√
2000	Grand Marquis	4.6L	2V	ABS/TCS	√	√	√	√
2000	Grand Marquis	4.6L	2V	ABS/TCS	√	√	√	√
2000	Grand Marquis	4.6L	2V	DDM	√	√	√	√
2000	Grand Marquis	4.6L	2V	EATC	√	√	√	√

2000	Grand Marquis	4.6L	2V	ECS	√	√	√	√
2000	Grand Marquis	4.6L	2V	PATS	√	√	√	√
2000	Grand Marquis	4.6L	2V	PCM	√	√	√	√
2000	Grand Marquis	4.6L	2V	RCM	√	√	√	√
2000	Grand Marquis	4.6L	2V	RCM	√	√	√	√
2002	Grand Marquis	4.6L	2V	ABS/TCS	√	√	√	√
2002	Grand Marquis	4.6L	2V	ABS/TCS	√	√	√	√
2002	Grand Marquis	4.6L	2V	ABS/TCS	√	√	√	√
2002	Grand Marquis	4.6L	2V	DDM	√	√	√	√
2002	Grand Marquis	4.6L	2V	EATC	√	√	√	√
2002	Grand Marquis	4.6L	2V	LCM	√	√	√	√
2002	Grand Marquis	4.6L	2V	PATS	√	√	√	√
2002	Grand Marquis	4.6L	2V	PCM	√	√	√	√
2002	Grand Marquis	4.6L	2V	RCM	√	√	√	√
2003	Grand Marquis	4.6L	2V	ABS/TCS	√	√	√	√
2003	Grand Marquis	4.6L	2V	ABS/TCS	√	√	√	√
2003	Grand Marquis	4.6L	2V	DDM	√	√	√	√
2003	Grand Marquis	4.6L	2V	EATC	√	√	√	√
2003	Grand Marquis	4.6L	2V	LCM	√	√	√	√
2003	Grand Marquis	4.6L	2V	PCM	√	√	√	√
2003	Grand Marquis	4.6L	2V	RASM	√	√	√	√
2003	Grand Marquis	4.6L	2V	RASM	√	√	√	√
2003	Grand Marquis	4.6L	2V	RCM	√	√	√	√
2003	Grand Marquis	4.6L	2V	VAPS	√	√	√	
2004	Grand Marquis	4.6L	2V	ABS/TCS	√	√	√	√
2004	Grand Marquis	4.6L	2V	ABS/TCS	√	√	√	√
2004	Grand Marquis	4.6L	2V	DDM	√	√	√	√
2004	Grand Marquis	4.6L	2V	EATC	√	√	√	√
2004	Grand Marquis	4.6L	2V	LCM	√	√	√	√
2004	Grand Marquis	4.6L	2V	MC	√	√	√	√
2004	Grand Marquis	4.6L	2V	PCM	√	√	√	√
2004	Grand Marquis	4.6L	2V	RASM	√	√	√	√
2004	Grand Marquis	4.6L	2V	RCM	√	√	√	√
2004	Grand Marquis	4.6L	2V	VAPS	√	√	√	
2005	Grand Marquis	4.6L	2V	ABS	√	√	√	√
2005	Grand Marquis	4.6L	2V	DDM	√	√	√	√
2005	Grand Marquis	4.6L	2V	EATC	√	√	√	√
2005	Grand Marquis	4.6L	2V	LCM	√	√	√	√
2005	Grand Marquis	4.6L	2V	MC	√	√	√	√
2005	Grand Marquis	4.6L	2V	PCM	√	√	√	√
2005	Grand Marquis	4.6L	2V	RASM	√	√	√	√
2005	Grand Marquis	4.6L	2V	RCM	√	√	√	√
2005	Grand Marquis	4.6L	2V	VAPS	√	√	√	
2006	Grand Marquis	4.6L	2V	ABS	√	√	√	√
2006	Grand Marquis	4.6L	2V	DDM	√	√	√	√

2006	Grand Marquis	4.6L	2V	EATC	√	√	√	√
2006	Grand Marquis	4.6L	2V	IC	√	√	√	√
2006	Grand Marquis	4.6L	2V	LCM	√	√	√	√
2006	Grand Marquis	4.6L	2V	MC	√	√	√	√
2006	Grand Marquis	4.6L	2V	PCM	√	√	√	√
2006	Grand Marquis	4.6L	2V	PCM	√	√	√	√
2006	Grand Marquis	4.6L	2V	RASM	√	√	√	√
2006	Grand Marquis	4.6L	2V	RCM	√	√	√	√
2006	Grand Marquis	4.6L	2V	VAPS	√	√	√	
2007	Grand Marquis	4.6L	2V	ABS	√	√	√	√
2007	Grand Marquis	4.6L	2V	DDM	√	√	√	√
2007	Grand Marquis	4.6L	2V	EATC	√	√	√	√
2007	Grand Marquis	4.6L	2V	IC	√	√	√	√
2007	Grand Marquis	4.6L	2V	LCM	√	√	√	√
2007	Grand Marquis	4.6L	2V	MC	√	√	√	√
2007	Grand Marquis	4.6L	2V	PCM	√	√	√	√
2007	Grand Marquis	4.6L	2V	PCM	√	√	√	√
2007	Grand Marquis	4.6L	2V	RCM	√	√	√	√
2007	Grand Marquis	4.6L	2V	VDM	√	√	√	√
2008	Grand Marquis	4.6L	2V	ABS	√	√	√	√
2008	Grand Marquis	4.6L	2V	DDM	√	√	√	√
2008	Grand Marquis	4.6L	2V	HVAC	√	√	√	√
2008	Grand Marquis	4.6L	2V	IC	√	√	√	√
2008	Grand Marquis	4.6L	2V	LCM	√	√	√	√
2008	Grand Marquis	4.6L	2V	MC	√	√	√	√
2008	Grand Marquis	4.6L	2V	PCM	√	√	√	√
2008	Grand Marquis	4.6L	2V	PCM	√	√	√	√
2008	Grand Marquis	4.6L	2V	RCM	√	√	√	√
2008	Grand Marquis	4.6L	2V	VDM	√	√	√	√
2009	Grand Marquis	4.6L	2V	ABS	√	√	√	√
2009	Grand Marquis	4.6L	2V	DDM	√	√	√	√
2009	Grand Marquis	4.6L	2V	HVAC	√	√	√	√
2009	Grand Marquis	4.6L	2V	IC	√	√	√	√
2009	Grand Marquis	4.6L	2V	LCM	√	√	√	√
2009	Grand Marquis	4.6L	2V	MC	√	√	√	√
2009	Grand Marquis	4.6L	2V	PCM	√	√	√	√
2009	Grand Marquis	4.6L	2V	PCM	√	√	√	√
2009	Grand Marquis	4.6L	2V	RCM	√	√	√	√
2009	Grand Marquis	4.6L	2V	VDM	√	√	√	√
2010	Grand Marquis	4.6L	2V	DDM	√	√	√	√
2010	Grand Marquis	4.6L	2V	HVAC	√	√	√	√
2010	Grand Marquis	4.6L	2V	IC	√	√	√	√
2010	Grand Marquis	4.6L	2V	LCM	√	√	√	√
2010	Grand Marquis	4.6L	2V	MC	√	√	√	√
2010	Grand Marquis	4.6L	2V	PCM	√	√	√	√



2010	Grand Marquis	4.6L	2V	PCM	✓	✓	✓	✓
2010	Grand Marquis	4.6L	2V	RCM	✓	✓	✓	✓
2010	Grand Marquis	4.6L	2V	VDM	✓	✓	✓	✓
2011	Grand Marquis	4.6L	2V	ABS	✓	✓	✓	
2011	Grand Marquis	4.6L	2V	DDM	✓	✓	✓	✓
2011	Grand Marquis	4.6L	2V	HVAC	✓	✓	✓	✓
2011	Grand Marquis	4.6L	2V	IC	✓	✓	✓	✓
2011	Grand Marquis	4.6L	2V	LCM	✓	✓	✓	✓
2011	Grand Marquis	4.6L	2V	PCM	✓	✓	✓	✓
2011	Grand Marquis	4.6L	2V	RCM	✓	✓	✓	✓
2011	Grand Marquis	4.6L	2V	VDM	✓	✓	✓	✓
1999.75	Ikon	1.6L	Zetec Rocam	ECS	✓	✓	✓	✓
1999.75	Ikon	1.6L	Zetec Rocam	HEC	✓	✓	✓	✓
1999.75	Ikon	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓
1999.75	Ikon	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓
2000.25	Ikon	1.8L	Endura-DE	PCM			✓	✓
2000.5	Ikon	1.3L	HCS	PCM	✓	✓	✓	✓
2001	Ikon	1.6L	Other	ECS	✓	✓	✓	✓
2001	Ikon	1.6L	Other	HEC	✓	✓	✓	✓
2001	Ikon	1.6L	Other	PCM	✓	✓	✓	✓
2003	Ikon	1.3L	Zetec Rocam	PCM	✓	✓	✓	✓
2003	Ikon	1.3L	Zetec Rocam	PCM	✓	✓	✓	✓
2003	Ikon	1.6L	Zetec Rocam	ECS	✓	✓	✓	✓
2003	Ikon	1.6L	Zetec Rocam	HEC	✓	✓	✓	✓
2003	Ikon	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓
2003	Ikon	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓
2003.25	Ikon	1.3L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓
2003.25	Ikon	1.3L	Zetec Rocam	CSM	✓	✓	✓	
2003.25	Ikon	1.3L	Zetec Rocam	ECS	✓	✓	✓	
2003.25	Ikon	1.3L	Zetec Rocam	GEM	✓	✓	✓	✓
2003.25	Ikon	1.3L	Zetec Rocam	PCM	✓	✓	✓	✓
2003.25	Ikon	1.3L	Zetec Rocam	PCM	✓	✓	✓	✓
2003.25	Ikon	1.6L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓
2003.25	Ikon	1.6L	Zetec Rocam	CSM	✓	✓	✓	
2003.25	Ikon	1.6L	Zetec Rocam	ECS	✓	✓	✓	
2003.25	Ikon	1.6L	Zetec Rocam	GEM	✓	✓	✓	✓
2003.25	Ikon	1.6L	Zetec Rocam	HEC	✓	✓	✓	✓
2003.25	Ikon	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓
2003.25	Ikon	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓
2003.25	Ikon	1.6L	Zetec Rocam	TCM	✓	✓	✓	
2009.25	Ikon	1.4L	Duratorq Turbo Diesel Common Rail	IC	✓	✓	✓	✓
2009.25	Ikon	1.4L	Duratorq Turbo Diesel Common Rail	PCM	✓	✓	✓	✓
2009	KA	1.2L	DURATEC 8V	ABS	✓	✓	✓	✓
2009	KA	1.2L	DURATEC 8V	BCMii	✓	✓	✓	✓
2009	KA	1.2L	DURATEC 8V	CTMii	✓	✓	✓	✓

2009	KA	1.2L	DURATEC 8V	EATC	√	√	√	√
2009	KA	1.2L	DURATEC 8V	EPS	√	√	√	√
2009	KA	1.2L	DURATEC 8V	IPC	√	√	√	√
2009	KA	1.2L	DURATEC 8V	PAM	√	√	√	√
2009	KA	1.2L	DURATEC 8V	PCM	√	√	√	√
2009	KA	1.2L	DURATEC 8V	RCM	√	√	√	√
2009	KA	1.3L	Duratorq-Turbo Diesel Common Rail	ABS	√	√	√	√
2009	KA	1.3L	Duratorq-Turbo Diesel Common Rail	BCMii	√	√	√	√
2009	KA	1.3L	Duratorq-Turbo Diesel Common Rail	CTMii	√	√	√	√
2009	KA	1.3L	Duratorq-Turbo Diesel Common Rail	EATC	√	√	√	√
2009	KA	1.3L	Duratorq-Turbo Diesel Common Rail	EPS	√	√	√	√
2009	KA	1.3L	Duratorq-Turbo Diesel Common Rail	IPC	√	√	√	√
2009	KA	1.3L	Duratorq-Turbo Diesel Common Rail	PAM	√	√	√	√
2009	KA	1.3L	Duratorq-Turbo Diesel Common Rail	PCM	√	√	√	√
2009	KA	1.3L	Duratorq-Turbo Diesel Common Rail	RCM	√	√	√	√
2009	KA	Other	Other	ABS	√	√	√	√
2009	KA	Other	Other	BCMii	√	√	√	√
2009	KA	Other	Other	CTMii	√	√	√	√
2009	KA	Other	Other	EATC	√	√	√	√
2009	KA	Other	Other	EPS	√	√	√	√
2009	KA	Other	Other	IPC	√	√	√	√
2009	KA	Other	Other	PAM	√	√	√	√
2009	KA	Other	Other	PCM	√	√	√	√
2009	KA	Other	Other	RCM	√	√	√	√
1997	Ka	1.3L	Endura-E	ABS/TCS	√	√	√	√
1997	Ka	1.3L	Endura-E	PATS	√	√	√	
1997	Ka	1.3L	Endura-E	PCM	√	√	√	√
1997.5	Ka	1.0L	HCS	ABS/TCS	√	√	√	√
1997.5	Ka	1.0L	HCS	CSM	√	√	√	
1997.5	Ka	1.0L	HCS	PATS	√	√	√	
1997.5	Ka	1.0L	HCS	PCM	√	√	√	√
1997.5	Ka	1.3L	Endura-E	ABS/TCS	√	√	√	√
1997.5	Ka	1.3L	Endura-E	CSM	√	√	√	
1997.5	Ka	1.3L	Endura-E	PATS	√	√	√	
1997.5	Ka	1.3L	Endura-E	PCM	√	√	√	√
1998.5	Ka	1.3L	Endura-E	ABS/TCS	√	√	√	√
1998.5	Ka	1.3L	Endura-E	CSM	√	√	√	
1998.5	Ka	1.3L	Endura-E	PATS	√	√	√	
1998.5	Ka	1.3L	Endura-E	PCM	√	√	√	√
1999	Ka	1.0L	HCS	ABS/TCS	√	√	√	√
1999	Ka	1.0L	HCS	CSM	√	√	√	
1999	Ka	1.0L	HCS	ECS	√	√	√	
1999	Ka	1.0L	HCS	PCM	√	√	√	√
1999	Ka	1.3L	Endura-E	ABS/TCS	√	√	√	√
1999	Ka	1.3L	Endura-E	CSM	√	√	√	

1999	Ka	1.3L	Endura-E	ECS	√	√	√	
1999	Ka	1.3L	Endura-E	PCM	√	√	√	√
1999.75	Ka	1.0L	Zetec Rocam	ABS/TCS	√	√	√	√
1999.75	Ka	1.0L	Zetec Rocam	CSM	√	√	√	
1999.75	Ka	1.0L	Zetec Rocam	PCM	√	√	√	√
2000	Ka	1.3L	DURATEC 8V	ABS/TCS	√	√	√	√
2000	Ka	1.3L	DURATEC 8V	CSM	√	√	√	
2000	Ka	1.3L	DURATEC 8V	ECS	√	√	√	
2000	Ka	1.3L	DURATEC 8V	GEM	√	√	√	√
2000	Ka	1.3L	DURATEC 8V	PCM	√	√	√	√
2000	Ka	1.3L	Endura-E	ABS/TCS	√	√	√	√
2000	Ka	1.3L	Endura-E	CSM	√	√	√	
2000	Ka	1.3L	Endura-E	ECS	√	√	√	
2000	Ka	1.3L	Endura-E	GEM	√	√	√	√
2000	Ka	1.3L	Endura-E	PCM	√	√	√	√
2000	Ka	1.6L	DURATEC 8V	ABS/TCS	√	√	√	√
2000	Ka	1.6L	DURATEC 8V	CSM	√	√	√	
2000	Ka	1.6L	DURATEC 8V	ECS	√	√	√	
2000	Ka	1.6L	DURATEC 8V	GEM	√	√	√	√
2000	Ka	1.6L	DURATEC 8V	PCM	√	√	√	√
2000	Ka	1.6L	DURATEC 8V	PCM	√	√	√	√
2001.5	Ka	1.6L	Zetec Rocam	ABS/TCS	√	√	√	√
2001.5	Ka	1.6L	Zetec Rocam	CSM	√	√	√	
2001.5	Ka	1.6L	Zetec Rocam	ECS	√	√	√	
2001.5	Ka	1.6L	Zetec Rocam	PCM	√	√	√	√
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	AWD	√	√	√	√
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	CMR	√	√	√	√
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	D_DCU	√	√	√	√
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	EATC	√	√	√	√
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	EPS	√	√	√	√
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	FFH	√	√	√	√
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	GEM	√	√	√	√
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	√
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	IC	√	√	√	√
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	PAM	√	√	√	√
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	P_DCU	√	√	√	√
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	RETM	√	√	√	√
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	RKE	√	√	√	√
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	



2008.5	Kuga	2.5L	I5	ACM	✓	✓	✓	
2008.5	Kuga	2.5L	I5	ACM	✓	✓	✓	
2008.5	Kuga	2.5L	I5	ACM	✓	✓	✓	
2008.5	Kuga	2.5L	I5	ACM	✓	✓	✓	
2008.5	Kuga	2.5L	I5	ACM	✓	✓	✓	✓
2008.5	Kuga	2.5L	I5	ACM	✓	✓	✓	✓
2008.5	Kuga	2.5L	I5	AWD	✓	✓	✓	✓
2008.5	Kuga	2.5L	I5	CMR	✓	✓	✓	✓
2008.5	Kuga	2.5L	I5	D_DCU	✓	✓	✓	✓
2008.5	Kuga	2.5L	I5	EATC	✓	✓	✓	✓
2008.5	Kuga	2.5L	I5	EPS	✓	✓	✓	✓
2008.5	Kuga	2.5L	I5	FFH	✓	✓	✓	✓
2008.5	Kuga	2.5L	I5	GEM	✓	✓	✓	✓
2008.5	Kuga	2.5L	I5	HCM	✓	✓	✓	✓
2008.5	Kuga	2.5L	I5	IC	✓	✓	✓	✓
2008.5	Kuga	2.5L	I5	PAM	✓	✓	✓	✓
2008.5	Kuga	2.5L	I5	PCM	✓	✓	✓	✓
2008.5	Kuga	2.5L	I5	P_DCU	✓	✓	✓	✓
2008.5	Kuga	2.5L	I5	RCM	✓	✓	✓	✓
2008.5	Kuga	2.5L	I5	RETM	✓	✓	✓	✓
2008.5	Kuga	2.5L	I5	RKE	✓	✓	✓	✓
2008.5	Kuga	2.5L	I5	SRM	✓	✓	✓	✓
2008.5	Kuga	2.5L	I5	TCM	✓	✓	✓	✓
2013.25	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	ABS	✓	✓	✓	
2013.25	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	ACM	✓	✓	✓	✓
2013.25	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	AHCM	✓	✓	✓	✓
2013.25	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	APIM	✓	✓	✓	✓
2013.25	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓
2013.25	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	DDM	✓	✓	✓	✓
2013.25	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	FCDIM	✓	✓	✓	✓
2013.25	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	FDSM	✓	✓	✓	✓
2013.25	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	GPSM	✓	✓	✓	✓
2013.25	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	HCM	✓	✓	✓	✓
2013.25	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	HVAC	✓	✓	✓	✓
2013.25	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	IPC	✓	✓	✓	✓
2013.25	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	IPM-A	✓	✓	✓	✓
2013.25	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	IPM-B	✓	✓	✓	✓
2013.25	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	PAM	✓	✓	✓	✓
2013.25	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2013.25	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	PDM	✓	✓	✓	✓
2013.25	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	PSCM	✓	✓	✓	✓
2013.25	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	RCM	✓	✓	✓	✓
2013.25	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	RFA	✓	✓	✓	✓
2013.25	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	RGTM	✓	✓	✓	✓

2013.25	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	SASM	√	√	√	√
2013.25	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	√
2013.25	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2013.25	Kuga	1.6L	EcoBoost - Gas Turbocharged Direct	TRM	√	√	√	√
2013.25	Kuga	1.6L	GTDI FGEC	ABS	√	√	√	
2013.25	Kuga	1.6L	GTDI FGEC	ACM	√	√	√	√
2013.25	Kuga	1.6L	GTDI FGEC	AHCM	√	√	√	√
2013.25	Kuga	1.6L	GTDI FGEC	APIM	√	√	√	√
2013.25	Kuga	1.6L	GTDI FGEC	BCMii	√	√	√	√
2013.25	Kuga	1.6L	GTDI FGEC	CCMii	√	√	√	√
2013.25	Kuga	1.6L	GTDI FGEC	DDM	√	√	√	√
2013.25	Kuga	1.6L	GTDI FGEC	FCDIM	√	√	√	√
2013.25	Kuga	1.6L	GTDI FGEC	FDSM	√	√	√	√
2013.25	Kuga	1.6L	GTDI FGEC	GPSM	√	√	√	√
2013.25	Kuga	1.6L	GTDI FGEC	HCM	√	√	√	√
2013.25	Kuga	1.6L	GTDI FGEC	HVAC	√	√	√	√
2013.25	Kuga	1.6L	GTDI FGEC	IPC	√	√	√	√
2013.25	Kuga	1.6L	GTDI FGEC	IPM-A	√	√	√	√
2013.25	Kuga	1.6L	GTDI FGEC	IPM-B	√	√	√	√
2013.25	Kuga	1.6L	GTDI FGEC	PAM	√	√	√	√
2013.25	Kuga	1.6L	GTDI FGEC	PCM	√	√	√	√
2013.25	Kuga	1.6L	GTDI FGEC	PDM	√	√	√	√
2013.25	Kuga	1.6L	GTDI FGEC	PSCM	√	√	√	√
2013.25	Kuga	1.6L	GTDI FGEC	RCM	√	√	√	√
2013.25	Kuga	1.6L	GTDI FGEC	RFA	√	√	√	√
2013.25	Kuga	1.6L	GTDI FGEC	RGTM	√	√	√	√
2013.25	Kuga	1.6L	GTDI FGEC	SASM	√	√	√	√
2013.25	Kuga	1.6L	GTDI FGEC	SOD-L	√	√	√	√
2013.25	Kuga	1.6L	GTDI FGEC	SOD-R	√	√	√	√
2013.25	Kuga	1.6L	GTDI FGEC	TRM	√	√	√	√
2013.25	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2013.25	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	AHCM	√	√	√	√
2013.25	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	APIM	√	√	√	√
2013.25	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	BCMii	√	√	√	√
2013.25	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	CCMii	√	√	√	√
2013.25	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	DDM	√	√	√	√
2013.25	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	FCDIM	√	√	√	√
2013.25	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	FDSM	√	√	√	√
2013.25	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	GPSM	√	√	√	√
2013.25	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	√
2013.25	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	HVAC	√	√	√	√
2013.25	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	IPC	√	√	√	√
2013.25	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	IPM-A	√	√	√	√
2013.25	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	IPM-B	√	√	√	√
2013.25	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	PAM	√	√	√	√

2013.25	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	PCM	✓	✓	✓	✓
2013.25	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	PDM	✓	✓	✓	✓
2013.25	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	PSCM	✓	✓	✓	✓
2013.25	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	RCM	✓	✓	✓	✓
2013.25	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	RFA	✓	✓	✓	✓
2013.25	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	RGTM	✓	✓	✓	✓
2013.25	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	SASM	✓	✓	✓	✓
2013.25	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	SOD-L	✓	✓	✓	✓
2013.25	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	SOD-R	✓	✓	✓	✓
2013.25	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	TCM	✓	✓	✓	✓
2013.25	Kuga	2.0L	Duratorq Turbo Diesel Common Rail	TRM	✓	✓	✓	✓
2013.25	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	ABS	✓	✓	✓	
2013.25	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓
2013.25	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	APIM	✓	✓	✓	✓
2013.25	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	BCMii	✓	✓	✓	✓
2013.25	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	CCMii	✓	✓	✓	✓
2013.25	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	DDM	✓	✓	✓	✓
2013.25	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	FCDIM	✓	✓	✓	✓
2013.25	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	FDSM	✓	✓	✓	✓
2013.25	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	GPSM	✓	✓	✓	✓
2013.25	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	HCM	✓	✓	✓	✓
2013.25	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	HVAC	✓	✓	✓	✓
2013.25	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	IPC	✓	✓	✓	✓
2013.25	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	IPM-A	✓	✓	✓	✓
2013.25	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	IPM-B	✓	✓	✓	✓
2013.25	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	PAM	✓	✓	✓	✓
2013.25	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2013.25	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	PDM	✓	✓	✓	✓
2013.25	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	PSCM	✓	✓	✓	✓
2013.25	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	RCM	✓	✓	✓	✓
2013.25	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	RFA	✓	✓	✓	✓
2013.25	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	RGTM	✓	✓	✓	✓
2013.25	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	SASM	✓	✓	✓	✓
2013.25	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓
2013.25	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-R	✓	✓	✓	✓
2013.25	Kuga	2.0L	EcoBoost - Gas Turbocharged Direct	TRM	✓	✓	✓	✓
1996	LASER / 323 / TIERRA	1.3L	B3	ABS	✓	✓	✓	✓
1996	LASER / 323 / TIERRA	1.3L	B3	PCM	✓	✓	✓	✓
1996	LASER / 323 / TIERRA	1.5L	Z5	ABS	✓	✓	✓	
1996	LASER / 323 / TIERRA	1.5L	Z5	PCM	✓	✓	✓	✓
1996	LASER / 323 / TIERRA	1.6L	B6	ABS	✓	✓	✓	
1996	LASER / 323 / TIERRA	1.6L	B6	PCM	✓	✓	✓	✓
1996	LASER / 323 / TIERRA	1.8L	BP	ABS	✓	✓	✓	

1996	LASER / 323 / TIERRA	1.8L	BP	PCM	√	√	√	√
1998	LASER / 323 / TIERRA	1.3L	B3	ABS	√	√	√	√
1998	LASER / 323 / TIERRA	1.3L	B3	PCM	√	√	√	√
1998	LASER / 323 / TIERRA	1.5L	ZL	ABS	√	√	√	√
1998	LASER / 323 / TIERRA	1.5L	ZL	PCM	√	√	√	√
1998	LASER / 323 / TIERRA	1.6L	ZM	ABS	√	√	√	√
1998	LASER / 323 / TIERRA	1.6L	ZM	PCM	√	√	√	√
1998	LASER / 323 / TIERRA	1.8L	FP	ABS	√	√	√	√
1998	LASER / 323 / TIERRA	1.8L	FP	PCM	√	√	√	√
1998	LASER / 323 / TIERRA	2.0L	RF	ABS	√	√	√	√
1998	LASER / 323 / TIERRA	2.0L	RF	PCM	√	√	√	√
2000	LASER / 323 / TIERRA	1.3L	B3	ABS	√	√	√	√
2000	LASER / 323 / TIERRA	1.3L	B3	ABS/TCS	√	√	√	√
2000	LASER / 323 / TIERRA	1.3L	B3	PCM	√	√	√	√
2000	LASER / 323 / TIERRA	1.6L	ZM	ABS	√	√	√	√
2000	LASER / 323 / TIERRA	1.6L	ZM	ABS/TCS	√	√	√	√
2000	LASER / 323 / TIERRA	1.6L	ZM	PCM	√	√	√	√
2000	LASER / 323 / TIERRA	1.8L	FP	ABS	√	√	√	√
2000	LASER / 323 / TIERRA	1.8L	FP	PCM	√	√	√	√
2000	LASER / 323 / TIERRA	2.0L	FS	ABS	√	√	√	√
2000	LASER / 323 / TIERRA	2.0L	FS	ABS/TCS	√	√	√	√
2000	LASER / 323 / TIERRA	2.0L	FS	PCM	√	√	√	√
2000	LASER / 323 / TIERRA	2.0L	RF-T	ABS	√	√	√	√
2000	LASER / 323 / TIERRA	2.0L	RF-T	PCM	√	√	√	√
2001	LASER / 323 / TIERRA	1.3L	B3	ABS	√	√	√	√
2001	LASER / 323 / TIERRA	1.3L	B3	PCM	√	√	√	√
2001	LASER / 323 / TIERRA	2.0L	FS	ABS	√	√	√	√
2001	LASER / 323 / TIERRA	2.0L	FS	PCM	√	√	√	√
Other	LASER / 323 / TIERRA	1.3L	B3	ABS	√	√	√	√
Other	LASER / 323 / TIERRA	1.3L	B3	PCM	√	√	√	√
Other	LASER / 323 / TIERRA	1.3L	Other	PCM	√	√	√	√
Other	LASER / 323 / TIERRA	1.5L	Other	PCM	√	√	√	√
Other	LASER / 323 / TIERRA	1.5L	Z5	ABS	√	√	√	
Other	LASER / 323 / TIERRA	1.5L	Z5	PCM	√	√	√	√
Other	LASER / 323 / TIERRA	1.5L	ZL	ABS	√	√	√	√
Other	LASER / 323 / TIERRA	1.5L	ZL	PCM	√	√	√	√
Other	LASER / 323 / TIERRA	1.6L	B6	ABS	√	√	√	
Other	LASER / 323 / TIERRA	1.6L	B6	PCM	√	√	√	√
Other	LASER / 323 / TIERRA	1.6L	Other	PCM	√	√	√	√
Other	LASER / 323 / TIERRA	1.6L	ZM	ABS	√	√	√	√
Other	LASER / 323 / TIERRA	1.6L	ZM	PCM	√	√	√	√
Other	LASER / 323 / TIERRA	1.8L	BP	ABS	√	√	√	
Other	LASER / 323 / TIERRA	1.8L	BP	PCM	√	√	√	√
Other	LASER / 323 / TIERRA	1.8L	FP	ABS	√	√	√	√
Other	LASER / 323 / TIERRA	1.8L	FP	PCM	√	√	√	√



Other	LASER / 323 / TIERRA	1.8L	Other	PCM	√	√	√	√
Other	LASER / 323 / TIERRA	2.0L	RF	ABS	√	√	√	√
Other	LASER / 323 / TIERRA	2.0L	RF	PCM	√	√	√	√
2000	LS	3.0L	Other	ABS/TCS	√	√	√	√
2000	LS	3.0L	Other	ACM	√	√	√	√
2000	LS	3.0L	Other	CPM	√	√	√	√
2000	LS	3.0L	Other	DDM	√	√	√	√
2000	LS	3.0L	Other	DSM	√	√	√	√
2000	LS	3.0L	Other	EATC	√	√	√	√
2000	LS	3.0L	Other	GEM	√	√	√	√
2000	LS	3.0L	Other	HEC	√	√	√	√
2000	LS	3.0L	Other	MC	√	√	√	√
2000	LS	3.0L	Other	PCM	√	√	√	√
2000	LS	3.0L	Other	PCM	√	√	√	√
2000	LS	3.0L	Other	RCM	√	√	√	√
2000	LS	3.0L	Other	REM	√	√	√	√
2000	LS	3.0L	Other	RESCU	√	√	√	√
2000	LS	3.0L	Other	SCLM	√	√	√	√
2000	LS	3.9L	Other	ABS/TCS	√	√	√	√
2000	LS	3.9L	Other	ACM	√	√	√	√
2000	LS	3.9L	Other	CPM	√	√	√	√
2000	LS	3.9L	Other	DDM	√	√	√	√
2000	LS	3.9L	Other	DSM	√	√	√	√
2000	LS	3.9L	Other	EATC	√	√	√	√
2000	LS	3.9L	Other	GEM	√	√	√	√
2000	LS	3.9L	Other	HEC	√	√	√	√
2000	LS	3.9L	Other	MC	√	√	√	√
2000	LS	3.9L	Other	PCM	√	√	√	√
2000	LS	3.9L	Other	RCM	√	√	√	√
2000	LS	3.9L	Other	REM	√	√	√	√
2000	LS	3.9L	Other	RESCU	√	√	√	√
2002	LS	3.0L	Other	ABS/TCS	√	√	√	√
2002	LS	3.0L	Other	ACM	√	√	√	√
2002	LS	3.0L	Other	CPM	√	√	√	√
2002	LS	3.0L	Other	DDM	√	√	√	√
2002	LS	3.0L	Other	DSM	√	√	√	√
2002	LS	3.0L	Other	EATC	√	√	√	√
2002	LS	3.0L	Other	GEM	√	√	√	√
2002	LS	3.0L	Other	HEC	√	√	√	√
2002	LS	3.0L	Other	MC	√	√	√	√
2002	LS	3.0L	Other	PCM	√	√	√	√
2002	LS	3.0L	Other	PCM	√	√	√	√
2002	LS	3.0L	Other	RCM	√	√	√	√
2002	LS	3.0L	Other	REM	√	√	√	√
2002	LS	3.0L	Other	RESCU	√	√	√	√

2002	LS	3.0L	Other	SCLM	√	√	√	√
2002	LS	3.9L	Other	ABS/TCS	√	√	√	√
2002	LS	3.9L	Other	ACM	√	√	√	√
2002	LS	3.9L	Other	CPM	√	√	√	√
2002	LS	3.9L	Other	DDM	√	√	√	√
2002	LS	3.9L	Other	DSM	√	√	√	√
2002	LS	3.9L	Other	GEM	√	√	√	√
2002	LS	3.9L	Other	HEC	√	√	√	√
2002	LS	3.9L	Other	MC	√	√	√	√
2002	LS	3.9L	Other	PCM	√	√	√	√
2002	LS	3.9L	Other	RCM	√	√	√	√
2002	LS	3.9L	Other	REM	√	√	√	√
2002	LS	3.9L	Other	RESCU	√	√	√	√
2003	LS	3.0L	Other	ABS/TCS	√	√	√	√
2003	LS	3.0L	Other	ACM	√	√	√	√
2003	LS	3.0L	Other	DCSM	√	√	√	√
2003	LS	3.0L	Other	DDM	√	√	√	√
2003	LS	3.0L	Other	DSM	√	√	√	√
2003	LS	3.0L	Other	EATC	√	√	√	√
2003	LS	3.0L	Other	EPB	√	√	√	√
2003	LS	3.0L	Other	GEM	√	√	√	√
2003	LS	3.0L	Other	HEC	√	√	√	√
2003	LS	3.0L	Other	MC	√	√	√	√
2003	LS	3.0L	Other	NAV	√	√	√	√
2003	LS	3.0L	Other	PAM	√	√	√	√
2003	LS	3.0L	Other	PCM	√	√	√	√
2003	LS	3.0L	Other	PCSM	√	√	√	√
2003	LS	3.0L	Other	RCM	√	√	√	√
2003	LS	3.0L	Other	REM	√	√	√	√
2003	LS	3.0L	Other	SCLM	√	√	√	√
2003	LS	3.0L	Other	VEMS	√	√	√	√
2003	LS	3.9L	4V	ABS/TCS	√	√	√	√
2003	LS	3.9L	4V	ACM	√	√	√	√
2003	LS	3.9L	4V	DCSM	√	√	√	√
2003	LS	3.9L	4V	DDM	√	√	√	√
2003	LS	3.9L	4V	DSM	√	√	√	√
2003	LS	3.9L	4V	EATC	√	√	√	√
2003	LS	3.9L	4V	EPB	√	√	√	√
2003	LS	3.9L	4V	GEM	√	√	√	√
2003	LS	3.9L	4V	HEC	√	√	√	√
2003	LS	3.9L	4V	MC	√	√	√	√
2003	LS	3.9L	4V	NAV	√	√	√	√
2003	LS	3.9L	4V	PAM	√	√	√	√
2003	LS	3.9L	4V	PCM	√	√	√	√
2003	LS	3.9L	4V	PCSM	√	√	√	√

2003	LS	3.9L	4V	RCM	√	√	√	√
2003	LS	3.9L	4V	REM	√	√	√	√
2003	LS	3.9L	4V	SCLM	√	√	√	√
2003	LS	3.9L	4V	VEMS	√	√	√	√
2004	LS	3.0L	Other	ABS/TCS	√	√	√	√
2004	LS	3.0L	Other	ACM	√	√	√	√
2004	LS	3.0L	Other	DCSM	√	√	√	√
2004	LS	3.0L	Other	DDM	√	√	√	√
2004	LS	3.0L	Other	DSM	√	√	√	√
2004	LS	3.0L	Other	EATC	√	√	√	√
2004	LS	3.0L	Other	EPB	√	√	√	√
2004	LS	3.0L	Other	GEM	√	√	√	√
2004	LS	3.0L	Other	HEC	√	√	√	√
2004	LS	3.0L	Other	MC	√	√	√	√
2004	LS	3.0L	Other	NAV	√	√	√	√
2004	LS	3.0L	Other	PAM	√	√	√	√
2004	LS	3.0L	Other	PCM	√	√	√	√
2004	LS	3.0L	Other	PCSM	√	√	√	√
2004	LS	3.0L	Other	RCM	√	√	√	√
2004	LS	3.0L	Other	REM	√	√	√	√
2004	LS	3.0L	Other	SCLM	√	√	√	√
2004	LS	3.9L	4V	ABS/TCS	√	√	√	√
2004	LS	3.9L	4V	ACM	√	√	√	√
2004	LS	3.9L	4V	DCSM	√	√	√	√
2004	LS	3.9L	4V	DDM	√	√	√	√
2004	LS	3.9L	4V	DSM	√	√	√	√
2004	LS	3.9L	4V	EATC	√	√	√	√
2004	LS	3.9L	4V	EPB	√	√	√	√
2004	LS	3.9L	4V	GEM	√	√	√	√
2004	LS	3.9L	4V	HEC	√	√	√	√
2004	LS	3.9L	4V	MC	√	√	√	√
2004	LS	3.9L	4V	NAV	√	√	√	√
2004	LS	3.9L	4V	PAM	√	√	√	√
2004	LS	3.9L	4V	PCM	√	√	√	√
2004	LS	3.9L	4V	PCSM	√	√	√	√
2004	LS	3.9L	4V	RCM	√	√	√	√
2004	LS	3.9L	4V	REM	√	√	√	√
2004	LS	3.9L	4V	SCLM	√	√	√	√
2005	LS	3.0L	Other	ABS/TCS	√	√	√	√
2005	LS	3.0L	Other	ACM	√	√	√	√
2005	LS	3.0L	Other	DCSM	√	√	√	√
2005	LS	3.0L	Other	DDM	√	√	√	√
2005	LS	3.0L	Other	DSM	√	√	√	√
2005	LS	3.0L	Other	EATC	√	√	√	√
2005	LS	3.0L	Other	EPB	√	√	√	√

2005	LS	3.0L	Other	GEM	√	√	√	√
2005	LS	3.0L	Other	HEC	√	√	√	√
2005	LS	3.0L	Other	MC	√	√	√	√
2005	LS	3.0L	Other	PAM	√	√	√	√
2005	LS	3.0L	Other	PCM	√	√	√	√
2005	LS	3.0L	Other	PCSM	√	√	√	√
2005	LS	3.0L	Other	RCM	√	√	√	√
2005	LS	3.0L	Other	REM	√	√	√	√
2005	LS	3.0L	Other	SCLM	√	√	√	√
2005	LS	3.9L	4V	ABS/TCS	√	√	√	√
2005	LS	3.9L	4V	ACM	√	√	√	√
2005	LS	3.9L	4V	DCSM	√	√	√	√
2005	LS	3.9L	4V	DDM	√	√	√	√
2005	LS	3.9L	4V	DSM	√	√	√	√
2005	LS	3.9L	4V	EATC	√	√	√	√
2005	LS	3.9L	4V	EPB	√	√	√	√
2005	LS	3.9L	4V	GEM	√	√	√	√
2005	LS	3.9L	4V	HEC	√	√	√	√
2005	LS	3.9L	4V	MC	√	√	√	√
2005	LS	3.9L	4V	NAV	√	√	√	√
2005	LS	3.9L	4V	PAM	√	√	√	√
2005	LS	3.9L	4V	PCM	√	√	√	√
2005	LS	3.9L	4V	PCSM	√	√	√	√
2005	LS	3.9L	4V	RCM	√	√	√	√
2005	LS	3.9L	4V	REM	√	√	√	√
2005	LS	3.9L	4V	SCLM	√	√	√	√
2006	LS	3.9L	4V	ABS/TCS	√	√	√	√
2006	LS	3.9L	4V	ACM	√	√	√	√
2006	LS	3.9L	4V	DCSM	√	√	√	√
2006	LS	3.9L	4V	DDM	√	√	√	√
2006	LS	3.9L	4V	DSM	√	√	√	√
2006	LS	3.9L	4V	EATC	√	√	√	√
2006	LS	3.9L	4V	EPB	√	√	√	√
2006	LS	3.9L	4V	GEM	√	√	√	√
2006	LS	3.9L	4V	HEC	√	√	√	√
2006	LS	3.9L	4V	MC	√	√	√	√
2006	LS	3.9L	4V	NAV	√	√	√	√
2006	LS	3.9L	4V	PAM	√	√	√	√
2006	LS	3.9L	4V	PCM	√	√	√	√
2006	LS	3.9L	4V	PCSM	√	√	√	√
2006	LS	3.9L	4V	RCM	√	√	√	√
2006	LS	3.9L	4V	REM	√	√	√	√
2006	LS	3.9L	4V	SCLM	√	√	√	√
Other	Liata	1.6L	Other	PCM	√	√	√	
Other	Liata	1.8L	Other	PCM	√	√	√	



2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	TCM	√	√	√	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	ABS	√	√	√	√
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	ABS	√	√	√	√
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	EATC	√	√	√	√
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	EATC	√	√	√	√
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	EPS	√	√	√	√
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	EPS	√	√	√	√
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	GEM	√	√	√	√
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	GEM	√	√	√	√
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	IC	√	√	√	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	IC	√	√	√	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	LPSDM	√	√	√	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	PCM	√	√	√	√
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	PCM	√	√	√	√
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	RCM	√	√	√	√
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	RCM	√	√	√	√
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	RKE	√	√	√	√
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	RKE	√	√	√	√
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	RPSDM	√	√	√	√
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	TCM	√	√	√	√
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	TCM	√	√	√	√
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	ABS	√	√	√	√
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	EATC	√	√	√	√
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	FFH	√	√	√	√
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	FFH	√	√	√	√
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	GEM	√	√	√	√
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	GEM	√	√	√	√
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	IC	√	√	√	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	LPSDM	√	√	√	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	PCM	√	√	√	√
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	PCM	√	√	√	√
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	RCM	√	√	√	√
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	RKE	√	√	√	√
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	RPSDM	√	√	√	√
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	TCM	√	√	√	
1998	MILLENIA / EUNOS 800	2.0L	KF	ABS	√	√	√	√
1998	MILLENIA / EUNOS 800	2.3L	KJ	ABS	√	√	√	√
1998	MILLENIA / EUNOS 800	2.5L	KL	ABS	√	√	√	√
2000	MILLENIA / EUNOS 800	2.0L	KF	ABS	√	√	√	√
2000	MILLENIA / EUNOS 800	2.3L	KJ	ABS	√	√	√	√
2000	MILLENIA / EUNOS 800	2.5L	KL	ABS	√	√	√	√
2002	MILLENIA / EUNOS 800	2.5L	KL	ABS/TCS	√	√	√	√
2002	MILLENIA / EUNOS 800	2.5L	KL	PCM	√	√	√	√
2009	MKS	3.7L	4V	4X4	√	√	√	√
2009	MKS	3.7L	4V	ABS	√	√	√	√

2009	MKS	3.7L	4V	ACM	✓	✓	✓	✓
2009	MKS	3.7L	4V	APIM	✓	✓	✓	✓
2009	MKS	3.7L	4V	C-CM	✓	✓	✓	✓
2009	MKS	3.7L	4V	DCSM	✓	✓	✓	✓
2009	MKS	3.7L	4V	DDM	✓	✓	✓	✓
2009	MKS	3.7L	4V	DDM	✓	✓	✓	✓
2009	MKS	3.7L	4V	DSM	✓	✓	✓	✓
2009	MKS	3.7L	4V	DSP	✓	✓	✓	✓
2009	MKS	3.7L	4V	FCIM	✓	✓	✓	✓
2009	MKS	3.7L	4V	FDIM	✓	✓	✓	
2009	MKS	3.7L	4V	GEM / SJB	✓	✓	✓	✓
2009	MKS	3.7L	4V	HCM	✓	✓	✓	✓
2009	MKS	3.7L	4V	HCM-2	✓	✓	✓	✓
2009	MKS	3.7L	4V	HD_LVL	✓	✓	✓	✓
2009	MKS	3.7L	4V	HVAC	✓	✓	✓	✓
2009	MKS	3.7L	4V	IPC	✓	✓	✓	✓
2009	MKS	3.7L	4V	OCSM	✓	✓	✓	✓
2009	MKS	3.7L	4V	PAM	✓	✓	✓	✓
2009	MKS	3.7L	4V	PCM	✓	✓	✓	✓
2009	MKS	3.7L	4V	RCM	✓	✓	✓	✓
2009	MKS	3.7L	4V	RFA	✓	✓	✓	✓
2009	MKS	3.7L	4V	SECM	✓	✓	✓	✓
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	4X4	✓	✓	✓	✓
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	ABS	✓	✓	✓	✓
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	ACM	✓	✓	✓	✓
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	APIM	✓	✓	✓	✓
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	C-CM	✓	✓	✓	✓
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	DCSM	✓	✓	✓	✓
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	DDM	✓	✓	✓	✓
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	FCIM	✓	✓	✓	✓
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	FDIM	✓	✓	✓	
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	GEM / SJB	✓	✓	✓	✓
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	GPSM	✓	✓	✓	✓
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	HCM	✓	✓	✓	✓
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	HCM-2	✓	✓	✓	✓
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	HD_LVL	✓	✓	✓	✓
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	HUD	✓	✓	✓	✓
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	HVAC	✓	✓	✓	✓
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	ILCM	✓	✓	✓	✓
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	IPC	✓	✓	✓	✓
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	OCSM	✓	✓	✓	✓
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	PAM	✓	✓	✓	✓
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓

2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	RETM	√	√	√	√
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	√
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	SASM	√	√	√	√
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	√
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R	√	√	√	√
2010	MKS	3.7L	4V	4X4	√	√	√	√
2010	MKS	3.7L	4V	ABS	√	√	√	√
2010	MKS	3.7L	4V	ACM	√	√	√	√
2010	MKS	3.7L	4V	APIM	√	√	√	√
2010	MKS	3.7L	4V	C-CM	√	√	√	√
2010	MKS	3.7L	4V	DCSM	√	√	√	√
2010	MKS	3.7L	4V	DDM	√	√	√	√
2010	MKS	3.7L	4V	DSM	√	√	√	√
2010	MKS	3.7L	4V	DSP	√	√	√	√
2010	MKS	3.7L	4V	FCIM	√	√	√	√
2010	MKS	3.7L	4V	FDIM	√	√	√	
2010	MKS	3.7L	4V	GEM / SJB	√	√	√	√
2010	MKS	3.7L	4V	GPSM	√	√	√	√
2010	MKS	3.7L	4V	HCM	√	√	√	√
2010	MKS	3.7L	4V	HCM-2	√	√	√	√
2010	MKS	3.7L	4V	HD_LVL	√	√	√	√
2010	MKS	3.7L	4V	HUD	√	√	√	√
2010	MKS	3.7L	4V	HVAC	√	√	√	√
2010	MKS	3.7L	4V	ILCM	√	√	√	√
2010	MKS	3.7L	4V	IPC	√	√	√	√
2010	MKS	3.7L	4V	OCSM	√	√	√	√
2010	MKS	3.7L	4V	PAM	√	√	√	√
2010	MKS	3.7L	4V	PCM	√	√	√	√
2010	MKS	3.7L	4V	PSCM	√	√	√	√
2010	MKS	3.7L	4V	RETM	√	√	√	√
2010	MKS	3.7L	4V	RFA	√	√	√	√
2010	MKS	3.7L	4V	SASM	√	√	√	√
2010	MKS	3.7L	4V	SOD-L	√	√	√	√
2010	MKS	3.7L	4V	SOD-R	√	√	√	√
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	4X4	√	√	√	√
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	C-CM	√	√	√	√
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	DCSM	√	√	√	√
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	√



2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	DSM	√	√	√	√
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	DSP	√	√	√	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	√
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	FDIM	√	√	√	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	GEM / SJB	√	√	√	√
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	√
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	HCM	√	√	√	√
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	HCM-2	√	√	√	√
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	HD_LVL	√	√	√	√
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	HUD	√	√	√	√
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	√
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ILCM	√	√	√	√
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	OCSM	√	√	√	√
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	√
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SASM	√	√	√	√
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2011	MKS	3.7L	4V	4X4	√	√	√	√
2011	MKS	3.7L	4V	ABS	√	√	√	√
2011	MKS	3.7L	4V	ACM	√	√	√	√
2011	MKS	3.7L	4V	APIM	√	√	√	√
2011	MKS	3.7L	4V	C-CM	√	√	√	√
2011	MKS	3.7L	4V	DCSM	√	√	√	√
2011	MKS	3.7L	4V	DDM	√	√	√	√
2011	MKS	3.7L	4V	DSM	√	√	√	√
2011	MKS	3.7L	4V	DSP	√	√	√	
2011	MKS	3.7L	4V	FCIM	√	√	√	√
2011	MKS	3.7L	4V	FDIM	√	√	√	
2011	MKS	3.7L	4V	GEM / SJB	√	√	√	√
2011	MKS	3.7L	4V	GPSM	√	√	√	√
2011	MKS	3.7L	4V	HCM	√	√	√	√
2011	MKS	3.7L	4V	HCM-2	√	√	√	√
2011	MKS	3.7L	4V	HD_LVL	√	√	√	√
2011	MKS	3.7L	4V	HUD	√	√	√	√
2011	MKS	3.7L	4V	HVAC	√	√	√	√
2011	MKS	3.7L	4V	ILCM	√	√	√	√
2011	MKS	3.7L	4V	IPC	√	√	√	√
2011	MKS	3.7L	4V	OCSM	√	√	√	√
2011	MKS	3.7L	4V	PAM	√	√	√	√

2011	MKS	3.7L	4V	PCM	√	√	√	√
2011	MKS	3.7L	4V	PSCM	√	√	√	√
2011	MKS	3.7L	4V	RCM	√	√	√	√
2011	MKS	3.7L	4V	RFA	√	√	√	√
2011	MKS	3.7L	4V	SASM	√	√	√	√
2011	MKS	3.7L	4V	SOD-L	√	√	√	√
2011	MKS	3.7L	4V	SOD-R	√	√	√	√
2012	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	4X4	√	√	√	√
2012	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2012	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2012	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2012	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	C-CM	√	√	√	√
2012	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	DCSM	√	√	√	√
2012	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	√
2012	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	DSM	√	√	√	√
2012	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	DSP	√	√	√	
2012	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	√
2012	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	FDIM	√	√	√	
2012	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	GEM / SJB	√	√	√	√
2012	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	√
2012	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	HCM	√	√	√	√
2012	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	HCM-2	√	√	√	√
2012	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	HD_LVL	√	√	√	√
2012	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	HUD	√	√	√	√
2012	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	√	√	√	√
2012	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2012	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	OCSM	√	√	√	√
2012	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2012	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2012	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2012	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2012	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	√
2012	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	SASM	√	√	√	√
2012	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	√
2012	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2012	MKS	3.7L	4V	4X4	√	√	√	√
2012	MKS	3.7L	4V	ABS	√	√	√	√
2012	MKS	3.7L	4V	ACM	√	√	√	√
2012	MKS	3.7L	4V	APIM	√	√	√	√
2012	MKS	3.7L	4V	C-CM	√	√	√	√
2012	MKS	3.7L	4V	DCSM	√	√	√	√
2012	MKS	3.7L	4V	DDM	√	√	√	√
2012	MKS	3.7L	4V	DSM	√	√	√	√
2012	MKS	3.7L	4V	DSP	√	√	√	

2012	MKS	3.7L	4V	FCIM	√	√	√	√
2012	MKS	3.7L	4V	FDIM	√	√	√	
2012	MKS	3.7L	4V	GEM / SJB	√	√	√	√
2012	MKS	3.7L	4V	GPSM	√	√	√	√
2012	MKS	3.7L	4V	HCM	√	√	√	√
2012	MKS	3.7L	4V	HCM-2	√	√	√	√
2012	MKS	3.7L	4V	HD_LVL	√	√	√	√
2012	MKS	3.7L	4V	HUD	√	√	√	√
2012	MKS	3.7L	4V	HVAC	√	√	√	√
2012	MKS	3.7L	4V	ILCM	√	√	√	√
2012	MKS	3.7L	4V	IPC	√	√	√	√
2012	MKS	3.7L	4V	OCSM	√	√	√	√
2012	MKS	3.7L	4V	PAM	√	√	√	√
2012	MKS	3.7L	4V	PCM	√	√	√	√
2012	MKS	3.7L	4V	PSCM	√	√	√	√
2012	MKS	3.7L	4V	RCM	√	√	√	√
2012	MKS	3.7L	4V	RFA	√	√	√	√
2012	MKS	3.7L	4V	SASM	√	√	√	√
2012	MKS	3.7L	4V	SOD-L	√	√	√	√
2012	MKS	3.7L	4V	SOD-R	√	√	√	√
2012	MKS	Other	Other	4X4	√	√	√	√
2012	MKS	Other	Other	ABS	√	√	√	√
2012	MKS	Other	Other	ACM	√	√	√	√
2012	MKS	Other	Other	APIM	√	√	√	√
2012	MKS	Other	Other	C-CM	√	√	√	√
2012	MKS	Other	Other	DCSM	√	√	√	√
2012	MKS	Other	Other	DDM	√	√	√	√
2012	MKS	Other	Other	DSM	√	√	√	√
2012	MKS	Other	Other	DSP	√	√	√	
2012	MKS	Other	Other	FCIM	√	√	√	√
2012	MKS	Other	Other	FDIM	√	√	√	
2012	MKS	Other	Other	GEM / SJB	√	√	√	√
2012	MKS	Other	Other	GPSM	√	√	√	√
2012	MKS	Other	Other	HCM	√	√	√	√
2012	MKS	Other	Other	HCM-2	√	√	√	√
2012	MKS	Other	Other	HD_LVL	√	√	√	√
2012	MKS	Other	Other	HUD	√	√	√	√
2012	MKS	Other	Other	HVAC	√	√	√	√
2012	MKS	Other	Other	ILCM	√	√	√	√
2012	MKS	Other	Other	IPC	√	√	√	√
2012	MKS	Other	Other	OCSM	√	√	√	√
2012	MKS	Other	Other	PAM	√	√	√	√
2012	MKS	Other	Other	PSCM	√	√	√	√
2012	MKS	Other	Other	RCM	√	√	√	√
2012	MKS	Other	Other	RFA	√	√	√	√

2012	MKS	Other	Other	SASM	√	√	√	√
2012	MKS	Other	Other	SOD-L	√	√	√	√
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	BCM#1	√	√	√	√
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	C-CM	√	√	√	√
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C	√	√	√	√
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	DCSM	√	√	√	√
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	√
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	DSM	√	√	√	√
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	DSP	√	√	√	√
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	FCDIM	√	√	√	√
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	√
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	√
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	HCM	√	√	√	√
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	HCM-2	√	√	√	√
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	HSWM	√	√	√	√
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	HUD	√	√	√	√
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	√
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	IPM-A	√	√	√	√
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	OCSM	√	√	√	√
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM	√	√	√	√
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	RACM	√	√	√	√
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	√
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	RTM	√	√	√	√
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	SCCM	√	√	√	√
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	VDM	√	√	√	√
2013	MKS	3.7L	TiVCT	ABS	√	√	√	√
2013	MKS	3.7L	TiVCT	ACM	√	√	√	√
2013	MKS	3.7L	TiVCT	APIM	√	√	√	√
2013	MKS	3.7L	TiVCT	BCM#1	√	√	√	√
2013	MKS	3.7L	TiVCT	C-CM	√	√	√	√
2013	MKS	3.7L	TiVCT	DACM-C	√	√	√	√
2013	MKS	3.7L	TiVCT	DCSM	√	√	√	√
2013	MKS	3.7L	TiVCT	DDM	√	√	√	√
2013	MKS	3.7L	TiVCT	DSM	√	√	√	√
2013	MKS	3.7L	TiVCT	DSP	√	√	√	√

2013	MKS	3.7L	TiVCT	FCDIM	✓	✓	✓	✓
2013	MKS	3.7L	TiVCT	FCIM	✓	✓	✓	✓
2013	MKS	3.7L	TiVCT	GPSM	✓	✓	✓	✓
2013	MKS	3.7L	TiVCT	HCM	✓	✓	✓	✓
2013	MKS	3.7L	TiVCT	HCM-2	✓	✓	✓	✓
2013	MKS	3.7L	TiVCT	HSWM	✓	✓	✓	✓
2013	MKS	3.7L	TiVCT	HUD	✓	✓	✓	✓
2013	MKS	3.7L	TiVCT	HVAC	✓	✓	✓	✓
2013	MKS	3.7L	TiVCT	IPC	✓	✓	✓	✓
2013	MKS	3.7L	TiVCT	IPM-A	✓	✓	✓	✓
2013	MKS	3.7L	TiVCT	OCSM	✓	✓	✓	✓
2013	MKS	3.7L	TiVCT	PAM	✓	✓	✓	✓
2013	MKS	3.7L	TiVCT	PCM	✓	✓	✓	✓
2013	MKS	3.7L	TiVCT	PSCM	✓	✓	✓	✓
2013	MKS	3.7L	TiVCT	RACM	✓	✓	✓	✓
2013	MKS	3.7L	TiVCT	RCM	✓	✓	✓	✓
2013	MKS	3.7L	TiVCT	RFA	✓	✓	✓	✓
2013	MKS	3.7L	TiVCT	RTM	✓	✓	✓	✓
2013	MKS	3.7L	TiVCT	SCCM	✓	✓	✓	✓
2013	MKS	3.7L	TiVCT	SOD-L	✓	✓	✓	✓
2013	MKS	3.7L	TiVCT	SOD-R	✓	✓	✓	✓
2013	MKS	3.7L	TiVCT	VDM	✓	✓	✓	✓
2014	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	ABS	✓	✓	✓	✓
2014	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	ACM	✓	✓	✓	✓
2014	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	APIM	✓	✓	✓	✓
2014	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	BCM#1	✓	✓	✓	✓
2014	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	C-CM	✓	✓	✓	✓
2014	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	DACM-C	✓	✓	✓	✓
2014	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	DCSM	✓	✓	✓	✓
2014	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓
2014	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	DSM	✓	✓	✓	✓
2014	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	DSP	✓	✓	✓	✓
2014	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	FCDIM	✓	✓	✓	✓
2014	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	FCIM	✓	✓	✓	✓
2014	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	GPSM	✓	✓	✓	✓
2014	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	HCM	✓	✓	✓	✓
2014	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	HCM-2	✓	✓	✓	✓
2014	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓
2014	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	HVAC	✓	✓	✓	✓
2014	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	IPC	✓	✓	✓	✓
2014	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	IPM-A	✓	✓	✓	✓
2014	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	OCSM	✓	✓	✓	✓
2014	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	PAM	✓	✓	✓	✓

2014	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2014	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	PSCM	✓	✓	✓	✓
2014	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	RACM	✓	✓	✓	✓
2014	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	RCM	✓	✓	✓	✓
2014	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	RFA	✓	✓	✓	✓
2014	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	RTM	✓	✓	✓	✓
2014	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	SCCM	✓	✓	✓	✓
2014	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-L	✓	✓	✓	✓
2014	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-R	✓	✓	✓	✓
2014	MKS	3.5L	EcoBoost - Gas Turbocharged Direct	VDM	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	ABS	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	ACM	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	APIM	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	BCM#1	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	C-CM	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	DACM-C	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	DCSM	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	DDM	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	DSM	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	DSP	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	FCDIM	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	FCIM	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	GPSM	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	HCM	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	HCM-2	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	HSWM	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	HUD	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	HVAC	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	IPC	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	IPM-A	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	OCSM	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	PAM	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	PCM	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	PSCM	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	RACM	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	RCM	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	RFA	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	RTM	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	SCCM	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	SOD-L	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	SOD-R	✓	✓	✓	✓
2014	MKS	3.7L	TiVCT	VDM	✓	✓	✓	✓
2010	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	4X4	✓	✓	✓	✓
2010	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	ABS	✓	✓	✓	✓

2010	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	√	√	√	√
2010	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	C-CM	√	√	√	√
2010	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	DCSM	√	√	√	√
2010	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	√
2010	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	DSM	√	√	√	√
2010	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	DSP	√	√	√	√
2010	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	√
2010	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	FDIM	√	√	√	√
2010	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	GEM / SJB	√	√	√	√
2010	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	HCM	√	√	√	√
2010	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	HCM-2	√	√	√	√
2010	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	HUD	√	√	√	√
2010	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	√
2010	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	ILCM	√	√	√	√
2010	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2010	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	LTM	√	√	√	√
2010	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	OCSM	√	√	√	√
2010	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2010	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2010	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	PCSM-2	√	√	√	√
2010	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2010	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM	√	√	√	√
2010	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	RETM	√	√	√	√
2010	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	√
2010	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	RHVAC	√	√	√	√
2010	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	SASM	√	√	√	√
2010	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	√
2010	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2010	MKT	3.7L	4V	4X4	√	√	√	√
2010	MKT	3.7L	4V	ABS	√	√	√	√
2010	MKT	3.7L	4V	ACM	√	√	√	√
2010	MKT	3.7L	4V	ACM	√	√	√	√
2010	MKT	3.7L	4V	APIM	√	√	√	√
2010	MKT	3.7L	4V	C-CM	√	√	√	√
2010	MKT	3.7L	4V	DDM	√	√	√	√
2010	MKT	3.7L	4V	DSM	√	√	√	√
2010	MKT	3.7L	4V	DSP	√	√	√	√
2010	MKT	3.7L	4V	FCIM	√	√	√	√
2010	MKT	3.7L	4V	FDIM	√	√	√	√
2010	MKT	3.7L	4V	GEM / SJB	√	√	√	√
2010	MKT	3.7L	4V	HCM	√	√	√	√
2010	MKT	3.7L	4V	HCM-2	√	√	√	√
2010	MKT	3.7L	4V	HUD	√	√	√	√

2010	MKT	3.7L	4V	HVAC	√	√	√	√
2010	MKT	3.7L	4V	ILCM	√	√	√	√
2010	MKT	3.7L	4V	IPC	√	√	√	√
2010	MKT	3.7L	4V	LTM	√	√	√	√
2010	MKT	3.7L	4V	OCSM	√	√	√	√
2010	MKT	3.7L	4V	PAM	√	√	√	√
2010	MKT	3.7L	4V	PCM	√	√	√	√
2010	MKT	3.7L	4V	PCSM-2	√	√	√	√
2010	MKT	3.7L	4V	PSCM	√	√	√	√
2010	MKT	3.7L	4V	RCM	√	√	√	√
2010	MKT	3.7L	4V	RCM	√	√	√	√
2010	MKT	3.7L	4V	RETM	√	√	√	√
2010	MKT	3.7L	4V	RFA	√	√	√	√
2010	MKT	3.7L	4V	RHVAC	√	√	√	√
2010	MKT	3.7L	4V	SASM	√	√	√	√
2010	MKT	3.7L	4V	SOD-L	√	√	√	√
2010	MKT	3.7L	4V	SOD-R	√	√	√	√
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	4X4	√	√	√	√
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	√	√	√	√
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	DCSM	√	√	√	√
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	√
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	DSM	√	√	√	√
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	DSP	√	√	√	√
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	√
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	FDIM	√	√	√	√
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	GEM / SJB	√	√	√	√
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	√	√	√	√
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	HCM	√	√	√	√
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	HCM-2	√	√	√	√
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	HUD	√	√	√	√
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	√
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	ILCM	√	√	√	√
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	LTM	√	√	√	√
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	√	√	√	√
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	PCSM-2	√	√	√	√
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√



2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	RETM	√	√	√	√
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	√
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	RHVAC	√	√	√	√
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	SASM	√	√	√	√
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	√
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2011	MKT	3.7L	4V	4X4	√	√	√	√
2011	MKT	3.7L	4V	ABS	√	√	√	√
2011	MKT	3.7L	4V	ACM	√	√	√	√
2011	MKT	3.7L	4V	APIM	√	√	√	√
2011	MKT	3.7L	4V	C-CM	√	√	√	√
2011	MKT	3.7L	4V	DCSM	√	√	√	√
2011	MKT	3.7L	4V	DDM	√	√	√	√
2011	MKT	3.7L	4V	DSM	√	√	√	√
2011	MKT	3.7L	4V	DSP	√	√	√	
2011	MKT	3.7L	4V	FCIM	√	√	√	√
2011	MKT	3.7L	4V	FDIM	√	√	√	√
2011	MKT	3.7L	4V	GEM / SJB	√	√	√	√
2011	MKT	3.7L	4V	GEM / SJB	√	√	√	√
2011	MKT	3.7L	4V	GPSM	√	√	√	√
2011	MKT	3.7L	4V	HCM	√	√	√	√
2011	MKT	3.7L	4V	HCM-2	√	√	√	√
2011	MKT	3.7L	4V	HUD	√	√	√	√
2011	MKT	3.7L	4V	HVAC	√	√	√	√
2011	MKT	3.7L	4V	ILCM	√	√	√	√
2011	MKT	3.7L	4V	IPC	√	√	√	√
2011	MKT	3.7L	4V	LTM	√	√	√	√
2011	MKT	3.7L	4V	OCSM	√	√	√	√
2011	MKT	3.7L	4V	PAM	√	√	√	√
2011	MKT	3.7L	4V	PCM	√	√	√	√
2011	MKT	3.7L	4V	PCSM-2	√	√	√	√
2011	MKT	3.7L	4V	PSCM	√	√	√	√
2011	MKT	3.7L	4V	RCM	√	√	√	√
2011	MKT	3.7L	4V	RETM	√	√	√	√
2011	MKT	3.7L	4V	RFA	√	√	√	√
2011	MKT	3.7L	4V	RHVAC	√	√	√	√
2011	MKT	3.7L	4V	SASM	√	√	√	√
2011	MKT	3.7L	4V	SOD-L	√	√	√	√
2011	MKT	3.7L	4V	SOD-R	√	√	√	√
2012	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	4X4	√	√	√	√
2012	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2012	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2012	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2012	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	C-CM	√	√	√	
2012	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	DCSM	√	√	√	√

2012	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	√
2012	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM	√	√	√	√
2012	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	√
2012	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	FDIM	√	√	√	√
2012	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	GEM / SJB	√	√	√	√
2012	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	√
2012	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	HCM	√	√	√	√
2012	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	HCM-2	√	√	√	√
2012	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	HUD	√	√	√	√
2012	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	√
2012	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	ILCM	√	√	√	√
2012	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2012	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	LTM	√	√	√	√
2012	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	OCSM	√	√	√	√
2012	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2012	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2012	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	PCSM-2	√	√	√	√
2012	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2012	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2012	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	RETM	√	√	√	√
2012	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	√
2012	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	RHVAC	√	√	√	√
2012	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SASM	√	√	√	√
2012	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	√
2012	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2012	MKT	3.7L	4V	4X4	√	√	√	√
2012	MKT	3.7L	4V	ABS	√	√	√	√
2012	MKT	3.7L	4V	ACM	√	√	√	√
2012	MKT	3.7L	4V	APIM	√	√	√	√
2012	MKT	3.7L	4V	C-CM	√	√	√	
2012	MKT	3.7L	4V	DCSM	√	√	√	√
2012	MKT	3.7L	4V	DDM	√	√	√	√
2012	MKT	3.7L	4V	DSM	√	√	√	√
2012	MKT	3.7L	4V	DSP	√	√	√	
2012	MKT	3.7L	4V	FCIM	√	√	√	√
2012	MKT	3.7L	4V	FDIM	√	√	√	√
2012	MKT	3.7L	4V	GEM / SJB	√	√	√	√
2012	MKT	3.7L	4V	GEM / SJB	√	√	√	√
2012	MKT	3.7L	4V	GPSM	√	√	√	√
2012	MKT	3.7L	4V	HCM	√	√	√	√
2012	MKT	3.7L	4V	HCM-2	√	√	√	√
2012	MKT	3.7L	4V	HUD	√	√	√	√
2012	MKT	3.7L	4V	HVAC	√	√	√	√

2012	MKT	3.7L	4V	IPC	√	√	√	√
2012	MKT	3.7L	4V	LTM	√	√	√	√
2012	MKT	3.7L	4V	OCSM	√	√	√	√
2012	MKT	3.7L	4V	PAM	√	√	√	√
2012	MKT	3.7L	4V	PCM	√	√	√	√
2012	MKT	3.7L	4V	PCSM-2	√	√	√	√
2012	MKT	3.7L	4V	PSCM	√	√	√	√
2012	MKT	3.7L	4V	RCM	√	√	√	√
2012	MKT	3.7L	4V	RETM	√	√	√	√
2012	MKT	3.7L	4V	RFA	√	√	√	√
2012	MKT	3.7L	4V	RHVAC	√	√	√	√
2012	MKT	3.7L	4V	SASM	√	√	√	√
2012	MKT	3.7L	4V	SOD-L	√	√	√	√
2012	MKT	3.7L	4V	SOD-R	√	√	√	√
2012	MKT	Other	Other	4X4	√	√	√	√
2012	MKT	Other	Other	ABS	√	√	√	√
2012	MKT	Other	Other	ACM	√	√	√	√
2012	MKT	Other	Other	APIM	√	√	√	√
2012	MKT	Other	Other	C-CM	√	√	√	√
2012	MKT	Other	Other	DCSM	√	√	√	√
2012	MKT	Other	Other	DDM	√	√	√	√
2012	MKT	Other	Other	DSM	√	√	√	√
2012	MKT	Other	Other	DSP	√	√	√	
2012	MKT	Other	Other	FCIM	√	√	√	√
2012	MKT	Other	Other	FDIM	√	√	√	√
2012	MKT	Other	Other	GEM / SJB	√	√	√	√
2012	MKT	Other	Other	GPSM	√	√	√	√
2012	MKT	Other	Other	HCM	√	√	√	√
2012	MKT	Other	Other	HCM-2	√	√	√	√
2012	MKT	Other	Other	HUD	√	√	√	√
2012	MKT	Other	Other	HVAC	√	√	√	√
2012	MKT	Other	Other	ILCM	√	√	√	√
2012	MKT	Other	Other	IPC	√	√	√	√
2012	MKT	Other	Other	LTM	√	√	√	√
2012	MKT	Other	Other	OCSM	√	√	√	√
2012	MKT	Other	Other	PAM	√	√	√	√
2012	MKT	Other	Other	PCSM-2	√	√	√	√
2012	MKT	Other	Other	PSCM	√	√	√	√
2012	MKT	Other	Other	RCM	√	√	√	√
2012	MKT	Other	Other	RETM	√	√	√	√
2012	MKT	Other	Other	RFA	√	√	√	√
2012	MKT	Other	Other	RHVAC	√	√	√	√
2012	MKT	Other	Other	SASM	√	√	√	√
2012	MKT	Other	Other	SOD-L	√	√	√	√
2012	MKT	Other	Other	SOD-R	√	√	√	√

2013	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2013	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2013	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2013	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	BCM#1	√	√	√	√
2013	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	C-CM	√	√	√	√
2013	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	DCSM	√	√	√	√
2013	MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	√	√	√	√
2013	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	DSM	√	√	√	√
2013	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	DSP	√	√	√	√
2013	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	√
2013	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	√
2013	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	HCM	√	√	√	√
2013	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	HSWM	√	√	√	√
2013	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	HUD	√	√	√	√
2013	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2013	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	IPM-A	√	√	√	√
2013	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	LTM	√	√	√	√
2013	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	OCSM	√	√	√	√
2013	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2013	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2013	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	PCSM-2	√	√	√	√
2013	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2013	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	RACM	√	√	√	√
2013	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2013	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	√
2013	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	RHVAC	√	√	√	√
2013	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	RTM	√	√	√	√
2013	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	SCCM	√	√	√	√
2013	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	√
2013	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2013	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	VDM	√	√	√	√
2013	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2013	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2013	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2013	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	√	√	√	√
2013	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	C-CM	√	√	√	√
2013	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	DCSM	√	√	√	√
2013	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	√
2013	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	DSM	√	√	√	√
2013	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	DSP	√	√	√	√
2013	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	√
2013	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	√

2013	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM	√	√	√	√
2013	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	HUD	√	√	√	√
2013	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	√
2013	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2013	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	IPM-A	√	√	√	√
2013	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	LTM	√	√	√	√
2013	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	OCSM	√	√	√	√
2013	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2013	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2013	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	PCSM-2	√	√	√	√
2013	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2013	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	RACM	√	√	√	√
2013	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2013	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	√
2013	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	RHVAC	√	√	√	√
2013	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	RTM	√	√	√	√
2013	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	SCCM	√	√	√	√
2013	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	√
2013	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2013	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	VDM	√	√	√	√
2013	MKT	3.7L	TiVCT	ABS	√	√	√	√
2013	MKT	3.7L	TiVCT	ACM	√	√	√	√
2013	MKT	3.7L	TiVCT	APIM	√	√	√	√
2013	MKT	3.7L	TiVCT	BCM#1	√	√	√	√
2013	MKT	3.7L	TiVCT	C-CM	√	√	√	√
2013	MKT	3.7L	TiVCT	DCSM	√	√	√	√
2013	MKT	3.7L	TiVCT	DDM	√	√	√	√
2013	MKT	3.7L	TiVCT	DSM	√	√	√	√
2013	MKT	3.7L	TiVCT	DSP	√	√	√	√
2013	MKT	3.7L	TiVCT	FCIM	√	√	√	√
2013	MKT	3.7L	TiVCT	GPSM	√	√	√	√
2013	MKT	3.7L	TiVCT	HCM	√	√	√	√
2013	MKT	3.7L	TiVCT	HSWM	√	√	√	√
2013	MKT	3.7L	TiVCT	HUD	√	√	√	√
2013	MKT	3.7L	TiVCT	HVAC	√	√	√	√
2013	MKT	3.7L	TiVCT	IPC	√	√	√	√
2013	MKT	3.7L	TiVCT	IPM-A	√	√	√	√
2013	MKT	3.7L	TiVCT	LTM	√	√	√	√
2013	MKT	3.7L	TiVCT	OCSM	√	√	√	√
2013	MKT	3.7L	TiVCT	PAM	√	√	√	√
2013	MKT	3.7L	TiVCT	PCM	√	√	√	√
2013	MKT	3.7L	TiVCT	PCSM-2	√	√	√	√
2013	MKT	3.7L	TiVCT	PSCM	√	√	√	√
2013	MKT	3.7L	TiVCT	RACM	√	√	√	√

2013	MKT	3.7L	TiVCT	RCM	√	√	√	√
2013	MKT	3.7L	TiVCT	RFA	√	√	√	√
2013	MKT	3.7L	TiVCT	RHVAC	√	√	√	√
2013	MKT	3.7L	TiVCT	RTM	√	√	√	√
2013	MKT	3.7L	TiVCT	SCCM	√	√	√	√
2013	MKT	3.7L	TiVCT	SOD-R	√	√	√	√
2013	MKT	3.7L	TiVCT	VDM	√	√	√	√
2014	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2014	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2014	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2014	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	BCM#1	√	√	√	√
2014	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	C-CM	√	√	√	√
2014	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	DCSM	√	√	√	√
2014	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	√
2014	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	DSM	√	√	√	√
2014	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	DSP	√	√	√	√
2014	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	√
2014	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	√
2014	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	HCM	√	√	√	√
2014	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	HSWM	√	√	√	√
2014	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	HUD	√	√	√	√
2014	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	√
2014	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2014	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	IPM-A	√	√	√	√
2014	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	LTM	√	√	√	√
2014	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	OCSM	√	√	√	√
2014	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2014	MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM	√	√	√	√
2014	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	PCSM-2	√	√	√	√
2014	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2014	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	RACM	√	√	√	√
2014	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2014	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	√
2014	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	RHVAC	√	√	√	√
2014	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	RTM	√	√	√	√
2014	MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM	√	√	√	√
2014	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2014	MKT	2.0L	EcoBoost - Gas Turbocharged Direct	VDM	√	√	√	√
2014	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2014	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2014	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2014	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	BCM#1	√	√	√	√
2014	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	C-CM	√	√	√	√

2014	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	DCSM	√	√	√	√
2014	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	√
2014	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	DSM	√	√	√	√
2014	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	DSP	√	√	√	√
2014	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	√
2014	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	√
2014	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	HCM	√	√	√	√
2014	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	HSWM	√	√	√	√
2014	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	HUD	√	√	√	√
2014	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	√
2014	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2014	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	IPM-A	√	√	√	√
2014	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	LTM	√	√	√	√
2014	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	√	√	√	√
2014	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2014	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2014	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	PCSM-2	√	√	√	√
2014	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2014	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	RACM	√	√	√	√
2014	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2014	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	√
2014	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC	√	√	√	√
2014	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	SCCM	√	√	√	√
2014	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	√
2014	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2014	MKT	3.5L	EcoBoost - Gas Turbocharged Direct	VDM	√	√	√	√
2014	MKT	3.7L	TiVCT	ABS	√	√	√	√
2014	MKT	3.7L	TiVCT	ACM	√	√	√	√
2014	MKT	3.7L	TiVCT	APIM	√	√	√	√
2014	MKT	3.7L	TiVCT	BCM#1	√	√	√	√
2014	MKT	3.7L	TiVCT	C-CM	√	√	√	√
2014	MKT	3.7L	TiVCT	DCSM	√	√	√	√
2014	MKT	3.7L	TiVCT	DDM	√	√	√	√
2014	MKT	3.7L	TiVCT	DSM	√	√	√	√
2014	MKT	3.7L	TiVCT	DSP	√	√	√	√
2014	MKT	3.7L	TiVCT	FCIM	√	√	√	√
2014	MKT	3.7L	TiVCT	GPSM	√	√	√	√
2014	MKT	3.7L	TiVCT	HCM	√	√	√	√
2014	MKT	3.7L	TiVCT	HSWM	√	√	√	√
2014	MKT	3.7L	TiVCT	HUD	√	√	√	√
2014	MKT	3.7L	TiVCT	HVAC	√	√	√	√
2014	MKT	3.7L	TiVCT	IPC	√	√	√	√
2014	MKT	3.7L	TiVCT	IPM-A	√	√	√	√

2014	MKT	3.7L	TiVCT	LTM	√	√	√	√
2014	MKT	3.7L	TiVCT	OCSM	√	√	√	√
2014	MKT	3.7L	TiVCT	PAM	√	√	√	√
2014	MKT	3.7L	TiVCT	PCM	√	√	√	√
2014	MKT	3.7L	TiVCT	PCSM-2	√	√	√	√
2014	MKT	3.7L	TiVCT	PSCM	√	√	√	√
2014	MKT	3.7L	TiVCT	RACM	√	√	√	√
2014	MKT	3.7L	TiVCT	RCM	√	√	√	√
2014	MKT	3.7L	TiVCT	RFA	√	√	√	√
2014	MKT	3.7L	TiVCT	RHVAC	√	√	√	√
2014	MKT	3.7L	TiVCT	RTM	√	√	√	√
2014	MKT	3.7L	TiVCT	SCCM	√	√	√	√
2014	MKT	3.7L	TiVCT	SOD-L	√	√	√	√
2014	MKT	3.7L	TiVCT	SOD-R	√	√	√	√
2014	MKT	3.7L	TiVCT	VDM	√	√	√	√
2014	MKT	Other	Other	ABS	√	√	√	√
2014	MKT	Other	Other	ACM	√	√	√	√
2014	MKT	Other	Other	APIM	√	√	√	√
2014	MKT	Other	Other	BCM#1	√	√	√	√
2014	MKT	Other	Other	C-CM	√	√	√	√
2014	MKT	Other	Other	DCSM	√	√	√	√
2014	MKT	Other	Other	DDM	√	√	√	√
2014	MKT	Other	Other	DSM	√	√	√	√
2014	MKT	Other	Other	DSP	√	√	√	√
2014	MKT	Other	Other	FCIM	√	√	√	√
2014	MKT	Other	Other	GPSM	√	√	√	√
2014	MKT	Other	Other	HCM	√	√	√	√
2014	MKT	Other	Other	HSWM	√	√	√	√
2014	MKT	Other	Other	HUD	√	√	√	√
2014	MKT	Other	Other	HVAC	√	√	√	√
2014	MKT	Other	Other	IPC	√	√	√	√
2014	MKT	Other	Other	IPM-A	√	√	√	√
2014	MKT	Other	Other	LTM	√	√	√	√
2014	MKT	Other	Other	OCSM	√	√	√	√
2014	MKT	Other	Other	PAM	√	√	√	√
2014	MKT	Other	Other	PCSM-2	√	√	√	√
2014	MKT	Other	Other	PSCM	√	√	√	√
2014	MKT	Other	Other	RACM	√	√	√	√
2014	MKT	Other	Other	RCM	√	√	√	√
2014	MKT	Other	Other	RFA	√	√	√	√
2014	MKT	Other	Other	RHVAC	√	√	√	√
2014	MKT	Other	Other	RTM	√	√	√	√
2014	MKT	Other	Other	SCCM	√	√	√	√
2014	MKT	Other	Other	SOD-L	√	√	√	√
2014	MKT	Other	Other	SOD-R	√	√	√	√



2014	MKT	Other	Other	VDM	√	√	√	√
2007	MKX	3.5L	4V	4X4	√	√	√	√
2007	MKX	3.5L	4V	ABS	√	√	√	√
2007	MKX	3.5L	4V	ACM	√	√	√	√
2007	MKX	3.5L	4V	DCSM	√	√	√	√
2007	MKX	3.5L	4V	DSM	√	√	√	√
2007	MKX	3.5L	4V	DSP	√	√	√	√
2007	MKX	3.5L	4V	EATC	√	√	√	√
2007	MKX	3.5L	4V	GEM	√	√	√	√
2007	MKX	3.5L	4V	HCM	√	√	√	√
2007	MKX	3.5L	4V	IC	√	√	√	√
2007	MKX	3.5L	4V	OCSM	√	√	√	√
2007	MKX	3.5L	4V	PAM	√	√	√	√
2007	MKX	3.5L	4V	PCM	√	√	√	√
2007	MKX	3.5L	4V	RCM	√	√	√	√
2007	MKX	3.5L	4V	RETM	√	√	√	√
2007	MKX	3.5L	4V	SASM	√	√	√	√
2007	MKX	3.5L	4V	SDARS	√	√	√	√
2008	MKX	3.5L	4V	4X4	√	√	√	√
2008	MKX	3.5L	4V	ABS	√	√	√	√
2008	MKX	3.5L	4V	ABS	√	√	√	√
2008	MKX	3.5L	4V	ACM	√	√	√	√
2008	MKX	3.5L	4V	APIM	√	√	√	√
2008	MKX	3.5L	4V	DCSM	√	√	√	√
2008	MKX	3.5L	4V	DSM	√	√	√	√
2008	MKX	3.5L	4V	DSP	√	√	√	√
2008	MKX	3.5L	4V	GEM / SJB	√	√	√	√
2008	MKX	3.5L	4V	HCM	√	√	√	√
2008	MKX	3.5L	4V	HVAC	√	√	√	√
2008	MKX	3.5L	4V	IC	√	√	√	√
2008	MKX	3.5L	4V	LTM	√	√	√	√
2008	MKX	3.5L	4V	OCSM	√	√	√	√
2008	MKX	3.5L	4V	PAM	√	√	√	√
2008	MKX	3.5L	4V	PCM	√	√	√	√
2008	MKX	3.5L	4V	RCM	√	√	√	√
2008	MKX	3.5L	4V	RETM	√	√	√	√
2008	MKX	3.5L	4V	SASM	√	√	√	√
2008	MKX	3.5L	4V	SDARS	√	√	√	√
2009	MKX	3.5L	4V	4X4	√	√	√	√
2009	MKX	3.5L	4V	ABS	√	√	√	√
2009	MKX	3.5L	4V	ABS	√	√	√	√
2009	MKX	3.5L	4V	ACM	√	√	√	√
2009	MKX	3.5L	4V	ACM	√	√	√	√
2009	MKX	3.5L	4V	ACM	√	√	√	√
2009	MKX	3.5L	4V	APIM	√	√	√	√

2009	MKX	3.5L	4V	APIM	√	√	√	√
2009	MKX	3.5L	4V	DCSM	√	√	√	√
2009	MKX	3.5L	4V	DCSM	√	√	√	√
2009	MKX	3.5L	4V	DSM	√	√	√	√
2009	MKX	3.5L	4V	DSM	√	√	√	√
2009	MKX	3.5L	4V	DSP	√	√	√	√
2009	MKX	3.5L	4V	GEM / SJB	√	√	√	√
2009	MKX	3.5L	4V	HCM	√	√	√	√
2009	MKX	3.5L	4V	HVAC	√	√	√	√
2009	MKX	3.5L	4V	IC	√	√	√	√
2009	MKX	3.5L	4V	IC	√	√	√	√
2009	MKX	3.5L	4V	LTM	√	√	√	√
2009	MKX	3.5L	4V	OCSM	√	√	√	√
2009	MKX	3.5L	4V	OCSM	√	√	√	√
2009	MKX	3.5L	4V	PAM	√	√	√	√
2009	MKX	3.5L	4V	PAM	√	√	√	√
2009	MKX	3.5L	4V	PCM	√	√	√	√
2009	MKX	3.5L	4V	PCM	√	√	√	√
2009	MKX	3.5L	4V	RCM	√	√	√	√
2009	MKX	3.5L	4V	RCM	√	√	√	√
2009	MKX	3.5L	4V	RETM	√	√	√	√
2009	MKX	3.5L	4V	SASM	√	√	√	√
2009	MKX	3.5L	4V	SDARS	√	√	√	√
2009	MKX	3.5L	4V	SDARS	√	√	√	√
2009	MKX	3.5L	4V	SDARS	√	√	√	√
2010	MKX	3.5L	4V	4X4	√	√	√	√
2010	MKX	3.5L	4V	ABS	√	√	√	√
2010	MKX	3.5L	4V	ACM	√	√	√	√
2010	MKX	3.5L	4V	ACM	√	√	√	√
2010	MKX	3.5L	4V	ACM	√	√	√	√
2010	MKX	3.5L	4V	APIM	√	√	√	√
2010	MKX	3.5L	4V	DCSM	√	√	√	√
2010	MKX	3.5L	4V	DCSM	√	√	√	√
2010	MKX	3.5L	4V	DSM	√	√	√	√
2010	MKX	3.5L	4V	DSM	√	√	√	√
2010	MKX	3.5L	4V	DSP	√	√	√	√
2010	MKX	3.5L	4V	GEM / SJB	√	√	√	√
2010	MKX	3.5L	4V	GPSM	√	√	√	√
2010	MKX	3.5L	4V	HCM	√	√	√	√
2010	MKX	3.5L	4V	HVAC	√	√	√	√
2010	MKX	3.5L	4V	IC	√	√	√	√
2010	MKX	3.5L	4V	LTM	√	√	√	√
2010	MKX	3.5L	4V	OCSM	√	√	√	√
2010	MKX	3.5L	4V	PAM	√	√	√	√
2010	MKX	3.5L	4V	PAM	√	√	√	√

2010	MKX	3.5L	4V	PCM	√	√	√	√
2010	MKX	3.5L	4V	PCM	√	√	√	√
2010	MKX	3.5L	4V	RETM	√	√	√	√
2010	MKX	3.5L	4V	SASM	√	√	√	√
2010	MKX	3.5L	4V	SDARS	√	√	√	√
2010	MKX	3.5L	4V	SDARS	√	√	√	√
2010	MKX	3.5L	4V	SDARS	√	√	√	√
2011	MKX	3.7L	TiVCT	ABS	√	√	√	√
2011	MKX	3.7L	TiVCT	ACM	√	√	√	√
2011	MKX	3.7L	TiVCT	APIM	√	√	√	√
2011	MKX	3.7L	TiVCT	BCM#1	√	√	√	√
2011	MKX	3.7L	TiVCT	BCM#1	√	√	√	√
2011	MKX	3.7L	TiVCT	C-CM	√	√	√	√
2011	MKX	3.7L	TiVCT	DCSM	√	√	√	√
2011	MKX	3.7L	TiVCT	DSM	√	√	√	√
2011	MKX	3.7L	TiVCT	DSP	√	√	√	
2011	MKX	3.7L	TiVCT	FCDIM	√	√	√	√
2011	MKX	3.7L	TiVCT	FCIM	√	√	√	√
2011	MKX	3.7L	TiVCT	FLM	√	√	√	√
2011	MKX	3.7L	TiVCT	GPSM	√	√	√	√
2011	MKX	3.7L	TiVCT	HCM	√	√	√	√
2011	MKX	3.7L	TiVCT	HSWM	√	√	√	√
2011	MKX	3.7L	TiVCT	HUD	√	√	√	√
2011	MKX	3.7L	TiVCT	HVAC	√	√	√	√
2011	MKX	3.7L	TiVCT	IPC	√	√	√	√
2011	MKX	3.7L	TiVCT	LTM	√	√	√	√
2011	MKX	3.7L	TiVCT	OCSM	√	√	√	√
2011	MKX	3.7L	TiVCT	OCSM	√	√	√	√
2011	MKX	3.7L	TiVCT	PAM	√	√	√	
2011	MKX	3.7L	TiVCT	PCM	√	√	√	√
2011	MKX	3.7L	TiVCT	RCM	√	√	√	√
2011	MKX	3.7L	TiVCT	RFA	√	√	√	√
2011	MKX	3.7L	TiVCT	SCCM	√	√	√	√
2011	MKX	3.7L	TiVCT	SOD-L	√	√	√	√
2011	MKX	3.7L	TiVCT	SOD-R	√	√	√	√
2011	MKX	3.7L	TiVCT	TPM	√	√	√	√
2012	MKX	3.7L	TiVCT	ABS	√	√	√	
2012	MKX	3.7L	TiVCT	ACM	√	√	√	
2012	MKX	3.7L	TiVCT	APIM	√	√	√	
2012	MKX	3.7L	TiVCT	BCM#1	√	√	√	√
2012	MKX	3.7L	TiVCT	C-CM	√	√	√	√
2012	MKX	3.7L	TiVCT	DCSM	√	√	√	√
2012	MKX	3.7L	TiVCT	DSM	√	√	√	
2012	MKX	3.7L	TiVCT	DSP	√	√	√	
2012	MKX	3.7L	TiVCT	FCDIM	√	√	√	

2012	MKX	3.7L	TiVCT	FCIM	√	√	√	
2012	MKX	3.7L	TiVCT	FLM	√	√	√	
2012	MKX	3.7L	TiVCT	GPSM	√	√	√	
2012	MKX	3.7L	TiVCT	HCM	√	√	√	√
2012	MKX	3.7L	TiVCT	HSWM	√	√	√	√
2012	MKX	3.7L	TiVCT	HUD	√	√	√	√
2012	MKX	3.7L	TiVCT	HVAC	√	√	√	
2012	MKX	3.7L	TiVCT	IPC	√	√	√	
2012	MKX	3.7L	TiVCT	LTM	√	√	√	
2012	MKX	3.7L	TiVCT	OCSM	√	√	√	
2012	MKX	3.7L	TiVCT	OCSM	√	√	√	
2012	MKX	3.7L	TiVCT	PAM	√	√	√	
2012	MKX	3.7L	TiVCT	PCM	√	√	√	√
2012	MKX	3.7L	TiVCT	RCM	√	√	√	√
2012	MKX	3.7L	TiVCT	RFA	√	√	√	√
2012	MKX	3.7L	TiVCT	SCCM	√	√	√	√
2012	MKX	3.7L	TiVCT	SOD-L	√	√	√	
2012	MKX	3.7L	TiVCT	SOD-R	√	√	√	
2012	MKX	3.7L	TiVCT	TPM	√	√	√	
2013	MKX	3.7L	TiVCT	ABS	√	√	√	√
2013	MKX	3.7L	TiVCT	ACM	√	√	√	√
2013	MKX	3.7L	TiVCT	APIM	√	√	√	√
2013	MKX	3.7L	TiVCT	BCM#1	√	√	√	√
2013	MKX	3.7L	TiVCT	C-CM	√	√	√	√
2013	MKX	3.7L	TiVCT	DCSM	√	√	√	√
2013	MKX	3.7L	TiVCT	DSM	√	√	√	√
2013	MKX	3.7L	TiVCT	DSP	√	√	√	
2013	MKX	3.7L	TiVCT	FCDIM	√	√	√	√
2013	MKX	3.7L	TiVCT	FCIM	√	√	√	√
2013	MKX	3.7L	TiVCT	FLM	√	√	√	√
2013	MKX	3.7L	TiVCT	GPSM	√	√	√	√
2013	MKX	3.7L	TiVCT	HCM	√	√	√	√
2013	MKX	3.7L	TiVCT	HSWM	√	√	√	√
2013	MKX	3.7L	TiVCT	HUD	√	√	√	√
2013	MKX	3.7L	TiVCT	HVAC	√	√	√	√
2013	MKX	3.7L	TiVCT	IPC	√	√	√	√
2013	MKX	3.7L	TiVCT	LTM	√	√	√	√
2013	MKX	3.7L	TiVCT	OCSM	√	√	√	√
2013	MKX	3.7L	TiVCT	OCSM	√	√	√	√
2013	MKX	3.7L	TiVCT	PAM	√	√	√	√
2013	MKX	3.7L	TiVCT	PCM	√	√	√	√
2013	MKX	3.7L	TiVCT	RCM	√	√	√	√
2013	MKX	3.7L	TiVCT	RFA	√	√	√	√
2013	MKX	3.7L	TiVCT	RTM	√	√	√	√
2013	MKX	3.7L	TiVCT	SCCM	√	√	√	√

2013	MKX	3.7L	TiVCT	SOD-L	√	√	√	√
2013	MKX	3.7L	TiVCT	SOD-R	√	√	√	√
2014	MKX	3.7L	TiVCT	ABS	√	√	√	√
2014	MKX	3.7L	TiVCT	ACM	√	√	√	√
2014	MKX	3.7L	TiVCT	APIM	√	√	√	√
2014	MKX	3.7L	TiVCT	BCM#1	√	√	√	√
2014	MKX	3.7L	TiVCT	C-CM	√	√	√	√
2014	MKX	3.7L	TiVCT	DCSM	√	√	√	√
2014	MKX	3.7L	TiVCT	DSM	√	√	√	√
2014	MKX	3.7L	TiVCT	DSP	√	√	√	√
2014	MKX	3.7L	TiVCT	FCDIM	√	√	√	√
2014	MKX	3.7L	TiVCT	FCIM	√	√	√	√
2014	MKX	3.7L	TiVCT	FLM	√	√	√	√
2014	MKX	3.7L	TiVCT	GPSM	√	√	√	√
2014	MKX	3.7L	TiVCT	HCM	√	√	√	√
2014	MKX	3.7L	TiVCT	HSWM	√	√	√	√
2014	MKX	3.7L	TiVCT	HUD	√	√	√	√
2014	MKX	3.7L	TiVCT	HVAC	√	√	√	√
2014	MKX	3.7L	TiVCT	IPC	√	√	√	√
2014	MKX	3.7L	TiVCT	LTM	√	√	√	√
2014	MKX	3.7L	TiVCT	OCSM	√	√	√	√
2014	MKX	3.7L	TiVCT	PAM	√	√	√	√
2014	MKX	3.7L	TiVCT	PCM	√	√	√	√
2014	MKX	3.7L	TiVCT	RCM	√	√	√	√
2014	MKX	3.7L	TiVCT	RFA	√	√	√	√
2014	MKX	3.7L	TiVCT	RTM	√	√	√	√
2014	MKX	3.7L	TiVCT	SCCM	√	√	√	√
2014	MKX	3.7L	TiVCT	SOD-L	√	√	√	√
2014	MKX	3.7L	TiVCT	SOD-R	√	√	√	√
2014	MKX	Other	Other	ABS	√	√	√	√
2014	MKX	Other	Other	ACM	√	√	√	√
2014	MKX	Other	Other	APIM	√	√	√	√
2014	MKX	Other	Other	BCM#1	√	√	√	√
2014	MKX	Other	Other	C-CM	√	√	√	√
2014	MKX	Other	Other	DCSM	√	√	√	√
2014	MKX	Other	Other	DSM	√	√	√	√
2014	MKX	Other	Other	DSP	√	√	√	√
2014	MKX	Other	Other	FCDIM	√	√	√	√
2014	MKX	Other	Other	FCIM	√	√	√	√
2014	MKX	Other	Other	FLM	√	√	√	√
2014	MKX	Other	Other	GPSM	√	√	√	√
2014	MKX	Other	Other	HCM	√	√	√	√
2014	MKX	Other	Other	HSWM	√	√	√	√
2014	MKX	Other	Other	HUD	√	√	√	√
2014	MKX	Other	Other	HVAC	√	√	√	√

2014	MKX	Other	Other	IPC	√	√	√	√
2014	MKX	Other	Other	LTM	√	√	√	√
2014	MKX	Other	Other	OCSM	√	√	√	√
2014	MKX	Other	Other	PAM	√	√	√	√
2014	MKX	Other	Other	RCM	√	√	√	√
2014	MKX	Other	Other	RFA	√	√	√	√
2014	MKX	Other	Other	RTM	√	√	√	√
2014	MKX	Other	Other	SCCM	√	√	√	√
2014	MKX	Other	Other	SOD-L	√	√	√	√
2014	MKX	Other	Other	SOD-R	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	BCM#1	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	C-CM	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	DACM-C	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	DSM	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	GFM	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	GSM	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	GWM	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	HCM	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	HSWM	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	HUD	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	IPM-A	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	OCSM	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	PDM	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	RACM	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	RGTM	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	RTM	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	SCCM	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-E	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	SCM-G	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	SCM-H	√	√	√	√

2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	TRCM	√	√	√	√
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	VDM	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	ABS	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	ACCM#2	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	ACM	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	BCM#1	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	BECM	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	C-CM	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	DACM-C	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	DCDC	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	DDM	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	DSM	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	DSP	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	FCDIM	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	FCIM	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	GFM	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	GPSM	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	GSM	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	GWM	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	HCM	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	HSWM	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	HUD	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	IPC	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	IPM-A	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	OCSM	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	PAM	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	PCM	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	PDM	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	PSCM	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	RACM	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	RCM	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	RGTM	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	RTM	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	SCCM	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-E	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-G	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-H	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	SOBDM-C	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	SOD-L	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	SOD-R	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	TRCM	√	√	√	√
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	VDM	√	√	√	√
2013	MKZ	3.7L	TiVCT	ABS	√	√	√	√

2013	MKZ	3.7L	TiVCT	ACM	√	√	√	√
2013	MKZ	3.7L	TiVCT	APIM	√	√	√	√
2013	MKZ	3.7L	TiVCT	BCM#1	√	√	√	√
2013	MKZ	3.7L	TiVCT	C-CM	√	√	√	√
2013	MKZ	3.7L	TiVCT	DACM-C	√	√	√	√
2013	MKZ	3.7L	TiVCT	DDM	√	√	√	√
2013	MKZ	3.7L	TiVCT	DSM	√	√	√	√
2013	MKZ	3.7L	TiVCT	DSP	√	√	√	√
2013	MKZ	3.7L	TiVCT	FCDIM	√	√	√	√
2013	MKZ	3.7L	TiVCT	FCIM	√	√	√	√
2013	MKZ	3.7L	TiVCT	GFM	√	√	√	√
2013	MKZ	3.7L	TiVCT	GSM	√	√	√	√
2013	MKZ	3.7L	TiVCT	GWM	√	√	√	√
2013	MKZ	3.7L	TiVCT	HCM	√	√	√	√
2013	MKZ	3.7L	TiVCT	HSWM	√	√	√	√
2013	MKZ	3.7L	TiVCT	HUD	√	√	√	√
2013	MKZ	3.7L	TiVCT	IPC	√	√	√	√
2013	MKZ	3.7L	TiVCT	IPM-A	√	√	√	√
2013	MKZ	3.7L	TiVCT	OCSM	√	√	√	√
2013	MKZ	3.7L	TiVCT	PAM	√	√	√	√
2013	MKZ	3.7L	TiVCT	PCM	√	√	√	√
2013	MKZ	3.7L	TiVCT	PDM	√	√	√	√
2013	MKZ	3.7L	TiVCT	PSCM	√	√	√	√
2013	MKZ	3.7L	TiVCT	RACM	√	√	√	√
2013	MKZ	3.7L	TiVCT	RCM	√	√	√	√
2013	MKZ	3.7L	TiVCT	RGTM	√	√	√	√
2013	MKZ	3.7L	TiVCT	RTM	√	√	√	√
2013	MKZ	3.7L	TiVCT	SCCM	√	√	√	√
2013	MKZ	3.7L	TiVCT	SCM-E	√	√	√	√
2013	MKZ	3.7L	TiVCT	SCM-G	√	√	√	√
2013	MKZ	3.7L	TiVCT	SCM-H	√	√	√	√
2013	MKZ	3.7L	TiVCT	SOD-L	√	√	√	√
2013	MKZ	3.7L	TiVCT	SOD-R	√	√	√	√
2013	MKZ	3.7L	TiVCT	TRCM	√	√	√	√
2013	MKZ	3.7L	TiVCT	VDM	√	√	√	√
2013	MKZ	Other	Other	ABS	√	√	√	√
2013	MKZ	Other	Other	ACM	√	√	√	√
2013	MKZ	Other	Other	APIM	√	√	√	√
2013	MKZ	Other	Other	BCM#1	√	√	√	√
2013	MKZ	Other	Other	C-CM	√	√	√	√
2013	MKZ	Other	Other	DACM-C	√	√	√	√
2013	MKZ	Other	Other	DDM	√	√	√	√
2013	MKZ	Other	Other	DSM	√	√	√	√
2013	MKZ	Other	Other	DSP	√	√	√	√
2013	MKZ	Other	Other	FCDIM	√	√	√	√



2013	MKZ	Other	Other	FCIM	√	√	√	√
2013	MKZ	Other	Other	GFM	√	√	√	√
2013	MKZ	Other	Other	GPSM	√	√	√	√
2013	MKZ	Other	Other	GSM	√	√	√	√
2013	MKZ	Other	Other	GWM	√	√	√	√
2013	MKZ	Other	Other	HCM	√	√	√	√
2013	MKZ	Other	Other	HSWM	√	√	√	√
2013	MKZ	Other	Other	HUD	√	√	√	√
2013	MKZ	Other	Other	IPC	√	√	√	√
2013	MKZ	Other	Other	IPM-A	√	√	√	√
2013	MKZ	Other	Other	OCSM	√	√	√	√
2013	MKZ	Other	Other	PAM	√	√	√	√
2013	MKZ	Other	Other	PDM	√	√	√	√
2013	MKZ	Other	Other	PSCM	√	√	√	√
2013	MKZ	Other	Other	RACM	√	√	√	√
2013	MKZ	Other	Other	RCM	√	√	√	√
2013	MKZ	Other	Other	RGTM	√	√	√	√
2013	MKZ	Other	Other	RTM	√	√	√	√
2013	MKZ	Other	Other	SCCM	√	√	√	√
2013	MKZ	Other	Other	SCM-E	√	√	√	√
2013	MKZ	Other	Other	SCM-G	√	√	√	√
2013	MKZ	Other	Other	SCM-H	√	√	√	√
2013	MKZ	Other	Other	SOD-L	√	√	√	√
2013	MKZ	Other	Other	SOD-R	√	√	√	√
2013	MKZ	Other	Other	TRCM	√	√	√	√
2013	MKZ	Other	Other	VDM	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	BCM#1	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	C-CM	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	DACM-C	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	DSM	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	GFM	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	GSM	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	GWM	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	HCM	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	HSWM	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	HUD	√	√	√	√

2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	IPM-A	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	OCSM	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	PDM	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	RACM	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	RGTM	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	RTM	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	SCCM	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-E	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	SCM-G	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	SCM-H	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	TRCM	√	√	√	√
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct	VDM	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	ABS	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	ACCM#2	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	ACM	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	BCM#1	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	BECM	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	C-CM	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	DACM-C	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	DCDC	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	DDM	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	DSM	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	DSP	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	FCDIM	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	FCIM	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	GFM	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	GPSM	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	GSM	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	GWM	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	HCM	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	HSWM	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	HUD	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	IPC	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	IPM-A	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	OCSM	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	PAM	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	PCM	√	√	√	√

2014	MKZ	2.0L	Full Hybrid Electric Vehicle	PDM	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	PSCM	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	RACM	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	RCM	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	RGTM	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	RTM	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	SCCM	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-E	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-G	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-H	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	SOBDM-C	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	SOD-L	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	SOD-R	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	TRCM	√	√	√	√
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	VDM	√	√	√	√
2014	MKZ	3.7L	TiVCT	ABS	√	√	√	√
2014	MKZ	3.7L	TiVCT	ACM	√	√	√	√
2014	MKZ	3.7L	TiVCT	APIM	√	√	√	√
2014	MKZ	3.7L	TiVCT	BCM#1	√	√	√	√
2014	MKZ	3.7L	TiVCT	C-CM	√	√	√	√
2014	MKZ	3.7L	TiVCT	DACM-C	√	√	√	√
2014	MKZ	3.7L	TiVCT	DDM	√	√	√	√
2014	MKZ	3.7L	TiVCT	DSM	√	√	√	√
2014	MKZ	3.7L	TiVCT	DSP	√	√	√	√
2014	MKZ	3.7L	TiVCT	FCDIM	√	√	√	√
2014	MKZ	3.7L	TiVCT	FCIM	√	√	√	√
2014	MKZ	3.7L	TiVCT	GFM	√	√	√	√
2014	MKZ	3.7L	TiVCT	GSM	√	√	√	√
2014	MKZ	3.7L	TiVCT	GWM	√	√	√	√
2014	MKZ	3.7L	TiVCT	HCM	√	√	√	√
2014	MKZ	3.7L	TiVCT	HSWM	√	√	√	√
2014	MKZ	3.7L	TiVCT	HUD	√	√	√	√
2014	MKZ	3.7L	TiVCT	IPC	√	√	√	√
2014	MKZ	3.7L	TiVCT	IPM-A	√	√	√	√
2014	MKZ	3.7L	TiVCT	OCSM	√	√	√	√
2014	MKZ	3.7L	TiVCT	PAM	√	√	√	√
2014	MKZ	3.7L	TiVCT	PCM	√	√	√	√
2014	MKZ	3.7L	TiVCT	PDM	√	√	√	√
2014	MKZ	3.7L	TiVCT	PSCM	√	√	√	√
2014	MKZ	3.7L	TiVCT	RACM	√	√	√	√
2014	MKZ	3.7L	TiVCT	RCM	√	√	√	√
2014	MKZ	3.7L	TiVCT	RGTM	√	√	√	√
2014	MKZ	3.7L	TiVCT	RTM	√	√	√	√
2014	MKZ	3.7L	TiVCT	SCCM	√	√	√	√
2014	MKZ	3.7L	TiVCT	SCM-E	√	√	√	√

2014	MKZ	3.7L	TiVCT	SCM-G	√	√	√	√
2014	MKZ	3.7L	TiVCT	SCM-H	√	√	√	√
2014	MKZ	3.7L	TiVCT	SOD-L	√	√	√	√
2014	MKZ	3.7L	TiVCT	SOD-R	√	√	√	√
2014	MKZ	3.7L	TiVCT	TRCM	√	√	√	√
2014	MKZ	3.7L	TiVCT	VDM	√	√	√	√
2007.25	MONDEO	1.6L	DURATEC VCT	ABS	√	√	√	√
2007.25	MONDEO	1.6L	DURATEC VCT	ACM	√	√	√	√
2007.25	MONDEO	1.6L	DURATEC VCT	AHCM	√	√	√	√
2007.25	MONDEO	1.6L	DURATEC VCT	BCMii	√	√	√	√
2007.25	MONDEO	1.6L	DURATEC VCT	CCMii	√	√	√	√
2007.25	MONDEO	1.6L	DURATEC VCT	CDP	√	√	√	√
2007.25	MONDEO	1.6L	DURATEC VCT	CMR	√	√	√	√
2007.25	MONDEO	1.6L	DURATEC VCT	DDM	√	√	√	√
2007.25	MONDEO	1.6L	DURATEC VCT	DSM	√	√	√	√
2007.25	MONDEO	1.6L	DURATEC VCT	HCM	√	√	√	√
2007.25	MONDEO	1.6L	DURATEC VCT	HVAC	√	√	√	√
2007.25	MONDEO	1.6L	DURATEC VCT	IPC	√	√	√	√
2007.25	MONDEO	1.6L	DURATEC VCT	PAM	√	√	√	√
2007.25	MONDEO	1.6L	DURATEC VCT	PBM	√	√	√	√
2007.25	MONDEO	1.6L	DURATEC VCT	PCM	√	√	√	√
2007.25	MONDEO	1.6L	DURATEC VCT	PDM	√	√	√	√
2007.25	MONDEO	1.6L	DURATEC VCT	PSCM	√	√	√	√
2007.25	MONDEO	1.6L	DURATEC VCT	RCM	√	√	√	√
2007.25	MONDEO	1.6L	DURATEC VCT	RFA	√	√	√	√
2007.25	MONDEO	1.6L	DURATEC VCT	SASM	√	√	√	√
2007.25	MONDEO	1.6L	DURATEC VCT	SRM	√	√	√	√
2007.25	MONDEO	1.6L	DURATEC VCT	TRM	√	√	√	√
2007.25	MONDEO	1.6L	DURATEC VCT	VDM	√	√	√	√
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail	AHCM	√	√	√	√
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail	BCMii	√	√	√	√
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail	CCMii	√	√	√	√
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail	CDP	√	√	√	√
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail	CMR	√	√	√	√
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail	DDM	√	√	√	√
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail	DSM	√	√	√	√
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	√
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail	HVAC	√	√	√	√
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail	IPC	√	√	√	√
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail	PAM	√	√	√	√
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail	PBM	√	√	√	√
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail	PDM	√	√	√	√

2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail	PSCM	√	√	√	√
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail	SASM	√	√	√	√
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	√
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail	TRM	√	√	√	√
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail	VDM	√	√	√	√
2007.25	MONDEO	2.0L	DURATEC-HE / I4	ABS	√	√	√	√
2007.25	MONDEO	2.0L	DURATEC-HE / I4	ACM	√	√	√	√
2007.25	MONDEO	2.0L	DURATEC-HE / I4	AHCM	√	√	√	√
2007.25	MONDEO	2.0L	DURATEC-HE / I4	BCMii	√	√	√	√
2007.25	MONDEO	2.0L	DURATEC-HE / I4	CCMii	√	√	√	√
2007.25	MONDEO	2.0L	DURATEC-HE / I4	CDP	√	√	√	√
2007.25	MONDEO	2.0L	DURATEC-HE / I4	CMR	√	√	√	√
2007.25	MONDEO	2.0L	DURATEC-HE / I4	DDM	√	√	√	√
2007.25	MONDEO	2.0L	DURATEC-HE / I4	DSM	√	√	√	√
2007.25	MONDEO	2.0L	DURATEC-HE / I4	HCM	√	√	√	√
2007.25	MONDEO	2.0L	DURATEC-HE / I4	HVAC	√	√	√	√
2007.25	MONDEO	2.0L	DURATEC-HE / I4	IPC	√	√	√	√
2007.25	MONDEO	2.0L	DURATEC-HE / I4	PAM	√	√	√	√
2007.25	MONDEO	2.0L	DURATEC-HE / I4	PBM	√	√	√	√
2007.25	MONDEO	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2007.25	MONDEO	2.0L	DURATEC-HE / I4	PDM	√	√	√	√
2007.25	MONDEO	2.0L	DURATEC-HE / I4	PSCM	√	√	√	√
2007.25	MONDEO	2.0L	DURATEC-HE / I4	RCM	√	√	√	√
2007.25	MONDEO	2.0L	DURATEC-HE / I4	RFA	√	√	√	√
2007.25	MONDEO	2.0L	DURATEC-HE / I4	SASM	√	√	√	√
2007.25	MONDEO	2.0L	DURATEC-HE / I4	SRM	√	√	√	√
2007.25	MONDEO	2.0L	DURATEC-HE / I4	TRM	√	√	√	√
2007.25	MONDEO	2.0L	DURATEC-HE / I4	VDM	√	√	√	√
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	AHCM	√	√	√	√
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	BCMii	√	√	√	√
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	CCMii	√	√	√	√
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	CDP	√	√	√	√
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	CMR	√	√	√	√
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	DDM	√	√	√	√
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	DSM	√	√	√	√
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	√
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	HVAC	√	√	√	√
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	IPC	√	√	√	√
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	PAM	√	√	√	√
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	PBM	√	√	√	√
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	PDM	√	√	√	√



2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	TRM	√	√	√	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	TRM	√	√	√	√
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	VDM	√	√	√	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	VDM	√	√	√	√
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	AHCM	√	√	√	√
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	BCMii	√	√	√	√
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	CCMii	√	√	√	√
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	CDP	√	√	√	√
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	CMR	√	√	√	√
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	√
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	DSM	√	√	√	√
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM	√	√	√	√
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	√
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	PBM	√	√	√	√
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	PDM	√	√	√	√
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM	√	√	√	√
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	SASM	√	√	√	√
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	SRM	√	√	√	√
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	TCM	√	√	√	√
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	TRM	√	√	√	√
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	VDM	√	√	√	√
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	ABS	√	√	√	√
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	ACM	√	√	√	√
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	AHCM	√	√	√	√
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	BCMii	√	√	√	√
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	CCMii	√	√	√	√
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	CDP	√	√	√	√
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	CMR	√	√	√	√
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	DDM	√	√	√	√
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	DSM	√	√	√	√
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	HCM	√	√	√	√
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	HVAC	√	√	√	√
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	IPC	√	√	√	√
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	PAM	√	√	√	√
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	PBM	√	√	√	√
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	PCM	√	√	√	√
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	PDM	√	√	√	√

2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	PSCM	√	√	√	√
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	RCM	√	√	√	√
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	RFA	√	√	√	√
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	SASM	√	√	√	√
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	SRM	√	√	√	√
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	TCM	√	√	√	√
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	TRM	√	√	√	√
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	VDM	√	√	√	√
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	AHCM	√	√	√	√
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	BCMii	√	√	√	√
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	CCMii	√	√	√	√
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	CDP	√	√	√	√
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	CMR	√	√	√	√
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	DDM	√	√	√	√
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	DSM	√	√	√	√
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	√
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	HVAC	√	√	√	√
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	PAM	√	√	√	√
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	PBM	√	√	√	√
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	PDM	√	√	√	√
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	PSCM	√	√	√	√
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	RFA	√	√	√	√
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	SASM	√	√	√	√
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	√
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	TRM	√	√	√	√
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	VDM	√	√	√	√
2007.25	MONDEO	2.3L	DURATEC-HE / I4	ABS	√	√	√	√
2007.25	MONDEO	2.3L	DURATEC-HE / I4	ACM	√	√	√	√
2007.25	MONDEO	2.3L	DURATEC-HE / I4	AHCM	√	√	√	√
2007.25	MONDEO	2.3L	DURATEC-HE / I4	AHCM	√	√	√	√
2007.25	MONDEO	2.3L	DURATEC-HE / I4	BCMii	√	√	√	√
2007.25	MONDEO	2.3L	DURATEC-HE / I4	CCMii	√	√	√	√
2007.25	MONDEO	2.3L	DURATEC-HE / I4	CDP	√	√	√	√
2007.25	MONDEO	2.3L	DURATEC-HE / I4	CMR	√	√	√	√
2007.25	MONDEO	2.3L	DURATEC-HE / I4	DDM	√	√	√	√
2007.25	MONDEO	2.3L	DURATEC-HE / I4	DSM	√	√	√	√
2007.25	MONDEO	2.3L	DURATEC-HE / I4	HCM	√	√	√	√
2007.25	MONDEO	2.3L	DURATEC-HE / I4	HVAC	√	√	√	√
2007.25	MONDEO	2.3L	DURATEC-HE / I4	IPC	√	√	√	√
2007.25	MONDEO	2.3L	DURATEC-HE / I4	PAM	√	√	√	√
2007.25	MONDEO	2.3L	DURATEC-HE / I4	PBM	√	√	√	√



2007.25	MONDEO	2.3L	DURATEC-HE / I4	PBM	√	√	√	√
2007.25	MONDEO	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2007.25	MONDEO	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2007.25	MONDEO	2.3L	DURATEC-HE / I4	PDM	√	√	√	√
2007.25	MONDEO	2.3L	DURATEC-HE / I4	PSCM	√	√	√	√
2007.25	MONDEO	2.3L	DURATEC-HE / I4	RCM	√	√	√	√
2007.25	MONDEO	2.3L	DURATEC-HE / I4	RFA	√	√	√	√
2007.25	MONDEO	2.3L	DURATEC-HE / I4	SASM	√	√	√	√
2007.25	MONDEO	2.3L	DURATEC-HE / I4	SRM	√	√	√	√
2007.25	MONDEO	2.3L	DURATEC-HE / I4	TCM	√	√	√	√
2007.25	MONDEO	2.3L	DURATEC-HE / I4	TRM	√	√	√	√
2007.25	MONDEO	2.3L	DURATEC-HE / I4	VDM	√	√	√	√
2007.25	MONDEO	2.5L	I5	ABS	√	√	√	√
2007.25	MONDEO	2.5L	I5	ACM	√	√	√	√
2007.25	MONDEO	2.5L	I5	AHCM	√	√	√	√
2007.25	MONDEO	2.5L	I5	BCMii	√	√	√	√
2007.25	MONDEO	2.5L	I5	CCMii	√	√	√	√
2007.25	MONDEO	2.5L	I5	CDP	√	√	√	√
2007.25	MONDEO	2.5L	I5	CMR	√	√	√	√
2007.25	MONDEO	2.5L	I5	DDM	√	√	√	√
2007.25	MONDEO	2.5L	I5	DSM	√	√	√	√
2007.25	MONDEO	2.5L	I5	HCM	√	√	√	√
2007.25	MONDEO	2.5L	I5	HVAC	√	√	√	√
2007.25	MONDEO	2.5L	I5	IPC	√	√	√	√
2007.25	MONDEO	2.5L	I5	PAM	√	√	√	√
2007.25	MONDEO	2.5L	I5	PBM	√	√	√	√
2007.25	MONDEO	2.5L	I5	PCM	√	√	√	√
2007.25	MONDEO	2.5L	I5	PDM	√	√	√	√
2007.25	MONDEO	2.5L	I5	PSCM	√	√	√	√
2007.25	MONDEO	2.5L	I5	RCM	√	√	√	√
2007.25	MONDEO	2.5L	I5	RFA	√	√	√	√
2007.25	MONDEO	2.5L	I5	SASM	√	√	√	√
2007.25	MONDEO	2.5L	I5	SRM	√	√	√	√
2007.25	MONDEO	2.5L	I5	TRM	√	√	√	√
2007.25	MONDEO	2.5L	I5	VDM	√	√	√	√
2011	MONDEO	1.6L	DURATEC VCT	ABS	√	√	√	√
2011	MONDEO	1.6L	DURATEC VCT	ACM	√	√	√	√
2011	MONDEO	1.6L	DURATEC VCT	AHCM	√	√	√	√
2011	MONDEO	1.6L	DURATEC VCT	BCMii	√	√	√	√
2011	MONDEO	1.6L	DURATEC VCT	CCMii	√	√	√	√
2011	MONDEO	1.6L	DURATEC VCT	CDP	√	√	√	√
2011	MONDEO	1.6L	DURATEC VCT	DABM	√	√	√	√
2011	MONDEO	1.6L	DURATEC VCT	DDM	√	√	√	√
2011	MONDEO	1.6L	DURATEC VCT	DSM	√	√	√	√
2011	MONDEO	1.6L	DURATEC VCT	HCM	√	√	√	√

2011	MONDEO	1.6L	DURATEC VCT	HVAC	√	√	√	√
2011	MONDEO	1.6L	DURATEC VCT	IPC	√	√	√	√
2011	MONDEO	1.6L	DURATEC VCT	IPM-A	√	√	√	√
2011	MONDEO	1.6L	DURATEC VCT	PAM	√	√	√	√
2011	MONDEO	1.6L	DURATEC VCT	PBM	√	√	√	√
2011	MONDEO	1.6L	DURATEC VCT	PCM	√	√	√	√
2011	MONDEO	1.6L	DURATEC VCT	PDM	√	√	√	√
2011	MONDEO	1.6L	DURATEC VCT	PSCM	√	√	√	√
2011	MONDEO	1.6L	DURATEC VCT	RCM	√	√	√	√
2011	MONDEO	1.6L	DURATEC VCT	RFA	√	√	√	√
2011	MONDEO	1.6L	DURATEC VCT	RGTM	√	√	√	√
2011	MONDEO	1.6L	DURATEC VCT	RHVAC	√	√	√	√
2011	MONDEO	1.6L	DURATEC VCT	SASM	√	√	√	√
2011	MONDEO	1.6L	DURATEC VCT	SOD-L	√	√	√	√
2011	MONDEO	1.6L	DURATEC VCT	SOD-R	√	√	√	√
2011	MONDEO	1.6L	DURATEC VCT	SRM	√	√	√	√
2011	MONDEO	1.6L	DURATEC VCT	TRM	√	√	√	
2011	MONDEO	1.6L	DURATEC VCT	VDM	√	√	√	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail	AHCM	√	√	√	√
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail	BCMii	√	√	√	√
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail	CCMii	√	√	√	√
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail	CDP	√	√	√	√
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail	CMR	√	√	√	√
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail	DABM	√	√	√	√
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail	DDM	√	√	√	√
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail	DSM	√	√	√	√
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	√
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail	HVAC	√	√	√	√
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail	IPC	√	√	√	√
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail	IPM-A	√	√	√	√
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail	PAM	√	√	√	√
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail	PBM	√	√	√	√
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail	PDM	√	√	√	√
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail	PSCM	√	√	√	√
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail	RFA	√	√	√	√
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail	RGTM	√	√	√	√
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail	RHVAC	√	√	√	√
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail	SASM	√	√	√	√
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail	SOD-L	√	√	√	√
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail	SOD-R	√	√	√	√
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	√

2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail	TRM	√	√	√	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail	VDM	√	√	√	
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Iniection	ACM	√	√	√	
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct	BCMii	√	√	√	√
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct	CCMii	√	√	√	√
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct	CDP	√	√	√	√
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct	CMR	√	√	√	√
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct	DABM	√	√	√	√
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	√
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct	DSM	√	√	√	√
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct	HCM	√	√	√	√
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	√
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct	IPM-A	√	√	√	√
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct	PBM	√	√	√	√
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct	PDM	√	√	√	√
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	√
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct	RGTM	√	√	√	√
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct	RHVAC	√	√	√	√
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Iniection	SASM	√	√	√	√
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	√
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct	SRM	√	√	√	√
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct	TRM	√	√	√	
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct	VDM	√	√	√	
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	AHCM	√	√	√	
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	BCMii	√	√	√	√
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	CDP	√	√	√	√
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	CMR	√	√	√	√
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	DABM	√	√	√	√
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	DDM	√	√	√	√
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	DSM	√	√	√	√
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	√
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	HVAC	√	√	√	√
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	IPC	√	√	√	√
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	IPM-A	√	√	√	√



2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	RCM	✓	✓	✓	
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	RCM	✓	✓	✓	
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	RCM	✓	✓	✓	✓
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	RFA	✓	✓	✓	
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	RFA	✓	✓	✓	✓
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	RGTM	✓	✓	✓	
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	RGTM	✓	✓	✓	✓
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	RHVAC	✓	✓	✓	
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	RHVAC	✓	✓	✓	✓
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	SASM	✓	✓	✓	
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	SASM	✓	✓	✓	✓
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	SOD-L	✓	✓	✓	
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	SOD-R	✓	✓	✓	
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	SOD-R	✓	✓	✓	✓
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	SRM	✓	✓	✓	
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	SRM	✓	✓	✓	✓
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	TCM	✓	✓	✓	
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	TCM	✓	✓	✓	✓
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	TRM	✓	✓	✓	
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail	VDM	✓	✓	✓	
2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	ABS	✓	✓	✓	
2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	ACM	✓	✓	✓	
2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	AHCM	✓	✓	✓	
2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	BCMii	✓	✓	✓	✓
2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	CCMii	✓	✓	✓	✓
2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	CDP	✓	✓	✓	✓
2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	CMR	✓	✓	✓	✓
2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	DABM	✓	✓	✓	✓
2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	DDM	✓	✓	✓	✓
2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	DSM	✓	✓	✓	✓
2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	HCM	✓	✓	✓	✓
2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	HVAC	✓	✓	✓	✓
2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓
2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	IPC	✓	✓	✓	✓
2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	IPM-A	✓	✓	✓	✓
2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	PAM	✓	✓	✓	✓
2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	PBM	✓	✓	✓	✓
2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	PBM	✓	✓	✓	✓
2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓
2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	RCM	✓	✓	✓	✓

2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	√
2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	RGTM	√	√	√	√
2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	RHVAC	√	√	√	√
2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	SASM	√	√	√	√
2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	√
2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	SRM	√	√	√	√
2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	TCM	√	√	√	√
2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	TRM	√	√	√	
2011	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct	VDM	√	√	√	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	ABS	√	√	√	√
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	ACM	√	√	√	√
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	AHCM	√	√	√	√
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	BCMii	√	√	√	√
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	CCMii	√	√	√	√
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	CDP	√	√	√	√
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	CMR	√	√	√	√
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	DABM	√	√	√	√
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	DDM	√	√	√	√
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	DSM	√	√	√	√
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	HCM	√	√	√	√
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	HVAC	√	√	√	√
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	IPC	√	√	√	√
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	IPM-A	√	√	√	√
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	PAM	√	√	√	√
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	PBM	√	√	√	√
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	PCM	√	√	√	√
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	PDM	√	√	√	√
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	PSCM	√	√	√	√
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	RCM	√	√	√	√
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	RFA	√	√	√	√
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	RGTM	√	√	√	√
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	RHVAC	√	√	√	√
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	SASM	√	√	√	√
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	SOD-L	√	√	√	√
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	SOD-R	√	√	√	√
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	SRM	√	√	√	√
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	TRM	√	√	√	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	VDM	√	√	√	
2011	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2011	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2011	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	AHCM	√	√	√	√
2011	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	BCMii	√	√	√	√
2011	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	CCMii	√	√	√	√
2011	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	CDP	√	√	√	√



2011	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2011	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	PDM	√	√	√	√
2011	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	PSCM	√	√	√	√
2011	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2011	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2011	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	RFA	√	√	√	√
2011	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	RGTM	√	√	√	√
2011	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	RHVAC	√	√	√	√
2011	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	SASM	√	√	√	√
2011	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	SOD-L	√	√	√	√
2011	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	SOD-R	√	√	√	√
2011	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	√
2011	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	TCM	√	√	√	√
2011	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail	TRM	√	√	√	
2011	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	VDM	√	√	√	
2011	MONDEO	2.3L	DURATEC-HE / I4	ACM	√	√	√	
2011	MONDEO	2.3L	DURATEC-HE / I4	AHCM	√	√	√	
2011	MONDEO	2.3L	DURATEC-HE / I4	BCMii	√	√	√	√
2011	MONDEO	2.3L	DURATEC-HE / I4	CCMii	√	√	√	√
2011	MONDEO	2.3L	DURATEC-HE / I4	CDP	√	√	√	√
2011	MONDEO	2.3L	DURATEC-HE / I4	CDP	√	√	√	√
2011	MONDEO	2.3L	DURATEC-HE / I4	CMR	√	√	√	√
2011	MONDEO	2.3L	DURATEC-HE / I4	DABM	√	√	√	√
2011	MONDEO	2.3L	DURATEC-HE / I4	DDM	√	√	√	√
2011	MONDEO	2.3L	DURATEC-HE / I4	DSM	√	√	√	√
2011	MONDEO	2.3L	DURATEC-HE / I4	HCM	√	√	√	√
2011	MONDEO	2.3L	DURATEC-HE / I4	HVAC	√	√	√	√
2011	MONDEO	2.3L	DURATEC-HE / I4	IPC	√	√	√	√
2011	MONDEO	2.3L	DURATEC-HE / I4	IPC	√	√	√	√
2011	MONDEO	2.3L	DURATEC-HE / I4	IPM-A	√	√	√	√
2011	MONDEO	2.3L	DURATEC-HE / I4	PAM	√	√	√	√
2011	MONDEO	2.3L	DURATEC-HE / I4	PBM	√	√	√	√
2011	MONDEO	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2011	MONDEO	2.3L	DURATEC-HE / I4	PDM	√	√	√	√
2011	MONDEO	2.3L	DURATEC-HE / I4	PSCM	√	√	√	√
2011	MONDEO	2.3L	DURATEC-HE / I4	RCM	√	√	√	√
2011	MONDEO	2.3L	DURATEC-HE / I4	RFA	√	√	√	√
2011	MONDEO	2.3L	DURATEC-HE / I4	RGTM	√	√	√	√
2011	MONDEO	2.3L	DURATEC-HE / I4	RHVAC	√	√	√	√
2011	MONDEO	2.3L	DURATEC-HE / I4	SASM	√	√	√	√
2011	MONDEO	2.3L	DURATEC-HE / I4	SOD-L	√	√	√	√
2011	MONDEO	2.3L	DURATEC-HE / I4	SOD-R	√	√	√	√
2011	MONDEO	2.3L	DURATEC-HE / I4	SRM	√	√	√	√



2011	MONDEO	2.3L	DURATEC-HE / I4	TCM	✓	✓	✓	✓
2011	MONDEO	2.3L	DURATEC-HE / I4	TRM	✓	✓	✓	
2011	MONDEO	2.3L	DURATEC-HE / I4	VDM	✓	✓	✓	
2003	Marauder	4.6L	4V	ABS/TCS	✓	✓	✓	✓
2003	Marauder	4.6L	4V	ABS/TCS	✓	✓	✓	✓
2003	Marauder	4.6L	4V	DDM	✓	✓	✓	✓
2003	Marauder	4.6L	4V	EATC	✓	✓	✓	✓
2003	Marauder	4.6L	4V	LCM	✓	✓	✓	✓
2003	Marauder	4.6L	4V	PCM	✓	✓	✓	✓
2003	Marauder	4.6L	4V	RASM	✓	✓	✓	✓
2003	Marauder	4.6L	4V	RCM	✓	✓	✓	✓
2003	Marauder	4.6L	4V	VAPS	✓	✓	✓	✓
2004	Marauder	4.6L	4V	ABS/TCS	✓	✓	✓	✓
2004	Marauder	4.6L	4V	ABS/TCS	✓	✓	✓	✓
2004	Marauder	4.6L	4V	DDM	✓	✓	✓	✓
2004	Marauder	4.6L	4V	EATC	✓	✓	✓	✓
2004	Marauder	4.6L	4V	LCM	✓	✓	✓	✓
2004	Marauder	4.6L	4V	PCM	✓	✓	✓	✓
2004	Marauder	4.6L	4V	RASM	✓	✓	✓	✓
2004	Marauder	4.6L	4V	RCM	✓	✓	✓	✓
2004	Marauder	4.6L	4V	VAPS	✓	✓	✓	✓
2006	Mariner	2.3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓
2006	Mariner	2.3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓
2006	Mariner	2.3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓
2006	Mariner	2.3L	DURATEC-HE / I4	IC	✓	✓	✓	✓
2006	Mariner	2.3L	DURATEC-HE / I4	PAM	✓	✓	✓	✓
2006	Mariner	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓
2006	Mariner	2.3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓
2006	Mariner	3.0L	4V	4X4	✓	✓	✓	✓
2006	Mariner	3.0L	4V	ABS	✓	✓	✓	✓
2006	Mariner	3.0L	4V	GEM	✓	✓	✓	✓
2006	Mariner	3.0L	4V	GEM	✓	✓	✓	✓
2006	Mariner	3.0L	4V	IC	✓	✓	✓	✓
2006	Mariner	3.0L	4V	PAM	✓	✓	✓	✓
2006	Mariner	3.0L	4V	PCM	✓	✓	✓	✓
2006	Mariner	3.0L	4V	RCM	✓	✓	✓	✓
2007	Mariner	2.3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓
2007	Mariner	2.3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓
2007	Mariner	2.3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓
2007	Mariner	2.3L	DURATEC-HE / I4	IC	✓	✓	✓	✓
2007	Mariner	2.3L	DURATEC-HE / I4	PAM	✓	✓	✓	✓
2007	Mariner	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓
2007	Mariner	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓
2007	Mariner	2.3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓
2007	Mariner	3.0L	4V	4X4	✓	✓	✓	✓

2007	Mariner	3.0L	4V	ABS	✓	✓	✓	✓
2007	Mariner	3.0L	4V	GEM	✓	✓	✓	✓
2007	Mariner	3.0L	4V	IC	✓	✓	✓	✓
2007	Mariner	3.0L	4V	PAM	✓	✓	✓	✓
2007	Mariner	3.0L	4V	RCM	✓	✓	✓	✓
2006	Mark LT	5.4L	3V	4X4	✓	✓	✓	✓
2006	Mark LT	5.4L	3V	ABS	✓	✓	✓	✓
2006	Mark LT	5.4L	3V	DSM	✓	✓	✓	✓
2006	Mark LT	5.4L	3V	EATC	✓	✓	✓	✓
2006	Mark LT	5.4L	3V	IC	✓	✓	✓	✓
2006	Mark LT	5.4L	3V	PAM	✓	✓	✓	✓
2006	Mark LT	5.4L	3V	PAM	✓	✓	✓	✓
2006	Mark LT	5.4L	3V	PCM	✓	✓	✓	✓
2006	Mark LT	5.4L	3V	RCM	✓	✓	✓	✓
2006	Mark LT	5.4L	3V	VSM	✓	✓	✓	✓
2007	Mark LT	5.4L	3V	4X4	✓	✓	✓	✓
2007	Mark LT	5.4L	3V	ABS	✓	✓	✓	✓
2007	Mark LT	5.4L	3V	DSM	✓	✓	✓	✓
2007	Mark LT	5.4L	3V	EATC	✓	✓	✓	✓
2007	Mark LT	5.4L	3V	IC	✓	✓	✓	✓
2007	Mark LT	5.4L	3V	PAM	✓	✓	✓	✓
2007	Mark LT	5.4L	3V	PCM	✓	✓	✓	✓
2007	Mark LT	5.4L	3V	RCM	✓	✓	✓	✓
2007	Mark LT	5.4L	3V	VSM	✓	✓	✓	✓
2008	Mark LT	5.4L	3V	4X4	✓	✓	✓	✓
2008	Mark LT	5.4L	3V	ABS	✓	✓	✓	✓
2008	Mark LT	5.4L	3V	DSM	✓	✓	✓	✓
2008	Mark LT	5.4L	3V	HVAC	✓	✓	✓	✓
2008	Mark LT	5.4L	3V	IC	✓	✓	✓	✓
2008	Mark LT	5.4L	3V	PAM	✓	✓	✓	✓
2008	Mark LT	5.4L	3V	PCM	✓	✓	✓	✓
2008	Mark LT	5.4L	3V	RCM	✓	✓	✓	✓
2008	Mark LT	5.4L	3V	RETM	✓	✓	✓	✓
2008	Mark LT	5.4L	3V	VSM	✓	✓	✓	✓
1996	Mark VIII	4.6L	4V	ABS/TCS	✓	✓	✓	✓
1996	Mark VIII	4.6L	4V	CPM	✓	✓	✓	✓
1996	Mark VIII	4.6L	4V	DDM	✓	✓	✓	✓
1996	Mark VIII	4.6L	4V	DSM	✓	✓	✓	✓
1996	Mark VIII	4.6L	4V	HEC	✓	✓	✓	✓
1996	Mark VIII	4.6L	4V	PCM	✓	✓	✓	✓
1996	Mark VIII	4.6L	4V	PSM	✓	✓	✓	✓
1996	Mark VIII	4.6L	4V	SCIL	✓	✓	✓	✓
1997	Mark VIII	4.6L	4V	ABS/TCS	✓	✓	✓	✓
1997	Mark VIII	4.6L	4V	CPM	✓	✓	✓	✓
1997	Mark VIII	4.6L	4V	DDM	✓	✓	✓	✓

1997	Mark VIII	4.6L	4V	DSM	√	√	√	√
1997	Mark VIII	4.6L	4V	EATC	√	√	√	
1997	Mark VIII	4.6L	4V	HEC	√	√	√	√
1997	Mark VIII	4.6L	4V	MC	√	√	√	√
1997	Mark VIII	4.6L	4V	PCM	√	√	√	√
1997	Mark VIII	4.6L	4V	PSM	√	√	√	√
1997	Mark VIII	4.6L	4V	SCIL	√	√	√	√
1998	Mark VIII	4.6L	4V	ABS/TCS	√	√	√	√
1998	Mark VIII	4.6L	4V	CPM	√	√	√	√
1998	Mark VIII	4.6L	4V	DDM	√	√	√	√
1998	Mark VIII	4.6L	4V	DSM	√	√	√	√
1998	Mark VIII	4.6L	4V	EATC	√	√	√	
1998	Mark VIII	4.6L	4V	HEC	√	√	√	√
1998	Mark VIII	4.6L	4V	MC	√	√	√	√
1998	Mark VIII	4.6L	4V	PCM	√	√	√	√
1998	Mark VIII	4.6L	4V	PSM	√	√	√	√
1998	Mark VIII	4.6L	4V	SCIL	√	√	√	√
2006	Milan	2.3L	DURATEC-HE / I4	ABS	√	√	√	√
2006	Milan	2.3L	DURATEC-HE / I4	ABS	√	√	√	√
2006	Milan	2.3L	DURATEC-HE / I4	ACM	√	√	√	√
2006	Milan	2.3L	DURATEC-HE / I4	ACM	√	√	√	√
2006	Milan	2.3L	DURATEC-HE / I4	EATC	√	√	√	√
2006	Milan	2.3L	DURATEC-HE / I4	GEM	√	√	√	√
2006	Milan	2.3L	DURATEC-HE / I4	GEM	√	√	√	√
2006	Milan	2.3L	DURATEC-HE / I4	IC	√	√	√	√
2006	Milan	2.3L	DURATEC-HE / I4	OCSM	√	√	√	√
2006	Milan	2.3L	DURATEC-HE / I4	OCSM	√	√	√	√
2006	Milan	2.3L	DURATEC-HE / I4	OCSM	√	√	√	√
2006	Milan	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2006	Milan	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2006	Milan	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2006	Milan	2.3L	DURATEC-HE / I4	RCM	√	√	√	√
2006	Milan	2.3L	DURATEC-HE / I4	RCM	√	√	√	√
2006	Milan	2.3L	DURATEC-HE / I4	TCM	√	√	√	√
2006	Milan	3.0L	4V	ABS	√	√	√	√
2006	Milan	3.0L	4V	ABS	√	√	√	√
2006	Milan	3.0L	4V	ACM	√	√	√	√
2006	Milan	3.0L	4V	ACM	√	√	√	√
2006	Milan	3.0L	4V	EATC	√	√	√	√
2006	Milan	3.0L	4V	GEM	√	√	√	√
2006	Milan	3.0L	4V	IC	√	√	√	√
2006	Milan	3.0L	4V	OCSM	√	√	√	√
2006	Milan	3.0L	4V	OCSM	√	√	√	√
2006	Milan	3.0L	4V	PCM	√	√	√	√
2006	Milan	3.0L	4V	PCM	√	√	√	√

2006	Milan	3.0L	4V	TCM	✓	✓	✓	✓
2007	Milan	2.3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓
2007	Milan	2.3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓
2007	Milan	2.3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓
2007	Milan	2.3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓
2007	Milan	2.3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓
2007	Milan	2.3L	DURATEC-HE / I4	EATC	✓	✓	✓	✓
2007	Milan	2.3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓
2007	Milan	2.3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓
2007	Milan	2.3L	DURATEC-HE / I4	IC	✓	✓	✓	✓
2007	Milan	2.3L	DURATEC-HE / I4	IC	✓	✓	✓	✓
2007	Milan	2.3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓
2007	Milan	2.3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓
2007	Milan	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓
2007	Milan	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓
2007	Milan	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓
2007	Milan	2.3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓
2007	Milan	2.3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓
2007	Milan	2.3L	DURATEC-HE / I4	SDARS	✓	✓	✓	✓
2007	Milan	2.3L	DURATEC-HE / I4	SDARS	✓	✓	✓	✓
2007	Milan	2.3L	DURATEC-HE / I4	TCM	✓	✓	✓	✓
2007	Milan	3.0L	4V	4X4	✓	✓	✓	✓
2007	Milan	3.0L	4V	ABS	✓	✓	✓	✓
2007	Milan	3.0L	4V	ABS	✓	✓	✓	✓
2007	Milan	3.0L	4V	ACM	✓	✓	✓	✓
2007	Milan	3.0L	4V	ACM	✓	✓	✓	✓
2007	Milan	3.0L	4V	EATC	✓	✓	✓	✓
2007	Milan	3.0L	4V	GEM	✓	✓	✓	✓
2007	Milan	3.0L	4V	IC	✓	✓	✓	✓
2007	Milan	3.0L	4V	IC	✓	✓	✓	✓
2007	Milan	3.0L	4V	OCSM	✓	✓	✓	✓
2007	Milan	3.0L	4V	OCSM	✓	✓	✓	✓
2007	Milan	3.0L	4V	PCM	✓	✓	✓	✓
2007	Milan	3.0L	4V	PCM	✓	✓	✓	✓
2007	Milan	3.0L	4V	RCM	✓	✓	✓	✓
2007	Milan	3.0L	4V	RCM	✓	✓	✓	✓
2007	Milan	3.0L	4V	SDARS	✓	✓	✓	✓
2007	Milan	3.0L	4V	SDARS	✓	✓	✓	✓
2007	Milan	3.0L	4V	TCM	✓	✓	✓	✓
2008	Milan	2.3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓
2008	Milan	2.3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓
2008	Milan	2.3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓
2008	Milan	2.3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓
2008	Milan	2.3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓
2008	Milan	2.3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓

2008	Milan	2.3L	DURATEC-HE / I4	APIM	√	√	√	√
2008	Milan	2.3L	DURATEC-HE / I4	APIM	√	√	√	√
2008	Milan	2.3L	DURATEC-HE / I4	GEM / SJB	√	√	√	√
2008	Milan	2.3L	DURATEC-HE / I4	GEM / SJB	√	√	√	√
2008	Milan	2.3L	DURATEC-HE / I4	GEM / SJB	√	√	√	√
2008	Milan	2.3L	DURATEC-HE / I4	HVAC	√	√	√	√
2008	Milan	2.3L	DURATEC-HE / I4	IC	√	√	√	√
2008	Milan	2.3L	DURATEC-HE / I4	IC	√	√	√	√
2008	Milan	2.3L	DURATEC-HE / I4	OCSM	√	√	√	√
2008	Milan	2.3L	DURATEC-HE / I4	OCSM	√	√	√	√
2008	Milan	2.3L	DURATEC-HE / I4	OCSM	√	√	√	√
2008	Milan	2.3L	DURATEC-HE / I4	PAM	√	√	√	√
2008	Milan	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2008	Milan	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2008	Milan	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2008	Milan	2.3L	DURATEC-HE / I4	RCM	√	√	√	√
2008	Milan	2.3L	DURATEC-HE / I4	RCM	√	√	√	√
2008	Milan	2.3L	DURATEC-HE / I4	SDARS	√	√	√	√
2008	Milan	2.3L	DURATEC-HE / I4	TCM	√	√	√	√
2008	Milan	3.0L	4V	4X4	√	√	√	√
2008	Milan	3.0L	4V	ABS	√	√	√	√
2008	Milan	3.0L	4V	ABS	√	√	√	√
2008	Milan	3.0L	4V	ACM	√	√	√	√
2008	Milan	3.0L	4V	ACM	√	√	√	√
2008	Milan	3.0L	4V	APIM	√	√	√	√
2008	Milan	3.0L	4V	APIM	√	√	√	√
2008	Milan	3.0L	4V	GEM / SJB	√	√	√	√
2008	Milan	3.0L	4V	GEM / SJB	√	√	√	√
2008	Milan	3.0L	4V	HVAC	√	√	√	√
2008	Milan	3.0L	4V	IC	√	√	√	√
2008	Milan	3.0L	4V	OCSM	√	√	√	√
2008	Milan	3.0L	4V	OCSM	√	√	√	√
2008	Milan	3.0L	4V	PAM	√	√	√	√
2008	Milan	3.0L	4V	PCM	√	√	√	√
2008	Milan	3.0L	4V	PCM	√	√	√	√
2008	Milan	3.0L	4V	RCM	√	√	√	√
2008	Milan	3.0L	4V	SDARS	√	√	√	√
2008	Milan	3.0L	4V	TCM	√	√	√	√
2009	Milan	2.3L	DURATEC-HE / I4	4X4	√	√	√	√
2009	Milan	2.3L	DURATEC-HE / I4	ABS	√	√	√	√
2009	Milan	2.3L	DURATEC-HE / I4	ACM	√	√	√	√
2009	Milan	2.3L	DURATEC-HE / I4	ACM	√	√	√	√
2009	Milan	2.3L	DURATEC-HE / I4	APIM	√	√	√	√
2009	Milan	2.3L	DURATEC-HE / I4	APIM	√	√	√	√
2009	Milan	2.3L	DURATEC-HE / I4	GEM / SJB	√	√	√	√

2009	Milan	2.3L	DURATEC-HE / I4	GEM / SJB	√	√	√	√
2009	Milan	2.3L	DURATEC-HE / I4	HVAC	√	√	√	√
2009	Milan	2.3L	DURATEC-HE / I4	IC	√	√	√	√
2009	Milan	2.3L	DURATEC-HE / I4	IC	√	√	√	√
2009	Milan	2.3L	DURATEC-HE / I4	OCSM	√	√	√	√
2009	Milan	2.3L	DURATEC-HE / I4	OCSM	√	√	√	√
2009	Milan	2.3L	DURATEC-HE / I4	PAM	√	√	√	√
2009	Milan	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2009	Milan	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2009	Milan	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2009	Milan	2.3L	DURATEC-HE / I4	RCM	√	√	√	√
2009	Milan	2.3L	DURATEC-HE / I4	RCM	√	√	√	√
2009	Milan	2.3L	DURATEC-HE / I4	SDARS	√	√	√	√
2009	Milan	2.3L	DURATEC-HE / I4	SDARS	√	√	√	√
2009	Milan	2.3L	DURATEC-HE / I4	TCM	√	√	√	√
2009	Milan	3.0L	4V	4X4	√	√	√	√
2009	Milan	3.0L	4V	ABS	√	√	√	√
2009	Milan	3.0L	4V	ABS	√	√	√	√
2009	Milan	3.0L	4V	ACM	√	√	√	√
2009	Milan	3.0L	4V	ACM	√	√	√	√
2009	Milan	3.0L	4V	APIM	√	√	√	√
2009	Milan	3.0L	4V	APIM	√	√	√	√
2009	Milan	3.0L	4V	GEM / SJB	√	√	√	√
2009	Milan	3.0L	4V	GEM / SJB	√	√	√	√
2009	Milan	3.0L	4V	HVAC	√	√	√	√
2009	Milan	3.0L	4V	IC	√	√	√	√
2009	Milan	3.0L	4V	OCSM	√	√	√	√
2009	Milan	3.0L	4V	OCSM	√	√	√	√
2009	Milan	3.0L	4V	PAM	√	√	√	√
2009	Milan	3.0L	4V	PCM	√	√	√	√
2009	Milan	3.0L	4V	PCM	√	√	√	√
2009	Milan	3.0L	4V	RCM	√	√	√	√
2009	Milan	3.0L	4V	SDARS	√	√	√	√
2009	Milan	3.0L	4V	TCM	√	√	√	√
2010	Milan	2.5L	DURATEC-HE / I4	4X4	√	√	√	√
2010	Milan	2.5L	DURATEC-HE / I4	ABS	√	√	√	√
2010	Milan	2.5L	DURATEC-HE / I4	ABS	√	√	√	√
2010	Milan	2.5L	DURATEC-HE / I4	ACM	√	√	√	√
2010	Milan	2.5L	DURATEC-HE / I4	ACM	√	√	√	√
2010	Milan	2.5L	DURATEC-HE / I4	APIM	√	√	√	√
2010	Milan	2.5L	DURATEC-HE / I4	DSP	√	√	√	
2010	Milan	2.5L	DURATEC-HE / I4	DSP	√	√	√	
2010	Milan	2.5L	DURATEC-HE / I4	FCIM	√	√	√	
2010	Milan	2.5L	DURATEC-HE / I4	FCIM	√	√	√	√
2010	Milan	2.5L	DURATEC-HE / I4	FDIM	√	√	√	√

2010	Milan	2.5L	DURATEC-HE / I4	FDIM	✓	✓	✓	✓
2010	Milan	2.5L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓
2010	Milan	2.5L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓
2010	Milan	2.5L	DURATEC-HE / I4	GPSM	✓	✓	✓	✓
2010	Milan	2.5L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓
2010	Milan	2.5L	DURATEC-HE / I4	IPC	✓	✓	✓	✓
2010	Milan	2.5L	DURATEC-HE / I4	IPC	✓	✓	✓	✓
2010	Milan	2.5L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓
2010	Milan	2.5L	DURATEC-HE / I4	PAM	✓	✓	✓	✓
2010	Milan	2.5L	DURATEC-HE / I4	PAM	✓	✓	✓	✓
2010	Milan	2.5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓
2010	Milan	2.5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓
2010	Milan	2.5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓
2010	Milan	2.5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓
2010	Milan	2.5L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓
2010	Milan	2.5L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓
2010	Milan	2.5L	DURATEC-HE / I4	RCM	✓	✓	✓	✓
2010	Milan	2.5L	DURATEC-HE / I4	RCM	✓	✓	✓	✓
2010	Milan	2.5L	DURATEC-HE / I4	SOD-L	✓	✓	✓	✓
2010	Milan	2.5L	DURATEC-HE / I4	SOD-R	✓	✓	✓	✓
2010	Milan	2.5L	HEV / ATKINSON 4V	4X4	✓	✓	✓	✓
2010	Milan	2.5L	HEV / ATKINSON 4V	ABS	✓	✓	✓	✓
2010	Milan	2.5L	HEV / ATKINSON 4V	ACCM#2	✓	✓	✓	✓
2010	Milan	2.5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓
2010	Milan	2.5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓
2010	Milan	2.5L	HEV / ATKINSON 4V	APIM	✓	✓	✓	✓
2010	Milan	2.5L	HEV / ATKINSON 4V	BECM	✓	✓	✓	✓
2010	Milan	2.5L	HEV / ATKINSON 4V	DCDC	✓	✓	✓	✓
2010	Milan	2.5L	HEV / ATKINSON 4V	DSP	✓	✓	✓	
2010	Milan	2.5L	HEV / ATKINSON 4V	DSP	✓	✓	✓	
2010	Milan	2.5L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	
2010	Milan	2.5L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	✓
2010	Milan	2.5L	HEV / ATKINSON 4V	FDIM	✓	✓	✓	✓
2010	Milan	2.5L	HEV / ATKINSON 4V	FDIM	✓	✓	✓	✓
2010	Milan	2.5L	HEV / ATKINSON 4V	GEM / SJB	✓	✓	✓	✓
2010	Milan	2.5L	HEV / ATKINSON 4V	HVAC	✓	✓	✓	✓
2010	Milan	2.5L	HEV / ATKINSON 4V	IPC	✓	✓	✓	✓
2010	Milan	2.5L	HEV / ATKINSON 4V	OCSM	✓	✓	✓	✓
2010	Milan	2.5L	HEV / ATKINSON 4V	PAM	✓	✓	✓	✓
2010	Milan	2.5L	HEV / ATKINSON 4V	PAM	✓	✓	✓	✓
2010	Milan	2.5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓
2010	Milan	2.5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓
2010	Milan	2.5L	HEV / ATKINSON 4V	PSCM	✓	✓	✓	✓
2010	Milan	2.5L	HEV / ATKINSON 4V	PSCM	✓	✓	✓	✓
2010	Milan	2.5L	HEV / ATKINSON 4V	RCM	✓	✓	✓	✓
2010	Milan	2.5L	HEV / ATKINSON 4V	RCM	✓	✓	✓	✓

2010	Milan	2.5L	HEV / ATKINSON 4V	SOD-L	√	√	√	√
2010	Milan	2.5L	HEV / ATKINSON 4V	SOD-R	√	√	√	√
2010	Milan	2.5L	HEV / ATKINSON 4V	TCM	√	√	√	√
2010	Milan	3.0L	4V	4X4	√	√	√	√
2010	Milan	3.0L	4V	ABS	√	√	√	√
2010	Milan	3.0L	4V	ACM	√	√	√	√
2010	Milan	3.0L	4V	APIM	√	√	√	√
2010	Milan	3.0L	4V	DSP	√	√	√	
2010	Milan	3.0L	4V	FCIM	√	√	√	
2010	Milan	3.0L	4V	FCIM	√	√	√	√
2010	Milan	3.0L	4V	FDIM	√	√	√	√
2010	Milan	3.0L	4V	GEM / SJB	√	√	√	√
2010	Milan	3.0L	4V	GPSM	√	√	√	√
2010	Milan	3.0L	4V	HVAC	√	√	√	√
2010	Milan	3.0L	4V	IPC	√	√	√	√
2010	Milan	3.0L	4V	OCSM	√	√	√	√
2010	Milan	3.0L	4V	PAM	√	√	√	√
2010	Milan	3.0L	4V	PCM	√	√	√	√
2010	Milan	3.0L	4V	PSCM	√	√	√	√
2010	Milan	3.0L	4V	RCM	√	√	√	√
2010	Milan	3.0L	4V	SOD-L	√	√	√	√
2010	Milan	3.0L	4V	SOD-R	√	√	√	√
2011	Milan	2.5L	DURATEC-HE / I4	4X4	√	√	√	√
2011	Milan	2.5L	DURATEC-HE / I4	ABS	√	√	√	√
2011	Milan	2.5L	DURATEC-HE / I4	ACM	√	√	√	√
2011	Milan	2.5L	DURATEC-HE / I4	APIM	√	√	√	√
2011	Milan	2.5L	DURATEC-HE / I4	DSP	√	√	√	
2011	Milan	2.5L	DURATEC-HE / I4	FCIM	√	√	√	
2011	Milan	2.5L	DURATEC-HE / I4	FCIM	√	√	√	√
2011	Milan	2.5L	DURATEC-HE / I4	FDIM	√	√	√	√
2011	Milan	2.5L	DURATEC-HE / I4	GEM / SJB	√	√	√	√
2011	Milan	2.5L	DURATEC-HE / I4	GPSM	√	√	√	√
2011	Milan	2.5L	DURATEC-HE / I4	HVAC	√	√	√	√
2011	Milan	2.5L	DURATEC-HE / I4	IPC	√	√	√	√
2011	Milan	2.5L	DURATEC-HE / I4	OCSM	√	√	√	√
2011	Milan	2.5L	DURATEC-HE / I4	PAM	√	√	√	√
2011	Milan	2.5L	DURATEC-HE / I4	PCM	√	√	√	√
2011	Milan	2.5L	DURATEC-HE / I4	PCM	√	√	√	√
2011	Milan	2.5L	DURATEC-HE / I4	PCM	√	√	√	√
2011	Milan	2.5L	DURATEC-HE / I4	PSCM	√	√	√	√
2011	Milan	2.5L	DURATEC-HE / I4	RCM	√	√	√	√
2011	Milan	2.5L	DURATEC-HE / I4	SOD-L	√	√	√	√
2011	Milan	2.5L	DURATEC-HE / I4	SOD-R	√	√	√	√
2011	Milan	2.5L	HEV / ATKINSON 4V	4X4	√	√	√	√
2011	Milan	2.5L	HEV / ATKINSON 4V	ABS	√	√	√	√



2011	Milan	2.5L	HEV / ATKINSON 4V	ACCM#2	✓	✓	✓	✓
2011	Milan	2.5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓
2011	Milan	2.5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓
2011	Milan	2.5L	HEV / ATKINSON 4V	APIM	✓	✓	✓	✓
2011	Milan	2.5L	HEV / ATKINSON 4V	BECM	✓	✓	✓	✓
2011	Milan	2.5L	HEV / ATKINSON 4V	DCDC	✓	✓	✓	✓
2011	Milan	2.5L	HEV / ATKINSON 4V	DSP	✓	✓	✓	
2011	Milan	2.5L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	
2011	Milan	2.5L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	✓
2011	Milan	2.5L	HEV / ATKINSON 4V	FDIM	✓	✓	✓	✓
2011	Milan	2.5L	HEV / ATKINSON 4V	GEM / SJB	✓	✓	✓	✓
2011	Milan	2.5L	HEV / ATKINSON 4V	GPSM	✓	✓	✓	✓
2011	Milan	2.5L	HEV / ATKINSON 4V	HVAC	✓	✓	✓	✓
2011	Milan	2.5L	HEV / ATKINSON 4V	IPC	✓	✓	✓	✓
2011	Milan	2.5L	HEV / ATKINSON 4V	OCSM	✓	✓	✓	✓
2011	Milan	2.5L	HEV / ATKINSON 4V	PAM	✓	✓	✓	✓
2011	Milan	2.5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓
2011	Milan	2.5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓
2011	Milan	2.5L	HEV / ATKINSON 4V	PSCM	✓	✓	✓	✓
2011	Milan	2.5L	HEV / ATKINSON 4V	RCM	✓	✓	✓	✓
2011	Milan	2.5L	HEV / ATKINSON 4V	SOD-L	✓	✓	✓	✓
2011	Milan	2.5L	HEV / ATKINSON 4V	SOD-R	✓	✓	✓	✓
2011	Milan	2.5L	HEV / ATKINSON 4V	TCM	✓	✓	✓	✓
2011	Milan	3.0L	4V	4X4	✓	✓	✓	✓
2011	Milan	3.0L	4V	ABS	✓	✓	✓	✓
2011	Milan	3.0L	4V	ACM	✓	✓	✓	✓
2011	Milan	3.0L	4V	APIM	✓	✓	✓	✓
2011	Milan	3.0L	4V	DSP	✓	✓	✓	
2011	Milan	3.0L	4V	FCIM	✓	✓	✓	
2011	Milan	3.0L	4V	FCIM	✓	✓	✓	✓
2011	Milan	3.0L	4V	FDIM	✓	✓	✓	✓
2011	Milan	3.0L	4V	GEM / SJB	✓	✓	✓	✓
2011	Milan	3.0L	4V	HVAC	✓	✓	✓	✓
2011	Milan	3.0L	4V	IPC	✓	✓	✓	✓
2011	Milan	3.0L	4V	OCSM	✓	✓	✓	✓
2011	Milan	3.0L	4V	PAM	✓	✓	✓	✓
2011	Milan	3.0L	4V	PCM	✓	✓	✓	✓
2011	Milan	3.0L	4V	PSCM	✓	✓	✓	✓
2011	Milan	3.0L	4V	RCM	✓	✓	✓	✓
2011	Milan	3.0L	4V	SOD-L	✓	✓	✓	✓
2011	Milan	3.0L	4V	SOD-R	✓	✓	✓	✓
1993.5	Mondeo	1.6L	Zetec	ABS	✓	✓	✓	✓
1993.5	Mondeo	1.6L	Zetec	CSM	✓	✓	✓	✓
1993.5	Mondeo	1.6L	Zetec	PATS			✓	✓
1993.5	Mondeo	1.6L	Zetec	PATS	✓	✓	✓	✓

1993.5	Mondeo	1.8L	Zetec	ABS	✓	✓	✓	✓
1993.5	Mondeo	1.8L	Zetec	CSM	✓	✓	✓	✓
1993.5	Mondeo	1.8L	Zetec	PATS			✓	✓
1993.5	Mondeo	1.8L	Zetec	PATS	✓	✓	✓	✓
1993.5	Mondeo	2.0L	Zetec	ABS	✓	✓	✓	✓
1993.5	Mondeo	2.0L	Zetec	CSM	✓	✓	✓	✓
1993.5	Mondeo	2.0L	Zetec	PATS			✓	✓
1993.5	Mondeo	2.0L	Zetec	PATS	✓	✓	✓	✓
1993.75	Mondeo	1.8L	Zetec	ABS	✓	✓	✓	✓
1993.75	Mondeo	1.8L	Zetec	CSM	✓	✓	✓	✓
1993.75	Mondeo	1.8L	Zetec	PATS			✓	✓
1993.75	Mondeo	1.8L	Zetec	PATS	✓	✓	✓	✓
1993.75	Mondeo	2.0L	Zetec	ABS	✓	✓	✓	✓
1993.75	Mondeo	2.0L	Zetec	CSM	✓	✓	✓	✓
1993.75	Mondeo	2.0L	Zetec	PATS			✓	✓
1993.75	Mondeo	2.0L	Zetec	PATS	✓	✓	✓	✓
1994.5	Mondeo	1.8L	Zetec	ABS	✓	✓	✓	✓
1994.5	Mondeo	1.8L	Zetec	CSM	✓	✓	✓	✓
1994.5	Mondeo	1.8L	Zetec	PATS			✓	✓
1994.5	Mondeo	1.8L	Zetec	PATS	✓	✓	✓	✓
1994.75	Mondeo	2.5L	Duratec-VE	ABS	✓	✓	✓	✓
1994.75	Mondeo	2.5L	Duratec-VE	CSM	✓	✓	✓	✓
1994.75	Mondeo	2.5L	Duratec-VE	PATS			✓	✓
1994.75	Mondeo	2.5L	Duratec-VE	PATS	✓	✓	✓	✓
1995	Mondeo	1.6L	Zetec	ABS			✓	✓
1995	Mondeo	1.6L	Zetec	CSM	✓	✓	✓	✓
1995	Mondeo	1.6L	Zetec	PATS			✓	✓
1995	Mondeo	1.6L	Zetec	PATS	✓	✓	✓	✓
1995	Mondeo	1.8L	Zetec	ABS			✓	✓
1995	Mondeo	1.8L	Zetec	CSM	✓	✓	✓	✓
1995	Mondeo	1.8L	Zetec	PATS			✓	✓
1995	Mondeo	1.8L	Zetec	PATS	✓	✓	✓	✓
1995	Mondeo	2.0L	Zetec	ABS			✓	✓
1995	Mondeo	2.0L	Zetec	CSM	✓	✓	✓	✓
1995	Mondeo	2.0L	Zetec	PATS			✓	✓
1995	Mondeo	2.0L	Zetec	PATS	✓	✓	✓	✓
1995	Mondeo	2.5L	Duratec-VE	ABS			✓	✓
1995	Mondeo	2.5L	Duratec-VE	CSM	✓	✓	✓	✓
1995	Mondeo	2.5L	Duratec-VE	PATS			✓	✓
1995	Mondeo	2.5L	Duratec-VE	PATS	✓	✓	✓	✓
1996	Mondeo	1.8L	Zetec	ABS			✓	✓
1996	Mondeo	1.8L	Zetec	CSM	✓	✓	✓	✓
1996	Mondeo	1.8L	Zetec	PATS			✓	✓
1996	Mondeo	1.8L	Zetec	PATS	✓	✓	✓	✓
1996	Mondeo	2.0L	Zetec	ABS			✓	✓

1996	Mondeo	2.0L	Zetec	CSM	√	√	√	√
1996	Mondeo	2.0L	Zetec	PATS			√	√
1996	Mondeo	2.0L	Zetec	PATS	√	√	√	√
1996	Mondeo	2.5L	Duratec-VE	ABS			√	√
1996	Mondeo	2.5L	Duratec-VE	CSM	√	√	√	√
1996	Mondeo	2.5L	Duratec-VE	PATS			√	√
1996	Mondeo	2.5L	Duratec-VE	PATS	√	√	√	√
1997	Mondeo	1.6L	Zetec	ABS	√	√	√	√
1997	Mondeo	1.6L	Zetec	CSM	√	√	√	√
1997	Mondeo	1.6L	Zetec	FFH	√	√	√	√
1997	Mondeo	1.6L	Zetec	PATS			√	√
1997	Mondeo	1.6L	Zetec	PATS	√	√	√	√
1997	Mondeo	1.6L	Zetec	PCM	√	√	√	√
1997	Mondeo	1.8L	Endura-DE	ABS	√	√	√	√
1997	Mondeo	1.8L	Endura-DE	CSM	√	√	√	√
1997	Mondeo	1.8L	Endura-DE	FFH	√	√	√	√
1997	Mondeo	1.8L	Endura-DE	PATS	√	√	√	√
1997	Mondeo	1.8L	Endura-DE	PCM			√	√
1997	Mondeo	1.8L	Zetec	ABS	√	√	√	√
1997	Mondeo	1.8L	Zetec	CSM	√	√	√	√
1997	Mondeo	1.8L	Zetec	FFH	√	√	√	√
1997	Mondeo	1.8L	Zetec	PATS			√	√
1997	Mondeo	1.8L	Zetec	PATS	√	√	√	√
1997	Mondeo	1.8L	Zetec	PCM	√	√	√	√
1997	Mondeo	1.8L	Zetec	PCM	√	√	√	√
1997	Mondeo	2.0L	Zetec	ABS	√	√	√	√
1997	Mondeo	2.0L	Zetec	CSM	√	√	√	√
1997	Mondeo	2.0L	Zetec	FFH	√	√	√	√
1997	Mondeo	2.0L	Zetec	PATS			√	√
1997	Mondeo	2.0L	Zetec	PATS	√	√	√	√
1997	Mondeo	2.0L	Zetec	PCM	√	√	√	√
1997	Mondeo	2.5L	Duratec-VE	ABS	√	√	√	√
1997	Mondeo	2.5L	Duratec-VE	CSM	√	√	√	√
1997	Mondeo	2.5L	Duratec-VE	FFH	√	√	√	√
1997	Mondeo	2.5L	Duratec-VE	PATS			√	√
1997	Mondeo	2.5L	Duratec-VE	PATS	√	√	√	√
1997	Mondeo	2.5L	Duratec-VE	PCM	√	√	√	√
1997	Mondeo	2.5L	Duratec-VE	PCM	√	√	√	√
1997	Mondeo	2.5L	Duratec-VE	PCM	√	√	√	√
1997	Mondeo	2.5L	Duratec-VE	PCM	√	√	√	√
1998	Mondeo	1.8L	Zetec	ABS	√	√	√	√
1998	Mondeo	1.8L	Zetec	ABS/TCS	√	√	√	√
1998	Mondeo	1.8L	Zetec	CSM	√	√	√	√
1998	Mondeo	1.8L	Zetec	FFH	√	√	√	√
1998	Mondeo	1.8L	Zetec	PATS	√	√	√	√
1998	Mondeo	1.8L	Zetec	PCM	√	√	√	√

1998	Mondeo	2.0L	Zetec	ABS	✓	✓	✓	✓
1998	Mondeo	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓
1998	Mondeo	2.0L	Zetec	CSM	✓	✓	✓	✓
1998	Mondeo	2.0L	Zetec	FFH	✓	✓	✓	✓
1998	Mondeo	2.0L	Zetec	PATS	✓	✓	✓	✓
1998	Mondeo	2.0L	Zetec	PCM	✓	✓	✓	✓
1998	Mondeo	2.0L	Zetec	PCM	✓	✓	✓	✓
1998	Mondeo	2.5L	Duratec-VE	ABS	✓	✓	✓	✓
1998	Mondeo	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓
1998	Mondeo	2.5L	Duratec-VE	CSM	✓	✓	✓	✓
1998	Mondeo	2.5L	Duratec-VE	FFH	✓	✓	✓	✓
1998	Mondeo	2.5L	Duratec-VE	PATS	✓	✓	✓	✓
1998	Mondeo	2.5L	Duratec-VE	PCM	✓	✓	✓	✓
1998	Mondeo	2.5L	Duratec-VE	PCM	✓	✓	✓	✓
1998.5	Mondeo	1.8L	Zetec	ABS	✓	✓	✓	✓
1998.5	Mondeo	1.8L	Zetec	ABS/TCS	✓	✓	✓	✓
1998.5	Mondeo	1.8L	Zetec	CSM	✓	✓	✓	✓
1998.5	Mondeo	1.8L	Zetec	FFH	✓	✓	✓	✓
1998.5	Mondeo	1.8L	Zetec	PATS	✓	✓	✓	✓
1998.5	Mondeo	1.8L	Zetec	PCM	✓	✓	✓	✓
1998.5	Mondeo	2.0L	Zetec	ABS	✓	✓	✓	✓
1998.5	Mondeo	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓
1998.5	Mondeo	2.0L	Zetec	CSM	✓	✓	✓	✓
1998.5	Mondeo	2.0L	Zetec	FFH	✓	✓	✓	✓
1998.5	Mondeo	2.0L	Zetec	PATS	✓	✓	✓	✓
1998.5	Mondeo	2.0L	Zetec	PCM	✓	✓	✓	✓
1998.5	Mondeo	2.5L	Duratec-VE	ABS	✓	✓	✓	✓
1998.5	Mondeo	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓
1998.5	Mondeo	2.5L	Duratec-VE	CSM	✓	✓	✓	✓
1998.5	Mondeo	2.5L	Duratec-VE	FFH	✓	✓	✓	✓
1998.5	Mondeo	2.5L	Duratec-VE	PATS	✓	✓	✓	✓
1998.5	Mondeo	2.5L	Duratec-VE	PCM	✓	✓	✓	✓
1998.5	Mondeo	2.5L	Duratec-VE	PCM	✓	✓	✓	✓
1998.75	Mondeo	1.6L	Zetec	ABS	✓	✓	✓	✓
1998.75	Mondeo	1.6L	Zetec	ABS/TCS	✓	✓	✓	✓
1998.75	Mondeo	1.6L	Zetec	CSM	✓	✓	✓	✓
1998.75	Mondeo	1.6L	Zetec	FFH	✓	✓	✓	✓
1998.75	Mondeo	1.6L	Zetec	PATS	✓	✓	✓	✓
1998.75	Mondeo	1.6L	Zetec	PCM	✓	✓	✓	✓
1998.75	Mondeo	1.8L	Zetec	ABS	✓	✓	✓	✓
1998.75	Mondeo	1.8L	Zetec	ABS/TCS	✓	✓	✓	✓
1998.75	Mondeo	1.8L	Zetec	CSM	✓	✓	✓	✓
1998.75	Mondeo	1.8L	Zetec	FFH	✓	✓	✓	✓
1998.75	Mondeo	1.8L	Zetec	PATS	✓	✓	✓	✓
1998.75	Mondeo	1.8L	Zetec	PCM	✓	✓	✓	✓

1998.75	Mondeo	2.0L	Zetec	ABS	✓	✓	✓	
1998.75	Mondeo	2.0L	Zetec	ABS	✓	✓	✓	✓
1998.75	Mondeo	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓
1998.75	Mondeo	2.0L	Zetec	CSM	✓	✓	✓	✓
1998.75	Mondeo	2.0L	Zetec	FFH	✓	✓	✓	✓
1998.75	Mondeo	2.0L	Zetec	PATS	✓	✓	✓	✓
1998.75	Mondeo	2.0L	Zetec	PCM	✓	✓	✓	✓
1998.75	Mondeo	2.0L	Zetec	PCM	✓	✓	✓	✓
1998.75	Mondeo	2.0L	Zetec	PCM	✓	✓	✓	✓
1999	Mondeo	1.6L	Zetec	ABS	✓	✓	✓	
1999	Mondeo	1.6L	Zetec	ABS/TCS	✓	✓	✓	✓
1999	Mondeo	1.6L	Zetec	CSM	✓	✓	✓	✓
1999	Mondeo	1.6L	Zetec	FFH	✓	✓	✓	✓
1999	Mondeo	1.6L	Zetec	PATS	✓	✓	✓	✓
1999	Mondeo	1.6L	Zetec	PCM	✓	✓	✓	✓
1999	Mondeo	1.8L	Zetec	ABS	✓	✓	✓	✓
1999	Mondeo	1.8L	Zetec	ABS/TCS	✓	✓	✓	✓
1999	Mondeo	1.8L	Zetec	CSM	✓	✓	✓	✓
1999	Mondeo	1.8L	Zetec	FFH	✓	✓	✓	✓
1999	Mondeo	1.8L	Zetec	PATS	✓	✓	✓	✓
1999	Mondeo	1.8L	Zetec	PCM	✓	✓	✓	✓
1999	Mondeo	2.0L	Zetec	ABS	✓	✓	✓	✓
1999	Mondeo	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓
1999	Mondeo	2.0L	Zetec	CSM	✓	✓	✓	✓
1999	Mondeo	2.0L	Zetec	FFH	✓	✓	✓	✓
1999	Mondeo	2.0L	Zetec	PATS	✓	✓	✓	✓
1999	Mondeo	2.0L	Zetec	PCM	✓	✓	✓	✓
1999	Mondeo	2.0L	Zetec	PCM	✓	✓	✓	✓
1999	Mondeo	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓
1999	Mondeo	2.5L	Duratec-VE	CSM	✓	✓	✓	✓
1999	Mondeo	2.5L	Duratec-VE	FFH	✓	✓	✓	✓
1999	Mondeo	2.5L	Duratec-VE	PATS	✓	✓	✓	✓
1999	Mondeo	2.5L	Duratec-VE	PCM	✓	✓	✓	✓
1999	Mondeo	2.5L	Duratec-VE	PCM	✓	✓	✓	✓
1999.75	Mondeo	2.5L	Duratec-VE	ABS	✓	✓	✓	✓
1999.75	Mondeo	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓
1999.75	Mondeo	2.5L	Duratec-VE	CSM	✓	✓	✓	✓
1999.75	Mondeo	2.5L	Duratec-VE	FFH	✓	✓	✓	✓
1999.75	Mondeo	2.5L	Duratec-VE	PATS	✓	✓	✓	
1999.75	Mondeo	2.5L	Duratec-VE	PATS	✓	✓	✓	✓
1999.75	Mondeo	2.5L	Duratec-VE	PCM	✓	✓	✓	✓
2000.25	Mondeo	1.8L	Zetec	ABS	✓	✓	✓	✓
2000.25	Mondeo	1.8L	Zetec	ABS/TCS	✓	✓	✓	
2000.25	Mondeo	1.8L	Zetec	AFCM	✓	✓	✓	
2000.25	Mondeo	1.8L	Zetec	CSM	✓	✓	✓	

2000.25	Mondeo	1.8L	Zetec	PATS	√	√	√	
2000.25	Mondeo	1.8L	Zetec	PCM	√	√	√	√
2000.5	Mondeo	2.0L	Zetec	ABS	√	√	√	√
2000.5	Mondeo	2.0L	Zetec	ABS/TCS	√	√	√	
2000.5	Mondeo	2.0L	Zetec	CSM	√	√	√	√
2000.5	Mondeo	2.0L	Zetec	PATS	√	√	√	
2000.5	Mondeo	2.0L	Zetec	PCM	√	√	√	√
2000.5	Mondeo	2.5L	Duratec-VE	ABS	√	√	√	√
2000.5	Mondeo	2.5L	Duratec-VE	ABS/TCS	√	√	√	
2000.5	Mondeo	2.5L	Duratec-VE	CSM	√	√	√	√
2000.5	Mondeo	2.5L	Duratec-VE	PATS	√	√	√	
2000.5	Mondeo	2.5L	Duratec-VE	PATS	√	√	√	√
2000.5	Mondeo	2.5L	Duratec-VE	PCM	√	√	√	√
2001	Mondeo	1.8L	DURATEC-HE / I4	ABS	√	√	√	√
2001	Mondeo	1.8L	DURATEC-HE / I4	ABS/TCS	√	√	√	√
2001	Mondeo	1.8L	DURATEC-HE / I4	ACM	√	√	√	√
2001	Mondeo	1.8L	DURATEC-HE / I4	CDP	√	√	√	√
2001	Mondeo	1.8L	DURATEC-HE / I4	CSM	√	√	√	√
2001	Mondeo	1.8L	DURATEC-HE / I4	EATC	√	√	√	√
2001	Mondeo	1.8L	DURATEC-HE / I4	EATC	√	√	√	√
2001	Mondeo	1.8L	DURATEC-HE / I4	EATC	√	√	√	√
2001	Mondeo	1.8L	DURATEC-HE / I4	GDM	√	√	√	√
2001	Mondeo	1.8L	DURATEC-HE / I4	GEM	√	√	√	√
2001	Mondeo	1.8L	DURATEC-HE / I4	HEC	√	√	√	√
2001	Mondeo	1.8L	DURATEC-HE / I4	LHID	√	√	√	√
2001	Mondeo	1.8L	DURATEC-HE / I4	NAV	√	√	√	√
2001	Mondeo	1.8L	DURATEC-HE / I4	PATS	√	√	√	√
2001	Mondeo	1.8L	DURATEC-HE / I4	PCM	√	√	√	√
2001	Mondeo	1.8L	DURATEC-HE / I4	RCM	√	√	√	√
2001	Mondeo	1.8L	DURATEC-HE / I4	RETM	√	√	√	√
2001	Mondeo	1.8L	DURATEC-HE / I4	RHID	√	√	√	√
2001	Mondeo	1.8L	DURATEC-HE / I4	SRM	√	√	√	√
2001	Mondeo	1.8L	DURATEC-SCi	ABS	√	√	√	√
2001	Mondeo	1.8L	DURATEC-SCi	ABS/TCS	√	√	√	√
2001	Mondeo	1.8L	DURATEC-SCi	ABS/TCS	√	√	√	√
2001	Mondeo	1.8L	DURATEC-SCi	ACM	√	√	√	√
2001	Mondeo	1.8L	DURATEC-SCi	CDP	√	√	√	√
2001	Mondeo	1.8L	DURATEC-SCi	CSM	√	√	√	√
2001	Mondeo	1.8L	DURATEC-SCi	EATC	√	√	√	√
2001	Mondeo	1.8L	DURATEC-SCi	GDM	√	√	√	√
2001	Mondeo	1.8L	DURATEC-SCi	GEM	√	√	√	√
2001	Mondeo	1.8L	DURATEC-SCi	HEC	√	√	√	√
2001	Mondeo	1.8L	DURATEC-SCi	LHID	√	√	√	√
2001	Mondeo	1.8L	DURATEC-SCi	NAV	√	√	√	√
2001	Mondeo	1.8L	DURATEC-SCi	PATS	√	√	√	√

2001	Mondeo	1.8L	DURATEC-SCi	PCM	✓	✓	✓	✓
2001	Mondeo	1.8L	DURATEC-SCi	RCM	✓	✓	✓	✓
2001	Mondeo	1.8L	DURATEC-SCi	RETM	✓	✓	✓	✓
2001	Mondeo	1.8L	DURATEC-SCi	RHID	✓	✓	✓	✓
2001	Mondeo	1.8L	DURATEC-SCi	SRM	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATEC-HE / I4	CDP	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATEC-HE / I4	CSM	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATEC-HE / I4	GDM	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATEC-HE / I4	HEC	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATEC-HE / I4	LHID	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATEC-HE / I4	NAV	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATEC-HE / I4	PATS	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATEC-HE / I4	RETM	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATEC-HE / I4	RHID	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATORQ_DI	ABS	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATORQ_DI	ABS/TCS	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATORQ_DI	ACM	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATORQ_DI	CDP	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATORQ_DI	CSM	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATORQ_DI	EATC	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATORQ_DI	FFH	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATORQ_DI	FIP	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATORQ_DI	GDM	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATORQ_DI	GDM	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATORQ_DI	GEM	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATORQ_DI	HEC	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATORQ_DI	LHID	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATORQ_DI	NAV	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATORQ_DI	PATS	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATORQ_DI	PCM	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATORQ_DI	RCM	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATORQ_DI	RETM	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATORQ_DI	RHID	✓	✓	✓	✓
2001	Mondeo	2.0L	DURATORQ_DI	SRM	✓	✓	✓	✓
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail	ABS	✓	✓	✓	✓





2001	Mondeo	2.2L	Duratorq Turbo Diesel Common Rail	RETM	√	√	√	√
2001	Mondeo	2.2L	Duratorq Turbo Diesel Common Rail	RHID	√	√	√	√
2001	Mondeo	2.2L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	√
2001	Mondeo	2.5L	Duratec-VE	ABS	√	√	√	√
2001	Mondeo	2.5L	Duratec-VE	ABS	√	√	√	√
2001	Mondeo	2.5L	Duratec-VE	ABS	√	√	√	√
2001	Mondeo	2.5L	Duratec-VE	ABS/TCS	√	√	√	√
2001	Mondeo	2.5L	Duratec-VE	ABS/TCS	√	√	√	√
2001	Mondeo	2.5L	Duratec-VE	ACM	√	√	√	√
2001	Mondeo	2.5L	Duratec-VE	CDP	√	√	√	√
2001	Mondeo	2.5L	Duratec-VE	CSM	√	√	√	√
2001	Mondeo	2.5L	Duratec-VE	EATC	√	√	√	√
2001	Mondeo	2.5L	Duratec-VE	EATC	√	√	√	√
2001	Mondeo	2.5L	Duratec-VE	GDM	√	√	√	√
2001	Mondeo	2.5L	Duratec-VE	GEM	√	√	√	√
2001	Mondeo	2.5L	Duratec-VE	HEC	√	√	√	√
2001	Mondeo	2.5L	Duratec-VE	LHID	√	√	√	√
2001	Mondeo	2.5L	Duratec-VE	NAV	√	√	√	√
2001	Mondeo	2.5L	Duratec-VE	PATS	√	√	√	√
2001	Mondeo	2.5L	Duratec-VE	PCM	√	√	√	√
2001	Mondeo	2.5L	Duratec-VE	PCM	√	√	√	√
2001	Mondeo	2.5L	Duratec-VE	PCM	√	√	√	√
2001	Mondeo	2.5L	Duratec-VE	RCM	√	√	√	√
2001	Mondeo	2.5L	Duratec-VE	RETM	√	√	√	√
2001	Mondeo	2.5L	Duratec-VE	RHID	√	√	√	√
2001	Mondeo	2.5L	Duratec-VE	SRM	√	√	√	√
2001	Mondeo	2.5L	Duratec-VE	TCM	√	√	√	√
2001	Mondeo	3.0L	Duratec SE	ABS	√	√	√	√
2001	Mondeo	3.0L	Duratec SE	ABS/TCS	√	√	√	√
2001	Mondeo	3.0L	Duratec SE	ACM	√	√	√	√
2001	Mondeo	3.0L	Duratec SE	CDP	√	√	√	√
2001	Mondeo	3.0L	Duratec SE	CSM	√	√	√	√
2001	Mondeo	3.0L	Duratec SE	EATC	√	√	√	√
2001	Mondeo	3.0L	Duratec SE	EATC	√	√	√	√
2001	Mondeo	3.0L	Duratec SE	GDM	√	√	√	√
2001	Mondeo	3.0L	Duratec SE	GEM	√	√	√	√
2001	Mondeo	3.0L	Duratec SE	HEC	√	√	√	√
2001	Mondeo	3.0L	Duratec SE	LHID	√	√	√	√
2001	Mondeo	3.0L	Duratec SE	NAV	√	√	√	√
2001	Mondeo	3.0L	Duratec SE	PATS	√	√	√	√
2001	Mondeo	3.0L	Duratec SE	PCM	√	√	√	√
2001	Mondeo	3.0L	Duratec SE	RCM	√	√	√	√
2001	Mondeo	3.0L	Duratec SE	RETM	√	√	√	√
2001	Mondeo	3.0L	Duratec SE	RHID	√	√	√	√
2001	Mondeo	3.0L	Duratec SE	SRM	√	√	√	√

2001	Mondeo	3.0L	Duratec-ST	ABS	✓	✓	✓	✓
2001	Mondeo	3.0L	Duratec-ST	ABS/TCS	✓	✓	✓	✓
2001	Mondeo	3.0L	Duratec-ST	ACM	✓	✓	✓	✓
2001	Mondeo	3.0L	Duratec-ST	CDP	✓	✓	✓	✓
2001	Mondeo	3.0L	Duratec-ST	CSM	✓	✓	✓	✓
2001	Mondeo	3.0L	Duratec-ST	EATC	✓	✓	✓	✓
2001	Mondeo	3.0L	Duratec-ST	EATC	✓	✓	✓	✓
2001	Mondeo	3.0L	Duratec-ST	GDM	✓	✓	✓	✓
2001	Mondeo	3.0L	Duratec-ST	GEM	✓	✓	✓	✓
2001	Mondeo	3.0L	Duratec-ST	HEC	✓	✓	✓	✓
2001	Mondeo	3.0L	Duratec-ST	LHID	✓	✓	✓	✓
2001	Mondeo	3.0L	Duratec-ST	PATS	✓	✓	✓	✓
2001	Mondeo	3.0L	Duratec-ST	PCM	✓	✓	✓	✓
2001	Mondeo	3.0L	Duratec-ST	RCM	✓	✓	✓	✓
2001	Mondeo	3.0L	Duratec-ST	RETM	✓	✓	✓	✓
2001	Mondeo	3.0L	Duratec-ST	RHID	✓	✓	✓	✓
2001	Mondeo	3.0L	Duratec-ST	SRM	✓	✓	✓	✓
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct	ABS	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct	ACM	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct	APIM	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct	C-CM	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct	DDM	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct	DSM	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct	DSP	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct	FCDIM	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct	FCIM	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct	FDSM	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct	GPSM	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct	GWM	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct	HCM	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct	HUD	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct	IPC	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct	IPM-A	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct	PAM	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct	PSCM	✓	✓	✓	✓
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct	RACM	✓	✓	✓	✓
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct	RCM	✓	✓	✓	✓
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct	RTM	✓	✓	✓	✓
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct	SCCM	✓	✓	✓	✓
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct	SCM-E	✓	✓	✓	✓

2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct	SCM-G	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct	SOD-L	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct	SOD-R	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost - Gas Turbocharged Direct	ABS	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost - Gas Turbocharged Direct	ACM	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost - Gas Turbocharged Direct	APIM	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost - Gas Turbocharged Direct	BCMii	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost - Gas Turbocharged Direct	C-CM	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost - Gas Turbocharged Direct	DDM	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost - Gas Turbocharged Direct	DSM	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost - Gas Turbocharged Direct	DSP	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost - Gas Turbocharged Direct	FCDIM	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost - Gas Turbocharged Direct	FCIM	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost - Gas Turbocharged Direct	FDSM	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost - Gas Turbocharged Direct	GPSM	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost - Gas Turbocharged Direct	GWM	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost - Gas Turbocharged Direct	HCM	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost - Gas Turbocharged Direct	HUD	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost - Gas Turbocharged Direct	IPC	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost - Gas Turbocharged Direct	IPM-A	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost - Gas Turbocharged Direct	PAM	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓
2013	Mondeo	2.0L	EcoBoost - Gas Turbocharged Direct	PDM	✓	✓	✓	✓
2013	Mondeo	2.0L	EcoBoost - Gas Turbocharged Direct	PSCM	✓	✓	✓	✓
2013	Mondeo	2.0L	EcoBoost - Gas Turbocharged Direct	RACM	✓	✓	✓	✓
2013	Mondeo	2.0L	EcoBoost - Gas Turbocharged Direct	RCM	✓	✓	✓	✓
2013	Mondeo	2.0L	EcoBoost - Gas Turbocharged Direct	RTM	✓	✓	✓	✓
2013	Mondeo	2.0L	EcoBoost - Gas Turbocharged Direct	SCCM	✓	✓	✓	✓
2013	Mondeo	2.0L	EcoBoost - Gas Turbocharged Direct	SCM-E	✓	✓	✓	✓
2013	Mondeo	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-G	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-L	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-R	✓	✓	✓	
Other	Mondeo	1.8L	Endura-DE	ABS	✓	✓	✓	✓
Other	Mondeo	1.8L	Endura-DE	CSM	✓	✓	✓	✓
Other	Mondeo	1.8L	Endura-DE	PATS			✓	✓
Other	Mondeo	1.8L	Endura-DE	PATS	✓	✓	✓	✓
2006	Montego	3.0L	4V	4X4	✓	✓	✓	✓
2006	Montego	3.0L	4V	ABS	✓	✓	✓	✓
2006	Montego	3.0L	4V	ABS	✓	✓	✓	✓
2006	Montego	3.0L	4V	ACM	✓	✓	✓	✓
2006	Montego	3.0L	4V	ACM	✓	✓	✓	✓
2006	Montego	3.0L	4V	ACM	✓	✓	✓	✓
2006	Montego	3.0L	4V	DSM	✓	✓	✓	✓

2006	Montego	3.0L	4V	DSM	✓	✓	✓	✓
2006	Montego	3.0L	4V	EATC	✓	✓	✓	✓
2006	Montego	3.0L	4V	GEM	✓	✓	✓	✓
2006	Montego	3.0L	4V	GEM	✓	✓	✓	✓
2006	Montego	3.0L	4V	IC	✓	✓	✓	✓
2006	Montego	3.0L	4V	IC	✓	✓	✓	✓
2006	Montego	3.0L	4V	PAM	✓	✓	✓	✓
2006	Montego	3.0L	4V	PAM	✓	✓	✓	✓
2006	Montego	3.0L	4V	PCM	✓	✓	✓	✓
2006	Montego	3.0L	4V	PCM	✓	✓	✓	✓
2006	Montego	3.0L	4V	RCM	✓	✓	✓	✓
2006	Montego	3.0L	4V	RCM	✓	✓	✓	✓
2006	Montego	3.0L	4V	RETM	✓	✓	✓	✓
2006	Montego	3.0L	4V	TCM	✓	✓	✓	✓
2007	Montego	3.0L	4V	4X4	✓	✓	✓	✓
2007	Montego	3.0L	4V	ABS	✓	✓	✓	✓
2007	Montego	3.0L	4V	ABS	✓	✓	✓	✓
2007	Montego	3.0L	4V	ACM	✓	✓	✓	✓
2007	Montego	3.0L	4V	ACM	✓	✓	✓	✓
2007	Montego	3.0L	4V	DSM	✓	✓	✓	✓
2007	Montego	3.0L	4V	EATC	✓	✓	✓	✓
2007	Montego	3.0L	4V	GEM	✓	✓	✓	✓
2007	Montego	3.0L	4V	IC	✓	✓	✓	✓
2007	Montego	3.0L	4V	PAM	✓	✓	✓	✓
2007	Montego	3.0L	4V	PAM	✓	✓	✓	✓
2007	Montego	3.0L	4V	PCM	✓	✓	✓	✓
2007	Montego	3.0L	4V	PCM	✓	✓	✓	✓
2007	Montego	3.0L	4V	PCM	✓	✓	✓	✓
2007	Montego	3.0L	4V	PCM	✓	✓	✓	✓
2007	Montego	3.0L	4V	RCM	✓	✓	✓	✓
2007	Montego	3.0L	4V	RCM	✓	✓	✓	✓
2007	Montego	3.0L	4V	RETM	✓	✓	✓	✓
2007	Montego	3.0L	4V	SDARS	✓	✓	✓	✓
2007	Montego	3.0L	4V	SDARS	✓	✓	✓	✓
2007	Montego	3.0L	4V	TCM	✓	✓	✓	✓
2004	Motorhome / Stripped Chassis / Step	6.8L	2V	ABS/TCS	✓	✓	✓	
2004	Motorhome / Stripped Chassis / Step	6.8L	2V	PCM	✓	✓	✓	✓
2006	Motorhome / Stripped Chassis / Step	6.8L	3V	ABS/TCS	✓	✓	✓	✓
2006	Motorhome / Stripped Chassis / Step	6.8L	3V	IC	✓	✓	✓	✓
2006	Motorhome / Stripped Chassis / Step Van	6.8L	3V	PCM	✓	✓	✓	✓
2007	Motorhome / Stripped Chassis / Step	6.8L	3V	ABS/TCS	✓	✓	✓	✓
2007	Motorhome / Stripped Chassis / Step	6.8L	3V	IC	✓	✓	✓	✓
2007	Motorhome / Stripped Chassis / Step Van	6.8L	3V	PCM	✓	✓	✓	✓
2008	Motorhome / Stripped Chassis / Step	6.8L	3V	ABS/TCS	✓	✓	✓	✓
2008	Motorhome / Stripped Chassis / Step	6.8L	3V	IC	✓	✓	✓	✓

2008	Motorhome / Stripped Chassis / Step Van	6.8L	3V	PCM	✓	✓	✓	✓
2009	Motorhome / Stripped Chassis / Step	6.8L	3V	ABS/TCS	✓	✓	✓	✓
2009	Motorhome / Stripped Chassis / Step	6.8L	3V	IC	✓	✓	✓	✓
2009	Motorhome / Stripped Chassis / Step Van	6.8L	3V	PCM	✓	✓	✓	✓
2011	Motorhome / Stripped Chassis / Step	6.8L	3V	ABS/TCS	✓	✓	✓	✓
2011	Motorhome / Stripped Chassis / Step	6.8L	3V	IC	✓	✓	✓	✓
2011	Motorhome / Stripped Chassis / Step Van	6.8L	3V	PCM	✓	✓	✓	✓
2012	Motorhome / Stripped Chassis / Step	6.8L	3V	ABS	✓	✓	✓	✓
2012	Motorhome / Stripped Chassis / Step	6.8L	3V	ABS	✓	✓	✓	✓
2012	Motorhome / Stripped Chassis / Step	6.8L	3V	ABS/TCS	✓	✓	✓	✓
2012	Motorhome / Stripped Chassis / Step	6.8L	3V	IC	✓	✓	✓	✓
2012	Motorhome / Stripped Chassis / Step	6.8L	3V	PCM	✓	✓	✓	✓
2012	Motorhome / Stripped Chassis / Step	6.8L	3V	PCM	✓	✓	✓	✓
2012	Motorhome / Stripped Chassis / Step	6.8L	3V	ABS	✓	✓	✓	✓
2012	Motorhome / Stripped Chassis / Step	6.8L	3V	IC	✓	✓	✓	✓
2012	Motorhome / Stripped Chassis / Step	6.8L	3V	PCM	✓	✓	✓	✓
2012	Motorhome / Stripped Chassis / Step	6.8L	3V	PCM	✓	✓	✓	✓
2013	Motorhome / Stripped Chassis / Step	6.8L	3V	ABS	✓	✓	✓	✓
2013	Motorhome / Stripped Chassis / Step	6.8L	3V	IC	✓	✓	✓	✓
2013	Motorhome / Stripped Chassis / Step	6.8L	3V	PCM	✓	✓	✓	✓
2013	Motorhome / Stripped Chassis / Step Van	6.8L	3V	PCM	✓	✓	✓	✓
2014	Motorhome / Stripped Chassis / Step	6.8L	3V	ABS	✓	✓	✓	✓
2014	Motorhome / Stripped Chassis / Step Van	6.8L	3V	PCM	✓	✓	✓	✓
2014	Motorhome / Stripped Chassis / Step	Other	Other	ABS	✓	✓	✓	✓
2014	Motorhome / Stripped Chassis / Step	Other	Other	IC	✓	✓	✓	✓
1997	Mountaineer	5.0L	Other	ABS/TCS	✓	✓	✓	✓
1997	Mountaineer	5.0L	Other	ARC	✓	✓	✓	✓
1997	Mountaineer	5.0L	Other	ARC	✓	✓	✓	✓
1997	Mountaineer	5.0L	Other	GEM	✓	✓	✓	✓
1997	Mountaineer	5.0L	Other	IAB	✓	✓	✓	✓
1997	Mountaineer	5.0L	Other	PCM	✓	✓	✓	✓
1997	Mountaineer	5.0L	Other	RAP	✓	✓	✓	✓
1998	Mountaineer	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓
1998	Mountaineer	4.0L	V6 SOHC	ARC	✓	✓	✓	✓
1998	Mountaineer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓
1998	Mountaineer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓
1998	Mountaineer	4.0L	V6 SOHC	GEM	✓	✓	✓	✓
1998	Mountaineer	4.0L	V6 SOHC	IAB	✓	✓	✓	✓
1998	Mountaineer	4.0L	V6 SOHC	PATS	✓	✓	✓	✓
1998	Mountaineer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
1998	Mountaineer	4.0L	V6 SOHC	RAP	✓	✓	✓	✓
1998	Mountaineer	5.0L	Other	ABS/TCS	✓	✓	✓	✓
1998	Mountaineer	5.0L	Other	ARC	✓	✓	✓	✓
1998	Mountaineer	5.0L	Other	DSM	✓	✓	✓	✓
1998	Mountaineer	5.0L	Other	EATC	✓	✓	✓	✓
1998	Mountaineer	5.0L	Other	GEM	✓	✓	✓	✓
1998	Mountaineer	5.0L	Other	IAB	✓	✓	✓	✓
1998	Mountaineer	5.0L	Other	PATS	✓	✓	✓	✓
1998	Mountaineer	5.0L	Other	PCM	✓	✓	✓	✓

1998	Mountaineer	5.0L	Other	RAP	✓	✓	✓	✓
1999	Mountaineer	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓
1999	Mountaineer	4.0L	V6 SOHC	ARC	✓	✓	✓	✓
1999	Mountaineer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓
1999	Mountaineer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓
1999	Mountaineer	4.0L	V6 SOHC	GEM	✓	✓	✓	✓
1999	Mountaineer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓
1999	Mountaineer	4.0L	V6 SOHC	PATS	✓	✓	✓	✓
1999	Mountaineer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
1999	Mountaineer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
1999	Mountaineer	4.0L	V6 SOHC	RAP	✓	✓	✓	✓
1999	Mountaineer	5.0L	Other	ABS/TCS	✓	✓	✓	✓
1999	Mountaineer	5.0L	Other	ARC	✓	✓	✓	✓
1999	Mountaineer	5.0L	Other	DSM	✓	✓	✓	✓
1999	Mountaineer	5.0L	Other	EATC	✓	✓	✓	✓
1999	Mountaineer	5.0L	Other	GEM	✓	✓	✓	✓
1999	Mountaineer	5.0L	Other	IAB	✓	✓	✓	✓
1999	Mountaineer	5.0L	Other	PAM	✓	✓	✓	✓
1999	Mountaineer	5.0L	Other	PATS	✓	✓	✓	✓
1999	Mountaineer	5.0L	Other	PCM	✓	✓	✓	✓
1999	Mountaineer	5.0L	Other	RAP	✓	✓	✓	✓
2000	Mountaineer	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓
2000	Mountaineer	4.0L	V6 SOHC	ARC	✓	✓	✓	✓
2000	Mountaineer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓
2000	Mountaineer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓
2000	Mountaineer	4.0L	V6 SOHC	GEM	✓	✓	✓	✓
2000	Mountaineer	4.0L	V6 SOHC	IAB	✓	✓	✓	✓
2000	Mountaineer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓
2000	Mountaineer	4.0L	V6 SOHC	PATS	✓	✓	✓	✓
2000	Mountaineer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2000	Mountaineer	4.0L	V6 SOHC	RAP	✓	✓	✓	✓
2000	Mountaineer	5.0L	Other	ABS/TCS	✓	✓	✓	✓
2000	Mountaineer	5.0L	Other	ARC	✓	✓	✓	✓
2000	Mountaineer	5.0L	Other	DSM	✓	✓	✓	✓
2000	Mountaineer	5.0L	Other	EATC	✓	✓	✓	✓
2000	Mountaineer	5.0L	Other	GEM	✓	✓	✓	✓
2000	Mountaineer	5.0L	Other	IAB	✓	✓	✓	✓
2000	Mountaineer	5.0L	Other	PAM	✓	✓	✓	✓
2000	Mountaineer	5.0L	Other	PATS	✓	✓	✓	✓
2000	Mountaineer	5.0L	Other	PCM	✓	✓	✓	✓
2000	Mountaineer	5.0L	Other	RAP	✓	✓	✓	✓
2002	Mountaineer	4.0L	V6 SOHC	4X4	✓	✓	✓	✓
2002	Mountaineer	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓
2002	Mountaineer	4.0L	V6 SOHC	CSM	✓	✓	✓	✓
2002	Mountaineer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓

2002	Mountaineer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓
2002	Mountaineer	4.0L	V6 SOHC	GEM	✓	✓	✓	✓
2002	Mountaineer	4.0L	V6 SOHC	IC	✓	✓	✓	✓
2002	Mountaineer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓
2002	Mountaineer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2002	Mountaineer	4.0L	V6 SOHC	RCM	✓	✓	✓	
2002	Mountaineer	4.6L	2V	4X4	✓	✓	✓	✓
2002	Mountaineer	4.6L	2V	ABS/TCS	✓	✓	✓	✓
2002	Mountaineer	4.6L	2V	CSM	✓	✓	✓	✓
2002	Mountaineer	4.6L	2V	DSM	✓	✓	✓	✓
2002	Mountaineer	4.6L	2V	EATC	✓	✓	✓	✓
2002	Mountaineer	4.6L	2V	IC	✓	✓	✓	✓
2002	Mountaineer	4.6L	2V	PAM	✓	✓	✓	✓
2002	Mountaineer	4.6L	2V	PCM	✓	✓	✓	✓
2002	Mountaineer	4.6L	2V	RCM	✓	✓	✓	
2002.5	Mountaineer	4.0L	V6 SOHC	4X4	✓	✓	✓	✓
2002.5	Mountaineer	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓
2002.5	Mountaineer	4.0L	V6 SOHC	CSM	✓	✓	✓	✓
2002.5	Mountaineer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓
2002.5	Mountaineer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓
2002.5	Mountaineer	4.0L	V6 SOHC	HEC	✓	✓	✓	✓
2002.5	Mountaineer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓
2002.5	Mountaineer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2002.5	Mountaineer	4.0L	V6 SOHC	RCM	✓	✓	✓	✓
2002.5	Mountaineer	4.0L	V6 SOHC	TPM	✓	✓	✓	✓
2002.5	Mountaineer	4.6L	2V	4X4	✓	✓	✓	✓
2002.5	Mountaineer	4.6L	2V	ABS/TCS	✓	✓	✓	✓
2002.5	Mountaineer	4.6L	2V	CSM	✓	✓	✓	✓
2002.5	Mountaineer	4.6L	2V	DSM	✓	✓	✓	✓
2002.5	Mountaineer	4.6L	2V	EATC	✓	✓	✓	✓
2002.5	Mountaineer	4.6L	2V	HEC	✓	✓	✓	✓
2002.5	Mountaineer	4.6L	2V	PAM	✓	✓	✓	✓
2002.5	Mountaineer	4.6L	2V	PCM	✓	✓	✓	✓
2002.5	Mountaineer	4.6L	2V	RCM	✓	✓	✓	✓
2002.5	Mountaineer	4.6L	2V	TPM	✓	✓	✓	✓
2003	Mountaineer	4.0L	V6 SOHC	4X4	✓	✓	✓	✓
2003	Mountaineer	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓
2003	Mountaineer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓
2003	Mountaineer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓
2003	Mountaineer	4.0L	V6 SOHC	HEC	✓	✓	✓	✓
2003	Mountaineer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓
2003	Mountaineer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2003	Mountaineer	4.0L	V6 SOHC	RCM	✓	✓	✓	✓
2003	Mountaineer	4.0L	V6 SOHC	TPM	✓	✓	✓	✓
2003	Mountaineer	4.0L	V6 SOHC	VSM	✓	✓	✓	✓

2003	Mountaineer	4.6L	2V	4X4	✓	✓	✓	✓
2003	Mountaineer	4.6L	2V	ABS/TCS	✓	✓	✓	✓
2003	Mountaineer	4.6L	2V	DSM	✓	✓	✓	✓
2003	Mountaineer	4.6L	2V	EATC	✓	✓	✓	✓
2003	Mountaineer	4.6L	2V	HEC	✓	✓	✓	✓
2003	Mountaineer	4.6L	2V	PAM	✓	✓	✓	✓
2003	Mountaineer	4.6L	2V	PCM	✓	✓	✓	✓
2003	Mountaineer	4.6L	2V	RCM	✓	✓	✓	✓
2003	Mountaineer	4.6L	2V	TPM	✓	✓	✓	✓
2003	Mountaineer	4.6L	2V	VSM	✓	✓	✓	✓
2004	Mountaineer	4.0L	V6 SOHC	4X4	✓	✓	✓	
2004	Mountaineer	4.0L	V6 SOHC	ABS	✓	✓	✓	✓
2004	Mountaineer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓
2004	Mountaineer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓
2004	Mountaineer	4.0L	V6 SOHC	IC	✓	✓	✓	✓
2004	Mountaineer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓
2004	Mountaineer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2004	Mountaineer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2004	Mountaineer	4.0L	V6 SOHC	RCM	✓	✓	✓	✓
2004	Mountaineer	4.0L	V6 SOHC	TPM	✓	✓	✓	
2004	Mountaineer	4.0L	V6 SOHC	VSM	✓	✓	✓	✓
2004	Mountaineer	4.6L	2V	4X4	✓	✓	✓	
2004	Mountaineer	4.6L	2V	ABS	✓	✓	✓	✓
2004	Mountaineer	4.6L	2V	ABS	✓	✓	✓	✓
2004	Mountaineer	4.6L	2V	DSM	✓	✓	✓	✓
2004	Mountaineer	4.6L	2V	EATC	✓	✓	✓	✓
2004	Mountaineer	4.6L	2V	IC	✓	✓	✓	✓
2004	Mountaineer	4.6L	2V	PAM	✓	✓	✓	✓
2004	Mountaineer	4.6L	2V	PCM	✓	✓	✓	✓
2004	Mountaineer	4.6L	2V	PCM	✓	✓	✓	✓
2004	Mountaineer	4.6L	2V	RCM	✓	✓	✓	✓
2004	Mountaineer	4.6L	2V	TPM	✓	✓	✓	
2004	Mountaineer	4.6L	2V	VSM	✓	✓	✓	✓
2005	Mountaineer	4.0L	V6 SOHC	4X4	✓	✓	✓	
2005	Mountaineer	4.0L	V6 SOHC	4X4	✓	✓	✓	
2005	Mountaineer	4.0L	V6 SOHC	ABS	✓	✓	✓	✓
2005	Mountaineer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓
2005	Mountaineer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓
2005	Mountaineer	4.0L	V6 SOHC	IC	✓	✓	✓	✓
2005	Mountaineer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓
2005	Mountaineer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2005	Mountaineer	4.0L	V6 SOHC	RCM	✓	✓	✓	✓
2005	Mountaineer	4.0L	V6 SOHC	TPM	✓	✓	✓	✓
2005	Mountaineer	4.0L	V6 SOHC	VSM	✓	✓	✓	✓
2005	Mountaineer	4.6L	2V	4X4	✓	✓	✓	



2005	Mountaineer	4.6L	2V	ABS	✓	✓	✓	✓
2005	Mountaineer	4.6L	2V	DSM	✓	✓	✓	✓
2005	Mountaineer	4.6L	2V	EATC	✓	✓	✓	✓
2005	Mountaineer	4.6L	2V	IC	✓	✓	✓	✓
2005	Mountaineer	4.6L	2V	PAM	✓	✓	✓	✓
2005	Mountaineer	4.6L	2V	RCM	✓	✓	✓	✓
2005	Mountaineer	4.6L	2V	TPM	✓	✓	✓	✓
2005	Mountaineer	4.6L	2V	VSM	✓	✓	✓	✓
2006	Mountaineer	4.0L	2V	4X4	✓	✓	✓	✓
2006	Mountaineer	4.0L	2V	ABS	✓	✓	✓	✓
2006	Mountaineer	4.0L	2V	ABS	✓	✓	✓	✓
2006	Mountaineer	4.0L	2V	ACM	✓	✓	✓	✓
2006	Mountaineer	4.0L	2V	DSM	✓	✓	✓	✓
2006	Mountaineer	4.0L	2V	EATC	✓	✓	✓	✓
2006	Mountaineer	4.0L	2V	GEM	✓	✓	✓	✓
2006	Mountaineer	4.0L	2V	GEM	✓	✓	✓	✓
2006	Mountaineer	4.0L	2V	IC	✓	✓	✓	✓
2006	Mountaineer	4.0L	2V	OCSM	✓	✓	✓	✓
2006	Mountaineer	4.0L	2V	PAM	✓	✓	✓	✓
2006	Mountaineer	4.0L	2V	PCM	✓	✓	✓	✓
2006	Mountaineer	4.0L	2V	PCM	✓	✓	✓	✓
2006	Mountaineer	4.0L	2V	PRB	✓	✓	✓	✓
2006	Mountaineer	4.0L	2V	RCM	✓	✓	✓	✓
2006	Mountaineer	4.0L	2V	RCM	✓	✓	✓	✓
2006	Mountaineer	4.0L	2V	RETM	✓	✓	✓	✓
2006	Mountaineer	4.0L	2V	RETM	✓	✓	✓	✓
2006	Mountaineer	4.0L	2V	SDARS	✓	✓	✓	✓
2006	Mountaineer	4.0L	2V	SDARS	✓	✓	✓	✓
2006	Mountaineer	4.6L	3V	4X4	✓	✓	✓	✓
2006	Mountaineer	4.6L	3V	4X4	✓	✓	✓	✓
2006	Mountaineer	4.6L	3V	ABS	✓	✓	✓	✓
2006	Mountaineer	4.6L	3V	ABS	✓	✓	✓	✓
2006	Mountaineer	4.6L	3V	ACM	✓	✓	✓	✓
2006	Mountaineer	4.6L	3V	ACM	✓	✓	✓	✓
2006	Mountaineer	4.6L	3V	DSM	✓	✓	✓	✓
2006	Mountaineer	4.6L	3V	EATC	✓	✓	✓	✓
2006	Mountaineer	4.6L	3V	EATC	✓	✓	✓	✓
2006	Mountaineer	4.6L	3V	GEM	✓	✓	✓	✓
2006	Mountaineer	4.6L	3V	GEM	✓	✓	✓	✓
2006	Mountaineer	4.6L	3V	IC	✓	✓	✓	✓
2006	Mountaineer	4.6L	3V	OCSM	✓	✓	✓	✓
2006	Mountaineer	4.6L	3V	OCSM	✓	✓	✓	✓
2006	Mountaineer	4.6L	3V	PAM	✓	✓	✓	✓
2006	Mountaineer	4.6L	3V	PAM	✓	✓	✓	✓
2006	Mountaineer	4.6L	3V	PCM	✓	✓	✓	✓

2006	Mountaineer	4.6L	3V	PCM	✓	✓	✓	✓
2006	Mountaineer	4.6L	3V	PRB	✓	✓	✓	✓
2006	Mountaineer	4.6L	3V	RCM	✓	✓	✓	✓
2006	Mountaineer	4.6L	3V	RCM	✓	✓	✓	✓
2006	Mountaineer	4.6L	3V	RETM	✓	✓	✓	✓
2006	Mountaineer	4.6L	3V	RETM	✓	✓	✓	✓
2006	Mountaineer	4.6L	3V	SDARS	✓	✓	✓	✓
2006	Mountaineer	4.6L	3V	SDARS	✓	✓	✓	✓
2006	Mountaineer	4.6L	3V	TCM	✓	✓	✓	✓
2006	Mountaineer	4.6L	3V	TCM	✓	✓	✓	✓
2007	Mountaineer	4.0L	2V	4X4	✓	✓	✓	✓
2007	Mountaineer	4.0L	2V	ABS	✓	✓	✓	✓
2007	Mountaineer	4.0L	2V	ACM	✓	✓	✓	✓
2007	Mountaineer	4.0L	2V	DSM	✓	✓	✓	✓
2007	Mountaineer	4.0L	2V	EATC	✓	✓	✓	✓
2007	Mountaineer	4.0L	2V	GEM	✓	✓	✓	✓
2007	Mountaineer	4.0L	2V	IC	✓	✓	✓	✓
2007	Mountaineer	4.0L	2V	OCSM	✓	✓	✓	✓
2007	Mountaineer	4.0L	2V	PAM	✓	✓	✓	✓
2007	Mountaineer	4.0L	2V	PCM	✓	✓	✓	✓
2007	Mountaineer	4.0L	2V	PCM	✓	✓	✓	✓
2007	Mountaineer	4.0L	2V	PRB	✓	✓	✓	✓
2007	Mountaineer	4.0L	2V	RCM	✓	✓	✓	✓
2007	Mountaineer	4.0L	2V	RETM	✓	✓	✓	
2007	Mountaineer	4.0L	2V	SDARS	✓	✓	✓	✓
2007	Mountaineer	4.6L	3V	4X4	✓	✓	✓	✓
2007	Mountaineer	4.6L	3V	4X4	✓	✓	✓	✓
2007	Mountaineer	4.6L	3V	ABS	✓	✓	✓	✓
2007	Mountaineer	4.6L	3V	ABS	✓	✓	✓	✓
2007	Mountaineer	4.6L	3V	ACM	✓	✓	✓	✓
2007	Mountaineer	4.6L	3V	ACM	✓	✓	✓	✓
2007	Mountaineer	4.6L	3V	DSM	✓	✓	✓	✓
2007	Mountaineer	4.6L	3V	EATC	✓	✓	✓	✓
2007	Mountaineer	4.6L	3V	EATC	✓	✓	✓	✓
2007	Mountaineer	4.6L	3V	GEM	✓	✓	✓	✓
2007	Mountaineer	4.6L	3V	GEM	✓	✓	✓	✓
2007	Mountaineer	4.6L	3V	IC	✓	✓	✓	✓
2007	Mountaineer	4.6L	3V	IC	✓	✓	✓	✓
2007	Mountaineer	4.6L	3V	OCSM	✓	✓	✓	✓
2007	Mountaineer	4.6L	3V	OCSM	✓	✓	✓	✓
2007	Mountaineer	4.6L	3V	PAM	✓	✓	✓	✓
2007	Mountaineer	4.6L	3V	PAM	✓	✓	✓	✓
2007	Mountaineer	4.6L	3V	PCM	✓	✓	✓	✓
2007	Mountaineer	4.6L	3V	PCM	✓	✓	✓	✓
2007	Mountaineer	4.6L	3V	PRB	✓	✓	✓	✓

2007	Mountaineer	4.6L	3V	RCM	✓	✓	✓	✓
2007	Mountaineer	4.6L	3V	RCM	✓	✓	✓	✓
2007	Mountaineer	4.6L	3V	RETM	✓	✓	✓	
2007	Mountaineer	4.6L	3V	RETM	✓	✓	✓	
2007	Mountaineer	4.6L	3V	SDARS	✓	✓	✓	✓
2007	Mountaineer	4.6L	3V	SDARS	✓	✓	✓	✓
2007	Mountaineer	4.6L	3V	TCM	✓	✓	✓	✓
2007	Mountaineer	4.6L	3V	TCM	✓	✓	✓	✓
2008	Mountaineer	4.0L	2V	4X4	✓	✓	✓	✓
2008	Mountaineer	4.0L	2V	4X4	✓	✓	✓	✓
2008	Mountaineer	4.0L	2V	ABS	✓	✓	✓	✓
2008	Mountaineer	4.0L	2V	ACM	✓	✓	✓	✓
2008	Mountaineer	4.0L	2V	APIM	✓	✓	✓	✓
2008	Mountaineer	4.0L	2V	DSM	✓	✓	✓	✓
2008	Mountaineer	4.0L	2V	GEM / SJB	✓	✓	✓	✓
2008	Mountaineer	4.0L	2V	HVAC	✓	✓	✓	✓
2008	Mountaineer	4.0L	2V	IC	✓	✓	✓	✓
2008	Mountaineer	4.0L	2V	OCSM	✓	✓	✓	✓
2008	Mountaineer	4.0L	2V	PAM	✓	✓	✓	✓
2008	Mountaineer	4.0L	2V	PCM	✓	✓	✓	✓
2008	Mountaineer	4.0L	2V	PRB	✓	✓	✓	✓
2008	Mountaineer	4.0L	2V	RCM	✓	✓	✓	✓
2008	Mountaineer	4.0L	2V	RETM	✓	✓	✓	
2008	Mountaineer	4.0L	2V	SDARS	✓	✓	✓	✓
2008	Mountaineer	4.6L	3V	4X4	✓	✓	✓	✓
2008	Mountaineer	4.6L	3V	4X4	✓	✓	✓	✓
2008	Mountaineer	4.6L	3V	ABS	✓	✓	✓	✓
2008	Mountaineer	4.6L	3V	ABS	✓	✓	✓	✓
2008	Mountaineer	4.6L	3V	ACM	✓	✓	✓	✓
2008	Mountaineer	4.6L	3V	ACM	✓	✓	✓	✓
2008	Mountaineer	4.6L	3V	ACM	✓	✓	✓	✓
2008	Mountaineer	4.6L	3V	APIM	✓	✓	✓	✓
2008	Mountaineer	4.6L	3V	APIM	✓	✓	✓	✓
2008	Mountaineer	4.6L	3V	DSM	✓	✓	✓	✓
2008	Mountaineer	4.6L	3V	DSM	✓	✓	✓	✓
2008	Mountaineer	4.6L	3V	GEM / SJB	✓	✓	✓	✓
2008	Mountaineer	4.6L	3V	GEM / SJB	✓	✓	✓	✓
2008	Mountaineer	4.6L	3V	GEM / SJB	✓	✓	✓	✓
2008	Mountaineer	4.6L	3V	HVAC	✓	✓	✓	✓
2008	Mountaineer	4.6L	3V	IC	✓	✓	✓	✓
2008	Mountaineer	4.6L	3V	IC	✓	✓	✓	✓
2008	Mountaineer	4.6L	3V	OCSM	✓	✓	✓	✓
2008	Mountaineer	4.6L	3V	OCSM	✓	✓	✓	✓
2008	Mountaineer	4.6L	3V	OCSM	✓	✓	✓	✓
2008	Mountaineer	4.6L	3V	PAM	✓	✓	✓	✓

2008	Mountaineer	4.6L	3V	PCM	√	√	√	√
2008	Mountaineer	4.6L	3V	PCM	√	√	√	√
2008	Mountaineer	4.6L	3V	PCM	√	√	√	√
2008	Mountaineer	4.6L	3V	PRB	√	√	√	√
2008	Mountaineer	4.6L	3V	RCM	√	√	√	√
2008	Mountaineer	4.6L	3V	RCM	√	√	√	√
2008	Mountaineer	4.6L	3V	RETM	√	√	√	
2008	Mountaineer	4.6L	3V	RETM	√	√	√	
2008	Mountaineer	4.6L	3V	SDARS	√	√	√	√
2008	Mountaineer	4.6L	3V	TCM	√	√	√	√
2008	Mountaineer	4.6L	3V	TCM	√	√	√	√
2009	Mountaineer	4.0L	2V	4X4	√	√	√	√
2009	Mountaineer	4.0L	2V	4X4	√	√	√	√
2009	Mountaineer	4.0L	2V	ABS	√	√	√	√
2009	Mountaineer	4.0L	2V	ABS	√	√	√	√
2009	Mountaineer	4.0L	2V	ACM	√	√	√	
2009	Mountaineer	4.0L	2V	ACM	√	√	√	√
2009	Mountaineer	4.0L	2V	APIM	√	√	√	
2009	Mountaineer	4.0L	2V	DSM	√	√	√	√
2009	Mountaineer	4.0L	2V	DSM	√	√	√	√
2009	Mountaineer	4.0L	2V	GEM / SJB	√	√	√	√
2009	Mountaineer	4.0L	2V	GEM / SJB	√	√	√	√
2009	Mountaineer	4.0L	2V	HVAC	√	√	√	√
2009	Mountaineer	4.0L	2V	HVAC	√	√	√	√
2009	Mountaineer	4.0L	2V	IC	√	√	√	√
2009	Mountaineer	4.0L	2V	IC	√	√	√	√
2009	Mountaineer	4.0L	2V	OCSM	√	√	√	√
2009	Mountaineer	4.0L	2V	PAM	√	√	√	√
2009	Mountaineer	4.0L	2V	PCM	√	√	√	√
2009	Mountaineer	4.0L	2V	PCM	√	√	√	√
2009	Mountaineer	4.0L	2V	PRB	√	√	√	√
2009	Mountaineer	4.0L	2V	RCM	√	√	√	√
2009	Mountaineer	4.0L	2V	RETM	√	√	√	√
2009	Mountaineer	4.0L	2V	RETM	√	√	√	√
2009	Mountaineer	4.0L	2V	SDARS	√	√	√	√
2009	Mountaineer	4.0L	2V	SDARS	√	√	√	√
2009	Mountaineer	4.6L	3V	4X4	√	√	√	√
2009	Mountaineer	4.6L	3V	ABS	√	√	√	√
2009	Mountaineer	4.6L	3V	ABS	√	√	√	√
2009	Mountaineer	4.6L	3V	ACM	√	√	√	
2009	Mountaineer	4.6L	3V	ACM	√	√	√	
2009	Mountaineer	4.6L	3V	ACM	√	√	√	√
2009	Mountaineer	4.6L	3V	ACM	√	√	√	√
2009	Mountaineer	4.6L	3V	APIM	√	√	√	
2009	Mountaineer	4.6L	3V	APIM	√	√	√	

2009	Mountaineer	4.6L	3V	DSM	√	√	√	√
2009	Mountaineer	4.6L	3V	DSM	√	√	√	√
2009	Mountaineer	4.6L	3V	GEM / SJB	√	√	√	√
2009	Mountaineer	4.6L	3V	GEM / SJB	√	√	√	√
2009	Mountaineer	4.6L	3V	HVAC	√	√	√	√
2009	Mountaineer	4.6L	3V	HVAC	√	√	√	√
2009	Mountaineer	4.6L	3V	IC	√	√	√	√
2009	Mountaineer	4.6L	3V	IC	√	√	√	√
2009	Mountaineer	4.6L	3V	OCSM	√	√	√	√
2009	Mountaineer	4.6L	3V	OCSM	√	√	√	√
2009	Mountaineer	4.6L	3V	PAM	√	√	√	√
2009	Mountaineer	4.6L	3V	PAM	√	√	√	√
2009	Mountaineer	4.6L	3V	PCM	√	√	√	√
2009	Mountaineer	4.6L	3V	PCM	√	√	√	√
2009	Mountaineer	4.6L	3V	PRB	√	√	√	√
2009	Mountaineer	4.6L	3V	RCM	√	√	√	√
2009	Mountaineer	4.6L	3V	RCM	√	√	√	√
2009	Mountaineer	4.6L	3V	RETM	√	√	√	√
2009	Mountaineer	4.6L	3V	RETM	√	√	√	√
2009	Mountaineer	4.6L	3V	SDARS	√	√	√	√
2009	Mountaineer	4.6L	3V	TCM	√	√	√	√
2009	Mountaineer	4.6L	3V	TCM	√	√	√	√
2010	Mountaineer	4.0L	2V	4X4	√	√	√	√
2010	Mountaineer	4.0L	2V	4X4	√	√	√	√
2010	Mountaineer	4.0L	2V	ABS	√	√	√	√
2010	Mountaineer	4.0L	2V	ACM	√	√	√	
2010	Mountaineer	4.0L	2V	ACM	√	√	√	√
2010	Mountaineer	4.0L	2V	APIM	√	√	√	
2010	Mountaineer	4.0L	2V	DSM	√	√	√	√
2010	Mountaineer	4.0L	2V	GEM / SJB	√	√	√	√
2010	Mountaineer	4.0L	2V	GPSM	√	√	√	√
2010	Mountaineer	4.0L	2V	HVAC	√	√	√	√
2010	Mountaineer	4.0L	2V	IC	√	√	√	√
2010	Mountaineer	4.0L	2V	OCSM	√	√	√	√
2010	Mountaineer	4.0L	2V	PAM	√	√	√	√
2010	Mountaineer	4.0L	2V	PCM	√	√	√	√
2010	Mountaineer	4.0L	2V	PCM	√	√	√	√
2010	Mountaineer	4.0L	2V	PRB	√	√	√	√
2010	Mountaineer	4.0L	2V	RCM	√	√	√	√
2010	Mountaineer	4.0L	2V	RETM	√	√	√	√
2010	Mountaineer	4.0L	2V	SDARS	√	√	√	√
2010	Mountaineer	4.6L	3V	4X4	√	√	√	√
2010	Mountaineer	4.6L	3V	ABS	√	√	√	√
2010	Mountaineer	4.6L	3V	ABS	√	√	√	√
2010	Mountaineer	4.6L	3V	ACM	√	√	√	

2010	Mountaineer	4.6L	3V	ACM	✓	✓	✓	
2010	Mountaineer	4.6L	3V	ACM	✓	✓	✓	✓
2010	Mountaineer	4.6L	3V	ACM	✓	✓	✓	✓
2010	Mountaineer	4.6L	3V	APIM	✓	✓	✓	
2010	Mountaineer	4.6L	3V	APIM	✓	✓	✓	
2010	Mountaineer	4.6L	3V	DSM	✓	✓	✓	✓
2010	Mountaineer	4.6L	3V	DSM	✓	✓	✓	✓
2010	Mountaineer	4.6L	3V	GEM / SJB	✓	✓	✓	✓
2010	Mountaineer	4.6L	3V	GEM / SJB	✓	✓	✓	✓
2010	Mountaineer	4.6L	3V	GPSM	✓	✓	✓	✓
2010	Mountaineer	4.6L	3V	HVAC	✓	✓	✓	✓
2010	Mountaineer	4.6L	3V	HVAC	✓	✓	✓	✓
2010	Mountaineer	4.6L	3V	IC	✓	✓	✓	✓
2010	Mountaineer	4.6L	3V	IC	✓	✓	✓	✓
2010	Mountaineer	4.6L	3V	OCSM	✓	✓	✓	✓
2010	Mountaineer	4.6L	3V	OCSM	✓	✓	✓	✓
2010	Mountaineer	4.6L	3V	PAM	✓	✓	✓	✓
2010	Mountaineer	4.6L	3V	PAM	✓	✓	✓	✓
2010	Mountaineer	4.6L	3V	PCM	✓	✓	✓	✓
2010	Mountaineer	4.6L	3V	PCM	✓	✓	✓	✓
2010	Mountaineer	4.6L	3V	PRB	✓	✓	✓	✓
2010	Mountaineer	4.6L	3V	RETM	✓	✓	✓	✓
2010	Mountaineer	4.6L	3V	RETM	✓	✓	✓	✓
2010	Mountaineer	4.6L	3V	SDARS	✓	✓	✓	✓
2010	Mountaineer	4.6L	3V	TCM	✓	✓	✓	✓
2010	Mountaineer	4.6L	3V	TCM	✓	✓	✓	✓
1994	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓
1994	Mustang	3.8L	Other	PCM	✓	✓	✓	✓
1995	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓
1995	Mustang	3.8L	Other	PCM	✓	✓	✓	✓
1996	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓
1996	Mustang	3.8L	Other	IAB	✓	✓	✓	✓
1996	Mustang	3.8L	Other	PATS	✓	✓	✓	✓
1996	Mustang	3.8L	Other	PCM	✓	✓	✓	✓
1996	Mustang	4.6L	2V	ABS/TCS	✓	✓	✓	✓
1996	Mustang	4.6L	2V	IAB	✓	✓	✓	✓
1996	Mustang	4.6L	2V	PATS	✓	✓	✓	✓
1996	Mustang	4.6L	2V	PCM	✓	✓	✓	✓
1996	Mustang	4.6L	4V	ABS/TCS	✓	✓	✓	✓
1996	Mustang	4.6L	4V	IAB	✓	✓	✓	✓
1996	Mustang	4.6L	4V	PATS	✓	✓	✓	✓
1996	Mustang	4.6L	4V	PCM	✓	✓	✓	✓
1996	Mustang	4.6L	Other	ABS/TCS	✓	✓	✓	✓
1996	Mustang	4.6L	Other	PATS	✓	✓	✓	✓
1996	Mustang	4.6L	Other	PCM	✓	✓	✓	✓

1997	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓
1997	Mustang	3.8L	Other	IAB	✓	✓	✓	✓
1997	Mustang	3.8L	Other	PATS	✓	✓	✓	✓
1997	Mustang	3.8L	Other	PCM	✓	✓	✓	✓
1997	Mustang	4.6L	2V	ABS/TCS	✓	✓	✓	✓
1997	Mustang	4.6L	2V	IAB	✓	✓	✓	✓
1997	Mustang	4.6L	2V	PATS	✓	✓	✓	✓
1997	Mustang	4.6L	2V	PCM	✓	✓	✓	✓
1997	Mustang	4.6L	4V	ABS/TCS	✓	✓	✓	✓
1997	Mustang	4.6L	4V	IAB	✓	✓	✓	✓
1997	Mustang	4.6L	4V	PATS	✓	✓	✓	✓
1997	Mustang	4.6L	4V	PCM	✓	✓	✓	✓
1997	Mustang	4.6L	Other	ABS/TCS	✓	✓	✓	✓
1997	Mustang	4.6L	Other	PATS	✓	✓	✓	✓
1997	Mustang	4.6L	Other	PCM	✓	✓	✓	✓
1998	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓
1998	Mustang	3.8L	Other	IAB	✓	✓	✓	✓
1998	Mustang	3.8L	Other	PATS	✓	✓	✓	✓
1998	Mustang	3.8L	Other	PCM	✓	✓	✓	✓
1998	Mustang	4.6L	2V	ABS/TCS	✓	✓	✓	✓
1998	Mustang	4.6L	2V	IAB	✓	✓	✓	✓
1998	Mustang	4.6L	2V	PATS	✓	✓	✓	✓
1998	Mustang	4.6L	2V	PCM	✓	✓	✓	✓
1998	Mustang	4.6L	4V	ABS/TCS	✓	✓	✓	✓
1998	Mustang	4.6L	4V	IAB	✓	✓	✓	✓
1998	Mustang	4.6L	4V	PATS	✓	✓	✓	✓
1998	Mustang	4.6L	4V	PCM	✓	✓	✓	✓
1999	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓
1999	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓
1999	Mustang	3.8L	Other	GEM	✓	✓	✓	✓
1999	Mustang	3.8L	Other	HEC	✓	✓	✓	✓
1999	Mustang	3.8L	Other	PCM	✓	✓	✓	✓
1999	Mustang	3.8L	Other	PCM	✓	✓	✓	✓
1999	Mustang	3.8L	Other	RCM	✓	✓	✓	✓
1999	Mustang	4.6L	2V	ABS/TCS	✓	✓	✓	✓
1999	Mustang	4.6L	2V	ABS/TCS	✓	✓	✓	✓
1999	Mustang	4.6L	2V	GEM	✓	✓	✓	✓
1999	Mustang	4.6L	2V	HEC	✓	✓	✓	✓
1999	Mustang	4.6L	2V	PCM	✓	✓	✓	✓
1999	Mustang	4.6L	2V	PCM	✓	✓	✓	✓
1999	Mustang	4.6L	2V	RCM	✓	✓	✓	✓
1999	Mustang	4.6L	4V	ABS/TCS	✓	✓	✓	✓
1999	Mustang	4.6L	4V	ABS/TCS	✓	✓	✓	✓
1999	Mustang	4.6L	4V	GEM	✓	✓	✓	✓
1999	Mustang	4.6L	4V	HEC	✓	✓	✓	✓

1999	Mustang	4.6L	4V	PCM	✓	✓	✓	✓
1999	Mustang	4.6L	4V	RCM	✓	✓	✓	✓
2000	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓
2000	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓
2000	Mustang	3.8L	Other	GEM	✓	✓	✓	✓
2000	Mustang	3.8L	Other	HEC	✓	✓	✓	✓
2000	Mustang	3.8L	Other	PCM	✓	✓	✓	✓
2000	Mustang	3.8L	Other	PCM	✓	✓	✓	✓
2000	Mustang	3.8L	Other	RCM	✓	✓	✓	✓
2000	Mustang	4.6L	2V	ABS/TCS	✓	✓	✓	✓
2000	Mustang	4.6L	2V	ABS/TCS	✓	✓	✓	✓
2000	Mustang	4.6L	2V	GEM	✓	✓	✓	✓
2000	Mustang	4.6L	2V	HEC	✓	✓	✓	✓
2000	Mustang	4.6L	2V	PCM	✓	✓	✓	✓
2000	Mustang	4.6L	2V	PCM	✓	✓	✓	✓
2000	Mustang	4.6L	2V	RCM	✓	✓	✓	✓
2000	Mustang	4.6L	4V	ABS/TCS	✓	✓	✓	✓
2000	Mustang	4.6L	4V	ABS/TCS	✓	✓	✓	✓
2000	Mustang	4.6L	4V	GEM	✓	✓	✓	✓
2000	Mustang	4.6L	4V	PCM	✓	✓	✓	✓
2000	Mustang	4.6L	4V	RCM	✓	✓	✓	✓
2000	Mustang	5.4L	Other	ABS/TCS	✓	✓	✓	✓
2000	Mustang	5.4L	Other	ABS/TCS	✓	✓	✓	✓
2000	Mustang	5.4L	Other	PCM	✓	✓	✓	✓
2002	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓
2002	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓
2002	Mustang	3.8L	Other	GEM	✓	✓	✓	✓
2002	Mustang	3.8L	Other	HEC	✓	✓	✓	✓
2002	Mustang	3.8L	Other	PCM	✓	✓	✓	✓
2002	Mustang	3.8L	Other	PCM	✓	✓	✓	✓
2002	Mustang	3.8L	Other	RCM	✓	✓	✓	✓
2002	Mustang	4.6L	2V	ABS/TCS	✓	✓	✓	✓
2002	Mustang	4.6L	2V	ABS/TCS	✓	✓	✓	✓
2002	Mustang	4.6L	2V	GEM	✓	✓	✓	✓
2002	Mustang	4.6L	2V	HEC	✓	✓	✓	✓
2002	Mustang	4.6L	2V	PCM	✓	✓	✓	✓
2002	Mustang	4.6L	2V	PCM	✓	✓	✓	✓
2002	Mustang	4.6L	2V	RCM	✓	✓	✓	✓
2003	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓
2003	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓
2003	Mustang	3.8L	Other	GEM	✓	✓	✓	✓
2003	Mustang	3.8L	Other	HEC	✓	✓	✓	✓
2003	Mustang	3.8L	Other	PCM	✓	✓	✓	✓
2003	Mustang	3.8L	Other	PCM	✓	✓	✓	✓
2003	Mustang	3.8L	Other	RCM	✓	✓	✓	✓



2003	Mustang	4.6L	2V	ABS/TCS	✓	✓	✓	✓
2003	Mustang	4.6L	2V	ABS/TCS	✓	✓	✓	✓
2003	Mustang	4.6L	2V	GEM	✓	✓	✓	✓
2003	Mustang	4.6L	2V	HEC	✓	✓	✓	✓
2003	Mustang	4.6L	2V	PCM	✓	✓	✓	✓
2003	Mustang	4.6L	2V	PCM	✓	✓	✓	✓
2003	Mustang	4.6L	2V	RCM	✓	✓	✓	✓
2003	Mustang	4.6L	4V	ABS/TCS	✓	✓	✓	✓
2003	Mustang	4.6L	4V	ABS/TCS	✓	✓	✓	✓
2003	Mustang	4.6L	4V	GEM	✓	✓	✓	✓
2003	Mustang	4.6L	4V	HEC	✓	✓	✓	✓
2003	Mustang	4.6L	4V	PCM	✓	✓	✓	✓
2003	Mustang	4.6L	4V	PCM	✓	✓	✓	✓
2003	Mustang	4.6L	4V	RCM	✓	✓	✓	✓
2004	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓
2004	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓
2004	Mustang	3.8L	Other	GEM	✓	✓	✓	✓
2004	Mustang	3.8L	Other	HEC	✓	✓	✓	✓
2004	Mustang	3.8L	Other	PCM	✓	✓	✓	✓
2004	Mustang	3.8L	Other	PCM	✓	✓	✓	✓
2004	Mustang	3.8L	Other	RCM	✓	✓	✓	✓
2004	Mustang	3.9L	Other	ABS/TCS	✓	✓	✓	✓
2004	Mustang	3.9L	Other	ABS/TCS	✓	✓	✓	✓
2004	Mustang	3.9L	Other	GEM	✓	✓	✓	✓
2004	Mustang	3.9L	Other	HEC	✓	✓	✓	✓
2004	Mustang	3.9L	Other	PCM	✓	✓	✓	✓
2004	Mustang	3.9L	Other	PCM	✓	✓	✓	✓
2004	Mustang	3.9L	Other	RCM	✓	✓	✓	✓
2004	Mustang	4.6L	2V	ABS/TCS	✓	✓	✓	✓
2004	Mustang	4.6L	2V	ABS/TCS	✓	✓	✓	✓
2004	Mustang	4.6L	2V	GEM	✓	✓	✓	✓
2004	Mustang	4.6L	2V	HEC	✓	✓	✓	✓
2004	Mustang	4.6L	2V	PCM	✓	✓	✓	✓
2004	Mustang	4.6L	2V	PCM	✓	✓	✓	✓
2004	Mustang	4.6L	2V	RCM	✓	✓	✓	✓
2004	Mustang	4.6L	4V	ABS/TCS	✓	✓	✓	✓
2004	Mustang	4.6L	4V	ABS/TCS	✓	✓	✓	✓
2004	Mustang	4.6L	4V	GEM	✓	✓	✓	✓
2004	Mustang	4.6L	4V	HEC	✓	✓	✓	✓
2004	Mustang	4.6L	4V	PCM	✓	✓	✓	✓
2004	Mustang	4.6L	4V	PCM	✓	✓	✓	✓
2004	Mustang	4.6L	4V	RCM	✓	✓	✓	✓
2005	Mustang	4.0L	V6 SOHC	ABS	✓	✓	✓	✓
2005	Mustang	4.0L	V6 SOHC	ACM	✓	✓	✓	✓
2005	Mustang	4.0L	V6 SOHC	GEM	✓	✓	✓	✓

2005	Mustang	4.0L	V6 SOHC	IC	√	√	√	√
2005	Mustang	4.0L	V6 SOHC	PCM	√	√	√	√
2005	Mustang	4.0L	V6 SOHC	PCM	√	√	√	√
2005	Mustang	4.0L	V6 SOHC	PCM	√	√	√	√
2005	Mustang	4.0L	V6 SOHC	RCM	√	√	√	√
2005	Mustang	4.6L	3V	ABS	√	√	√	√
2005	Mustang	4.6L	3V	ACM	√	√	√	√
2005	Mustang	4.6L	3V	GEM	√	√	√	√
2005	Mustang	4.6L	3V	IC	√	√	√	√
2005	Mustang	4.6L	3V	PCM	√	√	√	√
2005	Mustang	4.6L	3V	PCM	√	√	√	√
2005	Mustang	4.6L	3V	PCM	√	√	√	√
2005	Mustang	4.6L	3V	RCM	√	√	√	√
2006	Mustang	4.0L	V6 SOHC	ABS	√	√	√	√
2006	Mustang	4.0L	V6 SOHC	ABS	√	√	√	√
2006	Mustang	4.0L	V6 SOHC	ACM	√	√	√	√
2006	Mustang	4.0L	V6 SOHC	GEM	√	√	√	√
2006	Mustang	4.0L	V6 SOHC	PCM	√	√	√	√
2006	Mustang	4.0L	V6 SOHC	PCM	√	√	√	√
2006	Mustang	4.0L	V6 SOHC	PCM	√	√	√	√
2006	Mustang	4.0L	V6 SOHC	RCM	√	√	√	√
2006	Mustang	4.0L	V6 SOHC	RCM	√	√	√	√
2006	Mustang	4.6L	3V	ABS	√	√	√	√
2006	Mustang	4.6L	3V	ABS	√	√	√	√
2006	Mustang	4.6L	3V	ACM	√	√	√	√
2006	Mustang	4.6L	3V	GEM	√	√	√	√
2006	Mustang	4.6L	3V	IC	√	√	√	√
2006	Mustang	4.6L	3V	PCM	√	√	√	√
2006	Mustang	4.6L	3V	PCM	√	√	√	√
2006	Mustang	4.6L	3V	PCM	√	√	√	√
2006	Mustang	4.6L	3V	PCM	√	√	√	√
2006	Mustang	4.6L	3V	RCM	√	√	√	√
2007	Mustang	4.0L	V6 SOHC	ABS	√	√	√	√
2007	Mustang	4.0L	V6 SOHC	ABS	√	√	√	√
2007	Mustang	4.0L	V6 SOHC	ACM	√	√	√	√
2007	Mustang	4.0L	V6 SOHC	GEM	√	√	√	√
2007	Mustang	4.0L	V6 SOHC	IC	√	√	√	√
2007	Mustang	4.0L	V6 SOHC	PCM	√	√	√	√
2007	Mustang	4.0L	V6 SOHC	PCM	√	√	√	√
2007	Mustang	4.0L	V6 SOHC	PCM	√	√	√	√
2007	Mustang	4.0L	V6 SOHC	PCM	√	√	√	√
2007	Mustang	4.0L	V6 SOHC	PCM	√	√	√	√
2007	Mustang	4.0L	V6 SOHC	PCM	√	√	√	√
2007	Mustang	4.0L	V6 SOHC	RCM	√	√	√	√
2007	Mustang	4.0L	V6 SOHC	RCM	√	√	√	√

2007	Mustang	4.0L	V6 SOHC	SDARS	√	√	√	√
2007	Mustang	4.0L	V6 SOHC	SDARS	√	√	√	√
2007	Mustang	4.6L	3V	ABS	√	√	√	√
2007	Mustang	4.6L	3V	ACM	√	√	√	√
2007	Mustang	4.6L	3V	GEM	√	√	√	√
2007	Mustang	4.6L	3V	IC	√	√	√	√
2007	Mustang	4.6L	3V	PCM	√	√	√	√
2007	Mustang	4.6L	3V	PCM	√	√	√	√
2007	Mustang	4.6L	3V	PCM	√	√	√	√
2007	Mustang	4.6L	3V	PCM	√	√	√	√
2007	Mustang	4.6L	3V	PCM	√	√	√	√
2007	Mustang	4.6L	3V	PCM	√	√	√	√
2007	Mustang	4.6L	3V	RCM	√	√	√	√
2007	Mustang	4.6L	3V	SDARS	√	√	√	√
2007	Mustang	4.6L	3V	SDARS	√	√	√	√
2007	Mustang	5.4L	4V	ABS	√	√	√	√
2007	Mustang	5.4L	4V	ABS	√	√	√	√
2007	Mustang	5.4L	4V	ACM	√	√	√	√
2007	Mustang	5.4L	4V	GEM	√	√	√	√
2007	Mustang	5.4L	4V	IC	√	√	√	√
2007	Mustang	5.4L	4V	PCM	√	√	√	√
2007	Mustang	5.4L	4V	PCM	√	√	√	√
2007	Mustang	5.4L	4V	PCM	√	√	√	√
2007	Mustang	5.4L	4V	RCM	√	√	√	√
2007	Mustang	5.4L	4V	RCM	√	√	√	√
2007	Mustang	5.4L	4V	SDARS	√	√	√	√
2007	Mustang	5.4L	4V	SDARS	√	√	√	√
2008	Mustang	4.0L	V6 SOHC	ABS	√	√	√	√
2008	Mustang	4.0L	V6 SOHC	ACM	√	√	√	√
2008	Mustang	4.0L	V6 SOHC	GEM / SJB	√	√	√	√
2008	Mustang	4.0L	V6 SOHC	IC	√	√	√	√
2008	Mustang	4.0L	V6 SOHC	PCM	√	√	√	√
2008	Mustang	4.0L	V6 SOHC	PCM	√	√	√	√
2008	Mustang	4.0L	V6 SOHC	PCM	√	√	√	√
2008	Mustang	4.0L	V6 SOHC	PCM	√	√	√	√
2008	Mustang	4.0L	V6 SOHC	PCM	√	√	√	√
2008	Mustang	4.0L	V6 SOHC	PCM	√	√	√	√
2008	Mustang	4.0L	V6 SOHC	RCM	√	√	√	√
2008	Mustang	4.0L	V6 SOHC	SDARS	√	√	√	√
2008	Mustang	4.6L	3V	ABS	√	√	√	√
2008	Mustang	4.6L	3V	ACM	√	√	√	√
2008	Mustang	4.6L	3V	GEM / SJB	√	√	√	√
2008	Mustang	4.6L	3V	IC	√	√	√	√
2008	Mustang	4.6L	3V	IC	√	√	√	√
2008	Mustang	4.6L	3V	PCM	√	√	√	√

2008	Mustang	4.6L	3V	PCM	✓	✓	✓	✓
2008	Mustang	4.6L	3V	PCM	✓	✓	✓	✓
2008	Mustang	4.6L	3V	PCM	✓	✓	✓	✓
2008	Mustang	4.6L	3V	PCM	✓	✓	✓	✓
2008	Mustang	4.6L	3V	RCM	✓	✓	✓	✓
2008	Mustang	4.6L	3V	SDARS	✓	✓	✓	✓
2008	Mustang	5.4L	4V	ABS	✓	✓	✓	✓
2008	Mustang	5.4L	4V	ACM	✓	✓	✓	✓
2008	Mustang	5.4L	4V	IC	✓	✓	✓	✓
2008	Mustang	5.4L	4V	PCM	✓	✓	✓	✓
2008	Mustang	5.4L	4V	PCM	✓	✓	✓	✓
2008	Mustang	5.4L	4V	PCM	✓	✓	✓	✓
2008	Mustang	5.4L	4V	RCM	✓	✓	✓	✓
2008	Mustang	5.4L	4V	SDARS	✓	✓	✓	✓
2009	Mustang	4.0L	V6 SOHC	ABS	✓	✓	✓	✓
2009	Mustang	4.0L	V6 SOHC	ACM	✓	✓	✓	✓
2009	Mustang	4.0L	V6 SOHC	APIM	✓	✓	✓	✓
2009	Mustang	4.0L	V6 SOHC	GEM / SJB	✓	✓	✓	✓
2009	Mustang	4.0L	V6 SOHC	IC	✓	✓	✓	✓
2009	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2009	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2009	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2009	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2009	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2009	Mustang	4.0L	V6 SOHC	RCM	✓	✓	✓	✓
2009	Mustang	4.0L	V6 SOHC	SDARS	✓	✓	✓	✓
2009	Mustang	4.6L	3V	ABS	✓	✓	✓	✓
2009	Mustang	4.6L	3V	ACM	✓	✓	✓	✓
2009	Mustang	4.6L	3V	APIM	✓	✓	✓	✓
2009	Mustang	4.6L	3V	GEM / SJB	✓	✓	✓	✓
2009	Mustang	4.6L	3V	IC	✓	✓	✓	✓
2009	Mustang	4.6L	3V	PCM	✓	✓	✓	✓
2009	Mustang	4.6L	3V	PCM	✓	✓	✓	✓
2009	Mustang	4.6L	3V	PCM	✓	✓	✓	✓
2009	Mustang	4.6L	3V	PCM	✓	✓	✓	✓
2009	Mustang	4.6L	3V	PCM	✓	✓	✓	✓
2009	Mustang	4.6L	3V	RCM	✓	✓	✓	✓
2009	Mustang	4.6L	3V	SDARS	✓	✓	✓	✓
2009	Mustang	5.4L	4V	ABS	✓	✓	✓	✓
2009	Mustang	5.4L	4V	ACM	✓	✓	✓	✓
2009	Mustang	5.4L	4V	APIM	✓	✓	✓	✓
2009	Mustang	5.4L	4V	GEM / SJB	✓	✓	✓	✓
2009	Mustang	5.4L	4V	IC	✓	✓	✓	✓
2009	Mustang	5.4L	4V	PCM	✓	✓	✓	✓

2009	Mustang	5.4L	4V	PCM	✓	✓	✓	✓
2009	Mustang	5.4L	4V	RCM	✓	✓	✓	✓
2009	Mustang	5.4L	4V	SDARS	✓	✓	✓	✓
2010	Mustang	4.0L	V6 SOHC	ABS	✓	✓	✓	✓
2010	Mustang	4.0L	V6 SOHC	ACM	✓	✓	✓	✓
2010	Mustang	4.0L	V6 SOHC	APIM	✓	✓	✓	✓
2010	Mustang	4.0L	V6 SOHC	BCM-B	✓	✓	✓	✓
2010	Mustang	4.0L	V6 SOHC	FCIM	✓	✓	✓	✓
2010	Mustang	4.0L	V6 SOHC	FDIM	✓	✓	✓	✓
2010	Mustang	4.0L	V6 SOHC	GEM / SJB	✓	✓	✓	✓
2010	Mustang	4.0L	V6 SOHC	GPSM	✓	✓	✓	✓
2010	Mustang	4.0L	V6 SOHC	HVAC	✓	✓	✓	✓
2010	Mustang	4.0L	V6 SOHC	IPC	✓	✓	✓	✓
2010	Mustang	4.0L	V6 SOHC	OCSM	✓	✓	✓	✓
2010	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2010	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2010	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2010	Mustang	4.0L	V6 SOHC	RCM	✓	✓	✓	✓
2010	Mustang	4.6L	3V	ABS	✓	✓	✓	✓
2010	Mustang	4.6L	3V	ACM	✓	✓	✓	✓
2010	Mustang	4.6L	3V	APIM	✓	✓	✓	✓
2010	Mustang	4.6L	3V	BCM-B	✓	✓	✓	✓
2010	Mustang	4.6L	3V	FCIM	✓	✓	✓	✓
2010	Mustang	4.6L	3V	FDIM	✓	✓	✓	✓
2010	Mustang	4.6L	3V	GEM / SJB	✓	✓	✓	✓
2010	Mustang	4.6L	3V	GPSM	✓	✓	✓	✓
2010	Mustang	4.6L	3V	HVAC	✓	✓	✓	✓
2010	Mustang	4.6L	3V	IPC	✓	✓	✓	✓
2010	Mustang	4.6L	3V	OCSM	✓	✓	✓	✓
2010	Mustang	4.6L	3V	PCM	✓	✓	✓	✓
2010	Mustang	4.6L	3V	PCM	✓	✓	✓	✓
2010	Mustang	4.6L	3V	PCM	✓	✓	✓	✓
2010	Mustang	4.6L	3V	RCM	✓	✓	✓	✓
2010	Mustang	5.4L	4V	ABS	✓	✓	✓	✓
2010	Mustang	5.4L	4V	ACM	✓	✓	✓	✓
2010	Mustang	5.4L	4V	APIM	✓	✓	✓	✓
2010	Mustang	5.4L	4V	BCM-B	✓	✓	✓	✓
2010	Mustang	5.4L	4V	FCIM	✓	✓	✓	✓
2010	Mustang	5.4L	4V	FDIM	✓	✓	✓	✓
2010	Mustang	5.4L	4V	GPSM	✓	✓	✓	✓
2010	Mustang	5.4L	4V	HVAC	✓	✓	✓	✓
2010	Mustang	5.4L	4V	IPC	✓	✓	✓	✓
2010	Mustang	5.4L	4V	OCSM	✓	✓	✓	✓
2010	Mustang	5.4L	4V	PCM	✓	✓	✓	✓
2010	Mustang	5.4L	4V	PCM	✓	✓	✓	✓

2010	Mustang	5.4L	4V	RCM	√	√	√	√
2011	Mustang	3.7L	TiVCT	ABS	√	√	√	√
2011	Mustang	3.7L	TiVCT	ACM	√	√	√	√
2011	Mustang	3.7L	TiVCT	APIM	√	√	√	√
2011	Mustang	3.7L	TiVCT	BCM-B	√	√	√	√
2011	Mustang	3.7L	TiVCT	FCIM	√	√	√	
2011	Mustang	3.7L	TiVCT	FDIM	√	√	√	√
2011	Mustang	3.7L	TiVCT	GEM / SJB	√	√	√	√
2011	Mustang	3.7L	TiVCT	GPSM	√	√	√	√
2011	Mustang	3.7L	TiVCT	HVAC	√	√	√	√
2011	Mustang	3.7L	TiVCT	IPC	√	√	√	√
2011	Mustang	3.7L	TiVCT	OCSM	√	√	√	√
2011	Mustang	3.7L	TiVCT	PCM	√	√	√	√
2011	Mustang	3.7L	TiVCT	PCM	√	√	√	√
2011	Mustang	3.7L	TiVCT	PSCM	√	√	√	√
2011	Mustang	3.7L	TiVCT	RCM	√	√	√	√
2011	Mustang	5.0L	TiVCT	ABS	√	√	√	√
2011	Mustang	5.0L	TiVCT	ACM	√	√	√	√
2011	Mustang	5.0L	TiVCT	APIM	√	√	√	√
2011	Mustang	5.0L	TiVCT	BCM-B	√	√	√	√
2011	Mustang	5.0L	TiVCT	FCIM	√	√	√	
2011	Mustang	5.0L	TiVCT	FDIM	√	√	√	√
2011	Mustang	5.0L	TiVCT	GEM / SJB	√	√	√	√
2011	Mustang	5.0L	TiVCT	GPSM	√	√	√	√
2011	Mustang	5.0L	TiVCT	HVAC	√	√	√	√
2011	Mustang	5.0L	TiVCT	IPC	√	√	√	√
2011	Mustang	5.0L	TiVCT	OCSM	√	√	√	√
2011	Mustang	5.0L	TiVCT	PCM	√	√	√	√
2011	Mustang	5.0L	TiVCT	PCM	√	√	√	√
2011	Mustang	5.0L	TiVCT	PCM	√	√	√	√
2011	Mustang	5.0L	TiVCT	PCM	√	√	√	√
2011	Mustang	5.0L	TiVCT	PCM	√	√	√	√
2011	Mustang	5.0L	TiVCT	PCM	√	√	√	√
2011	Mustang	5.0L	TiVCT	PSCM	√	√	√	√
2011	Mustang	5.0L	TiVCT	RCM	√	√	√	√
2011	Mustang	5.4L	4V	ABS	√	√	√	√
2011	Mustang	5.4L	4V	ACM	√	√	√	√
2011	Mustang	5.4L	4V	APIM	√	√	√	√
2011	Mustang	5.4L	4V	BCM-B	√	√	√	√
2011	Mustang	5.4L	4V	FCIM	√	√	√	
2011	Mustang	5.4L	4V	FDIM	√	√	√	√
2011	Mustang	5.4L	4V	GEM / SJB	√	√	√	√
2011	Mustang	5.4L	4V	GPSM	√	√	√	√
2011	Mustang	5.4L	4V	HVAC	√	√	√	√
2011	Mustang	5.4L	4V	IPC	√	√	√	√
2011	Mustang	5.4L	4V	OCSM	√	√	√	√

2011	Mustang	5.4L	4V	PCM	✓	✓	✓	✓
2011	Mustang	5.4L	4V	PCM	✓	✓	✓	✓
2011	Mustang	5.4L	4V	PCM	✓	✓	✓	✓
2011	Mustang	5.4L	4V	PSCM	✓	✓	✓	✓
2011	Mustang	5.4L	4V	RCM	✓	✓	✓	✓
2012	Mustang	3.7L	TiVCT	ABS	✓	✓	✓	✓
2012	Mustang	3.7L	TiVCT	ACM	✓	✓	✓	
2012	Mustang	3.7L	TiVCT	APIM	✓	✓	✓	
2012	Mustang	3.7L	TiVCT	BCM-B	✓	✓	✓	✓
2012	Mustang	3.7L	TiVCT	FCIM	✓	✓	✓	
2012	Mustang	3.7L	TiVCT	FDIM	✓	✓	✓	✓
2012	Mustang	3.7L	TiVCT	GEM / SJB	✓	✓	✓	✓
2012	Mustang	3.7L	TiVCT	GPSM	✓	✓	✓	✓
2012	Mustang	3.7L	TiVCT	HVAC	✓	✓	✓	✓
2012	Mustang	3.7L	TiVCT	IPC	✓	✓	✓	✓
2012	Mustang	3.7L	TiVCT	OCSM	✓	✓	✓	✓
2012	Mustang	3.7L	TiVCT	PAM	✓	✓	✓	
2012	Mustang	3.7L	TiVCT	PCM	✓	✓	✓	✓
2012	Mustang	3.7L	TiVCT	PCM	✓	✓	✓	✓
2012	Mustang	3.7L	TiVCT	PSCM	✓	✓	✓	✓
2012	Mustang	3.7L	TiVCT	RCM	✓	✓	✓	✓
2012	Mustang	5.0L	BOSS	ABS	✓	✓	✓	✓
2012	Mustang	5.0L	BOSS	ACM	✓	✓	✓	
2012	Mustang	5.0L	BOSS	APIM	✓	✓	✓	
2012	Mustang	5.0L	BOSS	BCM-B	✓	✓	✓	✓
2012	Mustang	5.0L	BOSS	FCIM	✓	✓	✓	
2012	Mustang	5.0L	BOSS	GEM / SJB	✓	✓	✓	✓
2012	Mustang	5.0L	BOSS	GPSM	✓	✓	✓	✓
2012	Mustang	5.0L	BOSS	HVAC	✓	✓	✓	✓
2012	Mustang	5.0L	BOSS	IPC	✓	✓	✓	✓
2012	Mustang	5.0L	BOSS	OCSM	✓	✓	✓	✓
2012	Mustang	5.0L	BOSS	PAM	✓	✓	✓	
2012	Mustang	5.0L	BOSS	PCM	✓	✓	✓	✓
2012	Mustang	5.0L	BOSS	PCM	✓	✓	✓	✓
2012	Mustang	5.0L	BOSS	PCM	✓	✓	✓	✓
2012	Mustang	5.0L	BOSS	PSCM	✓	✓	✓	✓
2012	Mustang	5.0L	BOSS	RCM	✓	✓	✓	✓
2012	Mustang	5.0L	TiVCT	ABS	✓	✓	✓	✓
2012	Mustang	5.0L	TiVCT	ACM	✓	✓	✓	
2012	Mustang	5.0L	TiVCT	APIM	✓	✓	✓	
2012	Mustang	5.0L	TiVCT	BCM-B	✓	✓	✓	✓
2012	Mustang	5.0L	TiVCT	FCIM	✓	✓	✓	
2012	Mustang	5.0L	TiVCT	FDIM	✓	✓	✓	✓
2012	Mustang	5.0L	TiVCT	GEM / SJB	✓	✓	✓	✓
2012	Mustang	5.0L	TiVCT	GPSM	✓	✓	✓	✓

2012	Mustang	5.0L	TiVCT	HVAC	✓	✓	✓	✓
2012	Mustang	5.0L	TiVCT	IPC	✓	✓	✓	✓
2012	Mustang	5.0L	TiVCT	OCSM	✓	✓	✓	✓
2012	Mustang	5.0L	TiVCT	PAM	✓	✓	✓	
2012	Mustang	5.0L	TiVCT	PCM	✓	✓	✓	✓
2012	Mustang	5.0L	TiVCT	PCM	✓	✓	✓	✓
2012	Mustang	5.0L	TiVCT	PCM	✓	✓	✓	✓
2012	Mustang	5.0L	TiVCT	PCM	✓	✓	✓	✓
2012	Mustang	5.0L	TiVCT	PCM	✓	✓	✓	✓
2012	Mustang	5.0L	TiVCT	PSCM	✓	✓	✓	✓
2012	Mustang	5.0L	TiVCT	RCM	✓	✓	✓	✓
2012	Mustang	5.4L	4V	ABS	✓	✓	✓	✓
2012	Mustang	5.4L	4V	ACM	✓	✓	✓	
2012	Mustang	5.4L	4V	APIM	✓	✓	✓	
2012	Mustang	5.4L	4V	BCM-B	✓	✓	✓	✓
2012	Mustang	5.4L	4V	FCIM	✓	✓	✓	
2012	Mustang	5.4L	4V	FDIM	✓	✓	✓	✓
2012	Mustang	5.4L	4V	GEM / SJB	✓	✓	✓	✓
2012	Mustang	5.4L	4V	GPSM	✓	✓	✓	✓
2012	Mustang	5.4L	4V	HVAC	✓	✓	✓	✓
2012	Mustang	5.4L	4V	IPC	✓	✓	✓	✓
2012	Mustang	5.4L	4V	OCSM	✓	✓	✓	✓
2012	Mustang	5.4L	4V	PAM	✓	✓	✓	
2012	Mustang	5.4L	4V	PCM	✓	✓	✓	✓
2012	Mustang	5.4L	4V	PCM	✓	✓	✓	✓
2012	Mustang	5.4L	4V	PSCM	✓	✓	✓	✓
2012	Mustang	5.4L	4V	RCM	✓	✓	✓	✓
2013	Mustang	3.7L	TiVCT	ABS	✓	✓	✓	✓
2013	Mustang	3.7L	TiVCT	ACM	✓	✓	✓	✓
2013	Mustang	3.7L	TiVCT	APIM	✓	✓	✓	✓
2013	Mustang	3.7L	TiVCT	BCM-B	✓	✓	✓	✓
2013	Mustang	3.7L	TiVCT	FCIM	✓	✓	✓	
2013	Mustang	3.7L	TiVCT	FDIM	✓	✓	✓	✓
2013	Mustang	3.7L	TiVCT	GEM / SJB	✓	✓	✓	✓
2013	Mustang	3.7L	TiVCT	GPSM	✓	✓	✓	✓
2013	Mustang	3.7L	TiVCT	HVAC	✓	✓	✓	✓
2013	Mustang	3.7L	TiVCT	IPC	✓	✓	✓	✓
2013	Mustang	3.7L	TiVCT	OCSM	✓	✓	✓	✓
2013	Mustang	3.7L	TiVCT	PAM	✓	✓	✓	
2013	Mustang	3.7L	TiVCT	PCM	✓	✓	✓	✓
2013	Mustang	3.7L	TiVCT	PCM	✓	✓	✓	✓
2013	Mustang	3.7L	TiVCT	PCM	✓	✓	✓	✓
2013	Mustang	3.7L	TiVCT	PCM	✓	✓	✓	✓
2013	Mustang	3.7L	TiVCT	PSCM	✓	✓	✓	✓
2013	Mustang	3.7L	TiVCT	RCM	✓	✓	✓	✓



2013	Mustang	5.0L	BOSS	ABS	√	√	√	√
2013	Mustang	5.0L	BOSS	ACM	√	√	√	√
2013	Mustang	5.0L	BOSS	APIM	√	√	√	√
2013	Mustang	5.0L	BOSS	BCM-B	√	√	√	√
2013	Mustang	5.0L	BOSS	FCIM	√	√	√	
2013	Mustang	5.0L	BOSS	FDIM	√	√	√	√
2013	Mustang	5.0L	BOSS	GEM / SJB	√	√	√	√
2013	Mustang	5.0L	BOSS	GPSM	√	√	√	√
2013	Mustang	5.0L	BOSS	HVAC	√	√	√	√
2013	Mustang	5.0L	BOSS	IPC	√	√	√	√
2013	Mustang	5.0L	BOSS	OCSM	√	√	√	√
2013	Mustang	5.0L	BOSS	PAM	√	√	√	
2013	Mustang	5.0L	BOSS	PCM	√	√	√	√
2013	Mustang	5.0L	BOSS	PCM	√	√	√	√
2013	Mustang	5.0L	BOSS	PCM	√	√	√	√
2013	Mustang	5.0L	BOSS	PSCM	√	√	√	√
2013	Mustang	5.0L	BOSS	RCM	√	√	√	√
2013	Mustang	5.0L	TiVCT	ABS	√	√	√	√
2013	Mustang	5.0L	TiVCT	ABS	√	√	√	√
2013	Mustang	5.0L	TiVCT	ACM	√	√	√	√
2013	Mustang	5.0L	TiVCT	APIM	√	√	√	√
2013	Mustang	5.0L	TiVCT	BCM-B	√	√	√	√
2013	Mustang	5.0L	TiVCT	BCM-B	√	√	√	√
2013	Mustang	5.0L	TiVCT	FCIM	√	√	√	
2013	Mustang	5.0L	TiVCT	FDIM	√	√	√	√
2013	Mustang	5.0L	TiVCT	GEM / SJB	√	√	√	√
2013	Mustang	5.0L	TiVCT	GEM / SJB	√	√	√	√
2013	Mustang	5.0L	TiVCT	GPSM	√	√	√	√
2013	Mustang	5.0L	TiVCT	HVAC	√	√	√	√
2013	Mustang	5.0L	TiVCT	IPC	√	√	√	√
2013	Mustang	5.0L	TiVCT	OCSM	√	√	√	√
2013	Mustang	5.0L	TiVCT	PAM	√	√	√	
2013	Mustang	5.0L	TiVCT	PAM	√	√	√	√
2013	Mustang	5.0L	TiVCT	PCM	√	√	√	√
2013	Mustang	5.0L	TiVCT	PCM	√	√	√	√
2013	Mustang	5.0L	TiVCT	PCM	√	√	√	√
2013	Mustang	5.0L	TiVCT	PCM	√	√	√	√
2013	Mustang	5.0L	TiVCT	PCM	√	√	√	√
2013	Mustang	5.0L	TiVCT	PSCM	√	√	√	√
2013	Mustang	5.0L	TiVCT	RCM	√	√	√	√
2013	Mustang	5.8L	4V	ABS	√	√	√	√
2013	Mustang	5.8L	4V	ACM	√	√	√	√
2013	Mustang	5.8L	4V	APIM	√	√	√	√
2013	Mustang	5.8L	4V	BCM-B	√	√	√	√
2013	Mustang	5.8L	4V	FCIM	√	√	√	
2013	Mustang	5.8L	4V	FDIM	√	√	√	√

2013	Mustang	5.8L	4V	GEM / SJB	✓	✓	✓	✓
2013	Mustang	5.8L	4V	GPSM	✓	✓	✓	✓
2013	Mustang	5.8L	4V	HVAC	✓	✓	✓	✓
2013	Mustang	5.8L	4V	IPC	✓	✓	✓	✓
2013	Mustang	5.8L	4V	OCSM	✓	✓	✓	✓
2013	Mustang	5.8L	4V	PAM	✓	✓	✓	
2013	Mustang	5.8L	4V	PCM	✓	✓	✓	✓
2013	Mustang	5.8L	4V	PCM	✓	✓	✓	✓
2013	Mustang	5.8L	4V	PSCM	✓	✓	✓	✓
2013	Mustang	5.8L	4V	RCM	✓	✓	✓	✓
2013	Mustang	5.8L	4V	VDM	✓	✓	✓	✓
2014	Mustang	3.7L	TiVCT	ABS	✓	✓	✓	✓
2014	Mustang	3.7L	TiVCT	ACM	✓	✓	✓	✓
2014	Mustang	3.7L	TiVCT	APIM	✓	✓	✓	✓
2014	Mustang	3.7L	TiVCT	BCM-B	✓	✓	✓	✓
2014	Mustang	3.7L	TiVCT	FCIM	✓	✓	✓	
2014	Mustang	3.7L	TiVCT	FDIM	✓	✓	✓	✓
2014	Mustang	3.7L	TiVCT	GEM / SJB	✓	✓	✓	✓
2014	Mustang	3.7L	TiVCT	GPSM	✓	✓	✓	✓
2014	Mustang	3.7L	TiVCT	HVAC	✓	✓	✓	✓
2014	Mustang	3.7L	TiVCT	IPC	✓	✓	✓	✓
2014	Mustang	3.7L	TiVCT	OCSM	✓	✓	✓	✓
2014	Mustang	3.7L	TiVCT	PAM	✓	✓	✓	✓
2014	Mustang	3.7L	TiVCT	PCM	✓	✓	✓	✓
2014	Mustang	3.7L	TiVCT	PCM	✓	✓	✓	✓
2014	Mustang	3.7L	TiVCT	PCM	✓	✓	✓	✓
2014	Mustang	3.7L	TiVCT	PCM	✓	✓	✓	✓
2014	Mustang	3.7L	TiVCT	PSCM	✓	✓	✓	✓
2014	Mustang	3.7L	TiVCT	RCM	✓	✓	✓	✓
2014	Mustang	5.0L	TiVCT	ABS	✓	✓	✓	✓
2014	Mustang	5.0L	TiVCT	ABS	✓	✓	✓	✓
2014	Mustang	5.0L	TiVCT	ACM	✓	✓	✓	✓
2014	Mustang	5.0L	TiVCT	APIM	✓	✓	✓	✓
2014	Mustang	5.0L	TiVCT	APIM	✓	✓	✓	✓
2014	Mustang	5.0L	TiVCT	BCM-B	✓	✓	✓	✓
2014	Mustang	5.0L	TiVCT	FCIM	✓	✓	✓	
2014	Mustang	5.0L	TiVCT	FDIM	✓	✓	✓	✓
2014	Mustang	5.0L	TiVCT	GEM / SJB	✓	✓	✓	✓
2014	Mustang	5.0L	TiVCT	GEM / SJB	✓	✓	✓	✓
2014	Mustang	5.0L	TiVCT	GPSM	✓	✓	✓	✓
2014	Mustang	5.0L	TiVCT	HVAC	✓	✓	✓	✓
2014	Mustang	5.0L	TiVCT	IPC	✓	✓	✓	✓
2014	Mustang	5.0L	TiVCT	OCSM	✓	✓	✓	✓
2014	Mustang	5.0L	TiVCT	PAM	✓	✓	✓	✓
2014	Mustang	5.0L	TiVCT	PCM	✓	✓	✓	✓

2014	Mustang	5.0L	TiVCT	PCM	√	√	√	√
2014	Mustang	5.0L	TiVCT	PCM	√	√	√	√
2014	Mustang	5.0L	TiVCT	PCM	√	√	√	√
2014	Mustang	5.0L	TiVCT	PSCM	√	√	√	√
2014	Mustang	5.0L	TiVCT	RCM	√	√	√	√
2014	Mustang	Other	Other	ABS	√	√	√	√
2014	Mustang	Other	Other	APIM	√	√	√	√
2014	Mustang	Other	Other	BCM-B	√	√	√	√
2014	Mustang	Other	Other	FCIM	√	√	√	
2014	Mustang	Other	Other	FDIM	√	√	√	√
2014	Mustang	Other	Other	GEM / SJB	√	√	√	√
2014	Mustang	Other	Other	GPSM	√	√	√	√
2014	Mustang	Other	Other	HVAC	√	√	√	√
2014	Mustang	Other	Other	IPC	√	√	√	√
2014	Mustang	Other	Other	OCSM	√	√	√	√
2014	Mustang	Other	Other	PAM	√	√	√	√
2014	Mustang	Other	Other	PCM	√	√	√	√
2014	Mustang	Other	Other	PSCM	√	√	√	√
2014	Mustang	Other	Other	RCM	√	√	√	√
1996	Mystique	2.0L	Zetec	ABS/TCS	√	√	√	√
1996	Mystique	2.0L	Zetec	CSM	√	√	√	√
1996	Mystique	2.0L	Zetec	PCM	√	√	√	√
1996	Mystique	2.5L	Duratec-VE	ABS/TCS	√	√	√	√
1996	Mystique	2.5L	Duratec-VE	CSM	√	√	√	√
1996	Mystique	2.5L	Duratec-VE	PCM	√	√	√	√
1997	Mystique	2.0L	Zetec	ABS/TCS	√	√	√	√
1997	Mystique	2.0L	Zetec	CSM	√	√	√	√
1997	Mystique	2.0L	Zetec	PATS	√	√	√	√
1997	Mystique	2.0L	Zetec	PCM	√	√	√	√
1997	Mystique	2.5L	Duratec-VE	ABS/TCS	√	√	√	√
1997	Mystique	2.5L	Duratec-VE	CSM	√	√	√	√
1997	Mystique	2.5L	Duratec-VE	PATS	√	√	√	√
1997	Mystique	2.5L	Duratec-VE	PCM	√	√	√	√
1998	Mystique	2.0L	Zetec	ABS/TCS	√	√	√	√
1998	Mystique	2.0L	Zetec	ABS/TCS	√	√	√	√
1998	Mystique	2.0L	Zetec	CSM	√	√	√	√
1998	Mystique	2.0L	Zetec	PATS	√	√	√	√
1998	Mystique	2.0L	Zetec	PCM	√	√	√	√
1998	Mystique	2.5L	Duratec-VE	ABS/TCS	√	√	√	√
1998	Mystique	2.5L	Duratec-VE	ABS/TCS	√	√	√	√
1998	Mystique	2.5L	Duratec-VE	CSM	√	√	√	√
1998	Mystique	2.5L	Duratec-VE	PATS	√	√	√	√
1998	Mystique	2.5L	Duratec-VE	PCM	√	√	√	√
1999	Mystique	2.0L	Zetec	ABS/TCS	√	√	√	√
1999	Mystique	2.0L	Zetec	CSM	√	√	√	√

1999	Mystique	2.0L	Zetec	PCM	✓	✓	✓	✓
1999	Mystique	2.0L	Zetec	RCM	✓	✓	✓	✓
1999	Mystique	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓
1999	Mystique	2.5L	Duratec-VE	CSM	✓	✓	✓	✓
1999	Mystique	2.5L	Duratec-VE	PCM	✓	✓	✓	✓
1999	Mystique	2.5L	Duratec-VE	RCM	✓	✓	✓	✓
2000	Mystique	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓
2000	Mystique	2.0L	Zetec	CSM	✓	✓	✓	✓
2000	Mystique	2.0L	Zetec	PCM	✓	✓	✓	✓
2000	Mystique	2.0L	Zetec	RCM	✓	✓	✓	✓
2000	Mystique	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓
2000	Mystique	2.5L	Duratec-VE	CSM	✓	✓	✓	✓
2000	Mystique	2.5L	Duratec-VE	PCM	✓	✓	✓	✓
2000	Mystique	2.5L	Duratec-VE	RCM	✓	✓	✓	✓
2008	NOVO KA	1.0L	FFV	IC	✓	✓	✓	✓
2008	NOVO KA	1.0L	FFV	PCM	✓	✓	✓	✓
2008	NOVO KA	1.0L	FFV	RCM	✓	✓	✓	✓
2008	NOVO KA	1.0L	FFV	RKE	✓	✓	✓	✓
2008	NOVO KA	1.0L	Zetec Rocam	IC	✓	✓	✓	✓
2008	NOVO KA	1.0L	Zetec Rocam	PCM	✓	✓	✓	✓
2008	NOVO KA	1.0L	Zetec Rocam	RCM	✓	✓	✓	✓
2008	NOVO KA	1.0L	Zetec Rocam	RKE	✓	✓	✓	✓
2008	NOVO KA	1.6L	FFV	IC	✓	✓	✓	✓
2008	NOVO KA	1.6L	FFV	PCM	✓	✓	✓	✓
2008	NOVO KA	1.6L	FFV	RCM	✓	✓	✓	✓
2008	NOVO KA	1.6L	FFV	RKE	✓	✓	✓	✓
2008	NOVO KA	1.6L	Zetec Rocam	IC	✓	✓	✓	✓
2008	NOVO KA	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓
2008	NOVO KA	1.6L	Zetec Rocam	RCM	✓	✓	✓	✓
2008	NOVO KA	1.6L	Zetec Rocam	RKE	✓	✓	✓	✓
2008	NOVO KA	Other	Other	IC	✓	✓	✓	✓
2008	NOVO KA	Other	Other	PCM	✓	✓	✓	✓
2008	NOVO KA	Other	Other	RCM	✓	✓	✓	✓
2008	NOVO KA	Other	Other	RKE	✓	✓	✓	✓
2009	NOVO KA	1.0L	FFV	IC	✓	✓	✓	✓
2009	NOVO KA	1.0L	FFV	PCM	✓	✓	✓	✓
2009	NOVO KA	1.0L	FFV	RCM	✓	✓	✓	✓
2009	NOVO KA	1.0L	FFV	RKE	✓	✓	✓	✓
2009	NOVO KA	1.0L	FFV	TBM	✓	✓	✓	✓
2009	NOVO KA	1.0L	Zetec Rocam	IC	✓	✓	✓	✓
2009	NOVO KA	1.0L	Zetec Rocam	PCM	✓	✓	✓	✓
2009	NOVO KA	1.0L	Zetec Rocam	RCM	✓	✓	✓	✓
2009	NOVO KA	1.0L	Zetec Rocam	RKE	✓	✓	✓	✓
2009	NOVO KA	1.0L	Zetec Rocam	TBM	✓	✓	✓	✓
2009	NOVO KA	1.6L	FFV	IC	✓	✓	✓	✓

2009	NOVO KA	1.6L	FFV	PCM	√	√	√	√
2009	NOVO KA	1.6L	FFV	RCM	√	√	√	√
2009	NOVO KA	1.6L	FFV	RKE	√	√	√	√
2009	NOVO KA	1.6L	FFV	TBM	√	√	√	√
2009	NOVO KA	1.6L	Zetec Rocam	PCM	√	√	√	√
2009	NOVO KA	1.6L	Zetec Rocam	PCM	√	√	√	√
2009	NOVO KA	1.6L	Zetec Rocam	RCM	√	√	√	√
2009	NOVO KA	1.6L	Zetec Rocam	RKE	√	√	√	√
2009	NOVO KA	1.6L	Zetec Rocam	TBM	√	√	√	√
2011	NOVO KA	1.0L	FFV	IC	√	√	√	√
2011	NOVO KA	1.0L	FFV	PCM	√	√	√	√
2011	NOVO KA	1.0L	FFV	RCM	√	√	√	√
2011	NOVO KA	1.0L	FFV	RKE	√	√	√	√
2011	NOVO KA	1.0L	FFV	TBM	√	√	√	√
2011	NOVO KA	1.6L	FFV	IC	√	√	√	√
2011	NOVO KA	1.6L	FFV	PCM	√	√	√	√
2011	NOVO KA	1.6L	FFV	RCM	√	√	√	√
2011	NOVO KA	1.6L	FFV	RKE	√	√	√	√
2011	NOVO KA	1.6L	FFV	TBM	√	√	√	√
1998	Navigator	5.4L	Other	4WAS	√	√	√	√
1998	Navigator	5.4L	Other	ABS/TCS	√	√	√	√
1998	Navigator	5.4L	Other	DSM	√	√	√	√
1998	Navigator	5.4L	Other	GEM	√	√	√	√
1998	Navigator	5.4L	Other	IAB	√	√	√	√
1998	Navigator	5.4L	Other	PATS	√	√	√	√
1998	Navigator	5.4L	Other	PCM	√	√	√	√
1998	Navigator	5.4L	Other	RAP	√	√	√	√
1998	Navigator	5.4L	Other	RCC	√	√	√	√
1999	Navigator	5.4L	4V	4WAS	√	√	√	√
1999	Navigator	5.4L	4V	4WAS	√	√	√	√
1999	Navigator	5.4L	4V	ABS/TCS	√	√	√	√
1999	Navigator	5.4L	4V	DSM	√	√	√	√
1999	Navigator	5.4L	4V	EATC	√	√	√	√
1999	Navigator	5.4L	4V	GEM	√	√	√	√
1999	Navigator	5.4L	4V	HEC	√	√	√	√
1999	Navigator	5.4L	4V	PCM	√	√	√	√
1999	Navigator	5.4L	4V	PCM	√	√	√	√
1999	Navigator	5.4L	4V	RAP	√	√	√	√
1999	Navigator	5.4L	4V	RCM	√	√	√	√
2000	Navigator	5.4L	4V	4WAS	√	√	√	√
2000	Navigator	5.4L	4V	ABS/TCS	√	√	√	√
2000	Navigator	5.4L	4V	DSM	√	√	√	√
2000	Navigator	5.4L	4V	EATC	√	√	√	√
2000	Navigator	5.4L	4V	GEM	√	√	√	√
2000	Navigator	5.4L	4V	HEC	√	√	√	√

2000	Navigator	5.4L	4V	PAM	✓	✓	✓	✓
2000	Navigator	5.4L	4V	PCM	✓	✓	✓	✓
2000	Navigator	5.4L	4V	RAP	✓	✓	✓	✓
2000	Navigator	5.4L	4V	RCM	✓	✓	✓	✓
2003	Navigator	5.4L	4V	4X4	✓	✓	✓	✓
2003	Navigator	5.4L	4V	ABS/TCS	✓	✓	✓	✓
2003	Navigator	5.4L	4V	DCSM	✓	✓	✓	✓
2003	Navigator	5.4L	4V	DSM	✓	✓	✓	✓
2003	Navigator	5.4L	4V	EATC	✓	✓	✓	✓
2003	Navigator	5.4L	4V	HEC	✓	✓	✓	✓
2003	Navigator	5.4L	4V	LTM	✓	✓	✓	✓
2003	Navigator	5.4L	4V	NAV	✓	✓	✓	✓
2003	Navigator	5.4L	4V	PAM	✓	✓	✓	✓
2003	Navigator	5.4L	4V	PCM	✓	✓	✓	✓
2003	Navigator	5.4L	4V	PCM	✓	✓	✓	✓
2003	Navigator	5.4L	4V	PCSM	✓	✓	✓	✓
2003	Navigator	5.4L	4V	RCM	✓	✓	✓	✓
2003	Navigator	5.4L	4V	TPM	✓	✓	✓	✓
2003	Navigator	5.4L	4V	VDM	✓	✓	✓	✓
2003	Navigator	5.4L	4V	VSM	✓	✓	✓	✓
2004	Navigator	5.4L	4V	4X4	✓	✓	✓	✓
2004	Navigator	5.4L	4V	ABS/TCS	✓	✓	✓	✓
2004	Navigator	5.4L	4V	DCSM	✓	✓	✓	✓
2004	Navigator	5.4L	4V	DSM	✓	✓	✓	✓
2004	Navigator	5.4L	4V	EATC	✓	✓	✓	✓
2004	Navigator	5.4L	4V	HEC	✓	✓	✓	✓
2004	Navigator	5.4L	4V	LTM	✓	✓	✓	✓
2004	Navigator	5.4L	4V	NAV	✓	✓	✓	✓
2004	Navigator	5.4L	4V	PAM	✓	✓	✓	✓
2004	Navigator	5.4L	4V	PCM	✓	✓	✓	✓
2004	Navigator	5.4L	4V	PCM	✓	✓	✓	✓
2004	Navigator	5.4L	4V	PCSM	✓	✓	✓	✓
2004	Navigator	5.4L	4V	RCM	✓	✓	✓	✓
2004	Navigator	5.4L	4V	TPM	✓	✓	✓	✓
2004	Navigator	5.4L	4V	VDM	✓	✓	✓	✓
2004	Navigator	5.4L	4V	VSM	✓	✓	✓	✓
2005	Navigator	5.4L	3V	4X4	✓	✓	✓	✓
2005	Navigator	5.4L	3V	ABS	✓	✓	✓	✓
2005	Navigator	5.4L	3V	ABS	✓	✓	✓	✓
2005	Navigator	5.4L	3V	DCSM	✓	✓	✓	✓
2005	Navigator	5.4L	3V	DSM	✓	✓	✓	✓
2005	Navigator	5.4L	3V	DSM	✓	✓	✓	✓
2005	Navigator	5.4L	3V	EATC	✓	✓	✓	✓
2005	Navigator	5.4L	3V	EATC	✓	✓	✓	✓
2005	Navigator	5.4L	3V	IC	✓	✓	✓	✓



2006	Navigator	5.4L	3V	VSM	√	√	√	√
2007	Navigator	5.4L	3V	4X4	√	√	√	√
2007	Navigator	5.4L	3V	ABS	√	√	√	√
2007	Navigator	5.4L	3V	ABS	√	√	√	√
2007	Navigator	5.4L	3V	ACM	√	√	√	√
2007	Navigator	5.4L	3V	ACM	√	√	√	√
2007	Navigator	5.4L	3V	DCSM	√	√	√	√
2007	Navigator	5.4L	3V	DCSM	√	√	√	√
2007	Navigator	5.4L	3V	DSM	√	√	√	√
2007	Navigator	5.4L	3V	DSM	√	√	√	√
2007	Navigator	5.4L	3V	DSM	√	√	√	√
2007	Navigator	5.4L	3V	DSP	√	√	√	√
2007	Navigator	5.4L	3V	DSP	√	√	√	√
2007	Navigator	5.4L	3V	EATC	√	√	√	√
2007	Navigator	5.4L	3V	GEM	√	√	√	√
2007	Navigator	5.4L	3V	GEM	√	√	√	√
2007	Navigator	5.4L	3V	IC	√	√	√	√
2007	Navigator	5.4L	3V	IC	√	√	√	√
2007	Navigator	5.4L	3V	IC	√	√	√	√
2007	Navigator	5.4L	3V	LTM	√	√	√	√
2007	Navigator	5.4L	3V	PAM	√	√	√	
2007	Navigator	5.4L	3V	PCM	√	√	√	√
2007	Navigator	5.4L	3V	PCM	√	√	√	√
2007	Navigator	5.4L	3V	PCM	√	√	√	√
2007	Navigator	5.4L	3V	PRB	√	√	√	√
2007	Navigator	5.4L	3V	RCM	√	√	√	√
2007	Navigator	5.4L	3V	RCM	√	√	√	√
2007	Navigator	5.4L	3V	RCM	√	√	√	√
2007	Navigator	5.4L	3V	RCU	√	√	√	
2007	Navigator	5.4L	3V	RCU	√	√	√	
2007	Navigator	5.4L	3V	RETM	√	√	√	
2007	Navigator	5.4L	3V	RETM	√	√	√	
2007	Navigator	5.4L	3V	SDARS	√	√	√	√
2007	Navigator	5.4L	3V	SDARS	√	√	√	√
2007	Navigator	5.4L	3V	SDARS	√	√	√	√
2007	Navigator	5.4L	3V	TCM	√	√	√	√
2007	Navigator	5.4L	3V	VDM	√	√	√	√
2007	Navigator	5.4L	3V	VDM	√	√	√	√
2008	Navigator	5.4L	3V	4X4	√	√	√	√
2008	Navigator	5.4L	3V	ABS	√	√	√	√
2008	Navigator	5.4L	3V	ABS	√	√	√	√
2008	Navigator	5.4L	3V	ACM	√	√	√	√
2008	Navigator	5.4L	3V	ACM	√	√	√	√
2008	Navigator	5.4L	3V	APIM	√	√	√	√
2008	Navigator	5.4L	3V	APIM	√	√	√	√



2008	Navigator	5.4L	3V	DCSM	√	√	√	√
2008	Navigator	5.4L	3V	DCSM	√	√	√	√
2008	Navigator	5.4L	3V	DSM	√	√	√	√
2008	Navigator	5.4L	3V	DSM	√	√	√	√
2008	Navigator	5.4L	3V	DSP	√	√	√	√
2008	Navigator	5.4L	3V	DSP	√	√	√	√
2008	Navigator	5.4L	3V	GEM / SJB	√	√	√	√
2008	Navigator	5.4L	3V	HVAC	√	√	√	√
2008	Navigator	5.4L	3V	IC	√	√	√	√
2008	Navigator	5.4L	3V	IC	√	√	√	√
2008	Navigator	5.4L	3V	LTM	√	√	√	√
2008	Navigator	5.4L	3V	PAM	√	√	√	
2008	Navigator	5.4L	3V	PCM	√	√	√	√
2008	Navigator	5.4L	3V	PCM	√	√	√	√
2008	Navigator	5.4L	3V	PCM	√	√	√	√
2008	Navigator	5.4L	3V	PCM	√	√	√	√
2008	Navigator	5.4L	3V	PRB	√	√	√	√
2008	Navigator	5.4L	3V	RCM	√	√	√	√
2008	Navigator	5.4L	3V	RCM	√	√	√	√
2008	Navigator	5.4L	3V	RCU	√	√	√	√
2008	Navigator	5.4L	3V	RCU	√	√	√	√
2008	Navigator	5.4L	3V	RETM	√	√	√	
2008	Navigator	5.4L	3V	RETM	√	√	√	
2008	Navigator	5.4L	3V	SDARS	√	√	√	√
2008	Navigator	5.4L	3V	SDARS	√	√	√	√
2008	Navigator	5.4L	3V	TCM	√	√	√	√
2008	Navigator	5.4L	3V	VDM	√	√	√	√
2008	Navigator	5.4L	3V	VDM	√	√	√	√
2009	Navigator	5.4L	3V	4X4	√	√	√	√
2009	Navigator	5.4L	3V	ABS	√	√	√	√
2009	Navigator	5.4L	3V	ABS	√	√	√	√
2009	Navigator	5.4L	3V	ACM	√	√	√	√
2009	Navigator	5.4L	3V	ACM	√	√	√	√
2009	Navigator	5.4L	3V	APIM	√	√	√	√
2009	Navigator	5.4L	3V	APIM	√	√	√	√
2009	Navigator	5.4L	3V	DCSM	√	√	√	√
2009	Navigator	5.4L	3V	DSM	√	√	√	√
2009	Navigator	5.4L	3V	DSP	√	√	√	√
2009	Navigator	5.4L	3V	GEM / SJB	√	√	√	√
2009	Navigator	5.4L	3V	GEM / SJB	√	√	√	√
2009	Navigator	5.4L	3V	HVAC	√	√	√	√
2009	Navigator	5.4L	3V	IC	√	√	√	√
2009	Navigator	5.4L	3V	LTM	√	√	√	√
2009	Navigator	5.4L	3V	PAM	√	√	√	√
2009	Navigator	5.4L	3V	PCM	√	√	√	√

2009	Navigator	5.4L	3V	PRB	√	√	√	√
2009	Navigator	5.4L	3V	RCM	√	√	√	√
2009	Navigator	5.4L	3V	RCU	√	√	√	√
2009	Navigator	5.4L	3V	RETM	√	√	√	
2009	Navigator	5.4L	3V	SDARS	√	√	√	√
2009	Navigator	5.4L	3V	TCM	√	√	√	√
2009	Navigator	5.4L	3V	VDM	√	√	√	√
2009	Navigator	5.4L	3V	VDM	√	√	√	√
2010	Navigator	5.4L	3V	4X4	√	√	√	√
2010	Navigator	5.4L	3V	ABS	√	√	√	√
2010	Navigator	5.4L	3V	ABS	√	√	√	√
2010	Navigator	5.4L	3V	ACM	√	√	√	√
2010	Navigator	5.4L	3V	ACM	√	√	√	√
2010	Navigator	5.4L	3V	APIM	√	√	√	√
2010	Navigator	5.4L	3V	APIM	√	√	√	√
2010	Navigator	5.4L	3V	DCSM	√	√	√	√
2010	Navigator	5.4L	3V	DSM	√	√	√	√
2010	Navigator	5.4L	3V	DSP	√	√	√	√
2010	Navigator	5.4L	3V	GEM / SJB	√	√	√	√
2010	Navigator	5.4L	3V	GEM / SJB	√	√	√	√
2010	Navigator	5.4L	3V	GPSM	√	√	√	√
2010	Navigator	5.4L	3V	HVAC	√	√	√	√
2010	Navigator	5.4L	3V	IC	√	√	√	√
2010	Navigator	5.4L	3V	LTM	√	√	√	√
2010	Navigator	5.4L	3V	PAM	√	√	√	√
2010	Navigator	5.4L	3V	PCM	√	√	√	√
2010	Navigator	5.4L	3V	PCM	√	√	√	√
2010	Navigator	5.4L	3V	PCM	√	√	√	√
2010	Navigator	5.4L	3V	PRB	√	√	√	√
2010	Navigator	5.4L	3V	RCM	√	√	√	√
2010	Navigator	5.4L	3V	RCU	√	√	√	√
2010	Navigator	5.4L	3V	RETM	√	√	√	√
2010	Navigator	5.4L	3V	SDARS	√	√	√	√
2010	Navigator	5.4L	3V	TCCM	√	√	√	√
2010	Navigator	5.4L	3V	TCM	√	√	√	√
2010	Navigator	5.4L	3V	VDM	√	√	√	√
2010	Navigator	5.4L	3V	VDM	√	√	√	√
2011	Navigator	5.4L	3V	ABS	√	√	√	√
2011	Navigator	5.4L	3V	ABS	√	√	√	√
2011	Navigator	5.4L	3V	ACM	√	√	√	
2011	Navigator	5.4L	3V	ACM	√	√	√	
2011	Navigator	5.4L	3V	ACM	√	√	√	√
2011	Navigator	5.4L	3V	ACM	√	√	√	√
2011	Navigator	5.4L	3V	APIM	√	√	√	√
2011	Navigator	5.4L	3V	APIM	√	√	√	√

2011	Navigator	5.4L	3V	DCSM	√	√	√	√
2011	Navigator	5.4L	3V	DSM	√	√	√	√
2011	Navigator	5.4L	3V	DSP	√	√	√	√
2011	Navigator	5.4L	3V	GEM / SJB	√	√	√	√
2011	Navigator	5.4L	3V	GEM / SJB	√	√	√	√
2011	Navigator	5.4L	3V	GPSM	√	√	√	√
2011	Navigator	5.4L	3V	HVAC	√	√	√	√
2011	Navigator	5.4L	3V	IC	√	√	√	√
2011	Navigator	5.4L	3V	LTM	√	√	√	√
2011	Navigator	5.4L	3V	PAM	√	√	√	√
2011	Navigator	5.4L	3V	PCM	√	√	√	√
2011	Navigator	5.4L	3V	PCM	√	√	√	√
2011	Navigator	5.4L	3V	PCM	√	√	√	√
2011	Navigator	5.4L	3V	PRB	√	√	√	√
2011	Navigator	5.4L	3V	RCM	√	√	√	√
2011	Navigator	5.4L	3V	RCU	√	√	√	√
2011	Navigator	5.4L	3V	RETM	√	√	√	
2011	Navigator	5.4L	3V	SDARS	√	√	√	√
2011	Navigator	5.4L	3V	TCCM	√	√	√	√
2011	Navigator	5.4L	3V	TCM	√	√	√	√
2011	Navigator	5.4L	3V	VDM	√	√	√	√
2011	Navigator	5.4L	3V	VDM	√	√	√	√
2012	Navigator	5.4L	3V	ABS	√	√	√	
2012	Navigator	5.4L	3V	ABS	√	√	√	√
2012	Navigator	5.4L	3V	ABS	√	√	√	√
2012	Navigator	5.4L	3V	ACM	√	√	√	
2012	Navigator	5.4L	3V	ACM	√	√	√	√
2012	Navigator	5.4L	3V	APIM	√	√	√	
2012	Navigator	5.4L	3V	APIM	√	√	√	√
2012	Navigator	5.4L	3V	DCSM	√	√	√	√
2012	Navigator	5.4L	3V	DSM	√	√	√	√
2012	Navigator	5.4L	3V	DSP	√	√	√	√
2012	Navigator	5.4L	3V	GEM / SJB	√	√	√	√
2012	Navigator	5.4L	3V	GPSM	√	√	√	√
2012	Navigator	5.4L	3V	HVAC	√	√	√	
2012	Navigator	5.4L	3V	HVAC	√	√	√	√
2012	Navigator	5.4L	3V	IC	√	√	√	√
2012	Navigator	5.4L	3V	LTM	√	√	√	√
2012	Navigator	5.4L	3V	PAM	√	√	√	
2012	Navigator	5.4L	3V	PAM	√	√	√	√
2012	Navigator	5.4L	3V	PCM	√	√	√	√
2012	Navigator	5.4L	3V	PCM	√	√	√	√
2012	Navigator	5.4L	3V	PCM	√	√	√	√
2012	Navigator	5.4L	3V	PCM	√	√	√	√
2012	Navigator	5.4L	3V	PRB	√	√	√	√

2012	Navigator	5.4L	3V	RCM	√	√	√	√
2012	Navigator	5.4L	3V	RCU	√	√	√	
2012	Navigator	5.4L	3V	RCU	√	√	√	√
2012	Navigator	5.4L	3V	RETM	√	√	√	
2012	Navigator	5.4L	3V	SDARS	√	√	√	√
2012	Navigator	5.4L	3V	TCCM	√	√	√	√
2012	Navigator	5.4L	3V	VDM	√	√	√	√
2012	Navigator	5.4L	3V	VDM	√	√	√	√
2013	Navigator	5.4L	3V	ABS	√	√	√	√
2013	Navigator	5.4L	3V	ACM	√	√	√	√
2013	Navigator	5.4L	3V	ACM	√	√	√	√
2013	Navigator	5.4L	3V	APIM	√	√	√	√
2013	Navigator	5.4L	3V	APIM	√	√	√	√
2013	Navigator	5.4L	3V	DCSM	√	√	√	√
2013	Navigator	5.4L	3V	DSM	√	√	√	√
2013	Navigator	5.4L	3V	DSP	√	√	√	√
2013	Navigator	5.4L	3V	GEM / SJB	√	√	√	√
2013	Navigator	5.4L	3V	GEM / SJB	√	√	√	√
2013	Navigator	5.4L	3V	GPSM	√	√	√	√
2013	Navigator	5.4L	3V	HVAC	√	√	√	√
2013	Navigator	5.4L	3V	IC	√	√	√	√
2013	Navigator	5.4L	3V	LTM	√	√	√	√
2013	Navigator	5.4L	3V	PAM	√	√	√	√
2013	Navigator	5.4L	3V	PCM	√	√	√	√
2013	Navigator	5.4L	3V	PCM	√	√	√	√
2013	Navigator	5.4L	3V	PCM	√	√	√	√
2013	Navigator	5.4L	3V	PCM	√	√	√	√
2013	Navigator	5.4L	3V	PRB	√	√	√	√
2013	Navigator	5.4L	3V	RCM	√	√	√	√
2013	Navigator	5.4L	3V	RCU	√	√	√	√
2013	Navigator	5.4L	3V	SDARS	√	√	√	√
2013	Navigator	5.4L	3V	TBC	√	√	√	√
2013	Navigator	5.4L	3V	TCCM	√	√	√	√
2013	Navigator	5.4L	3V	VDM	√	√	√	√
2013	Navigator	Other	Other	ABS	√	√	√	√
2013	Navigator	Other	Other	ACM	√	√	√	√
2013	Navigator	Other	Other	APIM	√	√	√	√
2013	Navigator	Other	Other	DCSM	√	√	√	√
2013	Navigator	Other	Other	DSM	√	√	√	√
2013	Navigator	Other	Other	DSP	√	√	√	√
2013	Navigator	Other	Other	GEM / SJB	√	√	√	√
2013	Navigator	Other	Other	GPSM	√	√	√	√
2013	Navigator	Other	Other	HVAC	√	√	√	√
2013	Navigator	Other	Other	IC	√	√	√	√
2013	Navigator	Other	Other	LTM	√	√	√	√

2013	Navigator	Other	Other	PAM	√	√	√	√
2013	Navigator	Other	Other	PCM	√	√	√	
2013	Navigator	Other	Other	PCM	√	√	√	√
2013	Navigator	Other	Other	PRB	√	√	√	√
2013	Navigator	Other	Other	RCM	√	√	√	√
2013	Navigator	Other	Other	RCU	√	√	√	√
2013	Navigator	Other	Other	SDARS	√	√	√	√
2013	Navigator	Other	Other	TBC	√	√	√	√
2013	Navigator	Other	Other	TCCM	√	√	√	√
2013	Navigator	Other	Other	VDM	√	√	√	√
2014	Navigator	5.4L	3V	ABS	√	√	√	√
2014	Navigator	5.4L	3V	ABS	√	√	√	√
2014	Navigator	5.4L	3V	ACM	√	√	√	√
2014	Navigator	5.4L	3V	ACM	√	√	√	√
2014	Navigator	5.4L	3V	APIM	√	√	√	√
2014	Navigator	5.4L	3V	APIM	√	√	√	√
2014	Navigator	5.4L	3V	DCSM	√	√	√	√
2014	Navigator	5.4L	3V	DSM	√	√	√	√
2014	Navigator	5.4L	3V	DSP	√	√	√	√
2014	Navigator	5.4L	3V	GEM / SJB	√	√	√	√
2014	Navigator	5.4L	3V	GEM / SJB	√	√	√	√
2014	Navigator	5.4L	3V	GPSM	√	√	√	√
2014	Navigator	5.4L	3V	HVAC	√	√	√	√
2014	Navigator	5.4L	3V	IC	√	√	√	√
2014	Navigator	5.4L	3V	LTM	√	√	√	√
2014	Navigator	5.4L	3V	PAM	√	√	√	√
2014	Navigator	5.4L	3V	PCM	√	√	√	√
2014	Navigator	5.4L	3V	PCM	√	√	√	√
2014	Navigator	5.4L	3V	PCM	√	√	√	√
2014	Navigator	5.4L	3V	PCM	√	√	√	√
2014	Navigator	5.4L	3V	PRB	√	√	√	√
2014	Navigator	5.4L	3V	RCM	√	√	√	√
2014	Navigator	5.4L	3V	RCU	√	√	√	√
2014	Navigator	5.4L	3V	SDARS	√	√	√	√
2014	Navigator	5.4L	3V	TBC	√	√	√	√
2014	Navigator	5.4L	3V	TCCM	√	√	√	√
2014	Navigator	5.4L	3V	VDM	√	√	√	√
2007	Navigator L	5.4L	3V	4X4	√	√	√	√
2007	Navigator L	5.4L	3V	ABS	√	√	√	√
2007	Navigator L	5.4L	3V	ABS	√	√	√	√
2007	Navigator L	5.4L	3V	ACM	√	√	√	√
2007	Navigator L	5.4L	3V	ACM	√	√	√	√
2007	Navigator L	5.4L	3V	DCSM	√	√	√	√
2007	Navigator L	5.4L	3V	DSM	√	√	√	√
2007	Navigator L	5.4L	3V	DSP	√	√	√	√

2007	Navigator L	5.4L	3V	EATC	√	√	√	√
2007	Navigator L	5.4L	3V	GEM	√	√	√	√
2007	Navigator L	5.4L	3V	IC	√	√	√	√
2007	Navigator L	5.4L	3V	LTM	√	√	√	√
2007	Navigator L	5.4L	3V	PAM	√	√	√	
2007	Navigator L	5.4L	3V	PCM	√	√	√	√
2007	Navigator L	5.4L	3V	PCM	√	√	√	√
2007	Navigator L	5.4L	3V	PRB	√	√	√	√
2007	Navigator L	5.4L	3V	RCM	√	√	√	√
2007	Navigator L	5.4L	3V	RCU	√	√	√	
2007	Navigator L	5.4L	3V	RETM	√	√	√	
2007	Navigator L	5.4L	3V	SDARS	√	√	√	√
2007	Navigator L	5.4L	3V	SDARS	√	√	√	√
2007	Navigator L	5.4L	3V	TCM	√	√	√	√
2007	Navigator L	5.4L	3V	VDM	√	√	√	√
2007	Navigator L	5.4L	3V	VDM	√	√	√	√
2008	Navigator L	5.4L	3V	4X4	√	√	√	√
2008	Navigator L	5.4L	3V	ABS	√	√	√	√
2008	Navigator L	5.4L	3V	ABS	√	√	√	√
2008	Navigator L	5.4L	3V	ACM	√	√	√	√
2008	Navigator L	5.4L	3V	ACM	√	√	√	√
2008	Navigator L	5.4L	3V	APIM	√	√	√	√
2008	Navigator L	5.4L	3V	APIM	√	√	√	√
2008	Navigator L	5.4L	3V	DCSM	√	√	√	√
2008	Navigator L	5.4L	3V	DSM	√	√	√	√
2008	Navigator L	5.4L	3V	DSP	√	√	√	√
2008	Navigator L	5.4L	3V	GEM / SJB	√	√	√	√
2008	Navigator L	5.4L	3V	HVAC	√	√	√	√
2008	Navigator L	5.4L	3V	IC	√	√	√	√
2008	Navigator L	5.4L	3V	LTM	√	√	√	√
2008	Navigator L	5.4L	3V	PAM	√	√	√	
2008	Navigator L	5.4L	3V	PCM	√	√	√	√
2008	Navigator L	5.4L	3V	PCM	√	√	√	√
2008	Navigator L	5.4L	3V	PRB	√	√	√	√
2008	Navigator L	5.4L	3V	RCM	√	√	√	√
2008	Navigator L	5.4L	3V	RCU	√	√	√	√
2008	Navigator L	5.4L	3V	RETM	√	√	√	
2008	Navigator L	5.4L	3V	SDARS	√	√	√	√
2008	Navigator L	5.4L	3V	TCM	√	√	√	√
2008	Navigator L	5.4L	3V	VDM	√	√	√	√
2008	Navigator L	5.4L	3V	VDM	√	√	√	√
2009	Navigator L	5.4L	3V	4X4	√	√	√	√
2009	Navigator L	5.4L	3V	ABS	√	√	√	√
2009	Navigator L	5.4L	3V	ABS	√	√	√	√
2009	Navigator L	5.4L	3V	ACM	√	√	√	√

2009	Navigator L	5.4L	3V	ACM	√	√	√	√
2009	Navigator L	5.4L	3V	APIM	√	√	√	√
2009	Navigator L	5.4L	3V	APIM	√	√	√	√
2009	Navigator L	5.4L	3V	DCSM	√	√	√	√
2009	Navigator L	5.4L	3V	DSM	√	√	√	√
2009	Navigator L	5.4L	3V	DSP	√	√	√	√
2009	Navigator L	5.4L	3V	GEM / SJB	√	√	√	√
2009	Navigator L	5.4L	3V	GEM / SJB	√	√	√	√
2009	Navigator L	5.4L	3V	HVAC	√	√	√	√
2009	Navigator L	5.4L	3V	IC	√	√	√	√
2009	Navigator L	5.4L	3V	LTM	√	√	√	√
2009	Navigator L	5.4L	3V	PAM	√	√	√	√
2009	Navigator L	5.4L	3V	PCM	√	√	√	√
2009	Navigator L	5.4L	3V	PCM	√	√	√	√
2009	Navigator L	5.4L	3V	PRB	√	√	√	√
2009	Navigator L	5.4L	3V	RCM	√	√	√	√
2009	Navigator L	5.4L	3V	RETM	√	√	√	
2009	Navigator L	5.4L	3V	SDARS	√	√	√	√
2009	Navigator L	5.4L	3V	TCM	√	√	√	√
2009	Navigator L	5.4L	3V	VDM	√	√	√	√
2009	Navigator L	5.4L	3V	VDM	√	√	√	√
2010	Navigator L	5.4L	3V	4X4	√	√	√	√
2010	Navigator L	5.4L	3V	ABS	√	√	√	√
2010	Navigator L	5.4L	3V	ABS	√	√	√	√
2010	Navigator L	5.4L	3V	ACM	√	√	√	√
2010	Navigator L	5.4L	3V	ACM	√	√	√	√
2010	Navigator L	5.4L	3V	APIM	√	√	√	√
2010	Navigator L	5.4L	3V	APIM	√	√	√	√
2010	Navigator L	5.4L	3V	DCSM	√	√	√	√
2010	Navigator L	5.4L	3V	DSM	√	√	√	√
2010	Navigator L	5.4L	3V	DSP	√	√	√	√
2010	Navigator L	5.4L	3V	GEM / SJB	√	√	√	√
2010	Navigator L	5.4L	3V	GEM / SJB	√	√	√	√
2010	Navigator L	5.4L	3V	GPSM	√	√	√	√
2010	Navigator L	5.4L	3V	HVAC	√	√	√	√
2010	Navigator L	5.4L	3V	IC	√	√	√	√
2010	Navigator L	5.4L	3V	LTM	√	√	√	√
2010	Navigator L	5.4L	3V	PAM	√	√	√	√
2010	Navigator L	5.4L	3V	PCM	√	√	√	√
2010	Navigator L	5.4L	3V	PCM	√	√	√	√
2010	Navigator L	5.4L	3V	PRB	√	√	√	√
2010	Navigator L	5.4L	3V	RCM	√	√	√	√
2010	Navigator L	5.4L	3V	RCU	√	√	√	√
2010	Navigator L	5.4L	3V	RETM	√	√	√	√
2010	Navigator L	5.4L	3V	SDARS	√	√	√	√

2010	Navigator L	5.4L	3V	TCCM	✓	✓	✓	✓
2010	Navigator L	5.4L	3V	TCM	✓	✓	✓	✓
2010	Navigator L	5.4L	3V	VDM	✓	✓	✓	✓
2010	Navigator L	5.4L	3V	VDM	✓	✓	✓	✓
2011	Navigator L	5.4L	3V	ABS	✓	✓	✓	✓
2011	Navigator L	5.4L	3V	ABS	✓	✓	✓	✓
2011	Navigator L	5.4L	3V	ACM	✓	✓	✓	
2011	Navigator L	5.4L	3V	ACM	✓	✓	✓	
2011	Navigator L	5.4L	3V	ACM	✓	✓	✓	✓
2011	Navigator L	5.4L	3V	ACM	✓	✓	✓	✓
2011	Navigator L	5.4L	3V	APIM	✓	✓	✓	✓
2011	Navigator L	5.4L	3V	APIM	✓	✓	✓	✓
2011	Navigator L	5.4L	3V	DCSM	✓	✓	✓	✓
2011	Navigator L	5.4L	3V	DSM	✓	✓	✓	✓
2011	Navigator L	5.4L	3V	DSP	✓	✓	✓	✓
2011	Navigator L	5.4L	3V	GEM / SJB	✓	✓	✓	✓
2011	Navigator L	5.4L	3V	GEM / SJB	✓	✓	✓	✓
2011	Navigator L	5.4L	3V	GPSM	✓	✓	✓	✓
2011	Navigator L	5.4L	3V	HVAC	✓	✓	✓	✓
2011	Navigator L	5.4L	3V	IC	✓	✓	✓	✓
2011	Navigator L	5.4L	3V	LTM	✓	✓	✓	✓
2011	Navigator L	5.4L	3V	PAM	✓	✓	✓	✓
2011	Navigator L	5.4L	3V	PCM	✓	✓	✓	✓
2011	Navigator L	5.4L	3V	PCM	✓	✓	✓	✓
2011	Navigator L	5.4L	3V	PRB	✓	✓	✓	✓
2011	Navigator L	5.4L	3V	RCM	✓	✓	✓	✓
2011	Navigator L	5.4L	3V	RCU	✓	✓	✓	✓
2011	Navigator L	5.4L	3V	RETM	✓	✓	✓	
2011	Navigator L	5.4L	3V	SDARS	✓	✓	✓	✓
2011	Navigator L	5.4L	3V	TCCM	✓	✓	✓	✓
2011	Navigator L	5.4L	3V	TCM	✓	✓	✓	✓
2011	Navigator L	5.4L	3V	VDM	✓	✓	✓	✓
2011	Navigator L	5.4L	3V	VDM	✓	✓	✓	✓
2012	Navigator L	5.4L	3V	ABS	✓	✓	✓	
2012	Navigator L	5.4L	3V	ABS	✓	✓	✓	✓
2012	Navigator L	5.4L	3V	ACM	✓	✓	✓	
2012	Navigator L	5.4L	3V	ACM	✓	✓	✓	✓
2012	Navigator L	5.4L	3V	APIM	✓	✓	✓	
2012	Navigator L	5.4L	3V	APIM	✓	✓	✓	✓
2012	Navigator L	5.4L	3V	DCSM	✓	✓	✓	✓
2012	Navigator L	5.4L	3V	DSM	✓	✓	✓	✓
2012	Navigator L	5.4L	3V	DSP	✓	✓	✓	✓
2012	Navigator L	5.4L	3V	GEM / SJB	✓	✓	✓	✓
2012	Navigator L	5.4L	3V	GPSM	✓	✓	✓	✓
2012	Navigator L	5.4L	3V	HVAC	✓	✓	✓	



2012	Navigator L	5.4L	3V	HVAC	√	√	√	√
2012	Navigator L	5.4L	3V	IC	√	√	√	√
2012	Navigator L	5.4L	3V	LTM	√	√	√	√
2012	Navigator L	5.4L	3V	PAM	√	√	√	
2012	Navigator L	5.4L	3V	PAM	√	√	√	√
2012	Navigator L	5.4L	3V	PCM	√	√	√	√
2012	Navigator L	5.4L	3V	PCM	√	√	√	√
2012	Navigator L	5.4L	3V	PRB	√	√	√	√
2012	Navigator L	5.4L	3V	RCM	√	√	√	√
2012	Navigator L	5.4L	3V	RCU	√	√	√	
2012	Navigator L	5.4L	3V	RCU	√	√	√	√
2012	Navigator L	5.4L	3V	RETM	√	√	√	
2012	Navigator L	5.4L	3V	SDARS	√	√	√	√
2012	Navigator L	5.4L	3V	TCCM	√	√	√	√
2012	Navigator L	5.4L	3V	VDM	√	√	√	√
2013	Navigator L	5.4L	3V	ABS	√	√	√	√
2013	Navigator L	5.4L	3V	ACM	√	√	√	√
2013	Navigator L	5.4L	3V	ACM	√	√	√	√
2013	Navigator L	5.4L	3V	APIM	√	√	√	√
2013	Navigator L	5.4L	3V	APIM	√	√	√	√
2013	Navigator L	5.4L	3V	DCSM	√	√	√	√
2013	Navigator L	5.4L	3V	DSM	√	√	√	√
2013	Navigator L	5.4L	3V	DSP	√	√	√	√
2013	Navigator L	5.4L	3V	GEM / SJB	√	√	√	√
2013	Navigator L	5.4L	3V	GEM / SJB	√	√	√	√
2013	Navigator L	5.4L	3V	GPSM	√	√	√	√
2013	Navigator L	5.4L	3V	HVAC	√	√	√	√
2013	Navigator L	5.4L	3V	IC	√	√	√	√
2013	Navigator L	5.4L	3V	LTM	√	√	√	√
2013	Navigator L	5.4L	3V	PAM	√	√	√	√
2013	Navigator L	5.4L	3V	PCM	√	√	√	√
2013	Navigator L	5.4L	3V	PRB	√	√	√	√
2013	Navigator L	5.4L	3V	RCM	√	√	√	√
2013	Navigator L	5.4L	3V	RCU	√	√	√	√
2013	Navigator L	5.4L	3V	SDARS	√	√	√	√
2013	Navigator L	5.4L	3V	TBC	√	√	√	√
2013	Navigator L	5.4L	3V	TCCM	√	√	√	√
2013	Navigator L	5.4L	3V	VDM	√	√	√	√
2013	Navigator L	Other	Other	ABS	√	√	√	√
2013	Navigator L	Other	Other	ACM	√	√	√	√
2013	Navigator L	Other	Other	APIM	√	√	√	√
2013	Navigator L	Other	Other	DCSM	√	√	√	√
2013	Navigator L	Other	Other	DSM	√	√	√	√
2013	Navigator L	Other	Other	DSP	√	√	√	√
2013	Navigator L	Other	Other	GEM / SJB	√	√	√	√

2013	Navigator L	Other	Other	GPSM	√	√	√	√
2013	Navigator L	Other	Other	HVAC	√	√	√	√
2013	Navigator L	Other	Other	IC	√	√	√	√
2013	Navigator L	Other	Other	LTM	√	√	√	√
2013	Navigator L	Other	Other	PAM	√	√	√	√
2013	Navigator L	Other	Other	PCM	√	√	√	
2013	Navigator L	Other	Other	PRB	√	√	√	√
2013	Navigator L	Other	Other	RCM	√	√	√	√
2013	Navigator L	Other	Other	RCU	√	√	√	√
2013	Navigator L	Other	Other	SDARS	√	√	√	√
2013	Navigator L	Other	Other	TBC	√	√	√	√
2013	Navigator L	Other	Other	TCCM	√	√	√	√
2013	Navigator L	Other	Other	VDM	√	√	√	√
2014	Navigator L	5.4L	3V	ABS	√	√	√	√
2014	Navigator L	5.4L	3V	ACM	√	√	√	√
2014	Navigator L	5.4L	3V	ACM	√	√	√	√
2014	Navigator L	5.4L	3V	APIM	√	√	√	√
2014	Navigator L	5.4L	3V	APIM	√	√	√	√
2014	Navigator L	5.4L	3V	DCSM	√	√	√	√
2014	Navigator L	5.4L	3V	DSM	√	√	√	√
2014	Navigator L	5.4L	3V	DSP	√	√	√	√
2014	Navigator L	5.4L	3V	GEM / SJB	√	√	√	√
2014	Navigator L	5.4L	3V	GEM / SJB	√	√	√	√
2014	Navigator L	5.4L	3V	GPSM	√	√	√	√
2014	Navigator L	5.4L	3V	HVAC	√	√	√	√
2014	Navigator L	5.4L	3V	IC	√	√	√	√
2014	Navigator L	5.4L	3V	LTM	√	√	√	√
2014	Navigator L	5.4L	3V	PAM	√	√	√	√
2014	Navigator L	5.4L	3V	PCM	√	√	√	√
2014	Navigator L	5.4L	3V	PRB	√	√	√	√
2014	Navigator L	5.4L	3V	RCM	√	√	√	√
2014	Navigator L	5.4L	3V	RCU	√	√	√	√
2014	Navigator L	5.4L	3V	SDARS	√	√	√	√
2014	Navigator L	5.4L	3V	TBC	√	√	√	√
2014	Navigator L	5.4L	3V	TCCM	√	√	√	√
2014	Navigator L	5.4L	3V	VDM	√	√	√	√
1999	PREMACY / IXION	1.8L	FP	ABS	√	√	√	√
1999	PREMACY / IXION	1.8L	FP	PCM	√	√	√	√
1999	PREMACY / IXION	1.8L	FP_DE	ABS	√	√	√	√
1999	PREMACY / IXION	1.8L	FP_DE	PCM	√	√	√	√
1999	PREMACY / IXION	2.0L	RF-T	ABS	√	√	√	
1999	PREMACY / IXION	2.0L	RF-T	PCM	√	√	√	√
2001	PREMACY / IXION	2.0L	FS	ABS/TCS	√	√	√	√
2001	PREMACY / IXION	2.0L	FS	PCM	√	√	√	√
2002	PREMACY / IXION	1.8L	FP	ABS/TCS	√	√	√	√

2002	PREMACY / IXION	1.8L	FP	PCM	√	√	√	√
1996	PROBE / MX-6	2.0L	Other	PCM	√	√	√	√
1996	PROBE / MX-6	2.5L	KL	PCM	√	√	√	√
1997	PROBE / MX-6	2.0L	Other	PCM	√	√	√	√
1997	PROBE / MX-6	2.0L	Other	PCM	√	√	√	√
1997	PROBE / MX-6	2.5L	KL	PCM	√	√	√	√
1997.5	Puma	1.7L	Zetec-SE	ABS/TCS	√	√	√	√
1997.5	Puma	1.7L	Zetec-SE	HEC	√	√	√	√
1997.5	Puma	1.7L	Zetec-SE	PATS	√	√	√	√
1997.5	Puma	1.7L	Zetec-SE	PCM	√	√	√	√
1998.5	Puma	1.4L	Zetec-SE	HEC	√	√	√	√
1998.5	Puma	1.4L	Zetec-SE	PATS			√	√
1998.5	Puma	1.4L	Zetec-SE	PCM	√	√	√	√
1999.5	Puma	1.4L	Zetec-SE	ABS/TCS	√	√	√	√
1999.5	Puma	1.4L	Zetec-SE	GEM	√	√	√	√
1999.5	Puma	1.4L	Zetec-SE	HEC	√	√	√	√
1999.5	Puma	1.4L	Zetec-SE	PATS			√	√
1999.5	Puma	1.4L	Zetec-SE	PCM	√	√	√	√
1999.5	Puma	1.7L	Zetec-SE	ABS/TCS	√	√	√	√
1999.5	Puma	1.7L	Zetec-SE	GEM	√	√	√	√
1999.5	Puma	1.7L	Zetec-SE	HEC	√	√	√	√
1999.5	Puma	1.7L	Zetec-SE	PATS	√	√	√	√
1999.5	Puma	1.7L	Zetec-SE	PCM	√	√	√	√
2001	Puma	1.6L	Zetec-SE	ABS/TCS	√	√	√	√
2001	Puma	1.6L	Zetec-SE	GEM	√	√	√	√
2001	Puma	1.6L	Zetec-SE	HEC	√	√	√	√
2001	Puma	1.6L	Zetec-SE	PATS	√	√	√	√
2001	Puma	1.6L	Zetec-SE	PCM	√	√	√	√
2001	Puma	1.7L	Zetec-SE	ABS/TCS	√	√	√	√
2001	Puma	1.7L	Zetec-SE	GEM	√	√	√	√
2001	Puma	1.7L	Zetec-SE	HEC	√	√	√	√
2001	Puma	1.7L	Zetec-SE	PATS	√	√	√	√
2001	Puma	1.7L	Zetec-SE	PCM	√	√	√	√
2000	ROADSTER / MX-5	1.6L	B6	ABS	√	√	√	√
2000	ROADSTER / MX-5	1.8L	BP	ABS	√	√	√	√
2002	ROADSTER / MX-5	1.6L	B6	ABS/TCS	√	√	√	√
2002	ROADSTER / MX-5	1.6L	B6	PCM	√	√	√	√
2002	ROADSTER / MX-5	1.8L	BP	ABS/TCS	√	√	√	√
2002	ROADSTER / MX-5	1.8L	BP	PCM	√	√	√	√
2003	ROADSTER / MX-5	1.8L	BP Turbo	ABS/TCS	√	√	√	√
2003	ROADSTER / MX-5	1.8L	BP Turbo	PCM	√	√	√	√
2005	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	ABS	√	√	√	√
2005	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	ABS	√	√	√	√
2005	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	IC	√	√	√	
2005	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	PCM	√	√	√	√

2005	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	RCM	✓	✓	✓	✓
2005	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	RHT	✓	✓	✓	✓
2005	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	RKE	✓	✓	✓	✓
2005	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	TCM	✓	✓	✓	✓
2008	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	ABS	✓	✓	✓	✓
2008	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	ABS	✓	✓	✓	✓
2008	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	IC	✓	✓	✓	
2008	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	PCM	✓	✓	✓	✓
2008	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	RCM	✓	✓	✓	✓
2008	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	RHT	✓	✓	✓	✓
2008	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	RKE	✓	✓	✓	✓
2008	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	TCM	✓	✓	✓	✓
2005.5	Ranger	3.0L	I4 DSL Electronic	4X4	✓	✓	✓	✓
2005.5	Ranger	3.0L	I4 DSL Electronic	ABS/TCS	✓	✓	✓	✓
2005.5	Ranger	3.0L	I4 DSL Electronic	GEM	✓	✓	✓	✓
2005.5	Ranger	3.0L	I4 DSL Electronic	IC	✓	✓	✓	✓
2005.5	Ranger	3.0L	I4 DSL Electronic	PCM	✓	✓	✓	✓
2005.5	Ranger	3.0L	I4 DSL Electronic	RCM	✓	✓	✓	✓
2005.5	Ranger	3.0L	I4 DSL Electronic	TBM	✓	✓	✓	✓
2006	Ranger	2.3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓
2006	Ranger	2.3L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓
2006	Ranger	2.3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓
2006	Ranger	2.3L	DURATEC-HE / I4	IC	✓	✓	✓	✓
2006	Ranger	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓
2006	Ranger	2.3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓
2009.5	Ranger	2.3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓
2009.5	Ranger	2.3L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓
2009.5	Ranger	2.3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓
2009.5	Ranger	2.3L	DURATEC-HE / I4	IC	✓	✓	✓	✓
2009.5	Ranger	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓
2009.5	Ranger	2.3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓
2009.5	Ranger	2.3L	DURATEC-HE / I4	TBM	✓	✓	✓	✓
2003	Ranger / Courier / Mazda B Series /Bravo	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓
2003	Ranger / Courier / Mazda B Series /Bravo	4.0L	V6 SOHC	ESOF	✓	✓	✓	✓
1995	Ranger / Mazda B-Series / Courier	2.3L	OHC	ABS/TCS	✓	✓	✓	
1995	Ranger / Mazda B-Series / Courier	2.3L	OHC	GEM	✓	✓	✓	✓
1995	Ranger / Mazda B-Series / Courier	2.3L	OHC	PCM	✓	✓	✓	✓
1995	Ranger / Mazda B-Series / Courier	2.3L	OHC	RAP	✓	✓	✓	✓
1995	Ranger / Mazda B-Series / Courier	3.0L	Other	ABS/TCS	✓	✓	✓	
1995	Ranger / Mazda B-Series / Courier	3.0L	Other	GEM	✓	✓	✓	✓
1995	Ranger / Mazda B-Series / Courier	3.0L	Other	PCM	✓	✓	✓	✓
1995	Ranger / Mazda B-Series / Courier	3.0L	Other	RAP	✓	✓	✓	✓
1995	Ranger / Mazda B-Series / Courier	4.0L	Other	ABS/TCS	✓	✓	✓	





















2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail	IPC	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail	PAM	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail	PCM	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail	PCM	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail	PDM	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail	RCM	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail	SRM	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail	TBM	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail	TBM	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail	TCM	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail	TRM	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	4X4	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	ABS	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	GEM / SJB	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	IC	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	OCSM	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	PCM	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	RCM	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	SDARS	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	Other	Other	ABS	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	Other	Other	ABS	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	Other	Other	ACM	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	Other	Other	BCMii	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	Other	Other	DDM	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	Other	Other	FCDIM	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	Other	Other	HVAC	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	Other	Other	IPC	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	Other	Other	PAM	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	Other	Other	PDM	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	Other	Other	RCM	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	Other	Other	SRM	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	Other	Other	TBM	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	Other	Other	TCM	✓	✓	✓	✓
2011	Ranger / Mazda B-Series / Courier	Other	Other	TRM	✓	✓	✓	✓
2007	S.A. Courier	1.6L	FFV	PCM	✓	✓	✓	✓
2009	S.A. Courier	1.6L	FFV	IC	✓	✓	✓	✓
2009	S.A. Courier	1.6L	FFV	PCM	✓	✓	✓	✓
2009	S.A. Courier	1.6L	FFV	TBM	✓	✓	✓	✓
2009	S.A. Courier	1.6L	Zetec Rocam	IC	✓	✓	✓	✓
2009	S.A. Courier	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓
2009	S.A. Courier	1.6L	Zetec Rocam	TBM	✓	✓	✓	✓
2011	S.A. Courier	1.6L	FFV	IC	✓	✓	✓	✓
2011	S.A. Courier	1.6L	FFV	PCM	✓	✓	✓	✓

2011	S.A. Courier	1.6L	FFV	TBM	✓	✓	✓	✓
2002.5	S.A. Fiesta	1.0L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓
2002.5	S.A. Fiesta	1.0L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓
2002.5	S.A. Fiesta	1.0L	Zetec Rocam	IC	✓	✓	✓	✓
2002.5	S.A. Fiesta	1.0L	Zetec Rocam	PCM	✓	✓	✓	✓
2002.5	S.A. Fiesta	1.0L	Zetec Rocam	RCM	✓	✓	✓	
2002.5	S.A. Fiesta	1.0L	Zetec Rocam	RKE	✓	✓	✓	✓
2002.5	S.A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	ABS/TCS	✓	✓	✓	✓
2002.5	S.A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	ABS/TCS	✓	✓	✓	✓
2002.5	S.A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	IC	✓	✓	✓	✓
2002.5	S.A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	RCM	✓	✓	✓	
2002.5	S.A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	RKE	✓	✓	✓	✓
2002.5	S.A. Fiesta	1.6L	FFV	ABS/TCS	✓	✓	✓	✓
2002.5	S.A. Fiesta	1.6L	FFV	ABS/TCS	✓	✓	✓	✓
2002.5	S.A. Fiesta	1.6L	FFV	IC	✓	✓	✓	✓
2002.5	S.A. Fiesta	1.6L	FFV	PCM	✓	✓	✓	✓
2002.5	S.A. Fiesta	1.6L	FFV	RCM	✓	✓	✓	
2002.5	S.A. Fiesta	1.6L	FFV	RKE	✓	✓	✓	✓
2002.5	S.A. Fiesta	1.6L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓
2002.5	S.A. Fiesta	1.6L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓
2002.5	S.A. Fiesta	1.6L	Zetec Rocam	IC	✓	✓	✓	✓
2002.5	S.A. Fiesta	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓
2002.5	S.A. Fiesta	1.6L	Zetec Rocam	RCM	✓	✓	✓	
2002.5	S.A. Fiesta	1.6L	Zetec Rocam	RKE	✓	✓	✓	✓
2006	S.A. Fiesta	1.0L	FFV	ABS/TCS	✓	✓	✓	✓
2006	S.A. Fiesta	1.0L	FFV	ABS/TCS	✓	✓	✓	✓
2006	S.A. Fiesta	1.0L	FFV	IC	✓	✓	✓	✓
2006	S.A. Fiesta	1.0L	FFV	PCM	✓	✓	✓	✓
2006	S.A. Fiesta	1.0L	FFV	RCM	✓	✓	✓	
2006	S.A. Fiesta	1.0L	FFV	RKE	✓	✓	✓	✓
2006	S.A. Fiesta	1.6L	FFV	ABS/TCS	✓	✓	✓	✓
2006	S.A. Fiesta	1.6L	FFV	ABS/TCS	✓	✓	✓	✓
2006	S.A. Fiesta	1.6L	FFV	IC	✓	✓	✓	✓
2006	S.A. Fiesta	1.6L	FFV	PCM	✓	✓	✓	✓
2006	S.A. Fiesta	1.6L	FFV	RCM	✓	✓	✓	
2006	S.A. Fiesta	1.6L	FFV	RKE	✓	✓	✓	✓
2006	S.A. Fiesta	1.6L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓
2006	S.A. Fiesta	1.6L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓
2006	S.A. Fiesta	1.6L	Zetec Rocam	IC	✓	✓	✓	✓
2006	S.A. Fiesta	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓
2006	S.A. Fiesta	1.6L	Zetec Rocam	RCM	✓	✓	✓	
2006	S.A. Fiesta	1.6L	Zetec Rocam	RKE	✓	✓	✓	✓
2006	S.A. Fiesta	1.6L	Zetec Rocam	TCM	✓	✓	✓	✓
2009	S.A. Fiesta	1.0L	FFV	ABS/TCS	✓	✓	✓	✓
2009	S.A. Fiesta	1.0L	FFV	IC	✓	✓	✓	✓

2009	S.A. Fiesta	1.0L	FFV	PCM	✓	✓	✓	✓
2009	S.A. Fiesta	1.0L	FFV	RCM	✓	✓	✓	
2009	S.A. Fiesta	1.0L	FFV	RKE	✓	✓	✓	✓
2009	S.A. Fiesta	1.6L	FFV	ABS/TCS	✓	✓	✓	✓
2009	S.A. Fiesta	1.6L	FFV	IC	✓	✓	✓	✓
2009	S.A. Fiesta	1.6L	FFV	PCM	✓	✓	✓	✓
2009	S.A. Fiesta	1.6L	FFV	RCM	✓	✓	✓	
2009	S.A. Fiesta	1.6L	FFV	RKE	✓	✓	✓	✓
2009	S.A. Fiesta	1.6L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓
2009	S.A. Fiesta	1.6L	Zetec Rocam	IC	✓	✓	✓	✓
2009	S.A. Fiesta	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓
2009	S.A. Fiesta	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓
2009	S.A. Fiesta	1.6L	Zetec Rocam	RCM	✓	✓	✓	
2009	S.A. Fiesta	1.6L	Zetec Rocam	RKE	✓	✓	✓	✓
2009	S.A. Fiesta	1.6L	Zetec Rocam	TCM	✓	✓	✓	✓
2009	S.A. Fiesta	1.6L	Zetec Rocam	TCM	✓	✓	✓	✓
2010	S.A. Fiesta	1.0L	FFV	ABS/TCS	✓	✓	✓	✓
2010	S.A. Fiesta	1.0L	FFV	IC	✓	✓	✓	✓
2010	S.A. Fiesta	1.0L	FFV	PCM	✓	✓	✓	✓
2010	S.A. Fiesta	1.0L	FFV	RCM	✓	✓	✓	
2010	S.A. Fiesta	1.0L	FFV	RKE	✓	✓	✓	✓
2010	S.A. Fiesta	1.0L	FFV	TBM	✓	✓	✓	✓
2011	S.A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	ABS/TCS	✓	✓	✓	✓
2011	S.A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	IC	✓	✓	✓	✓
2011	S.A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	PCM	✓	✓	✓	✓
2011	S.A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	RCM	✓	✓	✓	
2011	S.A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail	RKE	✓	✓	✓	✓
2011	S.A. Fiesta	1.6L	FFV	ABS/TCS	✓	✓	✓	✓
2011	S.A. Fiesta	1.6L	FFV	IC	✓	✓	✓	✓
2011	S.A. Fiesta	1.6L	FFV	PCM	✓	✓	✓	✓
2011	S.A. Fiesta	1.6L	FFV	RCM	✓	✓	✓	
2011	S.A. Fiesta	1.6L	FFV	RKE	✓	✓	✓	✓
2011	S.A. Fiesta	1.6L	FFV	TBM	✓	✓	✓	✓
2005	SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A	ABS	✓	✓	✓	✓
2005	SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A	PCM	✓	✓	✓	✓
2005	SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A	RCM	✓	✓	✓	✓
2005	SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A_T	ABS	✓	✓	✓	✓
2005	SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A_T	PCM	✓	✓	✓	✓
2005	SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A_T	RCM	✓	✓	✓	✓
2005	SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A_T	TCM	✓	✓	✓	✓
1996	Sable	3.0L	4V	ABS/TCS	✓	✓	✓	✓
1996	Sable	3.0L	4V	GEM	✓	✓	✓	✓
1996	Sable	3.0L	4V	IAB	✓	✓	✓	
1996	Sable	3.0L	4V	PATS	✓	✓	✓	✓
1996	Sable	3.0L	4V	PCM	✓	✓	✓	✓



1996	Sable	3.0L	4V	RCC	√	√	√	√
1996	Sable	3.0L	Other	ABS/TCS	√	√	√	√
1996	Sable	3.0L	Other	GEM	√	√	√	√
1996	Sable	3.0L	Other	IAB	√	√	√	
1996	Sable	3.0L	Other	PATS	√	√	√	√
1996	Sable	3.0L	Other	PCM	√	√	√	√
1996	Sable	3.0L	Other	RAP	√	√	√	√
1996	Sable	3.0L	Other	RCC	√	√	√	√
1997	Sable	3.0L	4V	ABS/TCS	√	√	√	√
1997	Sable	3.0L	4V	GEM	√	√	√	√
1997	Sable	3.0L	4V	IAB	√	√	√	
1997	Sable	3.0L	4V	PATS	√	√	√	√
1997	Sable	3.0L	4V	PCM	√	√	√	√
1997	Sable	3.0L	4V	RAP	√	√	√	√
1997	Sable	3.0L	4V	RCC	√	√	√	√
1997	Sable	3.0L	Other	ABS/TCS	√	√	√	√
1997	Sable	3.0L	Other	GEM	√	√	√	√
1997	Sable	3.0L	Other	IAB	√	√	√	
1997	Sable	3.0L	Other	PATS	√	√	√	√
1997	Sable	3.0L	Other	PCM	√	√	√	√
1997	Sable	3.0L	Other	RAP	√	√	√	√
1997	Sable	3.0L	Other	RCC	√	√	√	√
1998	Sable	3.0L	4V	ABS/TCS	√	√	√	√
1998	Sable	3.0L	4V	GEM	√	√	√	√
1998	Sable	3.0L	4V	IAB	√	√	√	
1998	Sable	3.0L	4V	PATS	√	√	√	√
1998	Sable	3.0L	4V	PCM	√	√	√	√
1998	Sable	3.0L	4V	RAP	√	√	√	√
1998	Sable	3.0L	4V	RCC	√	√	√	√
1998	Sable	3.0L	Other	ABS/TCS	√	√	√	√
1998	Sable	3.0L	Other	GEM	√	√	√	√
1998	Sable	3.0L	Other	IAB	√	√	√	
1998	Sable	3.0L	Other	PATS	√	√	√	
1998	Sable	3.0L	Other	PCM	√	√	√	√
1998	Sable	3.0L	Other	RAP	√	√	√	√
1998	Sable	3.0L	Other	RAP	√	√	√	√
1998	Sable	3.0L	Other	RCC	√	√	√	√
1999	Sable	3.0L	4V	ABS/TCS	√	√	√	√
1999	Sable	3.0L	4V	GEM	√	√	√	√
1999	Sable	3.0L	4V	IAB	√	√	√	
1999	Sable	3.0L	4V	PATS	√	√	√	√
1999	Sable	3.0L	4V	PCM	√	√	√	√
1999	Sable	3.0L	4V	RAP	√	√	√	√
1999	Sable	3.0L	4V	RCC	√	√	√	√
1999	Sable	3.0L	Other	ABS/TCS	√	√	√	√

1999	Sable	3.0L	Other	GEM	✓	✓	✓	✓
1999	Sable	3.0L	Other	IAB	✓	✓	✓	
1999	Sable	3.0L	Other	PATS	✓	✓	✓	✓
1999	Sable	3.0L	Other	PCM	✓	✓	✓	✓
1999	Sable	3.0L	Other	RAP	✓	✓	✓	✓
1999	Sable	3.0L	Other	RCC	✓	✓	✓	✓
2000	Sable	3.0L	4V	ABS/TCS	✓	✓	✓	✓
2000	Sable	3.0L	4V	EATC	✓	✓	✓	
2000	Sable	3.0L	4V	GEM	✓	✓	✓	✓
2000	Sable	3.0L	4V	PCM	✓	✓	✓	✓
2000	Sable	3.0L	4V	RCM	✓	✓	✓	✓
2000	Sable	3.0L	FFV	ABS/TCS	✓	✓	✓	✓
2000	Sable	3.0L	FFV	EATC	✓	✓	✓	
2000	Sable	3.0L	FFV	GEM	✓	✓	✓	✓
2000	Sable	3.0L	FFV	PCM	✓	✓	✓	✓
2000	Sable	3.0L	FFV	RCM	✓	✓	✓	✓
2000	Sable	3.0L	Other	ABS/TCS	✓	✓	✓	✓
2000	Sable	3.0L	Other	EATC	✓	✓	✓	
2000	Sable	3.0L	Other	GEM	✓	✓	✓	✓
2000	Sable	3.0L	Other	PCM	✓	✓	✓	✓
2000	Sable	3.0L	Other	RCM	✓	✓	✓	✓
2002	Sable	3.0L	4V	ABS/TCS	✓	✓	✓	✓
2002	Sable	3.0L	4V	ABS/TCS	✓	✓	✓	✓
2002	Sable	3.0L	4V	EATC	✓	✓	✓	
2002	Sable	3.0L	4V	GEM	✓	✓	✓	✓
2002	Sable	3.0L	4V	PCM	✓	✓	✓	✓
2002	Sable	3.0L	4V	RCM	✓	✓	✓	
2002	Sable	3.0L	FFV	ABS/TCS	✓	✓	✓	✓
2002	Sable	3.0L	FFV	ABS/TCS	✓	✓	✓	✓
2002	Sable	3.0L	FFV	EATC	✓	✓	✓	
2002	Sable	3.0L	FFV	GEM	✓	✓	✓	✓
2002	Sable	3.0L	FFV	PCM	✓	✓	✓	✓
2002	Sable	3.0L	FFV	RCM	✓	✓	✓	
2002	Sable	3.0L	Other	ABS/TCS	✓	✓	✓	✓
2002	Sable	3.0L	Other	ABS/TCS	✓	✓	✓	✓
2002	Sable	3.0L	Other	EATC	✓	✓	✓	
2002	Sable	3.0L	Other	GEM	✓	✓	✓	✓
2002	Sable	3.0L	Other	PCM	✓	✓	✓	✓
2002	Sable	3.0L	Other	RCM	✓	✓	✓	
2003	Sable	3.0L	2V	ABS/TCS	✓	✓	✓	✓
2003	Sable	3.0L	2V	ABS/TCS	✓	✓	✓	✓
2003	Sable	3.0L	2V	EATC	✓	✓	✓	
2003	Sable	3.0L	2V	GEM	✓	✓	✓	✓
2003	Sable	3.0L	2V	RCM	✓	✓	✓	
2003	Sable	3.0L	4V	ABS/TCS	✓	✓	✓	✓

2003	Sable	3.0L	4V	ABS/TCS	✓	✓	✓	✓
2003	Sable	3.0L	4V	EATC	✓	✓	✓	
2003	Sable	3.0L	4V	GEM	✓	✓	✓	✓
2003	Sable	3.0L	4V	PCM	✓	✓	✓	✓
2003	Sable	3.0L	4V	RCM	✓	✓	✓	
2003	Sable	3.0L	FFV	ABS/TCS	✓	✓	✓	✓
2003	Sable	3.0L	FFV	ABS/TCS	✓	✓	✓	✓
2003	Sable	3.0L	FFV	EATC	✓	✓	✓	
2003	Sable	3.0L	FFV	GEM	✓	✓	✓	✓
2003	Sable	3.0L	FFV	PCM	✓	✓	✓	✓
2003	Sable	3.0L	FFV	RCM	✓	✓	✓	
2004	Sable	3.0L	2V	ABS	✓	✓	✓	✓
2004	Sable	3.0L	2V	EATC	✓	✓	✓	✓
2004	Sable	3.0L	2V	GEM	✓	✓	✓	✓
2004	Sable	3.0L	2V	IC	✓	✓	✓	✓
2004	Sable	3.0L	2V	PCM	✓	✓	✓	✓
2004	Sable	3.0L	2V	RCM	✓	✓	✓	✓
2004	Sable	3.0L	4V	ABS	✓	✓	✓	✓
2004	Sable	3.0L	4V	EATC	✓	✓	✓	✓
2004	Sable	3.0L	4V	GEM	✓	✓	✓	✓
2004	Sable	3.0L	4V	IC	✓	✓	✓	✓
2004	Sable	3.0L	4V	PCM	✓	✓	✓	✓
2004	Sable	3.0L	4V	RCM	✓	✓	✓	✓
2005	Sable	3.0L	2V	ABS	✓	✓	✓	✓
2005	Sable	3.0L	2V	EATC	✓	✓	✓	✓
2005	Sable	3.0L	2V	GEM	✓	✓	✓	✓
2005	Sable	3.0L	2V	IC	✓	✓	✓	✓
2005	Sable	3.0L	2V	PCM	✓	✓	✓	✓
2005	Sable	3.0L	2V	RCM	✓	✓	✓	✓
2005	Sable	3.0L	4V	ABS	✓	✓	✓	✓
2005	Sable	3.0L	4V	EATC	✓	✓	✓	✓
2005	Sable	3.0L	4V	GEM	✓	✓	✓	✓
2005	Sable	3.0L	4V	IC	✓	✓	✓	✓
2005	Sable	3.0L	4V	PCM	✓	✓	✓	✓
2005	Sable	3.0L	4V	RCM	✓	✓	✓	✓
2008	Sable	3.5L	4V	4X4	✓	✓	✓	✓
2008	Sable	3.5L	4V	ABS	✓	✓	✓	✓
2008	Sable	3.5L	4V	ACM	✓	✓	✓	✓
2008	Sable	3.5L	4V	APIM	✓	✓	✓	✓
2008	Sable	3.5L	4V	DSM	✓	✓	✓	✓
2008	Sable	3.5L	4V	GEM / SJB	✓	✓	✓	✓
2008	Sable	3.5L	4V	GEM / SJB	✓	✓	✓	✓
2008	Sable	3.5L	4V	HVAC	✓	✓	✓	✓
2008	Sable	3.5L	4V	IC	✓	✓	✓	✓
2008	Sable	3.5L	4V	OCSM	✓	✓	✓	✓

2008	Sable	3.5L	4V	PAM	✓	✓	✓	✓
2008	Sable	3.5L	4V	PCM	✓	✓	✓	✓
2008	Sable	3.5L	4V	RCM	✓	✓	✓	✓
2008	Sable	3.5L	4V	RETM	✓	✓	✓	✓
2008	Sable	3.5L	4V	SDARS	✓	✓	✓	✓
2008	Sable	3.5L	4V	SECM	✓	✓	✓	✓
2009	Sable	3.5L	4V	4X4	✓	✓	✓	✓
2009	Sable	3.5L	4V	ABS	✓	✓	✓	✓
2009	Sable	3.5L	4V	ACM	✓	✓	✓	✓
2009	Sable	3.5L	4V	APIM	✓	✓	✓	✓
2009	Sable	3.5L	4V	DSM	✓	✓	✓	✓
2009	Sable	3.5L	4V	GEM / SJB	✓	✓	✓	✓
2009	Sable	3.5L	4V	GEM / SJB	✓	✓	✓	✓
2009	Sable	3.5L	4V	HVAC	✓	✓	✓	✓
2009	Sable	3.5L	4V	IC	✓	✓	✓	✓
2009	Sable	3.5L	4V	OCSM	✓	✓	✓	✓
2009	Sable	3.5L	4V	PAM	✓	✓	✓	✓
2009	Sable	3.5L	4V	PCM	✓	✓	✓	✓
2009	Sable	3.5L	4V	RCM	✓	✓	✓	✓
2009	Sable	3.5L	4V	RETM	✓	✓	✓	✓
2009	Sable	3.5L	4V	SDARS	✓	✓	✓	✓
2009	Sable	3.5L	4V	SECM	✓	✓	✓	✓
2003.5	Street Ka	1.6L	DURATEC 8V	ABS/TCS	✓	✓	✓	✓
2003.5	Street Ka	1.6L	DURATEC 8V	CSM	✓	✓	✓	
2003.5	Street Ka	1.6L	DURATEC 8V	ECS	✓	✓	✓	
2003.5	Street Ka	1.6L	DURATEC 8V	GEM	✓	✓	✓	✓
2003.5	Street Ka	1.6L	DURATEC 8V	PCM	✓	✓	✓	✓
2004	TITAN (Isuzu OEM)	3.1L	4JG2	PCM	✓	✓	✓	✓
2004	TITAN (Isuzu OEM)	3.1L	4JG2 LPG	PCM	✓	✓	✓	✓
2004	TITAN (Isuzu OEM)	4.3L	4HF1 CNG	PCM	✓	✓	✓	✓
2004	TITAN (Isuzu OEM)	4.6L	4HG1 LPG	PCM	✓	✓	✓	✓
2004	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	PCM	✓	✓	✓	✓
2004	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	TCM	✓	✓	✓	✓
2004	TITAN (Isuzu OEM)	4.8L	4HL1	PCM	✓	✓	✓	✓
2004	TITAN (Isuzu OEM)	4.8L	4HL1	TCM	✓	✓	✓	✓
2004	TITAN (Isuzu OEM)	4.8L	4HL1_T	PCM	✓	✓	✓	✓
2004	TITAN (Isuzu OEM)	4.8L	4HL1_T	TCM	✓	✓	✓	✓
2007	TITAN (Isuzu OEM)	3.0L	4JJ1_T	ABS	✓	✓	✓	✓
2007	TITAN (Isuzu OEM)	3.0L	4JJ1_T	GEM	✓	✓	✓	✓
2007	TITAN (Isuzu OEM)	3.0L	4JJ1_T	PCM	✓	✓	✓	✓
2007	TITAN (Isuzu OEM)	3.0L	4JJ1_T	RCM	✓	✓	✓	✓
2007	TITAN (Isuzu OEM)	3.0L	4JJ1_T	TCM	✓	✓	✓	✓
2007	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	ABS	✓	✓	✓	✓
2007	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	GEM	✓	✓	✓	✓
2007	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	PCM	✓	✓	✓	✓

2007	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	RCM	√	√	√	√
2007	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	TCM	√	√	√	√
2007	TITAN (Isuzu OEM)	5.2L	4HK1_T	ABS	√	√	√	√
2007	TITAN (Isuzu OEM)	5.2L	4HK1_T	GEM	√	√	√	√
2007	TITAN (Isuzu OEM)	5.2L	4HK1_T	PATS	√	√	√	√
2007	TITAN (Isuzu OEM)	5.2L	4HK1_T	PCM	√	√	√	√
2007	TITAN (Isuzu OEM)	5.2L	4HK1_T	RCM	√	√	√	√
2007	TITAN (Isuzu OEM)	5.2L	4HK1_T	TCM	√	√	√	√
2011	TITAN (Isuzu OEM)	3.0L	4JJ1_T	ABS	√	√	√	√
2011	TITAN (Isuzu OEM)	3.0L	4JJ1_T	GEM	√	√	√	√
2011	TITAN (Isuzu OEM)	3.0L	4JJ1_T	PATS	√	√	√	√
2011	TITAN (Isuzu OEM)	3.0L	4JJ1_T	PCM	√	√	√	√
2011	TITAN (Isuzu OEM)	3.0L	4JJ1_T	RCM	√	√	√	√
2011	TITAN (Isuzu OEM)	3.0L	4JJ1_T	TCM	√	√	√	√
2011	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	ABS	√	√	√	√
2011	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	GEM	√	√	√	√
2011	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	PCM	√	√	√	√
2011	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	RCM	√	√	√	√
2011	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	TCM	√	√	√	√
1996	Taurus	3.0L	4V	ABS/TCS	√	√	√	√
1996	Taurus	3.0L	4V	GEM	√	√	√	√
1996	Taurus	3.0L	4V	IAB	√	√	√	√
1996	Taurus	3.0L	4V	PATS	√	√	√	√
1996	Taurus	3.0L	4V	PCM	√	√	√	√
1996	Taurus	3.0L	4V	RAP	√	√	√	√
1996	Taurus	3.0L	4V	RCC	√	√	√	√
1996	Taurus	3.0L	FFV	ABS/TCS	√	√	√	√
1996	Taurus	3.0L	FFV	GEM	√	√	√	√
1996	Taurus	3.0L	FFV	IAB	√	√	√	√
1996	Taurus	3.0L	FFV	PATS	√	√	√	√
1996	Taurus	3.0L	FFV	PCM	√	√	√	√
1996	Taurus	3.0L	FFV	RAP	√	√	√	√
1996	Taurus	3.0L	FFV	RCC	√	√	√	√
1996	Taurus	3.0L	Other	ABS/TCS	√	√	√	√
1996	Taurus	3.0L	Other	GEM	√	√	√	√
1996	Taurus	3.0L	Other	IAB	√	√	√	√
1996	Taurus	3.0L	Other	PATS	√	√	√	√
1996	Taurus	3.0L	Other	PCM	√	√	√	√
1996	Taurus	3.0L	Other	RAP	√	√	√	√
1996	Taurus	3.0L	Other	RCC	√	√	√	√
1996	Taurus	3.4L	SHO	ABS/TCS	√	√	√	√
1996	Taurus	3.4L	SHO	GEM	√	√	√	√
1996	Taurus	3.4L	SHO	IAB	√	√	√	√
1996	Taurus	3.4L	SHO	PATS	√	√	√	√
1996	Taurus	3.4L	SHO	PCM	√	√	√	√

1996	Taurus	3.4L	SHO	RAP	√	√	√	√
1996	Taurus	3.4L	SHO	RCC	√	√	√	√
1996	Taurus	3.4L	SHO	SARC	√	√	√	√
1997	Taurus	3.0L	4V	ABS/TCS	√	√	√	√
1997	Taurus	3.0L	4V	GEM	√	√	√	√
1997	Taurus	3.0L	4V	IAB	√	√	√	√
1997	Taurus	3.0L	4V	PATS	√	√	√	√
1997	Taurus	3.0L	4V	PCM	√	√	√	√
1997	Taurus	3.0L	4V	RAP	√	√	√	√
1997	Taurus	3.0L	4V	RCC	√	√	√	√
1997	Taurus	3.0L	FFV	ABS/TCS	√	√	√	√
1997	Taurus	3.0L	FFV	GEM	√	√	√	√
1997	Taurus	3.0L	FFV	IAB	√	√	√	√
1997	Taurus	3.0L	FFV	PATS	√	√	√	√
1997	Taurus	3.0L	FFV	PCM	√	√	√	√
1997	Taurus	3.0L	FFV	RAP	√	√	√	√
1997	Taurus	3.0L	FFV	RCC	√	√	√	√
1997	Taurus	3.0L	Other	ABS/TCS	√	√	√	√
1997	Taurus	3.0L	Other	GEM	√	√	√	√
1997	Taurus	3.0L	Other	IAB	√	√	√	√
1997	Taurus	3.0L	Other	PATS	√	√	√	√
1997	Taurus	3.0L	Other	PCM	√	√	√	√
1997	Taurus	3.0L	Other	RAP	√	√	√	√
1997	Taurus	3.0L	Other	RCC	√	√	√	√
1997	Taurus	3.4L	Other	ABS/TCS	√	√	√	√
1997	Taurus	3.4L	Other	GEM	√	√	√	√
1997	Taurus	3.4L	Other	PATS	√	√	√	√
1997	Taurus	3.4L	Other	PCM	√	√	√	√
1997	Taurus	3.4L	SHO	ABS/TCS	√	√	√	√
1997	Taurus	3.4L	SHO	GEM	√	√	√	√
1997	Taurus	3.4L	SHO	IAB	√	√	√	√
1997	Taurus	3.4L	SHO	PATS	√	√	√	√
1997	Taurus	3.4L	SHO	PCM	√	√	√	√
1997	Taurus	3.4L	SHO	RAP	√	√	√	√
1997	Taurus	3.4L	SHO	RCC	√	√	√	√
1997	Taurus	3.4L	SHO	SARC	√	√	√	√
1998	Taurus	3.0L	4V	ABS/TCS	√	√	√	√
1998	Taurus	3.0L	4V	IAB	√	√	√	√
1998	Taurus	3.0L	4V	PATS	√	√	√	√
1998	Taurus	3.0L	4V	PCM	√	√	√	√
1998	Taurus	3.0L	4V	RAP	√	√	√	√
1998	Taurus	3.0L	4V	RCC	√	√	√	√
1998	Taurus	3.0L	FFV	ABS/TCS	√	√	√	√
1998	Taurus	3.0L	FFV	GEM	√	√	√	√
1998	Taurus	3.0L	FFV	IAB	√	√	√	√

1998	Taurus	3.0L	FFV	PATS	√	√	√	√
1998	Taurus	3.0L	FFV	PCM	√	√	√	√
1998	Taurus	3.0L	FFV	RAP	√	√	√	√
1998	Taurus	3.0L	FFV	RCC	√	√	√	√
1998	Taurus	3.0L	Other	ABS/TCS	√	√	√	√
1998	Taurus	3.0L	Other	GEM	√	√	√	√
1998	Taurus	3.0L	Other	IAB	√	√	√	√
1998	Taurus	3.0L	Other	PATS	√	√	√	√
1998	Taurus	3.0L	Other	PCM	√	√	√	√
1998	Taurus	3.0L	Other	RAP	√	√	√	√
1998	Taurus	3.0L	Other	RAP	√	√	√	√
1998	Taurus	3.0L	Other	RCC	√	√	√	√
1998	Taurus	3.4L	SHO	ABS/TCS	√	√	√	√
1998	Taurus	3.4L	SHO	GEM	√	√	√	√
1998	Taurus	3.4L	SHO	IAB	√	√	√	√
1998	Taurus	3.4L	SHO	PATS	√	√	√	√
1998	Taurus	3.4L	SHO	PCM	√	√	√	√
1998	Taurus	3.4L	SHO	RAP	√	√	√	√
1998	Taurus	3.4L	SHO	RCC	√	√	√	√
1998	Taurus	3.4L	SHO	SARC	√	√	√	√
1999	Taurus	3.0L	4V	ABS/TCS	√	√	√	√
1999	Taurus	3.0L	4V	GEM	√	√	√	√
1999	Taurus	3.0L	4V	IAB	√	√	√	√
1999	Taurus	3.0L	4V	PATS	√	√	√	√
1999	Taurus	3.0L	4V	PCM	√	√	√	√
1999	Taurus	3.0L	4V	RAP	√	√	√	√
1999	Taurus	3.0L	4V	RCC	√	√	√	√
1999	Taurus	3.0L	FFV	ABS/TCS	√	√	√	√
1999	Taurus	3.0L	FFV	GEM	√	√	√	√
1999	Taurus	3.0L	FFV	IAB	√	√	√	√
1999	Taurus	3.0L	FFV	PATS	√	√	√	√
1999	Taurus	3.0L	FFV	PCM	√	√	√	√
1999	Taurus	3.0L	FFV	RAP	√	√	√	√
1999	Taurus	3.0L	FFV	RCC	√	√	√	√
1999	Taurus	3.0L	Other	ABS/TCS	√	√	√	√
1999	Taurus	3.0L	Other	GEM	√	√	√	√
1999	Taurus	3.0L	Other	IAB	√	√	√	√
1999	Taurus	3.0L	Other	PATS	√	√	√	√
1999	Taurus	3.0L	Other	PCM	√	√	√	√
1999	Taurus	3.0L	Other	RAP	√	√	√	√
1999	Taurus	3.0L	Other	RCC	√	√	√	√
1999	Taurus	3.4L	SHO	ABS/TCS	√	√	√	√
1999	Taurus	3.4L	SHO	PATS	√	√	√	√
1999	Taurus	3.4L	SHO	PCM	√	√	√	√
1999	Taurus	3.4L	SHO	RAP	√	√	√	√

1999	Taurus	3.4L	SHO	RCC	✓	✓	✓	✓
2000	Taurus	3.0L	4V	ABS/TCS	✓	✓	✓	✓
2000	Taurus	3.0L	4V	EATC	✓	✓	✓	
2000	Taurus	3.0L	4V	GEM	✓	✓	✓	✓
2000	Taurus	3.0L	4V	PCM	✓	✓	✓	✓
2000	Taurus	3.0L	4V	RCM	✓	✓	✓	✓
2000	Taurus	3.0L	FFV	ABS/TCS	✓	✓	✓	✓
2000	Taurus	3.0L	FFV	EATC	✓	✓	✓	
2000	Taurus	3.0L	FFV	GEM	✓	✓	✓	✓
2000	Taurus	3.0L	FFV	PCM	✓	✓	✓	✓
2000	Taurus	3.0L	FFV	RCM	✓	✓	✓	✓
2000	Taurus	3.0L	Other	ABS/TCS	✓	✓	✓	✓
2000	Taurus	3.0L	Other	EATC	✓	✓	✓	
2000	Taurus	3.0L	Other	GEM	✓	✓	✓	✓
2000	Taurus	3.0L	Other	PCM	✓	✓	✓	✓
2000	Taurus	3.0L	Other	RCM	✓	✓	✓	✓
2002	Taurus	3.0L	4V	ABS/TCS	✓	✓	✓	✓
2002	Taurus	3.0L	4V	ABS/TCS	✓	✓	✓	✓
2002	Taurus	3.0L	4V	EATC	✓	✓	✓	
2002	Taurus	3.0L	4V	GEM	✓	✓	✓	✓
2002	Taurus	3.0L	4V	PCM	✓	✓	✓	✓
2002	Taurus	3.0L	4V	RCM	✓	✓	✓	
2002	Taurus	3.0L	FFV	ABS/TCS	✓	✓	✓	✓
2002	Taurus	3.0L	FFV	ABS/TCS	✓	✓	✓	✓
2002	Taurus	3.0L	FFV	EATC	✓	✓	✓	
2002	Taurus	3.0L	FFV	GEM	✓	✓	✓	✓
2002	Taurus	3.0L	FFV	PCM	✓	✓	✓	✓
2002	Taurus	3.0L	FFV	RCM	✓	✓	✓	
2002	Taurus	3.0L	Other	ABS/TCS	✓	✓	✓	✓
2002	Taurus	3.0L	Other	ABS/TCS	✓	✓	✓	✓
2002	Taurus	3.0L	Other	EATC	✓	✓	✓	
2002	Taurus	3.0L	Other	GEM	✓	✓	✓	✓
2002	Taurus	3.0L	Other	PCM	✓	✓	✓	✓
2002	Taurus	3.0L	Other	RCM	✓	✓	✓	
2003	Taurus	3.0L	2V	ABS/TCS	✓	✓	✓	✓
2003	Taurus	3.0L	2V	EATC	✓	✓	✓	
2003	Taurus	3.0L	2V	GEM	✓	✓	✓	✓
2003	Taurus	3.0L	2V	PCM	✓	✓	✓	✓
2003	Taurus	3.0L	2V	RCM	✓	✓	✓	
2003	Taurus	3.0L	4V	ABS/TCS	✓	✓	✓	✓
2003	Taurus	3.0L	4V	ABS/TCS	✓	✓	✓	✓
2003	Taurus	3.0L	4V	EATC	✓	✓	✓	
2003	Taurus	3.0L	4V	GEM	✓	✓	✓	✓
2003	Taurus	3.0L	4V	PCM	✓	✓	✓	✓
2003	Taurus	3.0L	4V	RCM	✓	✓	✓	



2003	Taurus	3.0L	FFV	ABS/TCS	✓	✓	✓	✓
2003	Taurus	3.0L	FFV	ABS/TCS	✓	✓	✓	✓
2003	Taurus	3.0L	FFV	EATC	✓	✓	✓	
2003	Taurus	3.0L	FFV	GEM	✓	✓	✓	✓
2003	Taurus	3.0L	FFV	PCM	✓	✓	✓	✓
2003	Taurus	3.0L	FFV	RCM	✓	✓	✓	
2004	Taurus	3.0L	2V	ABS	✓	✓	✓	✓
2004	Taurus	3.0L	2V	EATC	✓	✓	✓	✓
2004	Taurus	3.0L	2V	GEM	✓	✓	✓	✓
2004	Taurus	3.0L	2V	IC	✓	✓	✓	✓
2004	Taurus	3.0L	2V	PCM	✓	✓	✓	✓
2004	Taurus	3.0L	2V	PCM	✓	✓	✓	✓
2004	Taurus	3.0L	2V	RCM	✓	✓	✓	✓
2004	Taurus	3.0L	4V	ABS	✓	✓	✓	✓
2004	Taurus	3.0L	4V	EATC	✓	✓	✓	✓
2004	Taurus	3.0L	4V	GEM	✓	✓	✓	✓
2004	Taurus	3.0L	4V	IC	✓	✓	✓	✓
2004	Taurus	3.0L	4V	PCM	✓	✓	✓	✓
2004	Taurus	3.0L	4V	PCM	✓	✓	✓	✓
2004	Taurus	3.0L	4V	RCM	✓	✓	✓	✓
2005	Taurus	3.0L	2V	ABS	✓	✓	✓	✓
2005	Taurus	3.0L	2V	EATC	✓	✓	✓	✓
2005	Taurus	3.0L	2V	GEM	✓	✓	✓	✓
2005	Taurus	3.0L	2V	IC	✓	✓	✓	✓
2005	Taurus	3.0L	2V	PCM	✓	✓	✓	✓
2005	Taurus	3.0L	2V	PCM	✓	✓	✓	✓
2005	Taurus	3.0L	2V	RCM	✓	✓	✓	✓
2005	Taurus	3.0L	4V	ABS	✓	✓	✓	✓
2005	Taurus	3.0L	4V	EATC	✓	✓	✓	✓
2005	Taurus	3.0L	4V	GEM	✓	✓	✓	✓
2005	Taurus	3.0L	4V	IC	✓	✓	✓	✓
2005	Taurus	3.0L	4V	PCM	✓	✓	✓	✓
2005	Taurus	3.0L	4V	PCM	✓	✓	✓	✓
2005	Taurus	3.0L	4V	RCM	✓	✓	✓	✓
2006	Taurus	3.0L	2V	ABS	✓	✓	✓	✓
2006	Taurus	3.0L	2V	EATC	✓	✓	✓	✓
2006	Taurus	3.0L	2V	GEM	✓	✓	✓	✓
2006	Taurus	3.0L	2V	IC	✓	✓	✓	✓
2006	Taurus	3.0L	2V	PCM	✓	✓	✓	✓
2006	Taurus	3.0L	2V	PCM	✓	✓	✓	✓
2006	Taurus	3.0L	2V	RCM	✓	✓	✓	✓
2007	Taurus	3.0L	2V	ABS	✓	✓	✓	✓
2007	Taurus	3.0L	2V	EATC	✓	✓	✓	✓
2007	Taurus	3.0L	2V	GEM	✓	✓	✓	✓
2007	Taurus	3.0L	2V	IC	✓	✓	✓	✓

2007	Taurus	3.0L	2V	PCM	✓	✓	✓	✓
2007	Taurus	3.0L	2V	PCM	✓	✓	✓	✓
2007	Taurus	3.0L	2V	RCM	✓	✓	✓	✓
2008	Taurus	3.5L	4V	4X4	✓	✓	✓	✓
2008	Taurus	3.5L	4V	ABS	✓	✓	✓	✓
2008	Taurus	3.5L	4V	ACM	✓	✓	✓	✓
2008	Taurus	3.5L	4V	APIM	✓	✓	✓	✓
2008	Taurus	3.5L	4V	DSM	✓	✓	✓	✓
2008	Taurus	3.5L	4V	GEM / SJB	✓	✓	✓	✓
2008	Taurus	3.5L	4V	GEM / SJB	✓	✓	✓	✓
2008	Taurus	3.5L	4V	HVAC	✓	✓	✓	✓
2008	Taurus	3.5L	4V	IC	✓	✓	✓	✓
2008	Taurus	3.5L	4V	OCSM	✓	✓	✓	✓
2008	Taurus	3.5L	4V	PAM	✓	✓	✓	✓
2008	Taurus	3.5L	4V	PCM	✓	✓	✓	✓
2008	Taurus	3.5L	4V	PCM	✓	✓	✓	✓
2008	Taurus	3.5L	4V	RCM	✓	✓	✓	✓
2008	Taurus	3.5L	4V	RETM	✓	✓	✓	✓
2008	Taurus	3.5L	4V	SDARS	✓	✓	✓	✓
2008	Taurus	3.5L	4V	SECM	✓	✓	✓	✓
2009	Taurus	3.5L	4V	4X4	✓	✓	✓	✓
2009	Taurus	3.5L	4V	ABS	✓	✓	✓	✓
2009	Taurus	3.5L	4V	ACM	✓	✓	✓	✓
2009	Taurus	3.5L	4V	APIM	✓	✓	✓	✓
2009	Taurus	3.5L	4V	DSM	✓	✓	✓	✓
2009	Taurus	3.5L	4V	GEM / SJB	✓	✓	✓	✓
2009	Taurus	3.5L	4V	GEM / SJB	✓	✓	✓	✓
2009	Taurus	3.5L	4V	HVAC	✓	✓	✓	✓
2009	Taurus	3.5L	4V	IC	✓	✓	✓	✓
2009	Taurus	3.5L	4V	OCSM	✓	✓	✓	✓
2009	Taurus	3.5L	4V	PAM	✓	✓	✓	✓
2009	Taurus	3.5L	4V	PCM	✓	✓	✓	✓
2009	Taurus	3.5L	4V	RCM	✓	✓	✓	✓
2009	Taurus	3.5L	4V	RETM	✓	✓	✓	✓
2009	Taurus	3.5L	4V	SDARS	✓	✓	✓	✓
2009	Taurus	3.5L	4V	SECM	✓	✓	✓	✓
2010	Taurus	3.5L	4V	4X4	✓	✓	✓	✓
2010	Taurus	3.5L	4V	ABS	✓	✓	✓	✓
2010	Taurus	3.5L	4V	ACM	✓	✓	✓	✓
2010	Taurus	3.5L	4V	ACM	✓	✓	✓	✓
2010	Taurus	3.5L	4V	APIM	✓	✓	✓	✓
2010	Taurus	3.5L	4V	C-CM	✓	✓	✓	✓
2010	Taurus	3.5L	4V	DCSM	✓	✓	✓	✓
2010	Taurus	3.5L	4V	DDM	✓	✓	✓	✓
2010	Taurus	3.5L	4V	DSM	✓	✓	✓	✓

2010	Taurus	3.5L	4V	DSP	✓	✓	✓	✓
2010	Taurus	3.5L	4V	FCIM	✓	✓	✓	
2010	Taurus	3.5L	4V	FCIM	✓	✓	✓	✓
2010	Taurus	3.5L	4V	FDIM	✓	✓	✓	
2010	Taurus	3.5L	4V	GEM / SJB	✓	✓	✓	✓
2010	Taurus	3.5L	4V	GPSM	✓	✓	✓	✓
2010	Taurus	3.5L	4V	HCM	✓	✓	✓	✓
2010	Taurus	3.5L	4V	HCM-2	✓	✓	✓	✓
2010	Taurus	3.5L	4V	HUD	✓	✓	✓	✓
2010	Taurus	3.5L	4V	HVAC	✓	✓	✓	✓
2010	Taurus	3.5L	4V	ILCM	✓	✓	✓	✓
2010	Taurus	3.5L	4V	IPC	✓	✓	✓	✓
2010	Taurus	3.5L	4V	OCSM	✓	✓	✓	✓
2010	Taurus	3.5L	4V	PAM	✓	✓	✓	
2010	Taurus	3.5L	4V	PCM	✓	✓	✓	✓
2010	Taurus	3.5L	4V	PSCM	✓	✓	✓	✓
2010	Taurus	3.5L	4V	RCM	✓	✓	✓	✓
2010	Taurus	3.5L	4V	RETM	✓	✓	✓	✓
2010	Taurus	3.5L	4V	RFA	✓	✓	✓	✓
2010	Taurus	3.5L	4V	SASM	✓	✓	✓	✓
2010	Taurus	3.5L	4V	SOD-L	✓	✓	✓	✓
2010	Taurus	3.5L	4V	SOD-R	✓	✓	✓	✓
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	4X4	✓	✓	✓	✓
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	ABS	✓	✓	✓	✓
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	ACM	✓	✓	✓	✓
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	APIM	✓	✓	✓	✓
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	C-CM	✓	✓	✓	✓
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	DCSM	✓	✓	✓	✓
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	DDM	✓	✓	✓	✓
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	DSM	✓	✓	✓	✓
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	DSP	✓	✓	✓	✓
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	FCIM	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	Iniection				
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	FCIM	✓	✓	✓	✓
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	FDIM	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	GEM / SJB	✓	✓	✓	✓
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	GPSM	✓	✓	✓	✓
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	HCM	✓	✓	✓	✓
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	HCM-2	✓	✓	✓	✓
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	HUD	✓	✓	✓	✓
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	ILCM	✓	✓	✓	✓
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	IPC	✓	✓	✓	✓
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	OCSM	✓	✓	✓	✓
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	PAM	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓

2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	PSCM	✓	✓	✓	✓
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	RCM	✓	✓	✓	✓
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	RETM	✓	✓	✓	✓
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	RFA	✓	✓	✓	✓
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	SASM	✓	✓	✓	✓
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-L	✓	✓	✓	✓
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-R	✓	✓	✓	✓
2011	Taurus	3.5L	4V	4X4	✓	✓	✓	✓
2011	Taurus	3.5L	4V	ABS	✓	✓	✓	✓
2011	Taurus	3.5L	4V	ACM	✓	✓	✓	✓
2011	Taurus	3.5L	4V	ACM	✓	✓	✓	✓
2011	Taurus	3.5L	4V	APIM	✓	✓	✓	✓
2011	Taurus	3.5L	4V	C-CM	✓	✓	✓	✓
2011	Taurus	3.5L	4V	DCSM	✓	✓	✓	✓
2011	Taurus	3.5L	4V	DDM	✓	✓	✓	✓
2011	Taurus	3.5L	4V	DSM	✓	✓	✓	✓
2011	Taurus	3.5L	4V	DSP	✓	✓	✓	
2011	Taurus	3.5L	4V	FCIM	✓	✓	✓	
2011	Taurus	3.5L	4V	FCIM	✓	✓	✓	✓
2011	Taurus	3.5L	4V	FDIM	✓	✓	✓	
2011	Taurus	3.5L	4V	GEM / SJB	✓	✓	✓	✓
2011	Taurus	3.5L	4V	GPSM	✓	✓	✓	✓
2011	Taurus	3.5L	4V	HCM	✓	✓	✓	✓
2011	Taurus	3.5L	4V	HCM-2	✓	✓	✓	✓
2011	Taurus	3.5L	4V	HUD	✓	✓	✓	✓
2011	Taurus	3.5L	4V	HVAC	✓	✓	✓	✓
2011	Taurus	3.5L	4V	ILCM	✓	✓	✓	✓
2011	Taurus	3.5L	4V	IPC	✓	✓	✓	✓
2011	Taurus	3.5L	4V	OCSM	✓	✓	✓	✓
2011	Taurus	3.5L	4V	PAM	✓	✓	✓	
2011	Taurus	3.5L	4V	PCM	✓	✓	✓	✓
2011	Taurus	3.5L	4V	PCM	✓	✓	✓	✓
2011	Taurus	3.5L	4V	PSCM	✓	✓	✓	✓
2011	Taurus	3.5L	4V	RCM	✓	✓	✓	✓
2011	Taurus	3.5L	4V	RETM	✓	✓	✓	✓
2011	Taurus	3.5L	4V	RFA	✓	✓	✓	✓
2011	Taurus	3.5L	4V	SASM	✓	✓	✓	✓
2011	Taurus	3.5L	4V	SOD-L	✓	✓	✓	✓
2011	Taurus	3.5L	4V	SOD-R	✓	✓	✓	✓
2011	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	4X4	✓	✓	✓	✓
2011	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	ABS	✓	✓	✓	✓
2011	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	ABS	✓	✓	✓	✓
2011	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	ACM	✓	✓	✓	✓

2011	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM	√	√	√	√
2011	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	DCSM	√	√	√	√
2011	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	√
2011	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	DSM	√	√	√	√
2011	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	DSP	√	√	√	
2011	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	
2011	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	√
2011	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	FDIM	√	√	√	
2011	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	GEM / SJB	√	√	√	√
2011	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	√
2011	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	HCM	√	√	√	√
2011	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	HCM-2	√	√	√	√
2011	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	HUD	√	√	√	√
2011	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	√
2011	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	ILCM	√	√	√	√
2011	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2011	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	OCSM	√	√	√	√
2011	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	
2011	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2011	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2011	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2011	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM	√	√	√	√
2011	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	RETM	√	√	√	√
2011	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	√
2011	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	SASM	√	√	√	√
2011	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	√
2011	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2012	Taurus	3.5L	4V	4X4	√	√	√	√
2012	Taurus	3.5L	4V	ABS	√	√	√	√
2012	Taurus	3.5L	4V	ACM	√	√	√	√
2012	Taurus	3.5L	4V	APIM	√	√	√	√
2012	Taurus	3.5L	4V	C-CM	√	√	√	√
2012	Taurus	3.5L	4V	DCSM	√	√	√	√
2012	Taurus	3.5L	4V	DDM	√	√	√	√
2012	Taurus	3.5L	4V	DSM	√	√	√	√
2012	Taurus	3.5L	4V	DSP	√	√	√	
2012	Taurus	3.5L	4V	FCIM	√	√	√	√
2012	Taurus	3.5L	4V	FDIM	√	√	√	
2012	Taurus	3.5L	4V	GEM / SJB	√	√	√	√
2012	Taurus	3.5L	4V	GPSM	√	√	√	√
2012	Taurus	3.5L	4V	HCM	√	√	√	√
2012	Taurus	3.5L	4V	HCM-2	√	√	√	√
2012	Taurus	3.5L	4V	HUD	√	√	√	√

2012	Taurus	3.5L	4V	HVAC	✓	✓	✓	✓
2012	Taurus	3.5L	4V	ILCM	✓	✓	✓	✓
2012	Taurus	3.5L	4V	IPC	✓	✓	✓	✓
2012	Taurus	3.5L	4V	OCSM	✓	✓	✓	✓
2012	Taurus	3.5L	4V	PAM	✓	✓	✓	
2012	Taurus	3.5L	4V	PCM	✓	✓	✓	✓
2012	Taurus	3.5L	4V	PCM	✓	✓	✓	✓
2012	Taurus	3.5L	4V	PSCM	✓	✓	✓	✓
2012	Taurus	3.5L	4V	RCM	✓	✓	✓	✓
2012	Taurus	3.5L	4V	RETM	✓	✓	✓	✓
2012	Taurus	3.5L	4V	RFA	✓	✓	✓	✓
2012	Taurus	3.5L	4V	SASM	✓	✓	✓	✓
2012	Taurus	3.5L	4V	SOD-L	✓	✓	✓	✓
2012	Taurus	3.5L	4V	SOD-R	✓	✓	✓	✓
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	4X4	✓	✓	✓	✓
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	ABS	✓	✓	✓	✓
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	ACM	✓	✓	✓	✓
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	ACM	✓	✓	✓	✓
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	APIM	✓	✓	✓	✓
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	C-CM	✓	✓	✓	✓
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	DCSM	✓	✓	✓	✓
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	DDM	✓	✓	✓	✓
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	DSM	✓	✓	✓	✓
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	DSP	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	FCIM	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	FCIM	✓	✓	✓	✓
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	FDIM	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	GEM / SJB	✓	✓	✓	✓
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	GPSM	✓	✓	✓	✓
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	HCM	✓	✓	✓	✓
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	HCM-2	✓	✓	✓	✓
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	HUD	✓	✓	✓	✓
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	HVAC	✓	✓	✓	✓
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	ILCM	✓	✓	✓	✓
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	IPC	✓	✓	✓	✓
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	PSCM	✓	✓	✓	✓
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	RCM	✓	✓	✓	✓
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	RETM	✓	✓	✓	✓
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	RFA	✓	✓	✓	✓
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	SASM	✓	✓	✓	✓
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-L	✓	✓	✓	✓

2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2012	Taurus	Other	Other	4X4	√	√	√	√
2012	Taurus	Other	Other	ABS	√	√	√	√
2012	Taurus	Other	Other	ACM	√	√	√	√
2012	Taurus	Other	Other	APIM	√	√	√	√
2012	Taurus	Other	Other	C-CM	√	√	√	√
2012	Taurus	Other	Other	DCSM	√	√	√	√
2012	Taurus	Other	Other	DDM	√	√	√	√
2012	Taurus	Other	Other	DSM	√	√	√	√
2012	Taurus	Other	Other	DSP	√	√	√	
2012	Taurus	Other	Other	FCIM	√	√	√	
2012	Taurus	Other	Other	FCIM	√	√	√	√
2012	Taurus	Other	Other	FDIM	√	√	√	
2012	Taurus	Other	Other	GEM / SJB	√	√	√	√
2012	Taurus	Other	Other	GPSM	√	√	√	√
2012	Taurus	Other	Other	HCM	√	√	√	√
2012	Taurus	Other	Other	HCM-2	√	√	√	√
2012	Taurus	Other	Other	HUD	√	√	√	√
2012	Taurus	Other	Other	HVAC	√	√	√	√
2012	Taurus	Other	Other	ILCM	√	√	√	√
2012	Taurus	Other	Other	IPC	√	√	√	√
2012	Taurus	Other	Other	OCSM	√	√	√	√
2012	Taurus	Other	Other	PAM	√	√	√	
2012	Taurus	Other	Other	PCM	√	√	√	√
2012	Taurus	Other	Other	PSCM	√	√	√	√
2012	Taurus	Other	Other	RCM	√	√	√	√
2012	Taurus	Other	Other	RETM	√	√	√	√
2012	Taurus	Other	Other	RFA	√	√	√	√
2012	Taurus	Other	Other	SASM	√	√	√	√
2012	Taurus	Other	Other	SOD-L	√	√	√	√
2012	Taurus	Other	Other	SOD-R	√	√	√	√
2013	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2013	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	√	√	√	√
2013	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2013	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	BCM#1	√	√	√	√
2013	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	C-CM	√	√	√	√
2013	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	DCSM	√	√	√	√
2013	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	√
2013	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	DSM	√	√	√	√
2013	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	DSP	√	√	√	√
2013	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	√	√	√	√
2013	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	GFM	√	√	√	√
2013	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	√





2013	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	RACM	√	√	√	√
2013	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2013	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	RFA	√	√	√	√
2013	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	RTM	√	√	√	√
2013	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SCCM	√	√	√	√
2013	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-L	√	√	√	√
2013	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-R	√	√	√	√
2013	Taurus	3.5L	TiVCT	ABS	√	√	√	√
2013	Taurus	3.5L	TiVCT	ACM	√	√	√	√
2013	Taurus	3.5L	TiVCT	APIM	√	√	√	√
2013	Taurus	3.5L	TiVCT	BCM#1	√	√	√	√
2013	Taurus	3.5L	TiVCT	C-CM	√	√	√	√
2013	Taurus	3.5L	TiVCT	DCSM	√	√	√	√
2013	Taurus	3.5L	TiVCT	DDM	√	√	√	√
2013	Taurus	3.5L	TiVCT	DSM	√	√	√	√
2013	Taurus	3.5L	TiVCT	DSP	√	√	√	√
2013	Taurus	3.5L	TiVCT	FCDIM	√	√	√	√
2013	Taurus	3.5L	TiVCT	FCIM	√	√	√	√
2013	Taurus	3.5L	TiVCT	GFM	√	√	√	√
2013	Taurus	3.5L	TiVCT	GPSM	√	√	√	√
2013	Taurus	3.5L	TiVCT	HCM	√	√	√	√
2013	Taurus	3.5L	TiVCT	HSWM	√	√	√	√
2013	Taurus	3.5L	TiVCT	HUD	√	√	√	√
2013	Taurus	3.5L	TiVCT	HVAC	√	√	√	√
2013	Taurus	3.5L	TiVCT	IPC	√	√	√	√
2013	Taurus	3.5L	TiVCT	OCSM	√	√	√	√
2013	Taurus	3.5L	TiVCT	PAM	√	√	√	√
2013	Taurus	3.5L	TiVCT	PCM	√	√	√	√
2013	Taurus	3.5L	TiVCT	PCM	√	√	√	√
2013	Taurus	3.5L	TiVCT	PCM	√	√	√	√
2013	Taurus	3.5L	TiVCT	PCM	√	√	√	√
2013	Taurus	3.5L	TiVCT	PSCM	√	√	√	√
2013	Taurus	3.5L	TiVCT	RACM	√	√	√	√
2013	Taurus	3.5L	TiVCT	RCM	√	√	√	√
2013	Taurus	3.5L	TiVCT	RFA	√	√	√	√
2013	Taurus	3.5L	TiVCT	RTM	√	√	√	√
2013	Taurus	3.5L	TiVCT	SCCM	√	√	√	√
2013	Taurus	3.5L	TiVCT	SOD-L	√	√	√	√
2013	Taurus	3.5L	TiVCT	SOD-R	√	√	√	√
2013	Taurus	3.7L	TiVCT	ABS	√	√	√	√
2013	Taurus	3.7L	TiVCT	ACM	√	√	√	√
2013	Taurus	3.7L	TiVCT	APIM	√	√	√	√
2013	Taurus	3.7L	TiVCT	BCM#1	√	√	√	√
2013	Taurus	3.7L	TiVCT	C-CM	√	√	√	√

2013	Taurus	3.7L	TiVCT	DCSM	√	√	√	√
2013	Taurus	3.7L	TiVCT	DDM	√	√	√	√
2013	Taurus	3.7L	TiVCT	DSM	√	√	√	√
2013	Taurus	3.7L	TiVCT	DSP	√	√	√	√
2013	Taurus	3.7L	TiVCT	FCDIM	√	√	√	√
2013	Taurus	3.7L	TiVCT	FCIM	√	√	√	√
2013	Taurus	3.7L	TiVCT	GFM	√	√	√	√
2013	Taurus	3.7L	TiVCT	GPSM	√	√	√	√
2013	Taurus	3.7L	TiVCT	HSWM	√	√	√	√
2013	Taurus	3.7L	TiVCT	HUD	√	√	√	√
2013	Taurus	3.7L	TiVCT	HVAC	√	√	√	√
2013	Taurus	3.7L	TiVCT	IPC	√	√	√	√
2013	Taurus	3.7L	TiVCT	IPM-A	√	√	√	√
2013	Taurus	3.7L	TiVCT	OCSM	√	√	√	√
2013	Taurus	3.7L	TiVCT	PAM	√	√	√	√
2013	Taurus	3.7L	TiVCT	PCM	√	√	√	√
2013	Taurus	3.7L	TiVCT	PCM	√	√	√	√
2013	Taurus	3.7L	TiVCT	PSCM	√	√	√	√
2013	Taurus	3.7L	TiVCT	RACM	√	√	√	√
2013	Taurus	3.7L	TiVCT	RCM	√	√	√	√
2013	Taurus	3.7L	TiVCT	RFA	√	√	√	√
2013	Taurus	3.7L	TiVCT	RTM	√	√	√	√
2013	Taurus	3.7L	TiVCT	SCCM	√	√	√	√
2013	Taurus	3.7L	TiVCT	SOD-L	√	√	√	√
2013	Taurus	3.7L	TiVCT	SOD-R	√	√	√	√
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	ACM	√	√	√	√
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	BCM#1	√	√	√	√
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	C-CM	√	√	√	√
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	DCSM	√	√	√	√
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	√
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	DSM	√	√	√	√
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	DSP	√	√	√	√
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	FCDIM	√	√	√	√
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	√
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM	√	√	√	√
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	HSWM	√	√	√	√
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	HUD	√	√	√	√
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	√
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	IPM-A	√	√	√	√
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	OCSM	√	√	√	√
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√

2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	PSCM	✓	✓	✓	✓
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	RACM	✓	✓	✓	✓
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	RCM	✓	✓	✓	✓
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	RFA	✓	✓	✓	✓
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	RTM	✓	✓	✓	✓
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	SCCM	✓	✓	✓	✓
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-L	✓	✓	✓	✓
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct	SOD-R	✓	✓	✓	✓
2014	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	ABS	✓	✓	✓	✓
2014	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	ACM	✓	✓	✓	✓
2014	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	APIM	✓	✓	✓	✓
2014	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓
2014	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	C-CM	✓	✓	✓	✓
2014	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	DCSM	✓	✓	✓	✓
2014	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	DDM	✓	✓	✓	✓
2014	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	DSM	✓	✓	✓	✓
2014	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	DSP	✓	✓	✓	✓
2014	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	FCDIM	✓	✓	✓	✓
2014	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	FCIM	✓	✓	✓	✓
2014	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GFM	✓	✓	✓	✓
2014	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	HSWM	✓	✓	✓	✓
2014	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	HUD	✓	✓	✓	✓
2014	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	HVAC	✓	✓	✓	✓
2014	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	IPC	✓	✓	✓	✓
2014	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	IPM-A	✓	✓	✓	✓
2014	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	OCSM	✓	✓	✓	✓
2014	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	PAM	✓	✓	✓	✓
2014	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2014	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2014	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	PSCM	✓	✓	✓	✓
2014	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	RACM	✓	✓	✓	✓
2014	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	RCM	✓	✓	✓	✓
2014	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	RFA	✓	✓	✓	✓
2014	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	RTM	✓	✓	✓	✓
2014	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	SCCM	✓	✓	✓	✓
2014	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-L	✓	✓	✓	✓
2014	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct	SOD-R	✓	✓	✓	✓
2014	Taurus	3.5L	TiVCT	ABS	✓	✓	✓	✓
2014	Taurus	3.5L	TiVCT	ACM	✓	✓	✓	✓
2014	Taurus	3.5L	TiVCT	APIM	✓	✓	✓	✓
2014	Taurus	3.5L	TiVCT	BCM#1	✓	✓	✓	✓

2014	Taurus	3.5L	TiVCT	C-CM	√	√	√	√
2014	Taurus	3.5L	TiVCT	DCSM	√	√	√	√
2014	Taurus	3.5L	TiVCT	DDM	√	√	√	√
2014	Taurus	3.5L	TiVCT	DSM	√	√	√	√
2014	Taurus	3.5L	TiVCT	DSP	√	√	√	√
2014	Taurus	3.5L	TiVCT	FCDIM	√	√	√	√
2014	Taurus	3.5L	TiVCT	FCIM	√	√	√	√
2014	Taurus	3.5L	TiVCT	GFM	√	√	√	√
2014	Taurus	3.5L	TiVCT	GPSM	√	√	√	√
2014	Taurus	3.5L	TiVCT	HSWM	√	√	√	√
2014	Taurus	3.5L	TiVCT	HUD	√	√	√	√
2014	Taurus	3.5L	TiVCT	HVAC	√	√	√	√
2014	Taurus	3.5L	TiVCT	IPC	√	√	√	√
2014	Taurus	3.5L	TiVCT	IPM-A	√	√	√	√
2014	Taurus	3.5L	TiVCT	OCSM	√	√	√	√
2014	Taurus	3.5L	TiVCT	PAM	√	√	√	√
2014	Taurus	3.5L	TiVCT	PCM	√	√	√	√
2014	Taurus	3.5L	TiVCT	PCM	√	√	√	√
2014	Taurus	3.5L	TiVCT	PSCM	√	√	√	√
2014	Taurus	3.5L	TiVCT	RACM	√	√	√	√
2014	Taurus	3.5L	TiVCT	RCM	√	√	√	√
2014	Taurus	3.5L	TiVCT	RFA	√	√	√	√
2014	Taurus	3.5L	TiVCT	RTM	√	√	√	√
2014	Taurus	3.5L	TiVCT	SCCM	√	√	√	√
2014	Taurus	3.5L	TiVCT	SOD-L	√	√	√	√
2014	Taurus	3.5L	TiVCT	SOD-R	√	√	√	√
2014	Taurus	3.7L	TiVCT	ABS	√	√	√	√
2014	Taurus	3.7L	TiVCT	ACM	√	√	√	√
2014	Taurus	3.7L	TiVCT	APIM	√	√	√	√
2014	Taurus	3.7L	TiVCT	BCM#1	√	√	√	√
2014	Taurus	3.7L	TiVCT	DCSM	√	√	√	√
2014	Taurus	3.7L	TiVCT	DDM	√	√	√	√
2014	Taurus	3.7L	TiVCT	DSM	√	√	√	√
2014	Taurus	3.7L	TiVCT	DSP	√	√	√	√
2014	Taurus	3.7L	TiVCT	FCDIM	√	√	√	√
2014	Taurus	3.7L	TiVCT	FCIM	√	√	√	√
2014	Taurus	3.7L	TiVCT	GFM	√	√	√	√
2014	Taurus	3.7L	TiVCT	GPSM	√	√	√	√
2014	Taurus	3.7L	TiVCT	HSWM	√	√	√	√
2014	Taurus	3.7L	TiVCT	HUD	√	√	√	√
2014	Taurus	3.7L	TiVCT	HVAC	√	√	√	√
2014	Taurus	3.7L	TiVCT	IPC	√	√	√	√
2014	Taurus	3.7L	TiVCT	IPM-A	√	√	√	√
2014	Taurus	3.7L	TiVCT	OCSM	√	√	√	√
2014	Taurus	3.7L	TiVCT	PAM	√	√	√	√

2014	Taurus	3.7L	TiVCT	PCM	✓	✓	✓	✓
2014	Taurus	3.7L	TiVCT	PCM	✓	✓	✓	✓
2014	Taurus	3.7L	TiVCT	PSCM	✓	✓	✓	✓
2014	Taurus	3.7L	TiVCT	RACM	✓	✓	✓	✓
2014	Taurus	3.7L	TiVCT	RCM	✓	✓	✓	✓
2014	Taurus	3.7L	TiVCT	RFA	✓	✓	✓	✓
2014	Taurus	3.7L	TiVCT	RTM	✓	✓	✓	✓
2014	Taurus	3.7L	TiVCT	SCCM	✓	✓	✓	✓
2014	Taurus	3.7L	TiVCT	SOD-L	✓	✓	✓	✓
2014	Taurus	3.7L	TiVCT	SOD-R	✓	✓	✓	✓
2008	Taurus X	3.5L	4V	4X4	✓	✓	✓	✓
2008	Taurus X	3.5L	4V	ABS	✓	✓	✓	✓
2008	Taurus X	3.5L	4V	ACM	✓	✓	✓	✓
2008	Taurus X	3.5L	4V	APIM	✓	✓	✓	✓
2008	Taurus X	3.5L	4V	DSM	✓	✓	✓	✓
2008	Taurus X	3.5L	4V	GEM / SJB	✓	✓	✓	✓
2008	Taurus X	3.5L	4V	HVAC	✓	✓	✓	✓
2008	Taurus X	3.5L	4V	IC	✓	✓	✓	✓
2008	Taurus X	3.5L	4V	LTM	✓	✓	✓	✓
2008	Taurus X	3.5L	4V	OCSM	✓	✓	✓	✓
2008	Taurus X	3.5L	4V	PAM	✓	✓	✓	✓
2008	Taurus X	3.5L	4V	PCM	✓	✓	✓	✓
2008	Taurus X	3.5L	4V	RCM	✓	✓	✓	✓
2008	Taurus X	3.5L	4V	RETM	✓	✓	✓	✓
2008	Taurus X	3.5L	4V	SDARS	✓	✓	✓	✓
2008	Taurus X	3.5L	4V	SECM	✓	✓	✓	✓
2009	Taurus X	3.5L	4V	4X4	✓	✓	✓	✓
2009	Taurus X	3.5L	4V	ABS	✓	✓	✓	✓
2009	Taurus X	3.5L	4V	ACM	✓	✓	✓	✓
2009	Taurus X	3.5L	4V	APIM	✓	✓	✓	✓
2009	Taurus X	3.5L	4V	DSM	✓	✓	✓	✓
2009	Taurus X	3.5L	4V	GEM / SJB	✓	✓	✓	✓
2009	Taurus X	3.5L	4V	HVAC	✓	✓	✓	✓
2009	Taurus X	3.5L	4V	IC	✓	✓	✓	✓
2009	Taurus X	3.5L	4V	LTM	✓	✓	✓	✓
2009	Taurus X	3.5L	4V	OCSM	✓	✓	✓	✓
2009	Taurus X	3.5L	4V	PAM	✓	✓	✓	✓
2009	Taurus X	3.5L	4V	PCM	✓	✓	✓	✓
2009	Taurus X	3.5L	4V	RCM	✓	✓	✓	✓
2009	Taurus X	3.5L	4V	RETM	✓	✓	✓	✓
2009	Taurus X	3.5L	4V	SDARS	✓	✓	✓	✓
2009	Taurus X	3.5L	4V	SECM	✓	✓	✓	✓
Other	Telstar	1.8L	Other	PCM	✓	✓	✓	
Other	Telstar	2.0L	Other	PCM	✓	✓	✓	
Other	Telstar	2.5L	Other	PCM	✓	✓	✓	

2004	Territory	4.0L	DOHC VCT	ABS	√	√	√	√
2004	Territory	4.0L	DOHC VCT	ABS/TCS	√	√	√	√
2004	Territory	4.0L	DOHC VCT	ACM	√	√	√	√
2004	Territory	4.0L	DOHC VCT	BEM	√	√	√	√
2004	Territory	4.0L	DOHC VCT	BEM	√	√	√	√
2004	Territory	4.0L	DOHC VCT	HIM	√	√	√	√
2004	Territory	4.0L	DOHC VCT	IC	√	√	√	√
2004	Territory	4.0L	DOHC VCT	IC	√	√	√	√
2004	Territory	4.0L	DOHC VCT	PAM	√	√	√	√
2004	Territory	4.0L	DOHC VCT	PCM	√	√	√	√
2004	Territory	4.0L	DOHC VCT	RCM	√	√	√	√
2006	Territory	4.0L	DOHC VCT	ABS	√	√	√	√
2006	Territory	4.0L	DOHC VCT	ACM	√	√	√	√
2006	Territory	4.0L	DOHC VCT	BEM	√	√	√	
2006	Territory	4.0L	DOHC VCT	HIM	√	√	√	√
2006	Territory	4.0L	DOHC VCT	IC	√	√	√	√
2006	Territory	4.0L	DOHC VCT	PAM	√	√	√	√
2006	Territory	4.0L	DOHC VCT	PCM	√	√	√	√
2006	Territory	4.0L	DOHC VCT	RCM	√	√	√	√
2006	Territory	4.0L	DOHC VCT	TCM	√	√	√	√
2011	Territory	2_7L	Direct Injection -	ABS	√	√	√	√
2011	Territory	2_7L	Direct Injection -	ACM	√	√	√	√
2011	Territory	2_7L	Direct Injection -	ACM	√	√	√	√
2011	Territory	2_7L	Direct Injection -	AWD#1	√	√	√	√
2011	Territory	2_7L	Direct Injection -	BEM	√	√	√	√
2011	Territory	2_7L	Direct Injection -	BEM	√	√	√	√
2011	Territory	2_7L	Direct Injection -	BEM	√	√	√	√
2011	Territory	2_7L	Direct Injection -	FDIM	√	√	√	√
2011	Territory	2_7L	Direct Injection -	FDIM	√	√	√	√
2011	Territory	2_7L	Direct Injection -	HIM	√	√	√	√
2011	Territory	2_7L	Direct Injection -	HIM	√	√	√	√
2011	Territory	2_7L	Direct Injection -	IPC	√	√	√	√
2011	Territory	2_7L	Direct Injection -	IPC	√	√	√	√
2011	Territory	2_7L	Direct Injection -	PAM	√	√	√	√
2011	Territory	2_7L	Direct Injection -	PAM	√	√	√	√
2011	Territory	2_7L	Direct Injection -	PCM	√	√	√	√
2011	Territory	2_7L	Direct Injection - Turbo	PCM	√	√	√	√
2011	Territory	2_7L	Direct Injection -	PSCM	√	√	√	√
2011	Territory	2_7L	Direct Injection -	RCM	√	√	√	√
2011	Territory	2_7L	Direct Injection -	RCM	√	√	√	√
2011	Territory	2_7L	Direct Injection -	TCM	√	√	√	√
2011	Territory	4.0L	DOHC VCT	ABS	√	√	√	√
2011	Territory	4.0L	DOHC VCT	ACM	√	√	√	√
2011	Territory	4.0L	DOHC VCT	BEM	√	√	√	√
2011	Territory	4.0L	DOHC VCT	FDIM	√	√	√	√

2011	Territory	4.0L	DOHC VCT	HIM	√	√	√	√
2011	Territory	4.0L	DOHC VCT	IPC	√	√	√	√
2011	Territory	4.0L	DOHC VCT	PAM	√	√	√	√
2011	Territory	4.0L	DOHC VCT	PCM	√	√	√	√
2011	Territory	4.0L	DOHC VCT	PSCM	√	√	√	√
2011	Territory	4.0L	DOHC VCT	RCM	√	√	√	√
2011	Territory	4.0L	DOHC VCT	TCM	√	√	√	√
2011	Territory	Other	Other	ABS	√	√	√	√
2011	Territory	Other	Other	ACM	√	√	√	√
2011	Territory	Other	Other	BEM	√	√	√	√
2011	Territory	Other	Other	FDIM	√	√	√	√
2011	Territory	Other	Other	HIM	√	√	√	√
2011	Territory	Other	Other	IPC	√	√	√	√
2011	Territory	Other	Other	PAM	√	√	√	√
2011	Territory	Other	Other	PSCM	√	√	√	√
2011	Territory	Other	Other	RCM	√	√	√	√
1994	Thunderbird	4.6L	2V	PCM	√	√	√	√
1995	Thunderbird	4.6L	2V	PCM	√	√	√	√
1996	Thunderbird	3.8L	Other	PCM	√	√	√	√
1996	Thunderbird	4.6L	2V	PCM	√	√	√	√
1996	Thunderbird	4.6L	Other	PCM	√	√	√	√
1997	Thunderbird	3.8L	Other	PCM	√	√	√	√
1997	Thunderbird	4.6L	2V	PCM	√	√	√	√
2002	Thunderbird	3.9L	4V	ABS/TCS	√	√	√	√
2002	Thunderbird	3.9L	4V	ACM	√	√	√	√
2002	Thunderbird	3.9L	4V	DDM	√	√	√	√
2002	Thunderbird	3.9L	4V	EATC	√	√	√	√
2002	Thunderbird	3.9L	4V	GEM	√	√	√	√
2002	Thunderbird	3.9L	4V	HEC	√	√	√	√
2002	Thunderbird	3.9L	4V	PCM	√	√	√	√
2002	Thunderbird	3.9L	4V	PCM	√	√	√	√
2002	Thunderbird	3.9L	4V	RCM	√	√	√	√
2002	Thunderbird	3.9L	4V	REM	√	√	√	√
2003	Thunderbird	3.9L	4V	ABS/TCS	√	√	√	√
2003	Thunderbird	3.9L	4V	ACM	√	√	√	√
2003	Thunderbird	3.9L	4V	DDM	√	√	√	√
2003	Thunderbird	3.9L	4V	EATC	√	√	√	√
2003	Thunderbird	3.9L	4V	GEM	√	√	√	√
2003	Thunderbird	3.9L	4V	HEC	√	√	√	√
2003	Thunderbird	3.9L	4V	PCM	√	√	√	√
2003	Thunderbird	3.9L	4V	PCM	√	√	√	√
2003	Thunderbird	3.9L	4V	RCM	√	√	√	√
2003	Thunderbird	3.9L	4V	REM	√	√	√	√
2004	Thunderbird	3.9L	4V	ABS/TCS	√	√	√	√
2004	Thunderbird	3.9L	4V	ACM	√	√	√	√

2004	Thunderbird	3.9L	4V	DDM	√	√	√	√
2004	Thunderbird	3.9L	4V	EATC	√	√	√	√
2004	Thunderbird	3.9L	4V	GEM	√	√	√	√
2004	Thunderbird	3.9L	4V	HEC	√	√	√	√
2004	Thunderbird	3.9L	4V	PCM	√	√	√	√
2004	Thunderbird	3.9L	4V	PCM	√	√	√	√
2004	Thunderbird	3.9L	4V	RCM	√	√	√	√
2004	Thunderbird	3.9L	4V	REM	√	√	√	√
2005	Thunderbird	3.9L	4V	ABS/TCS	√	√	√	√
2005	Thunderbird	3.9L	4V	ACM	√	√	√	√
2005	Thunderbird	3.9L	4V	DDM	√	√	√	√
2005	Thunderbird	3.9L	4V	EATC	√	√	√	√
2005	Thunderbird	3.9L	4V	GEM	√	√	√	√
2005	Thunderbird	3.9L	4V	HEC	√	√	√	√
2005	Thunderbird	3.9L	4V	PCM	√	√	√	√
2005	Thunderbird	3.9L	4V	PCM	√	√	√	√
2005	Thunderbird	3.9L	4V	RCM	√	√	√	√
2005	Thunderbird	3.9L	4V	REM	√	√	√	√
2000	Titan	4.0L	TF	PCM	√	√	√	√
2002	Titan	4.0L	TF	PCM	√	√	√	
1995	Town Car	4.6L	2V	ABS/TCS	√	√	√	
1995	Town Car	4.6L	2V	DDM	√	√	√	
1995	Town Car	4.6L	2V	DSM	√	√	√	
1995	Town Car	4.6L	2V	EATC	√	√	√	
1995	Town Car	4.6L	2V	LCM	√	√	√	
1995	Town Car	4.6L	2V	PCM	√	√	√	√
1996	Town Car	4.6L	2V	ABS/TCS	√	√	√	√
1996	Town Car	4.6L	2V	DDM	√	√	√	√
1996	Town Car	4.6L	2V	DSM	√	√	√	√
1996	Town Car	4.6L	2V	EATC	√	√	√	√
1996	Town Car	4.6L	2V	IAB	√	√	√	√
1996	Town Car	4.6L	2V	LCM	√	√	√	√
1996	Town Car	4.6L	2V	PCM	√	√	√	√
1997	Town Car	4.6L	2V	ABS/TCS	√	√	√	√
1997	Town Car	4.6L	2V	DDM	√	√	√	√
1997	Town Car	4.6L	2V	DSM	√	√	√	√
1997	Town Car	4.6L	2V	EATC	√	√	√	√
1997	Town Car	4.6L	2V	IAB	√	√	√	√
1997	Town Car	4.6L	2V	LCM	√	√	√	√
1997	Town Car	4.6L	2V	PCM	√	√	√	√
1998	Town Car	4.6L	2V	ABS/TCS	√	√	√	√
1998	Town Car	4.6L	2V	ACM	√	√	√	√
1998	Town Car	4.6L	2V	CPM	√	√	√	√
1998	Town Car	4.6L	2V	DDM	√	√	√	√
1998	Town Car	4.6L	2V	DSM	√	√	√	√



1998	Town Car	4.6L	2V	EATC	√	√	√	√
1998	Town Car	4.6L	2V	HEC	√	√	√	√
1998	Town Car	4.6L	2V	IAB	√	√	√	√
1998	Town Car	4.6L	2V	LCM	√	√	√	√
1998	Town Car	4.6L	2V	NGSC	√	√	√	√
1998	Town Car	4.6L	2V	PCM	√	√	√	√
1998	Town Car	4.6L	2V	RASM	√	√	√	√
1999	Town Car	4.6L	2V	ABS/TCS	√	√	√	√
1999	Town Car	4.6L	2V	ACM	√	√	√	√
1999	Town Car	4.6L	2V	ACM	√	√	√	√
1999	Town Car	4.6L	2V	CPM	√	√	√	√
1999	Town Car	4.6L	2V	DDM	√	√	√	√
1999	Town Car	4.6L	2V	DDM	√	√	√	√
1999	Town Car	4.6L	2V	DSM	√	√	√	√
1999	Town Car	4.6L	2V	EATC	√	√	√	√
1999	Town Car	4.6L	2V	HEC	√	√	√	√
1999	Town Car	4.6L	2V	LCM	√	√	√	√
1999	Town Car	4.6L	2V	LCM	√	√	√	√
1999	Town Car	4.6L	2V	NGSC	√	√	√	√
1999	Town Car	4.6L	2V	PCM	√	√	√	√
1999	Town Car	4.6L	2V	RASM	√	√	√	√
1999	Town Car	4.6L	2V	RCM	√	√	√	√
2000	Town Car	4.6L	2V	ABS/TCS	√	√	√	√
2000	Town Car	4.6L	2V	ABS/TCS	√	√	√	√
2000	Town Car	4.6L	2V	ACM	√	√	√	√
2000	Town Car	4.6L	2V	CPM	√	√	√	√
2000	Town Car	4.6L	2V	DDM	√	√	√	√
2000	Town Car	4.6L	2V	DSM	√	√	√	√
2000	Town Car	4.6L	2V	EATC	√	√	√	√
2000	Town Car	4.6L	2V	HEC	√	√	√	√
2000	Town Car	4.6L	2V	LCM	√	√	√	√
2000	Town Car	4.6L	2V	NGSC	√	√	√	√
2000	Town Car	4.6L	2V	PCM	√	√	√	√
2000	Town Car	4.6L	2V	RASM	√	√	√	√
2000	Town Car	4.6L	2V	RCM	√	√	√	√
2000	Town Car	4.6L	2V	RCM	√	√	√	√
2002	Town Car	4.6L	2V	ABS/TCS	√	√	√	√
2002	Town Car	4.6L	2V	ACM	√	√	√	√
2002	Town Car	4.6L	2V	CPM	√	√	√	√
2002	Town Car	4.6L	2V	DDM	√	√	√	√
2002	Town Car	4.6L	2V	DSM	√	√	√	√
2002	Town Car	4.6L	2V	EATC	√	√	√	√
2002	Town Car	4.6L	2V	HEC	√	√	√	√
2002	Town Car	4.6L	2V	LCM	√	√	√	√
2002	Town Car	4.6L	2V	NGSC	√	√	√	√

2002	Town Car	4.6L	2V	PCM	✓	✓	✓	✓
2002	Town Car	4.6L	2V	RASM	✓	✓	✓	✓
2002	Town Car	4.6L	2V	RCM	✓	✓	✓	✓
2002	Town Car	4.6L	2V	RESCU	✓	✓	✓	✓
2003	Town Car	4.6L	2V	ACM	✓	✓	✓	✓
2003	Town Car	4.6L	2V	CPM	✓	✓	✓	✓
2003	Town Car	4.6L	2V	DDM	✓	✓	✓	✓
2003	Town Car	4.6L	2V	DSM	✓	✓	✓	✓
2003	Town Car	4.6L	2V	EATC	✓	✓	✓	✓
2003	Town Car	4.6L	2V	HEC	✓	✓	✓	✓
2003	Town Car	4.6L	2V	LCM	✓	✓	✓	✓
2003	Town Car	4.6L	2V	LTM	✓	✓	✓	✓
2003	Town Car	4.6L	2V	MC	✓	✓	✓	✓
2003	Town Car	4.6L	2V	NAV	✓	✓	✓	✓
2003	Town Car	4.6L	2V	NGSC	✓	✓	✓	✓
2003	Town Car	4.6L	2V	PAM	✓	✓	✓	✓
2003	Town Car	4.6L	2V	PCM	✓	✓	✓	✓
2003	Town Car	4.6L	2V	RASM	✓	✓	✓	✓
2003	Town Car	4.6L	2V	RCM	✓	✓	✓	✓
2003	Town Car	4.6L	2V	RESCU	✓	✓	✓	✓
2004	Town Car	4.6L	2V	ABS/TCS	✓	✓	✓	✓
2004	Town Car	4.6L	2V	ACM	✓	✓	✓	✓
2004	Town Car	4.6L	2V	DDM	✓	✓	✓	✓
2004	Town Car	4.6L	2V	DSM	✓	✓	✓	✓
2004	Town Car	4.6L	2V	EATC	✓	✓	✓	✓
2004	Town Car	4.6L	2V	HEC	✓	✓	✓	✓
2004	Town Car	4.6L	2V	LCM	✓	✓	✓	✓
2004	Town Car	4.6L	2V	LTM	✓	✓	✓	✓
2004	Town Car	4.6L	2V	MC	✓	✓	✓	✓
2004	Town Car	4.6L	2V	NAV	✓	✓	✓	✓
2004	Town Car	4.6L	2V	NGSC	✓	✓	✓	✓
2004	Town Car	4.6L	2V	PAM	✓	✓	✓	✓
2004	Town Car	4.6L	2V	PCM	✓	✓	✓	✓
2004	Town Car	4.6L	2V	RASM	✓	✓	✓	✓
2004	Town Car	4.6L	2V	RCM	✓	✓	✓	✓
2005	Town Car	4.6L	2V	ABS	✓	✓	✓	✓
2005	Town Car	4.6L	2V	ACM	✓	✓	✓	✓
2005	Town Car	4.6L	2V	DDM	✓	✓	✓	✓
2005	Town Car	4.6L	2V	DSM	✓	✓	✓	✓
2005	Town Car	4.6L	2V	EATC	✓	✓	✓	✓
2005	Town Car	4.6L	2V	HEC	✓	✓	✓	✓
2005	Town Car	4.6L	2V	LCM	✓	✓	✓	✓
2005	Town Car	4.6L	2V	LTM	✓	✓	✓	✓
2005	Town Car	4.6L	2V	MC	✓	✓	✓	✓
2005	Town Car	4.6L	2V	NAV	✓	✓	✓	✓

2005	Town Car	4.6L	2V	PAM	✓	✓	✓	✓
2005	Town Car	4.6L	2V	PCM	✓	✓	✓	✓
2005	Town Car	4.6L	2V	PCM	✓	✓	✓	✓
2005	Town Car	4.6L	2V	RASM	✓	✓	✓	✓
2005	Town Car	4.6L	2V	RCM	✓	✓	✓	✓
2006	Town Car	4.6L	2V	ABS	✓	✓	✓	✓
2006	Town Car	4.6L	2V	DDM	✓	✓	✓	✓
2006	Town Car	4.6L	2V	DSM	✓	✓	✓	✓
2006	Town Car	4.6L	2V	EATC	✓	✓	✓	✓
2006	Town Car	4.6L	2V	IC	✓	✓	✓	✓
2006	Town Car	4.6L	2V	LCM	✓	✓	✓	✓
2006	Town Car	4.6L	2V	LTM	✓	✓	✓	✓
2006	Town Car	4.6L	2V	MC	✓	✓	✓	✓
2006	Town Car	4.6L	2V	NAV	✓	✓	✓	✓
2006	Town Car	4.6L	2V	PAM	✓	✓	✓	✓
2006	Town Car	4.6L	2V	PCM	✓	✓	✓	✓
2006	Town Car	4.6L	2V	PCM	✓	✓	✓	✓
2006	Town Car	4.6L	2V	PCM	✓	✓	✓	✓
2006	Town Car	4.6L	2V	RASM	✓	✓	✓	✓
2006	Town Car	4.6L	2V	RATC	✓	✓	✓	✓
2006	Town Car	4.6L	2V	RCM	✓	✓	✓	✓
2007	Town Car	4.6L	2V	ABS	✓	✓	✓	✓
2007	Town Car	4.6L	2V	DDM	✓	✓	✓	✓
2007	Town Car	4.6L	2V	DSM	✓	✓	✓	✓
2007	Town Car	4.6L	2V	EATC	✓	✓	✓	✓
2007	Town Car	4.6L	2V	IC	✓	✓	✓	✓
2007	Town Car	4.6L	2V	LCM	✓	✓	✓	✓
2007	Town Car	4.6L	2V	LTM	✓	✓	✓	✓
2007	Town Car	4.6L	2V	MC	✓	✓	✓	✓
2007	Town Car	4.6L	2V	NAV	✓	✓	✓	✓
2007	Town Car	4.6L	2V	PAM	✓	✓	✓	✓
2007	Town Car	4.6L	2V	PCM	✓	✓	✓	✓
2007	Town Car	4.6L	2V	PCM	✓	✓	✓	✓
2007	Town Car	4.6L	2V	PCM	✓	✓	✓	✓
2007	Town Car	4.6L	2V	RATC	✓	✓	✓	✓
2007	Town Car	4.6L	2V	RCM	✓	✓	✓	✓
2007	Town Car	4.6L	2V	VDM	✓	✓	✓	✓
2008	Town Car	4.6L	2V	ABS	✓	✓	✓	✓
2008	Town Car	4.6L	2V	DDM	✓	✓	✓	✓
2008	Town Car	4.6L	2V	DSM	✓	✓	✓	✓
2008	Town Car	4.6L	2V	HVAC	✓	✓	✓	✓
2008	Town Car	4.6L	2V	IC	✓	✓	✓	✓
2008	Town Car	4.6L	2V	LCM	✓	✓	✓	✓
2008	Town Car	4.6L	2V	LTM	✓	✓	✓	✓
2008	Town Car	4.6L	2V	MC	✓	✓	✓	✓

2008	Town Car	4.6L	2V	PAM	√	√	√	√
2008	Town Car	4.6L	2V	PCM	√	√	√	√
2008	Town Car	4.6L	2V	PCM	√	√	√	√
2008	Town Car	4.6L	2V	RATC	√	√	√	√
2008	Town Car	4.6L	2V	RCM	√	√	√	√
2008	Town Car	4.6L	2V	VDM	√	√	√	√
2009	Town Car	4.6L	2V	ABS	√	√	√	√
2009	Town Car	4.6L	2V	DDM	√	√	√	√
2009	Town Car	4.6L	2V	DSM	√	√	√	√
2009	Town Car	4.6L	2V	HVAC	√	√	√	√
2009	Town Car	4.6L	2V	IC	√	√	√	√
2009	Town Car	4.6L	2V	LCM	√	√	√	√
2009	Town Car	4.6L	2V	LTM	√	√	√	√
2009	Town Car	4.6L	2V	MC	√	√	√	√
2009	Town Car	4.6L	2V	NAV	√	√	√	√
2009	Town Car	4.6L	2V	PAM	√	√	√	√
2009	Town Car	4.6L	2V	PCM	√	√	√	√
2009	Town Car	4.6L	2V	PCM	√	√	√	√
2009	Town Car	4.6L	2V	PCM	√	√	√	√
2009	Town Car	4.6L	2V	RATC	√	√	√	√
2009	Town Car	4.6L	2V	RCM	√	√	√	√
2009	Town Car	4.6L	2V	VDM	√	√	√	√
2010	Town Car	4.6L	2V	ABS	√	√	√	√
2010	Town Car	4.6L	2V	DDM	√	√	√	√
2010	Town Car	4.6L	2V	DSM	√	√	√	√
2010	Town Car	4.6L	2V	HVAC	√	√	√	√
2010	Town Car	4.6L	2V	IC	√	√	√	√
2010	Town Car	4.6L	2V	LCM	√	√	√	√
2010	Town Car	4.6L	2V	LTM	√	√	√	√
2010	Town Car	4.6L	2V	MC	√	√	√	√
2010	Town Car	4.6L	2V	NAV	√	√	√	√
2010	Town Car	4.6L	2V	PAM	√	√	√	√
2010	Town Car	4.6L	2V	PCM	√	√	√	√
2010	Town Car	4.6L	2V	PCM	√	√	√	√
2010	Town Car	4.6L	2V	PCM	√	√	√	√
2010	Town Car	4.6L	2V	RATC	√	√	√	√
2010	Town Car	4.6L	2V	RCM	√	√	√	√
2010	Town Car	4.6L	2V	VDM	√	√	√	√
2011	Town Car	4.6L	2V	ABS	√	√	√	
2011	Town Car	4.6L	2V	DDM	√	√	√	√
2011	Town Car	4.6L	2V	DSM	√	√	√	√
2011	Town Car	4.6L	2V	HVAC	√	√	√	√
2011	Town Car	4.6L	2V	IC	√	√	√	√
2011	Town Car	4.6L	2V	LCM	√	√	√	√
2011	Town Car	4.6L	2V	LTM	√	√	√	√

2011	Town Car	4.6L	2V	PAM	√	√	√	√
2011	Town Car	4.6L	2V	PCM	√	√	√	√
2011	Town Car	4.6L	2V	PCM	√	√	√	√
2011	Town Car	4.6L	2V	RATC	√	√	√	√
2011	Town Car	4.6L	2V	RCM	√	√	√	√
2011	Town Car	4.6L	2V	VDM	√	√	√	√
1996	Tracer	1.9L	1.4 PT-E SFI	ABS/TCS	√	√	√	√
1996	Tracer	1.9L	1.4 PT-E SFI	PCM	√	√	√	√
1996	Tracer	1.9L	1.4 PT-E SFI	RAP	√	√	√	√
1997	Tracer	2.0L	SPI	ABS/TCS	√	√	√	√
1997	Tracer	2.0L	SPI	PCM	√	√	√	√
1997	Tracer	2.0L	SPI	RAP	√	√	√	√
1998	Tracer	2.0L	SPI	ABS/TCS	√	√	√	√
1998	Tracer	2.0L	SPI	ECS	√	√	√	√
1998	Tracer	2.0L	SPI	PCM	√	√	√	√
1998	Tracer	2.0L	SPI	RAP	√	√	√	√
1999	Tracer	2.0L	SPI	ABS/TCS	√	√	√	√
1999	Tracer	2.0L	SPI	IAB	√	√	√	
1999	Tracer	2.0L	SPI	PCM	√	√	√	√
1999	Tracer	2.0L	SPI	PCM	√	√	√	√
1999	Tracer	2.0L	SPI	RAP	√	√	√	√
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	AHCM	√	√	√	
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	APIM	√	√	√	
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	AWD#1	√	√	√	
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	BCMii	√	√	√	√
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	CCMii	√	√	√	√
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	FCDIM	√	√	√	√
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	FCIM	√	√	√	√
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	HCM	√	√	√	√
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	IPC	√	√	√	√
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	IPM-A	√	√	√	√
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	IPM-B	√	√	√	√
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	PAM	√	√	√	√
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	PRB	√	√	√	√
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	SASM	√	√	√	√
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	TRM	√	√	√	
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	√
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	ACM	√	√	√	√
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	AHCM	√	√	√	√
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	APIM	√	√	√	√
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	AWD#1	√	√	√	√

2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	BCMii	✓	✓	✓	✓
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	CCMii	✓	✓	✓	✓
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	FCDIM	✓	✓	✓	✓
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	FCIM	✓	✓	✓	✓
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	GPSM	✓	✓	✓	✓
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	HCM	✓	✓	✓	✓
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	IPC	✓	✓	✓	✓
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	IPM-A	✓	✓	✓	✓
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	IPM-B	✓	✓	✓	✓
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	PCM	✓	✓	✓	✓
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	PRB	✓	✓	✓	✓
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	RCM	✓	✓	✓	✓
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	SASM	✓	✓	✓	✓
2014	Transit	2.2L	Duratorq Turbo Diesel Common Rail	TRM	✓	✓	✓	
2014	Transit	2.2L	TDCi_StgVI	ABS	✓	✓	✓	
2014	Transit	2.2L	TDCi_StgVI	ACM	✓	✓	✓	
2014	Transit	2.2L	TDCi_StgVI	AHCM	✓	✓	✓	
2014	Transit	2.2L	TDCi_StgVI	APIM	✓	✓	✓	
2014	Transit	2.2L	TDCi_StgVI	AWD#1	✓	✓	✓	
2014	Transit	2.2L	TDCi_StgVI	BCMii	✓	✓	✓	✓
2014	Transit	2.2L	TDCi_StgVI	CCMii	✓	✓	✓	✓
2014	Transit	2.2L	TDCi_StgVI	FCDIM	✓	✓	✓	✓
2014	Transit	2.2L	TDCi_StgVI	GPSM	✓	✓	✓	✓
2014	Transit	2.2L	TDCi_StgVI	HCM	✓	✓	✓	✓
2014	Transit	2.2L	TDCi_StgVI	IPC	✓	✓	✓	✓
2014	Transit	2.2L	TDCi_StgVI	IPM-A	✓	✓	✓	✓
2014	Transit	2.2L	TDCi_StgVI	IPM-B	✓	✓	✓	✓
2014	Transit	2.2L	TDCi_StgVI	PAM	✓	✓	✓	✓
2014	Transit	2.2L	TDCi_StgVI	PCM	✓	✓	✓	✓
2014	Transit	2.2L	TDCi_StgVI	PRB	✓	✓	✓	✓
2014	Transit	2.2L	TDCi_StgVI	RCM	✓	✓	✓	✓
2014	Transit	2.2L	TDCi_StgVI	SASM	✓	✓	✓	✓
2014	Transit	2.2L	TDCi_StgVI	TRM	✓	✓	✓	
2014	Transit	3.2L	Duratorq Turbo Diesel Common Rail	PCM	✓	✓	✓	✓
2014	Transit	3.2L	Duratorq Turbo Diesel Common Rail	RDCM#1	✓	✓	✓	✓
2014	Transit	3.2L	Duratorq Turbo Diesel Common Rail	TCM	✓	✓	✓	✓
1995	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS	✓	✓	✓	✓
1995	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS/TCS	✓	✓	✓	✓
1995	Transit Connect	2.0L	2.0 DOHC SFI (8V)	CSM	✓	✓	✓	✓
1995	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PATS	✓	✓	✓	✓
1995	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓
1995	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓
1996	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS	✓	✓	✓	✓

1996	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS/TCS	✓	✓	✓	✓
1996	Transit Connect	2.0L	2.0 DOHC SFI (8V)	CSM	✓	✓	✓	✓
1996	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓
1996	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓
1997	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS	✓	✓	✓	✓
1997	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS/TCS	✓	✓	✓	✓
1997	Transit Connect	2.0L	2.0 DOHC SFI (8V)	CSM	✓	✓	✓	✓
1997	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PATS	✓	✓	✓	✓
1997	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓
1997	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓
1997.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS	✓	✓	✓	✓
1997.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS/TCS	✓	✓	✓	✓
1997.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	CSM	✓	✓	✓	✓
1997.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓
1997.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓
1998	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS	✓	✓	✓	✓
1998	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS/TCS	✓	✓	✓	✓
1998	Transit Connect	2.0L	2.0 DOHC SFI (8V)	CSM	✓	✓	✓	✓
1998	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓
1998	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓
1998.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS	✓	✓	✓	✓
1998.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS/TCS	✓	✓	✓	✓
1998.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	CSM	✓	✓	✓	✓
1998.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓
1998.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓
1999.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS	✓	✓	✓	✓
1999.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS/TCS	✓	✓	✓	✓
1999.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	AFCM	✓	✓	✓	✓
1999.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	CSM	✓	✓	✓	✓
1999.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓
1999.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓
2000	Transit Connect	2.4L	DURATORQ_DI	ABS/TCS	✓	✓	✓	✓
2000	Transit Connect	2.4L	DURATORQ_DI	CSM	✓	✓	✓	✓
2000	Transit Connect	2.4L	DURATORQ_DI	EPB	✓	✓	✓	✓
2000	Transit Connect	2.4L	DURATORQ_DI	FFH	✓	✓	✓	✓
2000	Transit Connect	2.4L	DURATORQ_DI	FIP	✓	✓	✓	✓
2000	Transit Connect	2.4L	DURATORQ_DI	HEC	✓	✓	✓	✓
2000	Transit Connect	2.4L	DURATORQ_DI	PAM	✓	✓	✓	✓
2000	Transit Connect	2.4L	DURATORQ_DI	PCM	✓	✓	✓	✓
2000	Transit Connect	2.4L	DURATORQ_DI	PCM	✓	✓	✓	✓
2000	Transit Connect	2.4L	DURATORQ_DI	RASM	✓	✓	✓	✓
2000	Transit Connect	2.4L	DURATORQ_DI	RCM	✓	✓	✓	✓
2000	Transit Connect	2.4L	DURATORQ_DI	RCM	✓	✓	✓	✓
2000	Transit Connect	2.4L	DURATORQ_DI	TCM	✓	✓	✓	✓
2000	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail	ABS/TCS	✓	✓	✓	✓

2000	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail	CSM	✓	✓	✓	✓
2000	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail	FFH	✓	✓	✓	✓
2000	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail	HEC	✓	✓	✓	✓
2000	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail	ICU			✓	✓
2000	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail	PAM	✓	✓	✓	✓
2000	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail	PCM	✓	✓	✓	✓
2000	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail	RCM	✓	✓	✓	✓
2001	Transit Connect	2.0L	DURATORQ_DI	ABS/TCS	✓	✓	✓	✓
2001	Transit Connect	2.0L	DURATORQ_DI	CSM	✓	✓	✓	✓
2001	Transit Connect	2.0L	DURATORQ_DI	EPB	✓	✓	✓	✓
2001	Transit Connect	2.0L	DURATORQ_DI	FFH	✓	✓	✓	✓
2001	Transit Connect	2.0L	DURATORQ_DI	HEC	✓	✓	✓	✓
2001	Transit Connect	2.0L	DURATORQ_DI	PAM	✓	✓	✓	✓
2001	Transit Connect	2.0L	DURATORQ_DI	PCM	✓	✓	✓	✓
2001	Transit Connect	2.0L	DURATORQ_DI	RASM	✓	✓	✓	✓
2001	Transit Connect	2.0L	DURATORQ_DI	RCM	✓	✓	✓	✓
2001	Transit Connect	2.0L	DURATORQ_DI	TCM	✓	✓	✓	✓
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail	ABS/TCS	✓	✓	✓	✓
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail	ABS/TCS	✓	✓	✓	✓
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail	CSM	✓	✓	✓	✓
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail	FFH	✓	✓	✓	✓
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail	FFH	✓	✓	✓	✓
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail	FIP	✓	✓	✓	✓
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail	HEC	✓	✓	✓	✓
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail	ICU			✓	✓
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail	PAM	✓	✓	✓	
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail	PCM	✓	✓	✓	✓
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail	RASM	✓	✓	✓	✓
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail	RCM	✓	✓	✓	✓
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail	TCM	✓	✓	✓	✓
2001	Transit Connect	2.3L	DOHC SFI (16V)	ABS/TCS	✓	✓	✓	✓
2001	Transit Connect	2.3L	DOHC SFI (16V)	CSM	✓	✓	✓	✓
2001	Transit Connect	2.3L	DOHC SFI (16V)	HEC	✓	✓	✓	✓
2001	Transit Connect	2.3L	DOHC SFI (16V)	PAM	✓	✓	✓	
2001	Transit Connect	2.3L	DOHC SFI (16V)	PCM	✓	✓	✓	✓
2001	Transit Connect	2.3L	DOHC SFI (16V)	RASM	✓	✓	✓	✓
2001	Transit Connect	2.3L	DOHC SFI (16V)	RCM	✓	✓	✓	✓
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail	ABS	✓	✓	✓	✓
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail	ABS/TCS	✓	✓	✓	✓
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail	ACM	✓	✓	✓	✓
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail	BCMii	✓	✓	✓	✓
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail	CSM	✓	✓	✓	✓
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail	FFH	✓	✓	✓	✓
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail	IPC	✓	✓	✓	✓



2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail	PAM	√	√	√	√
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail	PCM	√	√	√	√
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail	RCM	√	√	√	√
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail	SRM	√	√	√	√
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_C ommon_Rail_Ini_Stage_V	ABS	√	√	√	√
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_C ommon_Rail_Ini_Stage_V	ABS/TCS	√	√	√	√
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_C ommon_Rail_Ini_Stage_V	ACM	√	√	√	√
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_C ommon_Rail_Ini_Stage_V	BCMii	√	√	√	√
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_C ommon_Rail_Ini_Stage_V	CSM	√	√	√	√
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_C ommon_Rail_Ini_Stage_V	FFH	√	√	√	√
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_C ommon_Rail_Ini_Stage_V	IPC	√	√	√	√
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_C ommon_Rail_Ini_Stage_V	PAM	√	√	√	√
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_C ommon_Rail_Ini_Stage_V	PCM	√	√	√	√
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_C ommon_Rail_Ini_Stage_V	RCM	√	√	√	√
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_C ommon_Rail_Ini_Stage_V	SRM	√	√	√	√
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_C	ABS/TCS	√	√	√	√
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_C	ACM	√	√	√	√
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_C	BCMii	√	√	√	√
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_C	CSM	√	√	√	√
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_C	FFH	√	√	√	√
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_C	IPC	√	√	√	√
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_C	PAM	√	√	√	√
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_C	PCM	√	√	√	√
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_C	RCM	√	√	√	√
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_C	SRM	√	√	√	√
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	ABS	√	√	√	√
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	ABS/TCS	√	√	√	√
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	ACM	√	√	√	√
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	BCMii	√	√	√	√
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	CSM	√	√	√	√
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	FFH	√	√	√	√
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	IPC	√	√	√	√
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	PAM	√	√	√	√
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	PCM	√	√	√	√
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	RCM	√	√	√	√
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	SRM	√	√	√	√



2011	Transit Connect	2.0L	DURATEC-HE / I4	ABS	√	√	√	√
2011	Transit Connect	2.0L	DURATEC-HE / I4	ACM	√	√	√	√
2011	Transit Connect	2.0L	DURATEC-HE / I4	GEM / SJB	√	√	√	√
2011	Transit Connect	2.0L	DURATEC-HE / I4	IC	√	√	√	√
2011	Transit Connect	2.0L	DURATEC-HE / I4	OCSM	√	√	√	√
2011	Transit Connect	2.0L	DURATEC-HE / I4	PAM	√	√	√	√
2011	Transit Connect	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2011	Transit Connect	2.0L	DURATEC-HE / I4	RCM	√	√	√	√
2011	Transit Connect	2.0L	DURATEC-HE / I4	SRM	√	√	√	√
2011	Transit Connect	2.0L	DURATEC-HE / I4	VSM	√	√	√	√
2011	Transit Connect	28kWh	Battery_Electric_Vehicl	ABS	√	√	√	√
2011	Transit Connect	28kWh	Battery_Electric_Vehicl	ABS	√	√	√	√
2011	Transit Connect	28kWh	Battery_Electric_Vehicl	ACCM#2	√	√	√	√
2011	Transit Connect	28kWh	Battery_Electric_Vehicl	ACM	√	√	√	√
2011	Transit Connect	28kWh	Battery_Electric_Vehicl	GEM / SJB	√	√	√	√
2011	Transit Connect	28kWh	Battery_Electric_Vehicl	IC	√	√	√	√
2011	Transit Connect	28kWh	Battery_Electric_Vehicl	OCSM	√	√	√	√
2011	Transit Connect	28kWh	Battery_Electric_Vehicl	PAM	√	√	√	√
2011	Transit Connect	28kWh	Battery_Electric_Vehicl	PSCM	√	√	√	√
2011	Transit Connect	28kWh	Battery_Electric_Vehicl	RCM	√	√	√	√
2011	Transit Connect	28kWh	Battery_Electric_Vehicl	SRM	√	√	√	√
2011	Transit Connect	28kWh	Battery_Electric_Vehicl	VSM	√	√	√	√
2012	Transit Connect	2.0L	DURATEC-HE / I4	ABS	√	√	√	√
2012	Transit Connect	2.0L	DURATEC-HE / I4	ABS	√	√	√	√
2012	Transit Connect	2.0L	DURATEC-HE / I4	ACM	√	√	√	√
2012	Transit Connect	2.0L	DURATEC-HE / I4	APIM	√	√	√	√
2012	Transit Connect	2.0L	DURATEC-HE / I4	GEM / SJB	√	√	√	√
2012	Transit Connect	2.0L	DURATEC-HE / I4	IC	√	√	√	√
2012	Transit Connect	2.0L	DURATEC-HE / I4	OCSM	√	√	√	√
2012	Transit Connect	2.0L	DURATEC-HE / I4	PAM	√	√	√	
2012	Transit Connect	2.0L	DURATEC-HE / I4	PCM	√	√	√	√
2012	Transit Connect	2.0L	DURATEC-HE / I4	RCM	√	√	√	√
2012	Transit Connect	2.0L	DURATEC-HE / I4	SRM	√	√	√	√
2012	Transit Connect	2.0L	DURATEC-HE / I4	VSM	√	√	√	√
2013	Transit Connect	28kWh	Battery_Electric_Vehicl	ABS	√	√	√	√
2013	Transit Connect	28kWh	Battery_Electric_Vehicl	ABS	√	√	√	√
2013	Transit Connect	28kWh	Battery_Electric_Vehicl	ACCM#2	√	√	√	√
2013	Transit Connect	28kWh	Battery_Electric_Vehicl	ACM	√	√	√	√
2013	Transit Connect	28kWh	Battery_Electric_Vehicl	APIM	√	√	√	√
2013	Transit Connect	28kWh	Battery_Electric_Vehicl	GEM / SJB	√	√	√	√
2013	Transit Connect	28kWh	Battery_Electric_Vehicl	IC	√	√	√	√
2013	Transit Connect	28kWh	Battery_Electric_Vehicl	OCSM	√	√	√	√
2013	Transit Connect	28kWh	Battery_Electric_Vehicl	PAM	√	√	√	
2013	Transit Connect	28kWh	Battery_Electric_Vehicl	PSCM	√	√	√	
2013	Transit Connect	28kWh	Battery_Electric_Vehicl	RCM	√	√	√	

2013	Transit Connect	28kWh	Battery_Electric_Vehicl	VSM	√	√	√	√
2013	Transit Connect	Other	Other	ABS	√	√	√	√
2013	Transit Connect	Other	Other	ACM	√	√	√	√
2013	Transit Connect	Other	Other	APIM	√	√	√	√
2013	Transit Connect	Other	Other	GEM / SJB	√	√	√	√
2013	Transit Connect	Other	Other	IC	√	√	√	√
2013	Transit Connect	Other	Other	OCSM	√	√	√	√
2013	Transit Connect	Other	Other	PAM	√	√	√	
2013	Transit Connect	Other	Other	RCM	√	√	√	
2013	Transit Connect	Other	Other	VSM	√	√	√	√
2014	Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct	ABS	√	√	√	√
2014	Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct	AHCM	√	√	√	√
2014	Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct	APIM	√	√	√	√
2014	Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct	BCMii	√	√	√	√
2014	Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct	DDM	√	√	√	√
2014	Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct	FCDIM	√	√	√	√
2014	Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct	FCIM	√	√	√	√
2014	Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct	FDSM	√	√	√	√
2014	Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct	GPSM	√	√	√	√
2014	Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct	HCM	√	√	√	√
2014	Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct	HVAC	√	√	√	√
2014	Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct	IPC	√	√	√	√
2014	Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct	IPM-B	√	√	√	√
2014	Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct	PAM	√	√	√	√
2014	Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct	PCM	√	√	√	√
2014	Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct	PDM	√	√	√	√
2014	Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct	PSCM	√	√	√	√
2014	Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct	RCM	√	√	√	√
2014	Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct	SASM	√	√	√	√
2014	Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct	TRM	√	√	√	√
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail	ABS	√	√	√	
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	√	√	√	
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail	AHCM	√	√	√	
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail	APIM	√	√	√	
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail	BCMii	√	√	√	√
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail	DDM	√	√	√	√
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail	FCDIM	√	√	√	√
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail	FCIM	√	√	√	√
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail	FDSM	√	√	√	√
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection	GPSM	√	√	√	√
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail	HVAC	√	√	√	√
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail	IPC	√	√	√	√
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail	IPM-B	√	√	√	√

2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail	PAM	✓	✓	✓	✓
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail	PCM	✓	✓	✓	✓
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail	PDM	✓	✓	✓	✓
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail	PSCM	✓	✓	✓	✓
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail	RCM	✓	✓	✓	✓
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail	SASM	✓	✓	✓	✓
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail	TRM	✓	✓	✓	✓
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	ABS	✓	✓	✓	✓
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	ACM	✓	✓	✓	✓
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	ACM	✓	✓	✓	✓
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	AHCM	✓	✓	✓	✓
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	APIM	✓	✓	✓	✓
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	APIM	✓	✓	✓	✓
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	BCM#1	✓	✓	✓	✓
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	BCMii	✓	✓	✓	✓
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	DDM	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	DDM	✓	✓	✓	✓
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	FCIM	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	FCIM	✓	✓	✓	✓
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	FDSM	✓	✓	✓	✓
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	GPSM	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	GPSM	✓	✓	✓	✓
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	HCM	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	HCM	✓	✓	✓	✓
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	IPC	✓	✓	✓	✓
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	IPM-B	✓	✓	✓	✓
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	OCSM	✓	✓	✓	✓
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	PAM	✓	✓	✓	✓
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	PCM	✓	✓	✓	✓
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	PDM	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	PDM	✓	✓	✓	✓
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	PSCM	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	PSCM	✓	✓	✓	✓
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	RCM	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	RCM	✓	✓	✓	✓
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	SASM	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	SASM	✓	✓	✓	✓
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	TRM	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct	TRM	✓	✓	✓	✓
2014	Transit Connect	1.6L	TDCi ECO III	ABS	✓	✓	✓	✓

2014	Transit Connect	1.6L	TDCi ECO III	ACM	✓	✓	✓	✓
2014	Transit Connect	1.6L	TDCi ECO III	AHCM	✓	✓	✓	✓
2014	Transit Connect	1.6L	TDCi ECO III	APIM	✓	✓	✓	✓
2014	Transit Connect	1.6L	TDCi ECO III	BCMii	✓	✓	✓	✓
2014	Transit Connect	1.6L	TDCi ECO III	DDM	✓	✓	✓	✓
2014	Transit Connect	1.6L	TDCi ECO III	FCDIM	✓	✓	✓	✓
2014	Transit Connect	1.6L	TDCi ECO III	FCIM	✓	✓	✓	✓
2014	Transit Connect	1.6L	TDCi ECO III	FDSM	✓	✓	✓	✓
2014	Transit Connect	1.6L	TDCi ECO III	GPSM	✓	✓	✓	✓
2014	Transit Connect	1.6L	TDCi ECO III	HCM	✓	✓	✓	✓
2014	Transit Connect	1.6L	TDCi ECO III	HVAC	✓	✓	✓	✓
2014	Transit Connect	1.6L	TDCi ECO III	IPC	✓	✓	✓	✓
2014	Transit Connect	1.6L	TDCi ECO III	IPM-B	✓	✓	✓	✓
2014	Transit Connect	1.6L	TDCi ECO III	PAM	✓	✓	✓	✓
2014	Transit Connect	1.6L	TDCi ECO III	PCM	✓	✓	✓	✓
2014	Transit Connect	1.6L	TDCi ECO III	PDM	✓	✓	✓	✓
2014	Transit Connect	1.6L	TDCi ECO III	PSCM	✓	✓	✓	✓
2014	Transit Connect	1.6L	TDCi ECO III	RCM	✓	✓	✓	✓
2014	Transit Connect	1.6L	TDCi ECO III	SASM	✓	✓	✓	✓
2014	Transit Connect	1.6L	TDCi ECO III	TRM	✓	✓	✓	✓
2014	Transit Connect	2.5L	IVCT	ABS	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	ABS	✓	✓	✓	✓
2014	Transit Connect	2.5L	IVCT	ACM	✓	✓	✓	✓
2014	Transit Connect	2.5L	IVCT	APIM	✓	✓	✓	✓
2014	Transit Connect	2.5L	IVCT	BCM#1	✓	✓	✓	✓
2014	Transit Connect	2.5L	IVCT	DDM	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	FCDIM	✓	✓	✓	✓
2014	Transit Connect	2.5L	IVCT	FCIM	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	GPSM	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	HCM	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	HVAC	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	IPC	✓	✓	✓	✓
2014	Transit Connect	2.5L	IVCT	IPM-B	✓	✓	✓	✓
2014	Transit Connect	2.5L	IVCT	OCSM	✓	✓	✓	✓
2014	Transit Connect	2.5L	IVCT	PAM	✓	✓	✓	✓
2014	Transit Connect	2.5L	IVCT	PCM	✓	✓	✓	✓
2014	Transit Connect	2.5L	IVCT	PDM	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	PSCM	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	SASM	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	TRM	✓	✓	✓	
Other	Transit Connect	2.5L	2.5 turbo diesel engines with EPIC	ABS	✓	✓	✓	✓
Other	Transit Connect	2.5L	2.5 turbo diesel engines with EPIC	ABS/TCS	✓	✓	✓	✓
Other	Transit Connect	2.5L	2.5 turbo diesel engines with EPIC	CSM	✓	✓	✓	✓
Other	Transit Connect	2.5L	2.5 turbo diesel engines with EPIC	PCM			✓	✓
Other	Transit Connect	2.5L	2.5 turbo diesel engines with EPIC	PCM	✓	✓	✓	✓



2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail	IC	✓	✓	✓	✓
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail	IC	✓	✓	✓	✓
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail	PCM	✓	✓	✓	✓
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail	PCM	✓	✓	✓	✓
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail	RCM	✓	✓	✓	✓
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail	SRM	✓	✓	✓	✓
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail	ABS	✓	✓	✓	✓
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail	ACM	✓	✓	✓	✓
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail	AHCM	✓	✓	✓	✓
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail	APIM	✓	✓	✓	✓
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail	BCMii	✓	✓	✓	✓
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail	CCMii	✓	✓	✓	✓
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail	CCMii	✓	✓	✓	✓
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail	FCDIM	✓	✓	✓	
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail	GPSM	✓	✓	✓	
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail	HCM	✓	✓	✓	
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail	IPC	✓	✓	✓	
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail	IPM-A	✓	✓	✓	
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail	IPM-B	✓	✓	✓	
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail	PAM	✓	✓	✓	
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail	PCM	✓	✓	✓	✓
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail	PRB	✓	✓	✓	✓
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail	RCM	✓	✓	✓	✓
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail	SASM	✓	✓	✓	✓
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail	TBC	✓	✓	✓	✓
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail	TRM	✓	✓	✓	
Other	VX-1	1.4L	K14B	ABS	✓	✓	✓	✓
Other	VX-1	1.4L	K14B	BCM#1	✓	✓	✓	✓
Other	VX-1	1.4L	K14B	EPS	✓	✓	✓	✓
Other	VX-1	1.4L	K14B	IC	✓	✓	✓	✓
Other	VX-1	1.4L	K14B	PCM	✓	✓	✓	✓
Other	VX-1	1.4L	K14B	RCM	✓	✓	✓	✓
2001	Villager	3.3L	Other	PCM	✓	✓	✓	✓
2002	Villager	3.3L	Other	PCM	✓	✓	✓	✓
1995	Windstar	3.0L	V6 OHV	ABS/TCS	✓	✓	✓	
1995	Windstar	3.0L	V6 OHV	ABS/TCS	✓	✓	✓	✓
1995	Windstar	3.0L	V6 OHV	GEM	✓	✓	✓	✓
1995	Windstar	3.0L	V6 OHV	PCM	✓	✓	✓	✓
1995.5	Windstar	3.0L	V6 OHV	PCM	✓	✓	✓	✓
1996	Windstar	3.0L	V6 OHV	ABS/TCS	✓	✓	✓	
1996	Windstar	3.0L	V6 OHV	ABS/TCS	✓	✓	✓	✓
1996	Windstar	3.0L	V6 OHV	GEM	✓	✓	✓	✓
1996	Windstar	3.0L	V6 OHV	IAB	✓	✓	✓	✓
1996	Windstar	3.0L	V6 OHV	PATS	✓	✓	✓	
1996	Windstar	3.0L	V6 OHV	PCM	✓	✓	✓	✓



1996	Windstar	3.0L	V6 OHV	PCM	✓	✓	✓	✓
1996	Windstar	3.8L	V6 OHV	ABS/TCS	✓	✓	✓	
1996	Windstar	3.8L	V6 OHV	ABS/TCS	✓	✓	✓	✓
1996	Windstar	3.8L	V6 OHV	GEM	✓	✓	✓	✓
1996	Windstar	3.8L	V6 OHV	IAB	✓	✓	✓	✓
1996	Windstar	3.8L	V6 OHV	PATS	✓	✓	✓	
1996	Windstar	3.8L	V6 OHV	PCM	✓	✓	✓	✓
1997	Windstar	3.0L	V6 OHV	ABS/TCS	✓	✓	✓	
1997	Windstar	3.0L	V6 OHV	ABS/TCS	✓	✓	✓	✓
1997	Windstar	3.0L	V6 OHV	GEM	✓	✓	✓	✓
1997	Windstar	3.0L	V6 OHV	IAB	✓	✓	✓	✓
1997	Windstar	3.0L	V6 OHV	PATS	✓	✓	✓	
1997	Windstar	3.0L	V6 OHV	PCM	✓	✓	✓	✓
1997	Windstar	3.8L	V6 OHV	ABS/TCS	✓	✓	✓	
1997	Windstar	3.8L	V6 OHV	ABS/TCS	✓	✓	✓	✓
1997	Windstar	3.8L	V6 OHV	GEM	✓	✓	✓	✓
1997	Windstar	3.8L	V6 OHV	IAB	✓	✓	✓	✓
1997	Windstar	3.8L	V6 OHV	PATS	✓	✓	✓	
1998	Windstar	3.0L	V6 OHV	ABS/TCS	✓	✓	✓	
1998	Windstar	3.0L	V6 OHV	ABS/TCS	✓	✓	✓	✓
1998	Windstar	3.0L	V6 OHV	GEM	✓	✓	✓	✓
1998	Windstar	3.0L	V6 OHV	IAB	✓	✓	✓	✓
1998	Windstar	3.0L	V6 OHV	PATS	✓	✓	✓	
1998	Windstar	3.0L	V6 OHV	PCM	✓	✓	✓	✓
1998	Windstar	3.0L	V6 OHV	RAP	✓	✓	✓	✓
1998	Windstar	3.8L	V6 OHV	ABS/TCS	✓	✓	✓	
1998	Windstar	3.8L	V6 OHV	ABS/TCS	✓	✓	✓	✓
1998	Windstar	3.8L	V6 OHV	ABS/TCS	✓	✓	✓	✓
1998	Windstar	3.8L	V6 OHV	GEM	✓	✓	✓	✓
1998	Windstar	3.8L	V6 OHV	IAB	✓	✓	✓	✓
1998	Windstar	3.8L	V6 OHV	PATS	✓	✓	✓	
1998	Windstar	3.8L	V6 OHV	PCM	✓	✓	✓	✓
1998	Windstar	3.8L	V6 OHV	RAP	✓	✓	✓	✓
1999	Windstar	3.0L	V6 OHV	ABS/TCS	✓	✓	✓	✓
1999	Windstar	3.0L	V6 OHV	DDM	✓	✓	✓	✓
1999	Windstar	3.0L	V6 OHV	FEM	✓	✓	✓	✓
1999	Windstar	3.0L	V6 OHV	IC	✓	✓	✓	✓
1999	Windstar	3.0L	V6 OHV	MC	✓	✓	✓	✓
1999	Windstar	3.0L	V6 OHV	NGSC	✓	✓	✓	✓
1999	Windstar	3.0L	V6 OHV	PAM	✓	✓	✓	✓
1999	Windstar	3.0L	V6 OHV	PCM	✓	✓	✓	✓
1999	Windstar	3.0L	V6 OHV	RCM	✓	✓	✓	✓
1999	Windstar	3.0L	V6 OHV	REM	✓	✓	✓	✓
1999	Windstar	3.8L	V6 OHV	ABS/TCS	✓	✓	✓	✓
1999	Windstar	3.8L	V6 OHV	DDM	✓	✓	✓	✓

1999	Windstar	3.8L	V6 OHV	FEM	√	√	√	√
1999	Windstar	3.8L	V6 OHV	FEM	√	√	√	√
1999	Windstar	3.8L	V6 OHV	FEM	√	√	√	√
1999	Windstar	3.8L	V6 OHV	IC	√	√	√	√
1999	Windstar	3.8L	V6 OHV	LPSDM	√	√	√	√
1999	Windstar	3.8L	V6 OHV	MC	√	√	√	√
1999	Windstar	3.8L	V6 OHV	NGSC	√	√	√	√
1999	Windstar	3.8L	V6 OHV	PAM	√	√	√	√
1999	Windstar	3.8L	V6 OHV	PCM	√	√	√	√
1999	Windstar	3.8L	V6 OHV	PCM	√	√	√	√
1999	Windstar	3.8L	V6 OHV	RCM	√	√	√	√
1999	Windstar	3.8L	V6 OHV	REM	√	√	√	√
1999	Windstar	3.8L	V6 OHV	RPSDM	√	√	√	√
2000	Windstar	3.8L	V6 OHV	ABS/TCS	√	√	√	√
2000	Windstar	3.8L	V6 OHV	DDM	√	√	√	√
2000	Windstar	3.8L	V6 OHV	DDM	√	√	√	√
2000	Windstar	3.8L	V6 OHV	DSM	√	√	√	√
2000	Windstar	3.8L	V6 OHV	FEM	√	√	√	√
2000	Windstar	3.8L	V6 OHV	FEM	√	√	√	√
2000	Windstar	3.8L	V6 OHV	IC	√	√	√	√
2000	Windstar	3.8L	V6 OHV	LPSDM	√	√	√	√
2000	Windstar	3.8L	V6 OHV	MC	√	√	√	√
2000	Windstar	3.8L	V6 OHV	NGSC	√	√	√	√
2000	Windstar	3.8L	V6 OHV	PAM	√	√	√	√
2000	Windstar	3.8L	V6 OHV	PCM	√	√	√	√
2000	Windstar	3.8L	V6 OHV	RCM	√	√	√	√
2000	Windstar	3.8L	V6 OHV	RCM	√	√	√	√
2000	Windstar	3.8L	V6 OHV	REM	√	√	√	√
2000	Windstar	3.8L	V6 OHV	RPSDM	√	√	√	√
2002	Windstar	3.8L	V6 OHV	ABS/TCS	√	√	√	√
2002	Windstar	3.8L	V6 OHV	DDM	√	√	√	√
2002	Windstar	3.8L	V6 OHV	DSM	√	√	√	√
2002	Windstar	3.8L	V6 OHV	FEM	√	√	√	√
2002	Windstar	3.8L	V6 OHV	IC	√	√	√	√
2002	Windstar	3.8L	V6 OHV	LPSDM	√	√	√	√
2002	Windstar	3.8L	V6 OHV	MC	√	√	√	√
2002	Windstar	3.8L	V6 OHV	NGSC	√	√	√	√
2002	Windstar	3.8L	V6 OHV	PAM	√	√	√	√
2002	Windstar	3.8L	V6 OHV	PCM	√	√	√	√
2002	Windstar	3.8L	V6 OHV	RCM	√	√	√	√
2002	Windstar	3.8L	V6 OHV	REM	√	√	√	√
2002	Windstar	3.8L	V6 OHV	RPSDM	√	√	√	√
2003	Windstar	3.8L	V6 OHV	ABS/TCS	√	√	√	√
2003	Windstar	3.8L	V6 OHV	DDM	√	√	√	√
2003	Windstar	3.8L	V6 OHV	DSM	√	√	√	√

2003	Windstar	3.8L	V6 OHV	FEM	√	√	√	√
2003	Windstar	3.8L	V6 OHV	IC	√	√	√	√
2003	Windstar	3.8L	V6 OHV	LPSDM	√	√	√	√
2003	Windstar	3.8L	V6 OHV	MC	√	√	√	√
2003	Windstar	3.8L	V6 OHV	NGSC	√	√	√	√
2003	Windstar	3.8L	V6 OHV	PAM	√	√	√	√
2003	Windstar	3.8L	V6 OHV	PCM	√	√	√	√
2003	Windstar	3.8L	V6 OHV	RCM	√	√	√	√
2003	Windstar	3.8L	V6 OHV	REM	√	√	√	√
2003	Windstar	3.8L	V6 OHV	RPSDM	√	√	√	√
2006	Zephyr/MKZ	3.0L	4V	ABS	√	√	√	√
2006	Zephyr/MKZ	3.0L	4V	ABS	√	√	√	√
2006	Zephyr/MKZ	3.0L	4V	ACM	√	√	√	√
2006	Zephyr/MKZ	3.0L	4V	DCSM	√	√	√	√
2006	Zephyr/MKZ	3.0L	4V	DDM	√	√	√	√
2006	Zephyr/MKZ	3.0L	4V	DSM	√	√	√	√
2006	Zephyr/MKZ	3.0L	4V	DSP	√	√	√	√
2006	Zephyr/MKZ	3.0L	4V	EATC	√	√	√	√
2006	Zephyr/MKZ	3.0L	4V	GEM	√	√	√	√
2006	Zephyr/MKZ	3.0L	4V	IC	√	√	√	√
2006	Zephyr/MKZ	3.0L	4V	OCSM	√	√	√	√
2006	Zephyr/MKZ	3.0L	4V	OCSM	√	√	√	√
2006	Zephyr/MKZ	3.0L	4V	PCM	√	√	√	√
2006	Zephyr/MKZ	3.0L	4V	PCM	√	√	√	√
2006	Zephyr/MKZ	3.0L	4V	RCM	√	√	√	√
2006	Zephyr/MKZ	3.0L	4V	TCM	√	√	√	√
2007	Zephyr/MKZ	3.5L	4V	4X4	√	√	√	√
2007	Zephyr/MKZ	3.5L	4V	ABS	√	√	√	√
2007	Zephyr/MKZ	3.5L	4V	ABS	√	√	√	√
2007	Zephyr/MKZ	3.5L	4V	ACM	√	√	√	√
2007	Zephyr/MKZ	3.5L	4V	ACM	√	√	√	√
2007	Zephyr/MKZ	3.5L	4V	DCSM	√	√	√	√
2007	Zephyr/MKZ	3.5L	4V	DDM	√	√	√	√
2007	Zephyr/MKZ	3.5L	4V	DSM	√	√	√	√
2007	Zephyr/MKZ	3.5L	4V	DSP	√	√	√	√
2007	Zephyr/MKZ	3.5L	4V	EATC	√	√	√	√
2007	Zephyr/MKZ	3.5L	4V	GEM	√	√	√	√
2007	Zephyr/MKZ	3.5L	4V	IC	√	√	√	√
2007	Zephyr/MKZ	3.5L	4V	OCSM	√	√	√	√
2007	Zephyr/MKZ	3.5L	4V	OCSM	√	√	√	√
2007	Zephyr/MKZ	3.5L	4V	PCM	√	√	√	√
2007	Zephyr/MKZ	3.5L	4V	PCM	√	√	√	√
2007	Zephyr/MKZ	3.5L	4V	RCM	√	√	√	√
2007	Zephyr/MKZ	3.5L	4V	SDARS	√	√	√	√
2007	Zephyr/MKZ	3.5L	4V	SDARS	√	√	√	√



2009	Zephyr/MKZ	3.5L	4V	GEM / SJB	√	√	√	√
2009	Zephyr/MKZ	3.5L	4V	GEM / SJB	√	√	√	√
2009	Zephyr/MKZ	3.5L	4V	HVAC	√	√	√	√
2009	Zephyr/MKZ	3.5L	4V	IC	√	√	√	√
2009	Zephyr/MKZ	3.5L	4V	OCSM	√	√	√	√
2009	Zephyr/MKZ	3.5L	4V	OCSM	√	√	√	√
2009	Zephyr/MKZ	3.5L	4V	PAM	√	√	√	√
2009	Zephyr/MKZ	3.5L	4V	PAM	√	√	√	√
2009	Zephyr/MKZ	3.5L	4V	PCM	√	√	√	√
2009	Zephyr/MKZ	3.5L	4V	PCM	√	√	√	√
2009	Zephyr/MKZ	3.5L	4V	RCM	√	√	√	√
2009	Zephyr/MKZ	3.5L	4V	RCM	√	√	√	√
2009	Zephyr/MKZ	3.5L	4V	SDARS	√	√	√	√
2009	Zephyr/MKZ	3.5L	4V	SDARS	√	√	√	√
2009	Zephyr/MKZ	3.5L	4V	TCM	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	4X4	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	ABS	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	ABS	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	ABS	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	ACM	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	ACM	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	ACM	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	APIM	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	APIM	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	DCSM	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	DCSM	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	DDM	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	DDM	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	DSM	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	DSM	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	DSP	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	DSP	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	FCIM	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	FDIM	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	FDIM	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	GEM / SJB	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	GEM / SJB	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	GEM / SJB	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	GPSM	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	HCM	√	√	√	
2010	Zephyr/MKZ	3.5L	4V	HVAC	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	ILCM	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	IPC	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	IPC	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	OCSM	√	√	√	√

2010	Zephyr/MKZ	3.5L	4V	OCSM	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	PAM	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	PAM	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	PCM	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	PCM	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	RCM	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	RCM	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	SOD-L	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	SOD-R	√	√	√	√
2010	Zephyr/MKZ	3.5L	4V	TCM	√	√	√	√
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	4X4	√	√	√	√
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	ABS	√	√	√	√
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	ACCM#2	√	√	√	√
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	ACM	√	√	√	√
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	ACM	√	√	√	√
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	APIM	√	√	√	√
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	BECM	√	√	√	√
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	DCDC	√	√	√	√
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	DCSM	√	√	√	√
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	DDM	√	√	√	√
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	DSM	√	√	√	√
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	DSP	√	√	√	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	FCIM	√	√	√	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	FDIM	√	√	√	√
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	GEM / SJB	√	√	√	√
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	GPSM	√	√	√	√
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	HCM	√	√	√	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	HVAC	√	√	√	√
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	ILCM	√	√	√	√
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	IPC	√	√	√	√
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	OCSM	√	√	√	√
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	PAM	√	√	√	√
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	PCM	√	√	√	√
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	PCM	√	√	√	√
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	PSCM	√	√	√	√
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	RCM	√	√	√	√
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	SOD-L	√	√	√	√
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	SOD-R	√	√	√	√
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	TCM	√	√	√	√
2011	Zephyr/MKZ	3.5L	4V	4X4	√	√	√	√
2011	Zephyr/MKZ	3.5L	4V	ABS	√	√	√	√
2011	Zephyr/MKZ	3.5L	4V	ABS	√	√	√	√
2011	Zephyr/MKZ	3.5L	4V	ACM	√	√	√	√
2011	Zephyr/MKZ	3.5L	4V	ACM	√	√	√	√
2011	Zephyr/MKZ	3.5L	4V	APIM	√	√	√	√

2011	Zephyr/MKZ	3.5L	4V	APIM	✓	✓	✓	✓
2011	Zephyr/MKZ	3.5L	4V	DDM	✓	✓	✓	✓
2011	Zephyr/MKZ	3.5L	4V	DSM	✓	✓	✓	✓
2011	Zephyr/MKZ	3.5L	4V	DSP	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	FCIM	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	FDIM	✓	✓	✓	✓
2011	Zephyr/MKZ	3.5L	4V	GEM / SJB	✓	✓	✓	✓
2011	Zephyr/MKZ	3.5L	4V	GEM / SJB	✓	✓	✓	✓
2011	Zephyr/MKZ	3.5L	4V	GPSM	✓	✓	✓	✓
2011	Zephyr/MKZ	3.5L	4V	HCM	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	HVAC	✓	✓	✓	✓
2011	Zephyr/MKZ	3.5L	4V	ILCM	✓	✓	✓	✓
2011	Zephyr/MKZ	3.5L	4V	IPC	✓	✓	✓	✓
2011	Zephyr/MKZ	3.5L	4V	OCSM	✓	✓	✓	✓
2011	Zephyr/MKZ	3.5L	4V	OCSM	✓	✓	✓	✓
2011	Zephyr/MKZ	3.5L	4V	PAM	✓	✓	✓	✓
2011	Zephyr/MKZ	3.5L	4V	PCM	✓	✓	✓	✓
2011	Zephyr/MKZ	3.5L	4V	PCM	✓	✓	✓	✓
2011	Zephyr/MKZ	3.5L	4V	RCM	✓	✓	✓	✓
2011	Zephyr/MKZ	3.5L	4V	SOD-L	✓	✓	✓	✓
2011	Zephyr/MKZ	3.5L	4V	SOD-R	✓	✓	✓	✓
2011	Zephyr/MKZ	3.5L	4V	TCM	✓	✓	✓	✓
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	4X4	✓	✓	✓	✓
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	ABS	✓	✓	✓	✓
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	ACCM#2	✓	✓	✓	✓
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	APIM	✓	✓	✓	✓
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	BECM	✓	✓	✓	✓
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	DCDC	✓	✓	✓	✓
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	DCSM	✓	✓	✓	✓
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	DDM	✓	✓	✓	✓
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	DSM	✓	✓	✓	✓
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	DSP	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	FDIM	✓	✓	✓	✓
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	GEM / SJB	✓	✓	✓	✓
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	GPSM	✓	✓	✓	✓
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	HCM	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	HVAC	✓	✓	✓	✓
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	ILCM	✓	✓	✓	✓
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	IPC	✓	✓	✓	✓
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	OCSM	✓	✓	✓	✓
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	PAM	✓	✓	✓	✓
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	PSCM	✓	✓	✓	✓

2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	RCM	√	√	√	√
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	SOD-L	√	√	√	√
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	SOD-R	√	√	√	√
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	TCM	√	√	√	√
2012	Zephyr/MKZ	3.5L	4V	4X4	√	√	√	√
2012	Zephyr/MKZ	3.5L	4V	ABS	√	√	√	√
2012	Zephyr/MKZ	3.5L	4V	ABS	√	√	√	√
2012	Zephyr/MKZ	3.5L	4V	ACM	√	√	√	√
2012	Zephyr/MKZ	3.5L	4V	ACM	√	√	√	√
2012	Zephyr/MKZ	3.5L	4V	APIM	√	√	√	√
2012	Zephyr/MKZ	3.5L	4V	APIM	√	√	√	√
2012	Zephyr/MKZ	3.5L	4V	DCSM	√	√	√	√
2012	Zephyr/MKZ	3.5L	4V	DDM	√	√	√	√
2012	Zephyr/MKZ	3.5L	4V	DSM	√	√	√	√
2012	Zephyr/MKZ	3.5L	4V	DSP	√	√	√	
2012	Zephyr/MKZ	3.5L	4V	FCIM	√	√	√	
2012	Zephyr/MKZ	3.5L	4V	FDIM	√	√	√	√
2012	Zephyr/MKZ	3.5L	4V	GEM / SJB	√	√	√	√
2012	Zephyr/MKZ	3.5L	4V	GEM / SJB	√	√	√	√
2012	Zephyr/MKZ	3.5L	4V	GPSM	√	√	√	√
2012	Zephyr/MKZ	3.5L	4V	HCM	√	√	√	
2012	Zephyr/MKZ	3.5L	4V	HVAC	√	√	√	√
2012	Zephyr/MKZ	3.5L	4V	ILCM	√	√	√	√
2012	Zephyr/MKZ	3.5L	4V	IPC	√	√	√	√
2012	Zephyr/MKZ	3.5L	4V	OCSM	√	√	√	√
2012	Zephyr/MKZ	3.5L	4V	OCSM	√	√	√	√
2012	Zephyr/MKZ	3.5L	4V	PAM	√	√	√	√
2012	Zephyr/MKZ	3.5L	4V	PCM	√	√	√	√
2012	Zephyr/MKZ	3.5L	4V	PCM	√	√	√	√
2012	Zephyr/MKZ	3.5L	4V	RCM	√	√	√	√
2012	Zephyr/MKZ	3.5L	4V	SOD-L	√	√	√	√
2012	Zephyr/MKZ	3.5L	4V	SOD-R	√	√	√	√
2012	Zephyr/MKZ	3.5L	4V	TCM	√	√	√	√
2012	Zephyr/MKZ	Other	Other	4X4	√	√	√	√
2012	Zephyr/MKZ	Other	Other	ABS	√	√	√	√
2012	Zephyr/MKZ	Other	Other	ACM	√	√	√	√
2012	Zephyr/MKZ	Other	Other	APIM	√	√	√	√
2012	Zephyr/MKZ	Other	Other	DCSM	√	√	√	
2012	Zephyr/MKZ	Other	Other	DDM	√	√	√	√
2012	Zephyr/MKZ	Other	Other	DSM	√	√	√	√
2012	Zephyr/MKZ	Other	Other	DSP	√	√	√	
2012	Zephyr/MKZ	Other	Other	FCIM	√	√	√	
2012	Zephyr/MKZ	Other	Other	FDIM	√	√	√	√
2012	Zephyr/MKZ	Other	Other	GEM / SJB	√	√	√	√
2012	Zephyr/MKZ	Other	Other	HCM	√	√	√	



2012	Zephyr/MKZ	Other	Other	HVAC	√	√	√	√
2012	Zephyr/MKZ	Other	Other	ILCM	√	√	√	√
2012	Zephyr/MKZ	Other	Other	IPC	√	√	√	√
2012	Zephyr/MKZ	Other	Other	OCSM	√	√	√	√
2012	Zephyr/MKZ	Other	Other	PAM	√	√	√	√
2012	Zephyr/MKZ	Other	Other	RCM	√	√	√	√
2012	Zephyr/MKZ	Other	Other	SOD-L	√	√	√	√
2012	Zephyr/MKZ	Other	Other	SOD-R	√	√	√	√