

Brand	Area	Model	Year/Type	System	Function
MIT SUBISHI	China	V73		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	China	V97		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	China	Galant		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	China	Grandis		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	China	Lancer		Without smart	1.Live data 2.Change security code 3.All smart keys lost 4.Program remote 5.Program engine key code 6.Program engine key code&VIN write
MIT SUBISHI	China	Lancer		With smart	1.ECU identification 2.Live data 3.Change security code 4.All keys lost 5.Program remote 6.Program engine key code 7 Program engine key code&VIN write

MIT SUBISHI	China	Outlander	-2013	With smart	1.ECU identification 2.Live data 3.Change security code 4.All smart keys lost 5.Program engine key code 6.Program engine key code&VIN write
MIT SUBISHI	China	Outlander	2014-	With smart	1.All keys lost 2.Program smart keys
MIT SUBISHI	China	Outlander	2009-2013	Without smart	1.ECU identification 2.Live data 3.Change security code 4.All keys lost 5.Program remote 6.Program engine key code 7.Program engine key code&VIN write
MIT SUBISHI	China	Outlander	2014-2015	Without smart	1.ECU identification 2.Live data 3.Change security code 4.All keys lost 5.Program remote 6.Program engine key code 7.Program engine key code&VIN write
MIT SUBISHI	China	ASX		With smart	1.Program smart keys
MIT SUBISHI	China	ASX		Without smart	1.ECU identification 2.Live data 3.Change security code 4.All keys lost 5.Program remote 6.Program engine key code 7.Program engine key code&VIN write
MIT SUBISHI	China	L200 T RIT ON	Type 1	Immobiliser	1.Program keys 2.Program remotes
MIT SUBISHI	China	L200 T RIT ON	Type 2	Immobiliser	1.Program keys 2.Program remotes
MIT SUBISHI	China	L200 T RIT ON	Type 3	Immobiliser	1.Program keys 2.Program remotes
MIT SUBISHI	China	Pajero	2010-	Immobiliser	1.Program keys 2.Program remotes
MIT SUBISHI	China	Pajero sport	Type 1	Immobiliser	1.Program keys 2.Program remotes

MIT SUBISHI	China	Pajero sport	T ype 2	Immobiliser	1.All keys lost 2.Program remote
MIT SUBISHI	Israel	L200	2011	Immobiliser	1.ECU identification 2.Live data 3.Change secutity code 4.All keys lost 5.Program remote 6.Program engine key code 7.Program engine key code&VIN write
MIT SUBISHI	Israel	Lancer[CAN]		Immobiliser	1.ECU identification 2.Live data 3.Change secutity code 4.All keys lost 5.Program remote 6.Program engine key code 7.Program engine key code&VIN write
MIT SUBISHI	Israel	Outlander[CAN]	2012	With smart	1.ECU identification 2.Live data 3.Change secutity code 4.All keys lost 5.Program engine key code 6.Program engine key code&VIN write
MIT SUBISHI	Israel	Outlander[CAN]	2013-	With smart	1.All keys lost 2.Program remote
MIT SUBISHI	Israel	Outlander[CAN]		Immobiliser	1.ECU identification 2.Live data 3.Change secutity code 4.All keys lost 5.Program engine key code 6.Program engine key code&VIN write
MIT SUBISHI	Israel	Space[CAN]		With smart	1.All keys lost 2.Program remote
MIT SUBISHI	Australia	3000gt		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser

MIT SUBISHI	Australia	Airtrek		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Australia	Asx		With smart	1.All keys lost 2.Program remote
MIT SUBISHI	Australia	Asx		Without smart	1.ECU identification 2.Live data 3.Change security code 4.All keys lost 5.Program remote 6.Program engine key code 7.Program engine key code&VIN write
MIT SUBISHI	Australia	Colt	-04	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Australia	Challenger	99-03	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Australia	Express	96-	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Australia	Express		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Australia	EVO	Type 1	Without smart	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Australia	EVO	Type 2	Without smart	1.All keys lost 2.Program remote

MIT SUBISHI	Australia	EVO		With smart	1.Program smart keys
MIT SUBISHI	Australia	Galant		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Australia	Lancer	96-03	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Australia	Lancer	03-06	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Australia	Lancer[CAN]		With smart	1.All keys lost 2.Program remote
MIT SUBISHI	Australia	Lancer[CAN]		Without smart	1.ECU identification 2.Live data 3.Change security code 4.All keys lost 5.Program remote 6.Program engine key code 7.Program engine key code&VIN write
MIT SUBISHI	Australia	Lancer SW	96-03	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Australia	Lancer(sport)		Without smart	1.All keys lost 2.Program remote
MIT SUBISHI	Australia	Lancer Wagon		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Australia	Lancer Sport		With smart	1.All keys lost 2.Program remote

MIT SUBISHI	Australia	Lancer Sport		Without smart	1.ECU identification 2.Live data 3.Change security code 4.All keys lost 5.Program remote 6.Program engine key code 7.Program engine key code&VIN write
MIT SUBISHI	Australia	Lancer Sport back		With smart	1.All keys lost 2.Program remote
MIT SUBISHI	Australia	Lancer Sport back		Without smart	1.ECU identification 2.Live data 3.Change security code 4.All keys lost 5.Program remote 6.Program engine key code 7.Program engine key code&VIN write
MIT SUBISHI	Australia	Magna	96-05	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Australia	Mirage	96-02	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Australia	Mirage	04-12	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Australia	Mirage	12-	2012-	1.Program keys. 2.All keys lost
MIT SUBISHI	Australia	Nimbus	98-99	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser

MIT SUBISHI	Australia	Nimbus	99-02	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Australia	CJ Lancer	Sedan	With smart	1.All keys lost 2.Program remote
MIT SUBISHI	Australia	CJ Lancer	Sedan	Without smart	1.ECU identification 2.Live data 3.Change security code 4.All keys lost 5.Program remote 6.Program engine key code 7.Program engine key code&VIN write
MIT SUBISHI	Australia	CJ Lancer	Sportback	With smart	1.Program smart keys
MIT SUBISHI	Australia	CJ Lancer	Sportback	Without smart	1.ECU identification 2.Live data 3.Change security code 4.All keys lost 5.Program remote 6.Program engine key code 7.Program engine key code&VIN write
MIT SUBISHI	Australia	CJ Ralliart	Sedan	With smart	1.All keys lost 2.Program remote
MIT SUBISHI	Australia	CJ Ralliart	Sportback	With smart	1.All keys lost 2.Program remote
MIT SUBISHI	Australia	CJ Evolution		With smart	1.All keys lost 2.Program remote
MIT SUBISHI	Australia	Outlander		Immobiliser	1.ECU identification 2.Live data 3.Change security code 4.All keys lost 5.Program remote 6.Program engine key code 7.Program engine key code&VIN write

MIT SUBISHI	Australia	Outlander[CAN]	petrol -2012	With smart	1.ECU identification 2.Live data 3.Change security code 4.All keys lost 5.Program engine key code 6.Program engine key code&VIN write
MIT SUBISHI	Australia	Outlander[CAN]	petrol 2013-	Without smart	1.All keys lost 2.Program remote
MIT SUBISHI	Australia	Outlander	2013-	With smart	1.All keys lost 2.Program remote
MIT SUBISHI	Australia	Pajero	96-00	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Australia	Pajero	00-05	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Australia	Pajero IO	99-	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Australia	Star Wagon		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Australia	Triton Challenger	Type 1	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Australia	Triton Challenger	Type 2	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Australia	Triton Challenger	Type 3	Immobiliser	1.All keys lost 2.Program remote

MIT SUBISHI	Australia	Verada	96-02	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Africa	Eclipse		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Africa	Eclipse Dic mmna		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Africa	Endeavor		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Africa	GT 3000		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Africa	Galant		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Africa	Grandis		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Africa	Lancer	06-12	Immobiliser	1.All keys lost 2.Program remote
MIT SUBISHI	Africa	Lancer(middle East)	T ype 1	Without smart	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Africa	Lancer(middle East)	T ype 2	Without smart	1.All keys lost 2.Program remote

MIT SUBISHI	Africa	Lancer(middle East)		With smart	1.Program smart keys
MIT SUBISHI	Africa	L200	-07	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Africa	L200 T riton	-12	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Africa	Magna		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Africa	Nativa		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Africa	Outlander		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Africa	Pajero		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Africa	Shogun	01-06	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Africa	Strada		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser

MIT SUBISHI	Africa	Space star		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Africa	Space gear		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Africa	Space wagon		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Africa	sigma		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	America(USA)	Diamante		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	America(USA)	Eclipse		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	America(USA)	Eclipse[CAN]	06-09	Immobiliser	1.All keys lost 2.Key N0.
MIT SUBISHI	America(USA)	Endeavor		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	America(USA)	Endeavor[CAN]	06-09	Immobiliser	1.All keys lost 2.Key N0.

MIT SUBISHI	America(USA)	Evo		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	America(USA)	Galant	04-05	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	America(USA)	Galant[CAN]	06-09	Immobiliser	1.All keys lost 2.Key NO.
MIT SUBISHI	America(USA)	Galant[PIN1]	96-00	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	America(USA)	Galant[PIN1]	00-03	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	America(USA)	Galant[PIN2]	96-00	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	America(USA)	Galant[PIN2]	00-03	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	America(USA)	Lancer	96-03	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	America(USA)	Lancer		With smart	1.Program smart keys
MIT SUBISHI	America(USA)	Lancer		Without smart	1.All keys lost 2.Program remote

MIT SUBISHI	America(USA)	Lancer EVO	03-06	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	America(USA)	Lancer SW	96-03	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	America(USA)	Lancer[CAN]	08-09	Immobiliser	1.All keys lost 2.Key NO.
MIT SUBISHI	America(USA)	Lancer		With smart	1.Program smart keys
MIT SUBISHI	America(USA)	Lancer		Without smart	1.All keys lost 2.Program remote
MIT SUBISHI	America(USA)	Mirage	12-	Immobiliser	1.Program keys. 2.Program remote
MIT SUBISHI	America(USA)	Montero	99-00	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	America(USA)	Montero	01-06	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	America(USA)	Montero Sport	99-04	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	America(USA)	Outlander	00-03	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	America(USA)	Outlander	04-06	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser

MIT SUBISHI	America(USA)	Outlander[CAN]	07-09	Immobiliser	1.All keys lost 2.Key N0.
MIT SUBISHI	America(USA)	Outlander	14	With smart	1.Program smart keys
MIT SUBISHI	America(USA)	Outlander(sport)		With smart	1.Program smart keys
MIT SUBISHI	America(USA)	Outlander(sport)	-12	Without smart	1.All keys lost 2.Program remote
MIT SUBISHI	America(USA)	Outlander(sport)	12-	Without smart	1.All keys lost 2.Live data
MIT SUBISHI	America(USA)	Rvr	-12	Without smart	1.All keys lost 2.Program remote
MIT SUBISHI	America(USA)	Rvr	12-	Without smart	1.All keys lost 2.Live data
MIT SUBISHI	America(South USA)	Asx		Immobiliser	1.All keys lost 2.Live data
MIT SUBISHI	America(South USA)	Diamonte		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	America(South USA)	Eclipse		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	America(South USA)	Eclipse[CAN]		Immobiliser	1.All keys lost 2.Key N0.
MIT SUBISHI	America(South USA)	Endeavor		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	America(South USA)	Endeavor[CAN]		Immobiliser	1.All keys lost 2.Key N0.
MIT SUBISHI	America(South USA)	Evo		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser

MIT SUBISHI	America(South USA)	Galant		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	America(South USA)	Galant[CAN]		Immobiliser	1.All keys lost 2.Key NO.
MIT SUBISHI	America(South USA)	Lancer		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	America(South USA)	Lancer[CAN]		With smart	1.Program smart keys
MIT SUBISHI	America(South USA)	Lancer[CAN]		Without smart	1.All keys lost 2.Program remote
MIT SUBISHI	America(South USA)	Montero		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	America(South USA)	Montero	07	Immobiliser	1.Program keys 2.Read numbre of key
MIT SUBISHI	America(South USA)	Outlander		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	America(South USA)	Outlander[CAN]		With smart	1.Program smart keys
MIT SUBISHI	America(South USA)	Outlander[CAN]		Without smart	1.All keys lost 2.Program remote
MIT SUBISHI	America(South USA)	Outlander	13	With smart	1.Program smart keys
MIT SUBISHI	America(South USA)	Rvr	12	Without smart	1.All keys lost 2.Live data
MIT SUBISHI	America(South USA)	Pajero	v97/v98	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser

MIT SUBISHI	Europe	3000gt		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Europe	Asx		With smart	1.Program smart keys
MIT SUBISHI	Europe	Asx		Without smart	1.All keys lost 2.Program remote
MIT SUBISHI	Europe	Carisma(Greece)	96-04	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Europe	Carisma		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Europe	Colt	96-00	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Europe	Colt New	02-	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Europe	Colt Lander		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Europe	Eclipse		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser

MIT SUBISHI	Europe	Evo	Type 1	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Europe	Evo	Type 2	Without smart	1.All keys lost 2.Program remote
MIT SUBISHI	Europe	Evo		With smart	1.Program smart keys
MIT SUBISHI	Europe	Galant(Greece)	96-03	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Europe	Galant	96-04	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Europe	Grandis		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Europe	I-miev		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Europe	L200(Greece)	99-06	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Europe	L200		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser

MIT SUBISHI	Europe	L200[CAN]	11-	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Europe	L400		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Europe	Lancer(Greece)	96-03	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Europe	Lancer	T ype 1	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Europe	Lancer	T ype 2	Without smart	1.All keys lost 2.Program remote
MIT SUBISHI	Europe	Lancer		With smart	1.Program smart keys
MIT SUBISHI	Europe	Lancer[CAN]		Without smart	1.All keys lost 2.Program remote
MIT SUBISHI	Europe	Lancer[CAN]		With smart	1.Program smart keys
MIT SUBISHI	Europe	Lancer SW	96-03	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Europe	Mirage	12-	Immobiliser	1.Program keys. 2.Program remote
MIT SUBISHI	Europe	Magnum		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser

MIT SUBISHI	Europe	Outlander		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Europe	Outlander		With smart	1.Program smart keys
MIT SUBISHI	Europe	Outlander[CAN]	petrol	With smart	1.Program smart keys
MIT SUBISHI	Europe	Outlander[CAN]	petrol	Without smart	1.All keys lost 2.Program remote
MIT SUBISHI	Europe	Outlander[CAN]	Diesel	Without smart	1.All keys lost 2.Program remote
MIT SUBISHI	Europe	Pajero(Greece)	96-00	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Europe	Pajero	99-06	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Europe	Pajero New	00-03	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Europe	Pajero Pinin(Greece)	99-	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Europe	Pajero Pinin		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Europe	Pajero Sport	99-03	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser

MIT SUBISHI	Europe	Shogun		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Europe	Sigma		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Europe	Space wagon		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Europe	3000 GT	96-	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Japan)	Carisma	96-04	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Japan)	Colt	96-00	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Japan)	Eclipse	96-03	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Japan)	Galant[PIN1]	96-03	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser

MIT SUBISHI	Asia(Japan)	Galant[PIN2]	96-03	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Japan)	Lancer	96-03	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Japan)	Lancer	03-06	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Japan)	Lancer SW	96-03	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Japan)	L200	99-06	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Japan)	Montero	99-00	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Japan)	Montero	01-06	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Japan)	Montero IO	99-	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser

MIT SUBISHI	Asia(Japan)	Montero Sport	99-04	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Japan)	Nativa	01-02	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Japan)	Pajero	96-00	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Japan)	Pajero	00-05	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Japan)	Pajero IO	99-	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Japan)	Pajero PININ	99-	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Japan)	Pajero Sport	99-03	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Japan)	Shogun	96-00	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser

MIT SUBISHI	Asia(Japan)	Shogun	00-05	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Japan)	Shogun PININ	99-	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Japan)	Shogun Sport	99-03	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Japan)	Space Gear	96-	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Japan)	Space Runner	98-99	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Japan)	Space Runner	99-02	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Japan)	Space Start[PIN1]	99-	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Japan)	Space Start[PIN2]	99-	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser

MIT SUBISHI	Asia(Japan)	Space Wagon	98-99	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Japan)	Space Wagon	99-02	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Japan)	3000 GT	96-01	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Israel)	Carisma		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Israel)	Eclipse		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Israel)	EclipseDic mmna		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Israel)	Endeavor		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Israel)	Galant	1994-2004	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser

MIT SUBISHI	Asia(Israel)	Grandis		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Israel)	GT 3000		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Israel)	L200	2011	Immobiliser	1.Program keys 2.Read numbre of key
MIT SUBISHI	Asia(Israel)	L400		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Israel)	Lancer	T ype 1	Without smart	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Israel)	Lancer	T ype 2	Without smart	1.All keys lost 2.Program remote
MIT SUBISHI	Asia(Israel)	Lancer		With smart	1.Program smart keys
MIT SUBISHI	Asia(Israel)	Sport back		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Israel)	Magna		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Israel)	Magnum		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser

MIT SUBISHI	Asia(Israel)	Nativa		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Israel)	Outlander	T ype1	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Israel)	Outlander	T ype2	Without smart	1.All keys lost 2.Program remote
MIT SUBISHI	Asia(Israel)	Outlander		With smart	1.Program smart keys
MIT SUBISHI	Asia(Israel)	Outlander[CAN]		With smart	1.Program smart keys
MIT SUBISHI	Asia(Israel)	Pajero		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Israel)	Sigma		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Israel)	Spacewagon		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Israel)	Spacewagon	2013-	With smart	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Israel)	Space star		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser

MIT SUBISHI	Asia(Israel)	Space gear		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Israel)	Strada		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Other)	Delica	07-15	Immobiliser	1.All keys lost 2.Live data
MIT SUBISHI	Asia(Other)	Delica	07-15	Smart key system	1.All keys lost 2.Program remote 3.Live data
MIT SUBISHI	Asia(Other)	EVO 8		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Other)	EVO 9		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Other)	EVO 10	08-10	Immobiliser	1.All keys lost 2.Program remote
MIT SUBISHI	Asia(Other)	EVO 10		Smart key system	1.Program smart keys
MIT SUBISHI	Asia(Other)	Grandis		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Other)	Lancer CS		Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Other)	Lancer CY		Immobiliser	1.All keys lost 2.Program remote

MIT SUBISHI	Asia(Other)	L200 Triton	-K25106	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Other)	L200 Triton	06-	Immobiliser	1.Program keys 2.Program remotes
MIT SUBISHI	Asia(Other)	L200 Triton	06-	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MIT SUBISHI	Asia(Other)	L200 Triton	06-	Immobiliser	1.All keys lost 2.Program remote
MIT SUBISHI	Asia(Other)	Outlander	05-12	With smart	1.Program smart keys
MIT SUBISHI	Asia(Other)	Pajero(CK)	00-10	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser