

Brand	Vehicle Type	ECU Model	Year	System	Function
NISSAN	All	Type 1(4 pincode)	KWP200	Immobiliser system	1.Program keys
NISSAN	All	Type 2(4 pincode)	CANBUS	Immobiliser system	1.Erase DTC 2.Program keys
NISSAN		Type 1(12 pincode)	KWP200	Immobiliser system	1.Erase DTC 2.Program keys
NISSAN		Type 2(12 pincode)	CANBUS	Immobiliser system	1.Erase DTC 2.Program keys
NISSAN		Type 3(20 pincode)		Immobiliser system	1.Erase DTC
NISSAN		Help		Immobiliser system	
NISSAN		Read bcm code and Release steering lock		Immobiliser system	1.Read BCM code 2.Release steering lock
NISSAN		4 pincode - type 1		Immobiliser system	1.Fault codes 2.Erase DTC 3.Program keys
NISSAN		4 pincode - type 2		Immobiliser system	1.Erase DTC 2.Program keys
NISSAN		12 pincode - type 1		Immobiliser system	1.Erase DTC 2.Program keys
NISSAN		12 pincode - type 2		Immobiliser system	1.Erase DTC 2.Program keys
NISSAN		20 pincode - type 2		Immobiliser system	1.Program keys
NISSAN	All	4 pincode - type 1		Smart key system	1.Program smart keys
NISSAN	All	4 pincode - type 2		Smart key system	1.Erase DTC 2.Program keys
NISSAN	All	4 pincode - type 3		Smart key system	1.Program smart keys 2.Erase all smart keys 3.Program steering lock
NISSAN	All	4 pincode - type 4		Smart key system	1.Program smart keys 2.Erase all smart keys
NISSAN	All	4 pincode - type 5		Smart key system	1.Read BCM code 2.Release steering lock 3.Program smart keys
NISSAN	All	4 pincode - type 6		Smart key system	1.Read BCM code 2.Release steering lock 3.Program smart keys
NISSAN		12 pincode		Smart key system	1.Read number of keys 2.Program keys 3.Program remote 4.Erase remotes
NISSAN		20 pincode - type1		Smart key system	1.Program smart keys
NISSAN		20 pincode - type2		Smart key system	1.Program smart keys 2.Replace engine ECU
NISSAN	Teana		-2012	Body System(BCM)	1.Erase DTC 2.Program keys
NISSAN	Teana		-2012	Smart key system	1.Erase DTC 2.Program keys
NISSAN	Teana		2013-	Smart key system	1.Program smart keys 2.Replace engine ECU

NISSAN	New March			Smart key system	1.Read BCM code 2.Release steering lock 3.Program smart keys
NISSAN	New Sunny			Smart key system	1.Read BCM code 2.Release steering lock 3.Program smart keys
NISSAN	New Tiida			Smart key system	1.Read BCM code 2.Release steering lock 3.Program smart keys
NISSAN	Altima Hybrid		07-11	Smart key system	1.Release steering lock 2.Program smart keys
NISSAN	LANNIA		2015-	Smart key system	1.Read BCM code 2.Release steering lock 3.Program smart keys
NISSAN	Qichen			Body System(BCM)	1.Read BCM code 2.Release steering lock
NISSAN	Qichen			Immobiliser system	1.Fault codes 2.Erase DTC 3.Program keys
NISSAN	Qichen			Immobiliser system	1.Erase DTC 2.Program keys
NISSAN	New Sylphy			Without Smart key system	1.Erase DTC 2.Program keys
NISSAN	New Sylphy			With Smart key system	1.Read BCM code 2.Release steering lock
NISSAN	New X-Trail			With Smart key system	1.Program smart keys
NISSAN	New X-Trail			Without Smart key system	1.Program keys
NISSAN	Murano			Smart key system	1.Program smart keys 2.Replace engine ECU
NISSAN	Qashqai			With Smart key system	1.Program smart keys
NISSAN	Qashqai			Without Smart key system	1.Program keys
NISSAN	Qashqai			Without Smart key system	1.Erase DTC 2.Program keys
NISSAN	JX35			Smart key system	1.Program smart keys 2.Replace engine ECU
NISSAN	Q50			Smart key system	1.Program smart keys 2.Replace engine ECU
NISSAN	QX60			Smart key system	1.Program smart keys 2.Replace engine ECU
NISSAN	Cima			Smart key system	1.Program smart keys 2.Replace engine ECU
NISSAN		type 1		Remote	1.Program a remote key 2.Erase remote keys
NISSAN		type 2		Remote	1.Program remote 2.Erase remotes